

02-Engine

02

Start system	2-603
Technical specifications.....	2-603
Precautions	2-604
Preparation.....	2-605
Structure and installation location	2-606
General Inspection	2-607
Operating Principle.....	2-612
Diagnostic Information and Procedures.....	2-613
Removal and Installation.....	2-630

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Start system



Start system

Technical specifications

General specifications


Name	Specification
Commutator ring gear runout	
Commutator diameter	
Starter brush length	

02

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



2-603



Precautions

Precautions

1. No matter the engine is running or not, when the ignition switch is turned on, do not enable any components in the system such as any cable of the battery, fuel injector, fuel pump, ignition system wire, electronic control unit (ECU) wire, etc.
2. When the engine is difficult to start, the starting time once cannot be too long (generally not greater than 5s), and the other start should be made 15s later. It will not only allow the battery electrolyte to penetrate into the inner layers of the electrode plates, so that the battery potential can be restored to facilitate the engine start, but also it can avoid that the starter is damaged due to overheating after long-time continuous operation.
3. Be careful not to damage the insulating parts when disassembling the starter.
4. Do not use the starter to drive the car, so as to avoid damage to the starter due to excessive load.
5. Release the ignition switch in time after the engine starts, and let the ignition switch automatically return to the ignition gear, so as to avoid the wear when starting the electric motor and one-way clutch after the starter idles at high speed for a long time.
6. Do not turn the ignition switch to the starting gear when the engine is running, so as to avoid the fact that the driving gear of starter collides with the flywheel gear ring of engine.
7. The performance testing time of the starter in maintenance shall not exceed 5s to avoid damage to the starter.







Start system



Preparation


General and special tools

No.	Tool name	Tool figure	Tool code	Remarks
1	Dial gauge	 LFX60-SM-01201	-	Measure the starting commutator gear ring runout
2	Calipers	 LFX60-SM-01200	-	Measure the diameter and length
3	Digital universal meter	 LFX60-SM-02800	-	Measure the voltage and resistance
4	Conductor assembly	 LFX60-SM-02801	-	Testing circuit

02

Structure and installation location

Component Location Plan



No.	Part Name
1	Starter assembly
2	Starter mounting bolt

No.	Part Name
3	Starter mounting bolt

Start system




General Inspection

Starter detection

Testing

1. Check the starter assembly.




① Note:

- To prevent the starter from running, disconnect the field coil lead from terminal A.
- Complete the following tests within 3 to 5 s.


(a). As shown, connect the battery to the two terminals A and B of the starter, and check if the clutch pinion is moving outward. If the clutch pinion does not run or move outward, replace the electromagnetic starter switch assembly.

02




(b). As shown, disconnect the terminal A lead and check that the clutch pinion can remain in place (no inward movement).

2-607



(c). As shown, disconnect the terminal A lead and D lead, and check if the clutch pinion can return (inward movement).




(d). As shown, perform no load test on the starter, and observe and record the current value (using the multimeter's current mode).

● Note:


- Use a vise to hold the starter caught by the aluminum plate or the cloth.
- When the battery voltage is below 11.5V, the current value should be <90A; replace the starter if the current value does not meet the requirements.

2. Check the starter magnetic switch.



(a). As shown, push the core in, and check if the core can quickly return; if not, replace the magnetic switch assembly.


Start system



(b). As shown, use the multimeter's ohm mode to measure the resistance between terminals A and B; replace the magnetic switch if it does not meet the requirements.


Resistance: $<1\Omega$

02




(c). As shown, use the multimeter's ohm mode to measure the resistance between terminal B and housing; replace the magnetic switch if it does not meet the requirements.

Resistance: $<2\Omega$




3. Check the armature coil.




(a). As shown, use the multimeter's ohm mode to check if any two commutation bars are conductive; if not, replace the armature winding.

2-609




(b). Test the commutator in the Ohm gear of multimeter, as shown in the figure to check if the commutator (as shown in Figure A) and armature core (as shown in Figure B) are conductive; if conductive, replace the armature winding.

4. Check the commutator.



(a). Check the surface of the commutator for contamination and burns; if yes, polish with a sandpaper.
 (b). Put the commutator on the V-shaped block, and check the commutator gear ring with a dial indicator; if the difference is greater than the maximum value, repair it or replace it if necessary.

Maximum gear ring difference: 0.05mm



(c). Use the vernier caliper to measure the diameter of the commutator, and replace the armature if the diameter is less than the minimum.


Standard Diameter:30mm

Minimum diameter:29mm

Start system



5. Check the starter brush.



(a). Use the vernier caliper to check the length of the brush. If the length is less than the minimum, replace the brush. Replace the brush carrier and the starter yoke assembly, if necessary.

Standard Diameter:15.5mm

Minimum diameter:10mm

02

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



2-611




Operating Principle

System Overview

The start-up system consists of a battery, a start-up switch, a starter and related lines, all of which are connected by wires. When the start signal is received, and the power supply is supplied to the starter's electromagnetic switch; the electromagnetic switch coil generates a magnetic field to drive the plunger and gear transmission rod, then the pinion gets engaged with the engine's flywheel gear ring; finally, the electromagnetic switch is closed, and the engine starts. After the engine is started, the pinion will overrun the clutch protection armature, to avoid that the flywheel drives the pinion driving armature, until the switch is disconnected, and then the return spring will make the pinion to return its original position.

Starter

The starter consists of stator assembly, armature assembly, overdrive clutch assembly, electromagnetic switch assembly, front shell, rear shell, brush carrier and transmission rod.



شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Start system



Diagnostic Information and Procedures

Diagnosis Instructions

Before starting to diagnose a fault in the startup system, familiarize yourself with the operating principle of the startup system, and then start the system diagnostics, which helps to determine the correct troubleshooting steps in the event of a failure. More importantly, this also helps to determine whether the customer's situation belongs to normal operation.

Any troubleshooting of the start-up system should begin with the start-up system check, so as to instruct the service personnel to take the next logical step to troubleshoot. Comprehend and correctly use the diagnostic flow chart to shorten the diagnosis time and avoid the misjudgement.

02

General equipment

Digital universal meter
Diagnostic equipment of vehicle

Visual Inspection

1. Confirm the customer's question.
2. Visually check for obvious signs of mechanical or electrical damage.

Visual inspection table

Mechanical	Electrical
<ul style="list-style-type: none"> • One-touch start switch • Ignition switch • Starter • Flyweight disk 	<ul style="list-style-type: none"> • Fuse • Harness or plug • Battery • Engine compartment fuse box • PEPS
<ol style="list-style-type: none"> 3. Check the system lines easy to see or can be seen. 4. If the observed or proposed problem is obvious and its cause is identified, rectify the cause before proceeding with next step. 5. If for the problem, there are no obvious findings, then confirm the fault and refer to the symptom table. 	

2-613



List of fault symptoms

Symptom	Possible point of failure	Recommended Measures
The starter can not be operated	<ul style="list-style-type: none"> Fuse Battery Harness or plug Engine compartment fuse box Dashboard fuse box Ignition switch/one-touch start switch Starter PEPSECU 	<p>Refer to: Diagnostic process for starter failing to work</p>
The starter can not stop running	<ul style="list-style-type: none"> Starter relay Harness or plug Engine compartment fuse box Ignition switch/one-touch start switch PEPSECU 	<p>Refer to: Diagnostic process for starter failing to stop running</p>
The starter is working but the engine is not working	<ul style="list-style-type: none"> Starter Flywheel 	<ul style="list-style-type: none"> Repair or replace the starter Refer to: Replacement of starter Repair or replace the flywheel Refer to: Replacement of flywheel
The starter is running slowly	<ul style="list-style-type: none"> Battery voltage low Engine accessories Starter 	<ul style="list-style-type: none"> Charge or replace the battery. Reference: Replacement of the battery Repair the booster pump and other accessories; replace, if necessary. Repair or replace the starter Refer to: Replacement of starter
Abnormal start-up noise	<ul style="list-style-type: none"> Starter fasteners get loose Flywheel fasteners get loose Starter Flywheel 	<ul style="list-style-type: none"> Reinstall the starter fasteners Reinstall the flywheel fasteners Repair or replace the starter Refer to: Replacement of starter Repair or replace the flywheel Refer to: Replacement of flywheel

Start system





Diagnostic process for starter failing to work

Test condition	Details/results/measures
1. General inspection.	<p>A. Check whether the battery positive and negative harness connection is loose. B. Check the starter positive terminal harness and harness plug for looseness. Is it OK after checking? →Yes To step 2. →No Repair the fault position.</p>
2. Check the battery voltage.	<p>A. Measure the battery voltage with a multimeter. Standard value: 11 ~ 14V Is the voltage normal? →Yes To step 3. →No Charge or replace the battery. Refer to: Replacement of battery</p>
3. Check the fuse.	<p>A. Check the fuse starting relay fuse FS01 and starting switch fuse SB03. Fuse rated capacity: FS01 (15A), SB03 (30A) Is it OK after checking? →Yes To step 4. →No Replace the fuse.</p>
4. Check the K01 starter relay.	<p>A. Operate the ignition switch to turn the power to OFF state. B. Remove the engine compartment fuse box K01 starter relay. C. Replace the K01 starter relay and check whether the starting operation is normal. Is the starter running normal? →Yes Replace the K01 starter relay. →No To step 5.</p>

02



Test condition	Details/results/measures
<p>5. Check the K01 starter relay power line.</p> 	<p>A. Operate the ignition switch to turn the power to OFF state. B. Remove the engine compartment fuse box K01 starter relay. C. Measure the voltage between the engine compartment fuse box K01 starter relay terminal 3 and the fixed ground point with the multimeter. Standard value:11 ~ 14V Is the voltage normal? →Yes To step 6. →No Check the K01 starting relay power line; if necessary, replace the electrical box of engine compartment.</p>
<p>6. Check the K01 starter relay ground line.</p> 	<p>A. Operate the ignition switch to turn the power to OFF state. B. Remove the engine compartment fuse box K01 starter relay. C. Measure the resistance between the engine compartment fuse box K01 starter relay terminal 1 and the fixed ground point with the multimeter. Standard value:Less than 5Ω Is the resistance normal? →Yes To step 6. →No Repair the K01 starter relay ground line fault and replace the harness if necessary.</p>
<p>7. Check the starter power line.</p>	<p>A. Check whether the start power line is loose. B. Measure the voltage between the starter power line and fixed ground point with the multimeter. Standard value:11 ~ 14V Is the voltage normal? →Yes To step 8. →No Repair the starter power line fault and replace the harness if necessary.</p>

Start system



Test condition	Details/results/measures
8. Check the starter relay input voltage.	<p>A. Operate the ignition switch to turn the power to OFF state.</p> <p>B. Disconnect the battery negative connector.</p> <p>C. Disconnect the starter harness plug E08a.</p> <p>D. Connect the battery negative terminal.</p> <p>E. Start the engine, and use a multimeter to measure the voltage between terminal 1 of the starter harness plug E08a and the reliable ground point.</p> <p>Standard value:11 ~ 14V</p> <p>Is the voltage normal?</p> <p>→Yes To step 9.</p> <p>→No To step 10.</p>
9. Check the starter.	<p>A. Replace the starter.</p> <p>Refer to: Replacement of starter</p> <p>Confirm that the fault has been ruled out.</p>
10. Check the starter relay input voltage line.	<p>A. Operate the ignition switch to turn the power to OFF state.</p> <p>B. Disconnect the battery negative connector.</p> <p>C. Remove the engine compartment fuse box K01 starter relay.</p> <p>D. Disconnect the starter harness plug E08a.</p> <p>E. Measure the resistance between the engine compartment fuse box K01 starter relay terminal 5 and the starter harness plug E08a terminal 1 with the multimeter.</p> <p>Standard value:Less than 5Ω</p> <p>F. Measure the resistance between the starter harness plug E08a terminal 1 and the fixed ground point with the multimeter.</p> <p>Standard value:10MΩ or higher</p> <p>Is the resistance normal?</p> <p>→Yes To step 11.</p> <p>→No Repair the starter relay input voltage line fault and replace the harness if necessary.</p>

02



Test condition	Details/results/measures
11. Check the K01 starter relay control line.	<p>A. Operate the ignition switch to turn the power to OFF state. B. Disconnect the battery negative connector. C. Remove the engine compartment fuse box K01 starter relay. D. Disconnect the harness plug I19 of the ignition switch. E. Use a multimeter to measure the resistance between the terminal 2 of K01 starting relay in the engine compartment electrical box / terminal 4 of ignition switch harness plug I19 and the reliable ground point.</p> <p>Standard value: Less than 5Ω</p> <p>Is the resistance normal?</p> <p>→Yes To step 12. →No Repair the K01 starter relay control line fault and replace the harness if necessary.</p>
12. Check the power supply for ignition switch.	<p>A. Operate the ignition switch to turn the power to OFF state. B. Disconnect the battery negative connector. C. Disconnect the ignition switch harness plug I19. D. Connect the battery negative terminal. E. Operate the ignition switch to turn the power to ON state. F. Measure the voltage between the ignition switch harness plug I19 terminal 5 and fixed ground point with the multimeter.</p> <p>Standard value: 11 ~ 14 V</p> <p>Is the voltage normal?</p> <p>→Yes To step 13. →No Repair the ignition switch start power line fault and replace the dashboard fuse box if necessary.</p>
13. Check the ignition switch.	<p>A. Replace the ignition switch. Refer to: Replacement of ignition switch Confirm that the fault has been ruled out.</p>

Start system





Diagnostic process for starter failing to run (one-button start)

Test condition	Details/results/measures
1. Check the PEPS system DTC.	<p>A. Operate the ignition switch to turn the power to OFF and connect the diagnostic meter.</p> <p>B. Operate the ignition switch to turn the power to ON, turn on the diagnostic meter - use the latest software version.</p> <p>C. Read PEPS DTC. Is there PEPS DTC? →Yes Refer to: Diagnostic trouble code (DTC) list. Perform DTC diagnostic procedure. →No To step 2.</p>
2. General inspection.	<p>A. Check whether the battery positive and negative harness connection is loose.</p> <p>B. Check the starter positive terminal harness and harness plug for looseness. Is it OK after checking? →Yes To step 3. →No Repair the fault position.</p>
3. Check the battery voltage.	<p>A. Measure the battery voltage with a multimeter. Standard value: 11 ~ 14V Is the voltage normal? →Yes To step 4. →No Charge or replace the battery. Refer to: Replacement of battery</p>
4. Check the fuse.	<p>A. Check the fuse FS01 of K01 starter relay. Fuse rated capacity: 15A Is it OK after checking? →Yes To step 5. →No Replace the fuse.</p>


02



Test condition	Details/results/measures
5. Check the K01 starter relay.	<p>A. Operate the ignition switch to turn the power to OFF state.</p> <p>B. Remove the engine compartment fuse box K01 starter relay.</p> <p>C. Replace the K01 starter relay and check whether the starting operation is normal.</p> <p>Is the starter running normal?</p> <p>→Yes Replace the K01 starter relay.</p> <p>→No To step 6.</p>
6. Check the K01 starter relay power line.	 <p>A. Operate the ignition switch to turn the power to OFF state.</p> <p>B. Remove the engine compartment fuse box K01 starter relay.</p> <p>C. Measure the voltage between the engine compartment fuse box K01 starter relay terminal 3 and the fixed ground point with the multimeter.</p> <p>Standard value: 11 ~ 14V</p> <p>Is the voltage normal?</p> <p>→Yes To step 7.</p> <p>→No Check the K01 starting relay power line; if necessary, replace the electrical box of engine compartment.</p>
7. Check the K01 starter relay ground line.	 <p>A. Operate the ignition switch to turn the power to OFF state.</p> <p>B. Remove the engine compartment fuse box K01 starter relay.</p> <p>C. Measure the resistance between the engine compartment fuse box K01 starter relay terminal 1 and the fixed ground point with the multimeter.</p> <p>Standard value: Less than 5Ω</p> <p>Is the resistance normal?</p> <p>→Yes To step 8.</p> <p>→No Repair the K01 starter relay ground line fault and replace the harness if necessary.</p>

Start system

 力帆汽车
LIFAN AUTO

Test condition	Details/results/measures
8. Check the starter power line.	<p>A. Check whether the start power line is loose. B. Measure the voltage between the starter power line and fixed ground point with the multimeter. Standard value:11 ~ 14V Is the voltage normal? →Yes To step 9. →No Repair the starter power line fault and replace the harness if necessary.</p>
9. Check the starter relay input voltage.	 <p>A. Operate the ignition switch to turn the power to OFF state. B. Disconnect the battery negative connector. C. Disconnect the starter harness plug E08a. D. Start the engine, and use a multimeter to measure the voltage between terminal 1 of the starter harness plug E08a and the reliable ground point. Standard value:11 ~ 14V Is the voltage normal? →Yes To step 10. →No To step 11.</p>
10. Check the starter.	<p>A. Replace the starter. Refer to: Replace the starter. Confirm that the fault has been ruled out.</p>




02



Test condition	Details/results/measures
11. Check the starter relay input voltage line.	<p>A. Operate the ignition switch to turn the power to OFF state.</p> <p>B. Disconnect the battery negative connector.</p> <p>C. Remove the engine compartment fuse box K01 starter relay.</p> <p>D. Disconnect the starter harness plug E08a.</p> <p>E. Measure the resistance between the engine compartment fuse box K01 starter relay terminal 5 and the starter harness plug E08a terminal 1 with the multimeter.</p> <p>Standard value:Less than 5Ω</p> <p>F. Measure the resistance between the starter harness plug E08a terminal 1 and the fixed ground point with the multimeter.</p> <p>Standard value:10MΩ or higher</p> <p>Is the resistance normal?</p> <p>→Yes</p> <p>To step 12.</p> <p>→No</p> <p>Repair the starter relay input voltage line fault and replace the harness if necessary.</p>
12. Check the K01 starter relay control line.	<p>A. Operate the ignition switch to turn the power to OFF state.</p> <p>B. Disconnect the battery negative connector.</p> <p>C. Remove the engine compartment fuse box K01 starter relay.</p> <p>D. Disconnect the PEPS ECU harness plug I26.</p> <p>E. Use a multimeter to measure the resistance between the terminal 2 of K01 starting relay in the engine compartment electrical box / terminal 14 of PEPSECU harness plug I26 and the reliable ground point.</p> <p>Standard value:Less than 5Ω</p> <p>Is the resistance normal?</p> <p>→Yes</p> <p>To step 13.</p> <p>→No</p> <p>Repair the K01 starter relay control line fault and replace the harness if necessary.</p>

Start system



Test condition	Details/results/measures
<p>13. Check the start signal feedback line.</p> 	<p>A. Operate the ignition switch to turn the power to OFF state. B. Disconnect the battery negative connector. C. Remove the engine compartment fuse box K01 starter relay. D. Disconnect the PEPS ECU harness plug I26. E. Use a multimeter to measure the resistance between the terminal 5 of K01 starting relay in the engine compartment electrical box / terminal 9 of PEPSECU harness plug I26 and the reliable ground point.</p> <p>Standard value: Less than 5Ω</p> <p>Is the resistance normal? → Yes To step 14. → No Repair the K01 starter relay control line fault and replace the harness if necessary.</p>
<p>14. Check the signal line of one-button start switch.</p>  	<p>A. Operate the ignition switch to turn the power to OFF state. B. Disconnect the battery negative connector. C. Disconnect the harness plug of one-button start switch. D. Disconnect the PEPS ECU harness plug I26. E. Use a multimeter to measure the resistance between the terminal 3 of harness plug I30 of one-button start switch and the terminal 21 of PEPSECU harness plug I26.</p> <p>Standard value: Less than 5Ω</p> <p>F. Use a multimeter to measure the resistance between the terminal 8 of harness plug I30 of one-button start switch and the terminal 5 of PEPSECU harness plug I26.</p> <p>Standard value: Less than 5Ω</p> <p>Is the resistance normal? → Yes To step 15. → No Repair the ignition switch start power line fault and replace the dashboard fuse box if necessary.</p>
<p>15. Check the one-touch start switch.</p>	<p>A. Replace the one-touch start switch.</p> <p>Refer to: Replacement of one-touch start switch</p> <p>Is the troubleshooting successful? → Yes Replace the one-touch start switch. → No To step 16.</p>



Start system

Test condition	Details/results/measures
16. Check the PEPS ECU.	<p>A. Replace the PEPS ECU. Refer to: Replacement of PEPS ECU Confirm that the fault has been ruled out.</p>

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Start system




Diagnostic process for starter failing to stop running

Test condition	Details/results/measures
1. Check the K01 starter relay.	<p>A. Remove the engine compartment fuse box K01 starter relay.</p> <p>B. Operate the ignition switch to turn the power to ON state.</p> <p>Is the starter running stopped?</p> <p>→Yes To step 4.</p> <p>→No To step 2.</p>
2. Check the starter relay line.	<p>A. Operate the ignition switch to turn the power to OFF state.</p> <p>B. Disconnect the battery negative connector.</p> <p>C. Disconnect the starter harness plug E08a.</p> <p>D. Connect the battery negative terminal.</p> <p>E. Operate the ignition switch to turn the power to ON state.</p> <p>F. Measure the voltage between the starter harness plug E08a terminal 1 and the fixed ground point with the multimeter.</p> <p>Standard value:0V</p> <p>Is the voltage normal?</p> <p>→Yes To step 3.</p> <p>→No Repair the starter relay line fault and replace the harness if necessary.</p>
3. Check the starter.	<p>A. Replace the starter.</p> <p>Refer to: Replacement of starter</p> <p>Confirm that the fault has been ruled out.</p>
4. Replace the K01 starter relay.	<p>A. Operate the ignition switch to turn the power to OFF state.</p> <p>B. Replace the engine compartment fuse box K01 starter relay.</p> <p>Is the troubleshooting successful?</p> <p>→Yes Replace the K01 starter relay.</p> <p>→No To step 5.</p>


02



Test condition	Details/results/measures
<p>5. Check the K01 starter relay control line.</p> 	<p>A. Operate the ignition switch to turn the power to OFF state. B. Disconnect the battery negative connector. C. Disconnect the ignition switch harness plug I19. D. Connect the battery negative terminal. E. Operate the ignition switch to turn the power to ON state. F. Measure the voltage between the ignition switch harness plug I19 terminal 4 and fixed ground point with the multimeter. Standard value:0V Is the voltage normal? →Yes To step 6. →No Check the K01 starting relay control line; if necessary, replace the electrical box of engine compartment.</p>
<p>6. Check the ignition switch.</p>	<p>A. Replace the ignition switch. Refer to: Replacement of ignition switch Confirm that the fault has been ruled out.</p>

دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




Start system



Diagnostic process for starter failing to stop running (one-button start)

Test condition	Details/results/measures
1. Check the PEPS system DTC.	<p>A. Switch off the ignition switch; switch on the ignition switch to connect the automobile diagnosis device.</p> <p>B. Operate the ignition switch to turn the power to ON, turn on the diagnostic meter - use the latest software version.</p> <p>C. Read PEPS DTC. Is there PEPS DTC? →Yes Refer to: Diagnostic trouble code (DTC) list. Perform DTC diagnostic procedure. →No To step 2.</p>
2. Check the K01 starter relay.	<p>A. Remove the engine compartment fuse box K01 starter relay.</p> <p>B. Operate the ignition switch to turn the power to ON state. Is the starter running stopped? →Yes To step 5. →No To step 3.</p>
3. Check the starter relay line.	<p>A. Operate the ignition switch to turn the power to OFF state.</p> <p>B. Disconnect the battery negative connector.</p> <p>C. Disconnect the starter harness plug E08a.</p> <p>D. Connect the battery negative terminal.</p> <p>E. Operate the ignition switch to turn the power to ON state.</p> <p>F. Measure the voltage between the starter harness plug E08a terminal 1 and the fixed ground point with the multimeter. Standard value:0V Is the voltage normal? →Yes To step 4. →No Repair the starter relay line fault and replace the harness if necessary.</p>
4. Check the starter.	<p>A. Replace the starter. Refer to: Replacement of starter Confirm that the fault has been ruled out.</p>

02





Start system

Test condition	Details/results/measures
5. Replace the K01 starter relay.	<p>A. Operate the ignition switch to turn the power to OFF state.</p> <p>B. Replace the engine compartment fuse box K01 starter relay.</p> <p>Is the troubleshooting successful?</p> <p>→Yes Replace the K01 starter relay.</p> <p>→No To step 6.</p>
6. Check the K01 starter relay control line.	<p>A. Operate the ignition switch to turn the power to OFF state.</p> <p>B. Disconnect the battery negative connector.</p> <p>C. Disconnect the PEPSECU harness plug 126.</p> <p>D. Connect the battery negative terminal.</p> <p>E. Operate the ignition switch to turn the power to ON state.</p> <p>F. Use a multimeter to measure the voltage between terminal 14 of PEPSECU harness plug 126 and the reliable ground point.</p> <p>Standard value:0V</p> <p>Is the voltage normal?</p> <p>→Yes To step 7.</p> <p>→No Check the K01 starting relay control line; if necessary, replace the electrical box of engine compartment.</p>
7. Check the start signal feedback line.	<p>A. Operate the ignition switch to turn the power to OFF state.</p> <p>B. Disconnect the battery negative connector.</p> <p>C. Disconnect the PEPSECU harness plug 126.</p> <p>D. Connect the battery negative terminal.</p> <p>E. Operate the ignition switch to turn the power to ON state.</p> <p>F. Use a multimeter to measure the voltage between terminal 9 of PEPSECU harness plug 126 and the reliable ground point.</p> <p>Standard value:0V</p> <p>Is the voltage normal?</p> <p>→Yes To step 8.</p> <p>→No Check the start signal feedback line for fault; and replace, if necessary.</p>

Start system



Test condition	Details/results/measures
8. Check the one-touch start switch.	<p>A. Replace the one-touch start switch. Is the troubleshooting successful? →Yes Replace the one-touch start switch. →No To step 9.</p>
9. Check the PEPS ECU.	<p>A. Replace the PEPS ECU. Refer to: Replacement of PEPS ECU Confirm that the fault has been ruled out.</p>

02

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



2-629


Removal and Installation

Replacement of starter


Removal

1. Disassemble the starter.

(a). Disconnect the battery negative terminal.



(b). Remove the starter's power supply fixing bolt 1.
 (c). Disconnect the starter harness plug 2.
 (d). Remove the starter fixing bolt 3.



(e). Remove the upper fixing bolts on the starter and take the starter assembly.

Installation

1. Install the starter.

(a). The installation sequence is the reverse of the disassembly order.