

EM-2

Engine Mechanical System

General Information

Specifications

Description		Specifications		Limit
		3.3L / 3.8L		
General				
Type		V-type, DOHC		
Number of cylinders		6		
Bore		92mm(3.6220in.) / 96mm(3.7795in.)		
Stroke		83.8mm(3.2992in.) / 87.0mm(3.4252in.)		
Total displacement		3,342cc(203.94cu.in.) / 3,778cc(230.55cu.in.)		
Compression ratio		10.4		
Firing order		1-2-3-4-5-6		
Valve timing				
Intake	Opens(ATDC)	14°(3.3L) / 10°(3.8L)		
	Closes(ABDC)	66°		
Exhaust	Opens(BBDC)	52°		
	Closes(ATDC)	0°		
Cylinder head				
Flatness of gasket surface		Less than 0.05mm (0.0019in.) [Less than 0.02mm (0.0008in.) / 150x150]		
Flatness of manifold mounting	Intake	Less than 0.1mm(0.0039in.) [Less than 0.03mm(0.001in.) / 110x110]		
	Exhaust	Less than 0.1mm(0.0039in.) [Less than 0.03mm(0.001in.) / 110x110]		
Camshaft				
Cam height	LH Camshaft	Intake	46.3mm(1.8228in.) / 46.8mm(1.8425in.)	
		Exhaust	45.8mm (1.8031in.)	
	RH Camshaft	Intake	46.3mm(1.8228in.) / 46.8mm(1.8425in.)	
		Exhaust	45.8mm (1.8031in.)	
Journal outer diameter	LH, RHcamshaft	Intake	No.1: 27.964 ~ 27.978mm (1.1009 ~ 1.1015in.) No.2,3,4: 23.954 ~ 23.970mm(0.9430 ~ 0.9437in.)	
		Exhaust	No.1: 27.964 ~ 27.978mm(1.1009 ~ 1.1015in.) No.2,3,4: 23.954 ~ 23.970mm(0.9430 ~ 0.9437in.)	
Bearing oil clearance	LH, RHcamshaft	Intake	No.1: 0.027 ~ 0.057mm (0.0011 ~ 0.0022in.) No.2,3,4: 0.030 ~ 0.067mm (0.0012 ~ 0.0026in.)	
		Exhaust	No.1: 0.027 ~ 0.057mm (0.0011 ~ 0.0022in.) No.2,3,4: 0.030 ~ 0.067mm (0.0012 ~ 0.0026in.)	
End play		0.02 ~ 0.18mm (0.0008 ~ 0.0071in.)		

General Information

EM-3

Description		Specifications	Limit
		3.3L / 3.8L	
Valve			
Valve length	Intake	105.27mm(4.1445in.)	
	Exhaust	105.50mm (4.1535in.)	
Stem outer diameter	Intake	5.465 ~ 5.480mm (0.2151 ~ 0.2157in.)	
	Exhaust	5.458 ~ 5.470mm (0.2149 ~ 0.2153in.)	
Face angle		45.25° ~ 45.75°	
Thickness of valvehead(margin)	Intake	1.56 ~ 1.86mm (0.06142 ~ 0.07323in.)	
	Exhaust	1.73 ~ 2.03mm (0.06811 ~ 0.07992in.)	
Valve stem to valve guide clearance	Intake	0.020 ~ 0.047mm (0.00078 ~ 0.00185in.)	0.07mm (0.00275in.)
	Exhaust	0.030 ~ 0.054mm (0.00118 ~ 0.00212in.)	0.09mm (0.00354in.)
Valve guide			
Inner diameter	Intake	5.500 ~ 5.512mm (0.2165 ~ 0.2170in.)	
	Exhaust	5.500 ~ 5.512mm (0.2165 ~ 0.2170in.)	
Length	Intake	41.8 ~ 42.2mm (1.6457 ~ 1.6614in.)	
	Exhaust	41.8 ~ 42.2mm (1.6457 ~ 1.6614in.)	
Valve seat			
Width of seat contact	Intake	1.15 ~ 1.45mm(0.05118 ~ 0.05709in.)	
	Exhaust	1.35 ~ 1.65mm(0.05315 ~ 0.06496in.)	
Seat angle	Intake	44.75° ~ 45.20°	
	Exhaust	44.75° ~ 45.20°	
Valve spring			
Free length		43.86mm (1.7267in.)	
Load		19.3±0.8kg/34.0mm (42.7±1.8 lb/1.3386in.)	
		41.5±1.3kg/24.2mm (91.5±2.9 lb/0.9527in.)	
Out of squareness		Less than 1.5°	
MLA			
MLA outer diameter	Intake	34.964 ~ 34.980mm (1.3765 ~ 1.3772in.)	
	Exhaust	34.964 ~ 34.980mm (1.3765 ~ 1.3772in.)	
Cylinder head tappet bore inner diameter	Intake	35.000 ~ 35.025mm (1.3779 ~ 1.3789in.)	
	Exhaust	35.000 ~ 35.025mm (1.3779 ~ 1.3789in.)	
MLA to tappet bore clearance	Intake	0.020 ~ 0.061mm (0.0008 ~ 0.0024in.)	0.07mm (0.0027in.)
	Exhaust	0.020 ~ 0.061mm (0.0008 ~ 0.0024in.)	0.07mm (0.0027in.)
Valve clearance (At 20°C [68°F])			

EM-4

Engine Mechanical System

Description		Specifications	Limit
		3.3L / 3.8L	
Intake		0.17 ~ 0.23mm (0.0067 ~ 0.0090in.)	0.10 ~ 0.30mm (0.0039 ~ 0.0118in.)
Exhaust		0.27 ~ 0.33mm (0.0106 ~ 0.0129in.)	0.20 ~ 0.40mm (0.0078 ~ 0.0157in.)
Cylinder block			
Cylinder bore		92.00 ~ 92.03mm (3.6220 ~ 3.6232in.) / 96.00 ~ 96.03mm (3.7795 ~ 3.7807in.)	
Flatness of gasket surface		Less than 0.05mm (0.0019in.) [Less than 0.02mm (0.0008in.) / 150x150]	
Piston			
Piston outer diameter		91.96 ~ 91.99mm(3.6204 ~ 3.6216in.) / 95.96 ~ 95.99mm(3.7779 ~ 3.7791in.)	
Piston to cylinder clearance		0.03 ~ 0.05mm(0.0012 ~ 0.0020in.)	
Ring groove width	No. 1 ring groove	1.22 ~ 1.24mm (0.0480 ~ 0.0488in.)	1.26mm (0.0496in.)
	No. 2 ring groove	1.22 ~ 1.24mm (0.0480 ~ 0.0488in.)	1.26mm (0.0496in.)
	Oil ring groove	2.01 ~ 2.03mm (0.0791 ~ 0.0799in.)	2.05mm (0.0807in.)
Piston ring			
Side clearance	No. 1 ring	0.03 ~ 0.07mm (0.0012 ~ 0.0027in.)	0.1mm (0.004in.)
	No. 2 ring	0.03 ~ 0.07mm (0.0012 ~ 0.0027in.)	0.1mm (0.004in.)
	Oil ring	0.06 ~ 0.15mm (0.0024 ~ 0.0059in.)	0.2mm (0.008in.)
End gap	No. 1 ring	0.17 ~ 0.32mm (0.0067 ~ 0.0126in.)	0.6mm (0.0236in.)
	No. 2 ring	0.32 ~ 0.47mm (0.0126 ~ 0.0185in.)	0.7mm (0.0275in.)
	Oil ring	0.20 ~ 0.70mm (0.0078 ~ 0.0275in.)	0.8mm (0.0315in.)
Piston pin			
Piston pin outer diameter		23.001 ~ 23.006mm (0.9055 ~ 0.9057in.)	
Piston pin hole inner diameter		23.016 ~ 23.021mm (0.9061 ~ 0.9063in.)	
Piston pin hole clearance		0.01 ~ 0.02mm (0.0004 ~ 0.0008in.)	
Connecting rod small end inner diameter		22.974 ~ 22.985mm (0.9045 ~ 0.9049in.)	
Connecting rod small end hole clearance		-0.032 ~ -0.016mm (-0.0012 ~ 0.0006in.)	
Connecting rod			
Connecting rod big end inner diameter		58.000 ~ 58.018mm(2.2834 ~ 2.2842in.)	
Connecting rod bearing oil clearance		0.038 ~ 0.056mm (0.0015 ~ 0.0022in.)	
Side clearance		0.1 ~ 0.25mm (0.0039 ~ 0.0098in.)	
Crankshaft			
Main journal outer diameter		68.942 ~ 68.960mm (2.7142 ~ 2.7149in.)	
Pin journal outer diameter		54.954 ~ 54.972mm (2.1635 ~ 2.1642in.)	

General Information

EM-5

Description		Specifications	Limit
		3.3L / 3.8L	
Main bearing oil clearance		0.022 ~ 0.040mm (0.0008 ~ 0.0016in.)	
End play		0.10 ~ 0.28mm (0.0039 ~ 0.0110in.)	
Oil pump			
Relief valve opening pressure		450 ~ 550kPa (4.59 ~ 5.61kgf/cm ² , 65.28 ~ 79.79psi)	
Engine oil			
Oil quantity (Total)		6.0L(6.34U.S.qts, 5.28Imp.qts)	When replacing a short engine or a block assembly
Oil quantity (Oil pan)		5.5L(5.81U.S.qts, 4.84Imp.qts)	When replacing an oil pan only.
Oil quantity (Drain and refill)		5.2L(5.49U.S.qts, 4.58Imp.qts)	
Oil quality		Above SJ or SL, SAE 5w-20	
Oil pressure		130kPa(1.32kgf/cm ² , 18.77psi) [at 1000rpm, 110°C(230°F)]	
Cooling system			
Cooling method		Forced circulation with water pump	
Coolant quantity		8.4 ~ 8.6 L (8.9 ~ 9.1 us.qts, 7.4 ~ 7.6 Imp.qts)	
Thermostat	Type	Wax pellet type	
	Opening temperature	82±2°C (179.6±35.6°F)	
	Fully opened temperature	95°C (203°F)	
	Full lift	10mm (0.3937in.) MIN	
Radiator cap	Main valve opening pressure	93.16 ~ 122.58kpa (0.95 ~ 1.25kg/cm ² , 13.51 ~ 17.78psi)	
	Vacuum valve opening pressure	0 ~ 6.86 kpa (0 ~ 0.07kg/cm ² , 0 ~ 0.99psi)	
Water temperature sensor			
Type		Thermister type	
Resistance	20°C (68°F)	2.31 ~ 2.59KΩ	
	80°C(176°F)	0.3222 KΩ	

EM-6

Engine Mechanical System

Tightening Torques

Item	Quantity	Nm	kgf.m	lb-ft
Crankshaft pulley bolt	1	284.4 ~ 304.0	29.0 ~ 31.0	209.8 ~ 224.2
Timing chain cover bolt B	17	18.6 ~ 21.6	1.9 ~ 2.2	13.7 ~ 15.9
Timing chain cover bolt C	4	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Timing chain cover bolt D	2	58.8 ~ 68.6	6.0 ~ 7.0	43.4 ~ 50.6
Timing chain cover bolt F	2	24.5 ~ 26.5	2.5 ~ 2.7	18.1 ~ 19.5
Timing chain cover bolt G	4	21.6 ~ 23.5	2.2 ~ 2.4	15.9 ~ 17.4
Timing chain cover bolt H	1	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Timing chain cover bolt I	1	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Timing chain cover bolt J	1	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Timing chain cover bolt K	4	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Timing chain cover bolt L	1	21.6 ~ 26.5	2.2 ~ 2.7	15.9 ~ 19.5
Timing chain auto tensioner bolt	2	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Timing chain auto tensioner nut	2	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Timing chain auto tensioner arm bolt	2	18.6 ~ 21.6	1.9 ~ 2.2	13.7 ~ 15.9
Timing chain guide bolt	4	19.6 ~ 24.5	2.0 ~ 2.5	14.5 ~ 18.1
Oil pump chain cover bolt	2	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Oil pump chain tensioner bolt	1	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Oil pump chain guide bolt	2	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Oil pump chain sprocket bolt	1	18.6 ~ 21.6	1.9 ~ 2.2	13.7 ~ 15.9
Lower oil pan bolt	13	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Drive belt auto tensioner bolt(M12)	1	81.4 ~ 85.3	8.3 ~ 8.7	60.0 ~ 62.9
Drive belt auto tensioner bolt(M8)	1	17.7 ~ 21.6	1.8 ~ 2.2	13.0 ~ 15.9
Drive belt idler bolt	1	53.9 ~ 57.9	5.5 ~ 5.9	39.8 ~ 42.7
OCV(oil control valve) bolt	2	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Cylinder head bolt	16	39.2 + 120° + 90°	4.0 + 120° + 90°	28.9 + 120° + 90°
Cylinder head bolt	1	18.6 ~ 23.5	1.9 ~ 2.4	13.7 ~ 17.4
CVVT & cam sprocket bolt	4	64.7 ~ 76.5	6.6 ~ 7.8	47.7 ~ 56.4
Camshaft bearing cap bolt	32	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Cylinder head cover bolt	38	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Connecting rod bearing bolt	12	19.6 + 90°	2.0 + 90°	14.5 + 90°
Main bearing cap inner bolt(M11)	8	49.0 + 90°	5.0 + 90°	36.2 + 90°
Main bearing cap outer bolt(M8)	8	19.6 + 120°	2.0 + 120°	14.5 + 120°
Main bearing cap side bolt(M8)	8	29.4 ~ 31.4	3.0 ~ 3.2	21.7 ~ 23.1
Oil drain cover bolt	6	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7

General Information

EM-7

Item	Quantity	Nm	kgf.m	lb-ft
Rear oil seal case bolt	6	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Baffle plate bolt	12	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Upper oil pan bolt	16	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Knock sensor bolt	2	15.7 ~ 23.5	1.6 ~ 2.4	11.6 ~ 17.4
Drive plate bolt cap	8	71.54 ~ 75.46	7.3 ~ 7.7	52.80 ~ 55.69
Oil filter cap		24.5	2.5	18.1
Oil drain bolt cap	1	34.3 ~ 44.1	3.5 ~ 4.5	25.3 ~ 32.5
Oil pump bolt	3	20.6 ~ 22.6	2.1 ~ 2.3	15.2 ~ 16.6
Oil filter body bolt	10	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Water pump bolt(Timing chain cover bolt L)	1	21.6 ~ 26.5	2.2 ~ 2.7	15.9 ~ 19.5
Water pump bolt(Timing chain cover bolt K)	4	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Water pump bolt(Timing chain cover bolt G)	4	21.6 ~ 23.5	2.2 ~ 2.4	15.9 ~ 17.4
Water pump pulley bolt	4	7.8 ~ 9.8	0.8 ~ 1.0	5.8 ~ 7.2
Water temp. control nut	4	19.6 ~ 23.5	2.0 ~ 2.4	14.5 ~ 17.4
Water temp. control bolt	2	19.6 ~ 23.5	2.0 ~ 2.4	14.5 ~ 17.4
Water inlet pipe bolt	3	16.7 ~ 19.6	1.7 ~ 2.0	12.3 ~ 14.5
Air vent pipe bolt	2	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Intake manifold bolt	6	26.5 ~ 31.4	2.7 ~ 3.2	19.5 ~ 23.1
Intake manifold nut	2	18.6 ~ 23.5	1.9 ~ 2.4	13.7 ~ 17.4
Surge tank bolt (M6 × 36)	4	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Surge tank bolt (M6 × 128)	2	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Surge tank nut	2	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Breather pipe bolt	2	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Surge tank stay bolt (M10 × 20)	2	27.5 ~ 31.4	2.8 ~ 3.2	20.3 ~ 23.1
ETC bracket bolt	2	15.7 ~ 25.5	1.6 ~ 2.6	11.6 ~ 18.8
Exhaust manifold nut	16	39.2 ~ 44.1	4.0 ~ 4.5	28.9 ~ 32.6
Heat protector bolt	4	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Front muffler nut	8	39.2 ~ 58.8	4.0 ~ 6.0	28.9 ~ 43.4
Center muffler nut	4	39.2 ~ 58.8	4.0 ~ 6.0	28.9 ~ 43.4
Main muffler nut	4	39.2 ~ 58.8	4.0 ~ 6.0	28.9 ~ 43.4
Air cleaner assembly bolt	2	7.8 ~ 9.8	0.8 ~ 1.0	5.8 ~ 7.2
Intake air hose clamp bolt	1	1.9 ~ 2.9	0.2 ~ 0.3	1.4 ~ 2.2
Resonator bolt	1	7.8 ~ 9.8	0.8 ~ 1.0	5.8 ~ 7.2

EM-8

Engine Mechanical System


Inspection

Compression Pressure


 NOTICE

If there is lack of power, excessive oil consumption or poor fuel economy, measure the compression pressure.

1. Warm up engine until the normal operating temperature (80~95°C (176-203°F)).
2. Remove the surge tank. (Refer to Intake and exhaust system in this group)
3. Remove the ignition coil connectors (A) and ignition coils (B).



SBHEM8099D



SBHEM8150D

4. Remove the spark plugs.
Using a 16mm plug wrench, remove the 6 spark plugs.
5. Check cylinder compression pressure.
 - 1) Insert a compression gauge into the spark plug hole.
 - 2) Fully open the throttle.
 - 3) Crank the engine over 7 times to measure compression pressure.

 NOTICE

Always use a fully charged battery to obtain engine speed of 250 rpm or more.

- 4) Repeat step 1) through 3) for each cylinder.

 NOTICE

This measurement must be done in as short a time as possible.

Compression pressure :

1,029kPa (10.5kgf/cm², 149psi) (250~400 rpm)

Minimum pressure :

882kPa (9.0kgf/cm², 128psi)

- 5) If the cylinder compression in 1 or more cylinders is low, pour a small amount of engine oil into the cylinder through the spark plug hole and repeat step 1) through 3) for cylinders with low compression.
 - a. If adding oil helps the compression, it is likely that the piston rings and/or cylinder bore are worn or damaged.
 - b. If pressure stays low, a valve may be sticking or seating is improper, or there may be leakage past the gasket.
6. Reinstall the spark plugs.
7. Install the ignition coils and ignition connectors.
8. Install the surge tank. (Refer to Intake and exhaust system in this group)

General Information


EM-9

Valve Clearance Inspection And Adjustment

NOTICE

Inspect and adjust the valve clearance when the engine is cold (Engine coolant temperature : 20°C(68°F)) and cylinder head is installed on the cylinder block.


1. Remove the engine cover.
2. Remove the engine side cover.
3. Remove air cleaner assembly.
4. Remove the surge tank. (Refer to Intake and exhaust system in this group)
5. Remove the cylinder head cover. (Refer to Timing system in this group)
6. Set No.1 cylinder to TDC/compression.
 - 1) Turn the crankshaft pulley clockwise and align its groove with the timing mark "T" of the lower timing chain cover.




KDRF108A

- 2) Check that the mark (A) of the camshaft timing sprockets are in straight line on the cylinder head surface as shown in the illustration.

If not, turn the crankshaft clockwise one revolution (360°).



SBHEM8060D



SBHEM8061D

NOTICE


Do not rotate engine counterclockwise.

EM-10

Engine Mechanical System

7. Inspect the valve clearance.

- 1) With No.1 cylinder at TDC inspect clearances only on the valves shown in diagram below.



Measurement method.

- Using a thickness gauge, measure the clearance between the tappet and the base circle of camshaft.
- Record the out-of-specification valve clearance measurements. They will be used later to determine the required replacement adjusting tappet.

Valve clearance

Specification


Engine coolant temperature : 20°C [68°F]

Limit

Intake : 0.10 ~ 0.30mm (0.0039 ~ 0.0118in.)

Exhaust : 0.20 ~ 0.40mm (0.0078 ~ 0.0157in.)

- Turn the crankshaft pulley clockwise one revolution (360°) and align the groove with timing mark "T" of the lower timing chain cover.
- With No.4 cylinder at TDC inspect clearances only the valves shown in diagram below. (Refer to procedure step 1.)




General Information

EM-11


8. Adjust the intake and exhaust valve clearance.
 - 1) Set the No.1 cylinder to the TDC/compression.
 - 2) Remove the timing chain.

NOTICE


Before removing the timing chain, mark the RH/LH timing chain with an identification based on the location of the sprocket because the identification mark on the chain for TDC (Top Dead Center) can be erased.




SBHEM8062D



SBHEM8074D



SBHEM8063D




KDRF129A

EM-12


Engine Mechanical System

- 3) Remove the LH/RH camshaft bearing cap (A) and thrust bearing cap (B).




SBHEM8070D


- 4) Remove the LH/RH camshaft assembly (A).



SBHEM8072D



SBHEM8071D




SBHEM8073D

General Information

EM-13

- 5) Remove the MLA.
- 6) Measure the thickness of the removed tappet using a micrometer.



EDKE889D

- 7) Calculate the thickness of a new tappet so that the valve clearance comes within the specified value.

T : Thickness of removed tappet

A : Measured valve clearance

N : Thickness of new tappet

Intake : $N = T + [A - 0.20\text{mm}(0.0079\text{in.})]$

Exhaust : $N = T + [A - 0.30\text{mm}(0.0118\text{in.})]$

- 8) Select a new tappet with a thickness as close as possible to the calculated value.

NOTICE

Shims are available in 41 size increments of 0.015mm (0.0006in.) from 3.00mm (0.118in.) to 3.600mm (0.1417in.)


- 9) Place a new tappet on the cylinder head.

NOTICE


Apply engine oil at the selected tappet on the periphery and top surface.

- 10) Install the intake and exhaust camshaft.
- 11) Install the bearing caps. (Refer to Cylinder head assembly in this Group)
- 12) Install the timing chain. (Refer to Timing system in this Group)

- 13) Turn the crankshaft two turns in the operating direction (clockwise) and realign crankshaft sprocket and camshaft sprocket timing marks (A).



SBHEM8060D



SBHEM8061D

- 14) Recheck the valve clearance.

Valve clearance (Engine coolant temperature : 20°C [68°F])

[Specification]

Intake : 0.17 ~ 0.23mm (0.0067 ~ 0.0090in.)

Exhaust : 0.27 ~ 0.33mm (0.0106 ~ 0.0129in.)

EM-14

Engine Mechanical System

Troubleshooting

Symptom	Suspect area	Remedy
Engine misfire with abnormal internal lower engine noises.	Worn crankshaft bearings. Loose or damaged engine drive plate.	Replace the crankshaft and bearings as required. Repair or replace the drive plate as required.
	Worn piston rings. (Oil consumption may or may not cause the engine to misfire.)	Inspect the cylinder for a loss of compression. Repair or replace as required.
	Worn crankshaft thrust bearings	Replace the crankshaft and bearings as required.
Engine misfire with abnormal valve train noise.	Stuck valves. (Carbon buildup on the valve stem)	Repair or replace as required.
	Excessive worn or mis-aligned timing chain.	Replace the timing chain and sprocket as required.
	Worn camshaft lobes.	Replace the camshaft and valve lifters.
Engine misfire with coolant consumption.	- Faulty cylinder head gasket and/or cranking or other damage to the cylinder head and engine block cooling system - Coolant consumption may or may not cause the engine to overheat.	- Inspect the cylinder head and engine block for damage to the coolant passages and/or a faulty head gasket. - Repair or replace as required.
Engine misfire with excessive oil consumption.	Worn valves, guides and/or valve stem oil seals.	Repair or replace as required.
	Worn piston rings. (Oil consumption may or may not cause the engine to misfire)	- Inspect the cylinder for a loss of compression. - Repair or replace as required.
Engine noise on start-up, but only lasting a few seconds.	Incorrect oil viscosity.	Drain the oil. • Install the correct viscosity oil.
	Worn crankshaft thrust bearing.	- Inspect the thrust bearing and crankshaft. - Repair or replace as required.

General Information

EM-15

Symptom	Suspect area	Remedy
Upper engine noise, regardless of engine speed.	Low oil pressure.	Repair or replace as required.
	Broken valve spring.	Replace the valve spring.
	Worn or dirty valve lifters.	Replace the valve lifters.
	Stretched or broken timing chain and/or damaged sprocket teeth.	Replace the timing chain and sprockets.
	Worn timing chain tensioner, if applicable.	Replace the timing chain tensioner as required.
	Worn camshaft lobes.	- Inspect the camshaft lobes. - Replace the timing camshaft and valve lifters as required.
	Worn valve guides or valve stems.	Inspect the valves and valve guides, then repair as required.
	Stuck valves. Carbon on the valve stem or valve seat may cause the valve to stay open.	Inspect the valves and valve guides, then repair as required.
	Worn drive belt, idler, tensioner and bearing.	Replace as required.
Lower engine noise, regardless of engine speed.	Low oil pressure.	Repair as required.
	Loose or damaged drive plate.	Repair or replace the drive plate.
	Damaged oil pan, contacting the oil pump screen.	- Inspect the oil pan. - Inspect the oil pump screen. - Repair or replace as required.
	Oil pump screen loose, damaged or restricted.	- Inspect the oil pump screen. - Repair or replace as required.
	Excessive piston-to-cylinder bore clearance.	- Inspect the piston, piston pin and cylinder bore. - Repair as required.
	Excessive piston pin-to-piston clearance.	- Inspect the piston, piston pin and the connecting rod. - Repair or replace as required.
	Excessive connecting rod bearing clearance	Inspect the following components and repair as required. - The connecting rod bearings. - The connecting rods. - The crankshaft pin journals.
	Excessive crankshaft bearing clearance.	Inspect the following components, and repair as required. - The crankshaft bearings. - The crankshaft main journals. - The cylinder block.
	Incorrect piston, piston pin and connecting rod installation	- Verify the piston pins and connecting rods are installed correctly. - Repair as required.

EM-16





Engine Mechanical System

Symptom	Suspect area	Remedy
Engine noise under load.	Low oil pressure	Repair or replace as required.
	Excessive connecting rod bearing clearance .	Inspect the following components and repair as required : • The connecting rod bearings. • The connecting rods. • The crankshaft.
	Excessive crankshaft bearing clearance.	Inspect the following components, and repair as required. • The crankshaft bearings. • The crankshaft main journals. • The cylinder block.
Engine will not crank-crankshaft will not rotate.	Hydraulically locked cylinder. • Coolant/antifreeze in cylinder. • Oil in cylinder. • Fuel in cylinder.	1. Remove spark plugs and check for fluid. 2. Inspect for broken head gasket. 3. Inspect for cracked engine block or cylinder head. 4. Inspect for a sticking fuel injector and/or leaking fuel regulator.
	Broken timing chain and/or timing chain and/or timing chain gears.	1. Inspect timing chain and gears. 2. Repair as required.
	Material in cylinder. • Broken valve • Piston material • Foreign material	1. Inspect cylinder for damaged components and/or foreign materials. 2. Repair or replace as required.
	Seized crankshaft or connecting rod bearings.	1. Inspect crankshaft and connecting rod bearing. 2. Repair as required.
	Bent or broken connecting rod.	1. Inspect connecting rods. 2. Repair as required.
	Broken crankshaft.	1. Inspect crankshaft. 2. Repair as required.

General Information





EM-17

Special Service Tools

Tool (Number and name)	Illustration	Use
Crankshaft front oil seal installer (09231-3C100)	 KDRF233A	Installation of the front oil seal
Crankshaft pulley holder (09231-3M100)	 SBHEM8200D	Removal and installation of the crankshaft pulley. (In vehicle use)
Flywheel stopper (09231-3C300)	 SHDEM6201D	Removal and installation of the flywheel and crankshaft pulley (Engine disassembly)
Torque angle adapter (09221-4A000)	 LCAC030A	Installation of bolts & nuts needing an angular method
Valve stem seal remover (09222-29000)	 KDRF232A	Removal of the valve stem seal

EM-18

Engine Mechanical System

Tool (Number and name)	Illustration	Use
Valve stem seal installer (09222-3C100)	 LCAC030D	Installation of the valve stem seal
Valve spring compressor & holder (09222-3K000) (09222-3C300)	 ECRF003A	Removal and installation of the intake or exhaust valves A : 09222-3K000 B : 09222-3C300 (holder)
Crankshaft rear oil seal installer (09231-3C200) (09231-H1100)	 ACRF003A	Installation of the crankshaft rear oil seal A : 09231-3C200 B : 09231-H1100
Oil pan remover (09215-3C000)	 KDRF219A	Removal of oil pan


Engine And Transmission Assembly

EM-19

Engine And Transmission Assembly

Engine Mounting

Components



SBHEM9100L

1. Engine mounting
2. Transmission mounting

EM-20

Engine Mechanical System

Engine And Transmission Assembly

Removal

CAUTION


- Use fender covers to avoid damaging painted surfaces.
- To avoid damage, unplug the wiring connectors carefully while holding the connector portion.

NOTICE

- Mark all wiring and hoses to avoid misconnection.
1. Remove the transmission before removing the engine. (Refer to AT group)
 2. Disconnect the battery negative cable.
 3. Loosen the drain plug and drain the engine coolant.
 4. Remove the engine cover (A).


NOTICE

Remove the engine cover bolts as following method.




SBHEM8211D

5. Remove the engine side cover.
6. Remove the air duct (A).



SBHEM8001D

7. After recovering refrigerant, remove the high & low pressure pipe. (Refer to HA group)
8. Remove the intake air hose and air cleaner assembly.
 - 1) Disconnect the MAFS connector (A).
 - 2) Disconnect the breather hose (B).
 - 3) Remove the resonator (C).
 - 4) Remove the intake air hose (D) and air cleaner assembly (E).




SBHEM8002D

Engine And Transmission Assembly


EM-21

9. Remove the front wheels.
10. Remove the under cover.
11. Remove the radiator upper hose (A) and lower hose (B).




SBHEM8003D

13. Disconnect the heater hoses (A) and brake vacuum hose (B).




SBHEM8006D

14. Disconnect the ECM, PCM connector (A) and ground (B).




SBHEM8008D

12. Disconnect the ATF cooler hoses (A).



SBHEM8005D

15. Remove the fuse box cover (A).




SBHEM8009D

EM-22

Engine Mechanical System


16. Disconnect the wirings (A) from the fuse box.



SBHEM8010D

17. Remove the jump cable cover.


18. Disconnect the wiring (A) from the jump cable.



SBHEM8011D


19. Remove the fuse & relay box cover.

20. Remove the fuse & relay box mounting bolts (A) and wiring mounting bolts (B).



SBHEM8012D

21. Remove the fuse & relay box (A) after disconnect from the connector (B).




SBHEM8013D

Engine And Transmission Assembly


EM-23

22. Remove the connector (A) and wirings.



SBHEM8014D

23. Remove the fuel hose (A).



SBHEM8015D

24. Remove the tie rod end ball joint (A).

(Refer to ST group)

25. Remove the lower arm ball joint (B).

(Refer to SS group)


26. Remove the stabilizer bar link (C).

(Refer to SS group)

27. Remove the shock absorber lower mounting bolt and nut (D). (Refer to SS group)

28. Remove the height level sensor mounting bolt (E).

29. Remove the lower arm mounting bolt & nut (F) from the sub frame. (Refer to SS group)




SBHEM8016D

30. Remove the stabilizer bar. (Refer to SS group)

31. Remove the wheel housing under cover (A).

32. Disconnect the power steering fluid return hose (B) and then drain the power steering fluid.




SBHEM8017D

EM-24

Engine Mechanical System

33. Remove the steering column U-joint bolt (A).



SBHEM8018D


34. Support the sub frame (A) securely with a floor jack, and then remove the mounting bolts.

Tightening torque :

137.3 ~ 156.9N.m(14.0 ~ 16.0kgf.m, 101.3 ~ 115.7lb-ft)


NOTICE

- Check that all the cables, harness connector and hoses are disconnected from the engine and transaxle assembly.




SBHEM8019D

[Front]




SBHEM8020D

[Center]



SBHEM8021D

[Rear]



SBHEM8022D

Engine And Transmission Assembly

EM-25

35. Remove the engine assembly and sub frame by lifting vehicle.

CAUTION

- When removing the engine and transmission assembly, be careful not to damage any surrounding parts or body components.

Installation

Installation is in the reverse order of removal.

Perform the following :

- Adjust a shift cable.
- Refill engine with engine oil.
- Refill a transmission with fluid.
- Clean battery posts and cable terminals with sandpaper. Reassemble, then apply grease to prevent corrosion.
- Inspect for fuel leakage.
 - After assembling the fuel line, turn on the ignition switch (do not operate the starter) so that the fuel pump runs for approximately two seconds and fuel line pressurizes.
 - Repeat this operation two or three times, then check for fuel leakage at any point in the fuel line.
- Refill a radiator and a reservoir tank with engine coolant.
- Bleed air from the cooling system.
 - Start engine and let it run until it warms up. (until the radiator fan operates 3 or 4 times.)
 - Turn Off the engine. Check the level in the radiator, add coolant if needed. This will allow trapped air to be removed from the cooling system.
 - Put radiator cap on tightly, then run the engine again and check for leaks.


EM-26

Engine Mechanical System

Timing System

Timing Chain

Components




SBHEM9075L

1. Drive belt
2. Drive belt tensioner
3. Idler
4. Crank shaft pulley

5. Water pump pulley
6. Oil pan
7. Cylinder head cover

Timing System

EM-27



SBHEM9076L

- | | | |
|--------------------------------|---------------------------------|---------------------------------|
| 1. Timing chain cover | 7. Timing chain tensioner arm | 13. Timing chain |
| 2. Oil pump chain cover | 8. Timing chain | 14. Timing chain guide |
| 3. Oil pump sprocket | 9. Timing chain guide | 15. Tensioner adapter |
| 4. Oil pump chain | 10. Timing chain auto tensioner | 16. Gasket |
| 5. Crankshaft sprocket | 11. Timing chain tensioner arm | 17. Oil pump chain guide |
| 6. Timing chain auto tensioner | 12. Crankshaft sprocket | 18. Oil pump tensioner assembly |

EM-28

Engine Mechanical System

Removal

⚠ CAUTION

- Use fender covers to avoid damaging painted surfaces.
- To avoid damage, unplug the wiring connectors carefully while holding the connector portion.


📖 NOTICE

- Mark all wiring and hoses to avoid misconnection.
- Turn the crankshaft pulley so that the No.1 piston is at top dead center.

1. Disconnect the battery negative cable.
2. Loosen the drain plug and drain the engine coolant.
3. Remove the engine cover (A).


📖 NOTICE

Remove the engine cover bolts as following method.




SBHEM8211D

4. Remove the engine side cover.
5. Remove the air duct (A).



SBHEM8001D

6. Remove the intake air hose and air cleaner assembly.
 - 1) Disconnect the MAFS connector (A).
 - 2) Disconnect the breather hose (B).
 - 3) Remove the resonator (C).
 - 4) Remove the intake air hose (D) and air cleaner assembly (E).




SBHEM8002D


Timing System

EM-29

7. Remove the radiator upper hose (A) and lower hose (B).




SBHEM8003D




SBHEM8004D

8. Remove the fuel hose (A).



SBHEM8015D


9. Remove the power steering reservoir tank and bracket (A).



SBHEM8023D

10. Disconnect the engine wiring connectors.

- 1) Disconnect the power steering oil pressure switch connector(A) and RH knock sensor connector(B).




SBHEM8024D

EM-30


Engine Mechanical System

- 2) Disconnect the MAP sensor connector (A), ETC connector (B), RH exhaust OCV connector (C), RH injector connector (D) and RH ignition coil connector (E).




SBHEM8025D

- 3) Disconnect the LH knock sensor connector (A), LH/RH intake OCV connector (B) and LH exhaust OCV connector (C).




SBHEM8026D

- 4) Disconnect the LH injector connector (A) and LH ignition coil connector (B).



SBHEM8027D

- 5) Disconnect the oil pressure switch connector (A), LH exhaust camshaft CMP sensor connector (B) and LH oxygen sensor connector (C).




SBHEM8029D

Timing System


EM-31

- 6) Disconnect the LH intake camshaft CMP sensor connector (A) ,RH intake camshaft CMP sensor connector (B) and condenser connector (C).




SBHEM8030D

- 7) Disconnect the VIS solenoid valve connector (A),PCSV connector (B) and RH oxygen sensor connector (C).




SBHEM8031D

- 8) Disconnect the water temperature sensor connector (A) and oil temperature sensor connector (B).




SBHEM8032D

- 9) Disconnect the RH exhaust camshaft CMP sensor connector (A).



SBHEM8033D

11. Remove the oil level gauge tube (A).




SBHEM8034D

EM-32


Engine Mechanical System

12. Remove the breather pipe & hose (A).




SBHEM8035D

13. Remove the LH side coolant pipe and hose (A).




SBHEM8036D

14. Remove the fuel pipe (A) and vacuum pipe (B).




SBHEM8037D

15. Remove the throttle body coolant hose & pipe (A).




SBHEM8038D

16. Remove the RH side coolant pipe(A).



SBHEM8039D

17. Remove the PCV hose (A) and surge tank stay (B).




SBHEM8040D

Timing System


EM-33

18. Remove the surge tank assembly (A).




SBHEM8043D

19. Disconnect the RH ignition coil connector (A) and the injector connector (B).




SBHEM8044D

20. Remove the LH/RH ignition coils (A).




SBHEM8050D




SBHEM8051D

EM-34**Engine Mechanical System**

21. Remove the connector brackets (A) from the LH/RH cylinder head cover.




SBHEM8052D




SBHEM8055D


22. Remove the LH/RH cylinder head cover (A).




SBHEM8053D



SBHEM8056D



SBHEM8054D




SBHEM8057D

Timing System


EM-35

23. Remove the drive belt (A).




SBHEM8058D

24. Remove the power steering pump (A). (Refer to ST group)




KDRF102A

25. Remove the air conditioner compressor (A). (Refer to HA group)




SBHEM8101D

26. Remove the alternator (A). (Refer to EE group)




KDRF104A

27. Remove the drive belt idler (A).



KDRF105A

28. Remove the drive belt auto tensioner (A).




SENEM8020D

EM-36

Engine Mechanical System


29. Remove the water pump pulley (A).



SBHEM8059D


30. Set No.1 cylinder to TDC/compression.

- 1) Turn the crankshaft pulley clockwise and align its groove with the timing mark "T" of the lower timing chain cover.




KDRF108A

- 2) Check that the mark (A) of the camshaft timing sprockets are in straight line on the cylinder head surface as shown in the illustration. If not, turn the crankshaft clockwise one revolution (360°).



SBHEM8060D



SBHEM8061D

NOTICE


Do not rotate engine counterclockwise.

Timing System

EM-37

31. Remove the lower oil pan (A).

Insert the blade of SST(09215-3C000) between the upper oil pan and lower oil pan. Cut off applied sealer and remove the lower oil pan.




SBLM16019L

NOTICE

- Insert the SST between the oil pan and the ladder frame by tapping it with a plastic hammer in the direction of arrow.
- After tapping the SST with a plastic hammer along the direction of arrow around more than 2/3 edge of the oil pan, remove it from the ladder frame.
- Do not turn over the SST abruptly without tapping. It be result in damage of the SST.
- Be careful not to damage the contact surfaces of Upper oil pan and lower oil pan.


32. Remove the crankshaft pulley (A).



KDRF109A


NOTICE

- Use the SST(09231-3M100) to remove the crankshaft pulley bolt.



SBHEM8201D

33. Remove the water vent hose (A) from the timing chain cover.




SBHEM8092D

EM-38

Engine Mechanical System

34. Remove the timing chain cover (A).




SBHEM8064D

CAUTION


- Be careful not to damage the contact surfaces of cylinder block, cylinder head and timing chain cover.

NOTICE


- Before removing the timing chain, mark the RH/LH timing chain with an identification based on the location of the sprocket because the identification mark on the chain for TDC (Top Dead Center) can be erased.




KDRF129A



SBHEM8062D



SBHEM8063D




SBHEM8074D

Timing System


EM-39

35. Remove the oil pump chain cover (A).




SBHEM8209D

36. Remove the oil pump chain tensioner assembly (A).




KDRF119A

37. Remove the oil pump chain guide (A).




KDRF120A

38. Install a set pin after compressing the RH timing chain tensioner.



KCRF105A

39. Remove the RH timing chain auto tensioner (A) and the RH timing chain tensioner arm (B).




KDRF117A

EM-40


Engine Mechanical System

40. Remove the RH timing chain guide (A) and RH timing chain (B).




SBHEM8065D

41. Remove the oil pump chain sprocket (A) and oil pump chain (B).




KDRF121A

42. Remove the crankshaft sprocket (A) (O/P & RH camshaft drive).



KDRF122A

43. Install a set pin after compressing the LH timing chain tensioner.




SBHEM8066D

Timing System


EM-41

44. Remove the LH timing chain auto tensioner (A) and LH timing chain tensioner arm (B).




KDRF124A

45. Remove the LH timing chain guide (A) and LH timing chain (B).




SBHEM8067D

46. Remove the crankshaft sprocket (A). (LH camshaft drive).



KDRF126A

47. Remove the tensioner adapter assembly (A).



KDRF127A

EM-42

Engine Mechanical System


Inspection

Sprockets, Chain Tensioner, Chain Guide, Chain Tensioner Arm

1. Check the camshaft sprocket and crankshaft sprocket for abnormal wear, cracks, or damage. Replace as necessary.
2. Inspect the tensioner arm and chain guide for abnormal wear, cracks, or damage. Replace as necessary.
3. Check that the tensioner piston moves smoothly when the ratchet pawl is released with thin rod.


Installation

1. The key (A) of crankshaft should be aligned with the timing mark (B) of timing chain cover. As a result of this, the piston of No.1 cylinder is placed at the top dead center on compression stroke.



KDRF128A

2. Install the tensioner adapter assembly (A).




KDRF127A

Timing System

EM-43

3. Install the crankshaft sprocket (A). (LH camshaft drive).




KDRF126A

4. Install the LH timing chain guide (A) and LH timing chain (B).

Tightening torque :

19.6 ~ 24.5N.m (2.0 ~ 2.5kgf.m, 14.5 ~ 18.1lb-ft)




SBHEM8067D

NOTICE


To install the timing chain with no slack between each shaft (cam, crank), follow the below procedure.

Crankshaft sprocket → Timing chain guide → Exhaust camshaft sprocket → Intake camshaft sprocket.

The timing mark of each sprockets should be matched with timing mark (color link) of timing chain at installing timing chain.



SBHEM8062D



SBHEM8074D

EM-44


Engine Mechanical System

5. Install the LH timing chain auto tensioner (A) and LH timing chain tensioner arm (B).

Tightening torque


A : 9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)

B : 18.6 ~ 21.6N.m (1.9 ~ 2.2kgf.m, 13.7 ~ 15.9lb-ft)



KDRF124A

6. Install the crankshaft sprocket (A) (O/P & RH camshaft drive).




KDRF122A

7. Install the oil pump chain sprocket (A) and oil pump chain (B).

Tightening torque :

18.6 ~ 21.6N.m (1.9 ~ 2.2kgf.m, 13.7 ~ 15.9lb-ft)




KDRF121A

8. Install the RH timing chain guide (A) and RH timing chain (B).

Tightening torque :

A : 19.6 ~ 24.5N.m (2.0 ~ 2.5kgf.m, 14.5 ~ 18.1lb-ft)



SBHEM8065D

Timing System


EM-45

NOTICE


To install the timing chain with no slack between each shaft (cam, crank), follow the below procedure.

Crankshaft sprocket → Timing chain guide → Intake camshaft sprocket → Exhaust camshaft sprocket.

The timing mark of each sprockets should be matched with timing mark (color link) of timing chain at installing timing chain.



SBHEM8063D




KDRF129A

- Install the RH timing chain auto tensioner (A) and the RH timing chain tensioner arm (B).

Tightening torque

A : 9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)

B : 18.6 ~ 21.6N.m (1.9 ~ 2.2kgf.m, 13.7 ~ 15.9lb-ft)




KDRF117A

- Install the oil pump chain guide (A).

Tightening torque :

9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)



KDRF120A


EM-46

Engine Mechanical System

11. Install the oil pump chain tensioner assembly (A).


Tightening torque :

9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)



KDRF119A

12. Pull out the pins of hydraulic tensioner (LH & RH).




KCRF105A

13. Install the oil pump chain cover (A).

Tightening torque :

9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)




SBHEM8209D

14. After rotating the crankshaft 2 revolutions in regular direction (clockwise viewed from front), confirm the timing mark.

NOTICE

Always turn the crankshaft clockwise.

Turning the crankshaft counter clockwise before building up oil pressure in the hydraulic timing chain tensioner may result in the chain disengaging from the sprocket teeth.



SBHEM8066D


Timing System

EM-47

15. Install the timing chain cover.


- 1) The sealant locations on chain cover and on counter parts (cylinder head, cylinder block, and lower oil pan) must be free of engine oil and etc.
- 2) Before assembling the timing chain cover, the liquid sealant TB 1217H should be applied on the gap between cylinder head and cylinder block.
The part must be assembled within 5 minutes after sealant was applied.

Bead width : 2.5mm(0.1in.)




KDRF134A

- 3) After applying liquid sealant TB1217H on timing chain cover. The part must be assembled within 5 minutes after sealant was applied.
Sealant should be applied without discontinuity.



SNFM18033N

- 4) Install the new gasket (A) to the timing chain cover.



SBHEM8093D

NOTICE

During timing cover installation, care not to take off applied sealant on the timing cover by contact with other parts.

EM-48

Engine Mechanical System

- 5) The dowel pins on the cylinder block and holes on the timing chain cover should be used as a reference in order to assemble the timing chain cover to be in exact position.

Tightening torque

B(17) :

18.62 ~ 21.56N.m (1.9 ~ 2.2kgf.m, 13.74 ~ 15.91lb-ft)

C(4) :

9.80 ~ 11.76N.m (1.0 ~ 1.2kgf.m, 7.23 ~ 8.68lb-ft)

D(2) :

58.80 ~ 68.80N.m (6.0 ~ 7.0kgf.m, 43.40 ~ 50.63lb-ft)

F(2) :

24.50 ~ 26.46N.m (2.5 ~ 2.7kgf.m, 18.08 ~ 19.53lb-ft)

G(4) :

21.56 ~ 23.52N.m (2.2 ~ 2.4kgf.m, 15.91 ~ 17.36lb-ft)

H(1) :

9.80 ~ 11.76N.m (1.0 ~ 1.2kgf.m, 7.23 ~ 8.68lb-ft)

I(1) :

9.80 ~ 11.76N.m (1.0 ~ 1.2kgf.m, 7.23 ~ 8.68lb-ft)

J(1) :

9.80 ~ 11.76N.m (1.0 ~ 1.2kgf.m, 7.23 ~ 8.68lb-ft)


K(4) :

9.80 ~ 11.76N.m (1.0 ~ 1.2kgf.m, 7.23 ~ 8.68lb-ft)

L(1) :

21.56 ~ 26.46N.m (2.2 ~ 2.7kgf.m, 15.91 ~ 19.53lb-ft)


- New bolt



SBHEM8094D


- 6) The firing and/or blow out test should not be performed within 30 minutes after the timing chain cover was assembled.

16. Install the water vent hose (A) to the timing chain cover.



SBHEM8092D

17. Using SST(09231-3C100), install timing chain cover oil seal.



SENEM8026D


Timing System

EM-49

18. Install the lower oil pan (A).

- 1) Using a gasket scraper, remove all the old packing material from the gasket surfaces.
- 2) Before assembling the oil pan, the liquid sealant TB 1217H should be applied on oil pan. The part must be assembled within 5 minutes after the sealant was applied.

Bead width : 2.5mm(0.1in.)



SBLM16020L

⚠ CAUTION


- Clean the sealing face before assembling two parts.
- Remove harmful foreign matters on the sealing face before applying sealant.
- When applying sealant gasket, sealant must not be protruded into the inside of oil pan.
- To prevent leakage of oil, apply sealant gasket to the inner threads of the bolt holes.

3) Install the oil pan (A).

Uniformly tighten the bolts in several passes.

Tightening torque :

9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)




SBLM16102L

19. Install the crankshaft pulley (A).

Tightening torque :

284.4 ~ 304.0N.m (29.0~31.0kgf.m, 209.8~224.2lb-ft)




KDRF109A

EM-50

Engine Mechanical System

NOTICE

- Use the SST(09231-3M100) to install the crankshaft pulley bolt.




SBHEM8201D

20. Install the water pump pulley (A).

Tightening torque :

7.8 ~ 9.8N.m (0.8 ~ 1.0kgf.m, 5.8 ~ 7.2lb-ft)



SBHEM8059D

21. Install the drive belt auto tensioner (A).


Tightening torque

Bolt (B) :

81.4 ~ 85.3N.m (8.3 ~ 8.7kgf.m, 60.0 ~ 62.9lb-ft)

Bolt (C) :

17.7 ~ 21.6N.m (1.8 ~ 2.2kgf.m, 13.0 ~ 15.9lb-ft)




SENEM8020D

22. Install the drive belt idler (A).

Tightening torque :

52.9 ~ 57.9N.m (5.4 ~ 5.9kgf.m, 39.1 ~ 42.7lb-ft)



KDRF105A


Timing System

EM-51

23. Install the alternator (A). (Refer to EE group)


Tightening torque :

26.5 ~ 33.3N.m (2.7 ~ 3.4kgf.m, 19.5 ~ 24.6lb-ft)




KDRF104A

24. Install the air conditioner compressor (A). (Refer to HA group)




SBHEM8101D

25. Install the power steering pump (A). (Refer to ST group)



KDRF102A

26. Install the drive belt (A).



SBHEM8058D


EM-52

Engine Mechanical System

27. Install the LH/RH cylinder head cover (A).

- 1) The hardening sealant located on the upper area between timing chain cover and cylinder head should be removed before assembling cylinder head cover.
- 2) After applying sealant(TB1217H), it should be assembled within 5 minutes.

Bead width : 2.5mm(0.1in.)



SBHEM8095D


- 3) The firing and/or blow out test should not be performed within 30 minutes after the cylinder head cover was assembled.
- 4) Install the cylinder head cover bolts as following method.

Tightening torque :

9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)


⚠ CAUTION

Do not reuse cylinder head cover gasket.




SBHEM8096D


28. Install the connector brackets (A) to the LH/RH cylinder head cover.



SBHEM8052D




SBHEM8053D



SBHEM8054D


Timing System

EM-53




SBHEM8055D

29. Install the LH/RH ignition coils (A).




SBHEM8050D



SBHEM8051D

30. Connect the RH ignition coil connector (A) and the injector connector (B).




SBHEM8044D

31. Install the surge tank assembly (A).

Tightening torque :

9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)



SBHEM8043D


EM-54

Engine Mechanical System

32. Install the PCV hose (A) and surge tank stay (B).

Tightening torque :

27.5 ~ 31.4N.m (2.8 ~ 3.2kgf.m, 20.3 ~ 23.1lb-ft)




SBHEM8040D

33. Install the RH side coolant pipe (A).

Tightening torque :

19.6 ~ 23.5N.m (2.0 ~ 2.4kgf.m, 14.5 ~ 17.4lb-ft)




SBHEM8039D

34. Install the throttle body coolant hose & pipe (A).

Tightening torque :

9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)




SBHEM8038D

35. Install the fuel pipe (A) and vacuum pipe (B).

Tightening torque :

9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)



SBHEM8037D

Timing System


EM-55

36. Install the LH side coolant pipe and hose (A).

Tightening torque

Bolt (B): 19.6 ~ 23.5Nm (2.0 ~ 2.4kgf.m, 14.5 ~ 17.4lb-ft)

Bolt (C): 9.8 ~ 11.8Nm (1.0 ~ 1.2 kgf.m, 7.2 ~ 8.7lb-ft)




SBHEM8143D

37. Install the breather pipe & hose (A).

Tightening torque :

9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)




SBHEM8035D

38. Install the oil level gauge tube (A).

Tightening torque :


18.6 ~ 22.6N.m (1.9 ~ 2.3kgf.m, 13.7 ~ 16.6lb-ft)



SBHEM8034D

39. Connect the engine wiring connectors.

- 1) Connect the RH exhaust camshaft CMP sensor connector (A).




SBHEM8033D

EM-56


Engine Mechanical System

- 2) Connect the water temperature sensor connector (A) and oil temperature sensor connector (B).




SBHEM8032D

- 3) Connect the VIS solenoid valve connector (A), PCSV connector (B) and RH oxygen sensor connector (C).




SBHEM8031D

- 4) Connect the LH intake camshaft CMP sensor connector (A), RH intake camshaft CMP sensor connector (B) and condenser connector (C).



SBHEM8030D

- 5) Connect the oil pressure switch connector (A), LH exhaust camshaft CMP sensor connector (B) and LH oxygen sensor connector (C).




SBHEM8029D

Timing System


EM-57

- 6) Connect the LH injector connector (A) and LH ignition coil connector (B).




SBHEM8027D

- 7) Connect the LH knock sensor connector (A), LH/RH intake OCV connector (B) and LH exhaust OCV connector (C).




SBHEM8026D

- 8) Connect the MAP sensor connector (A), ETC connector (B), RH exhaust OCV connector (C), RH injector connector (D) and RH ignition coil connector (E).



SBHEM8025D

- 9) Connect the power steering oil pressure switch connector (A) and RH knock sensor connector (B).



SBHEM8024D


EM-58

Engine Mechanical System

40. Install the power steering reservoir tank and bracket (A).

Tightening torque :

7.8 ~ 11.8N.m (0.8 ~ 1.2kgf.m, 5.8 ~ 8.7lb-ft)




SBHEM8023D

41. Install the fuel hose (A).


Tightening torque :

9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)




SBHEM8015D

42. Install the radiator upper hose(A) and lower hose(B).



SBHEM8003D



SBHEM8004D

Timing System

EM-59

43. Install the intake air hose and air cleaner assembly.

- 1) Install the intake air hose (D) and air cleaner assembly (E).

Tightening torque

Bolt (D) : 1.9 ~ 2.9N.m (0.2 ~ 0.3kgf.m, 1.4 ~ 2.2lb-ft)


Bolt (E) : 7.8 ~ 9.8N.m (0.8 ~ 1.0kgf.m, 5.8 ~ 7.2lb-ft)

- 2) Install the resonator (C).

Tightening torque :


Bolt (C) : 7.8 ~ 9.8N.m (0.8 ~ 1.0kgf.m, 5.8 ~ 7.2lb-ft)

- 3) Connect the breather hose (B).
- 4) Connect the MAFS connector (A).



SBHEM8002D

44. Install the air duct (A).




SBHEM8001D

45. Install the engine side cover.

46. Install the engine cover (A).

NOTICE

Install the engine cover bolts as following method.



SBHEM8211D

47. Connect the battery negative cable.

NOTICE

- Refill engine oil.
- Clean the battery posts and cable terminals with sandpaper. Assemble and then apply grease to prevent corrosion.
- Inspect for fuel leakage.
 - After assembling the fuel line, turn on the ignition switch (do not operate the starter) so that the fuel pump runs for approximately two seconds and fuel line pressurizes.
 - Repeat this operation two or three times, then check for fuel leakage at any point in the fuel lines.
- Refill radiator and reservoir tank with engine coolant.
- Bleed air from the cooling system.
 - Start engine and let it run until it warms up. (Until the radiator fan operates 3 or 4 times.)
 - Turn Off the engine. Check the level in the radiator, add coolant if needed. This will allow trapped air to be removed from the cooling system.
 - Put radiator cap on tightly, then run the engine again and check for leaks.


EM-60

Engine Mechanical System

Cylinder Head Assembly

Cylinder Head

Components




SBHEM9107L

- 1. RH Cylinder head
- 2. RH Cylinder head gasket
- 3. LH Cylinder head

- 4. LH Cylinder head gasket
- 5. Cylinder block

Cylinder Head Assembly

EM-61



SBHEM9077L

- | | | |
|--------------------------------|-----------------------------------|--------------------------|
| 1. Camshaft bearing cap | 6. Intake CVVT assembly | 11. Valve stem seal |
| 2. Camshaft thrust bearing cap | 7. Mechanical lash adjuster (MLA) | 12. Valve |
| 3. Exhaust camshaft | 8. Retainer lock | 13. Exhaust camshaft OCV |
| 4. Intake camshaft | 9. Retainer | 14. Intake camshaft OCV |
| 5. Exhaust CVVT assembly | 10. Valve spring | 15. Cylinder head |

EM-62

Engine Mechanical System


Removal

⚠ CAUTION

- Use fender covers to avoid damaging painted surfaces.
- To avoid damaging the cylinder head, wait until the engine coolant temperature drops below normal temperature (20°C [68°F]) before removing it.
- When handling a metal gasket, take care not to fold the gasket or damage the contact surface of the gasket.
- To avoid damage, unplug the wiring connectors carefully while holding the connector portion.


📌 NOTICE

- Mark all wiring and hoses to avoid misconnection.
 - Turn the crankshaft pulley so that the No. 1 piston is at top dead center.
1. Remove the timing chain. (Refer to Timing system in this group)
 2. Disconnect the heater hoses (A) and brake vacuum hose (B).




SBHEM8006D

3. Remove the mounting bolts (B, C) and then remove the water temperature control assembly (A).



SBHEM8041D



SBHEM8042D


Cylinder Head Assembly

EM-63

4. Disconnect the water vent hose (A) and then remove the intake the manifold (B).


⚠ CAUTION

- Be sure to drain the engine coolant before removing the intake manifold.
- If any coolant drained from the cylinder head vent hole has entered the intake port. This can potentially lead to engine trouble.




SBHEM8148D

5. Remove the exhaust manifold stays (A).




SBHEM8204D

6. Remove the LH/RH exhaust manifold heat protector (A).



SBHEM8046D




SBHEM8047D


EM-64

Engine Mechanical System

7. Remove the LH/RH exhaust manifold (A).




SBHEM8048D




SBHEM8069D

9. Remove the LH/RH camshaft bearing cap (A) and thrust bearing cap (B).




SBHEM8070D

8. Remove the LH/RH exhaust camshaft OCV (A).



SBHEM8068D




SBHEM8071D


Cylinder Head Assembly

EM-65

10. Remove the LH/RH camshaft assembly (A).





SBHEM8072D



SBHEM8073D

11. Remove the cylinder head.

- 1) Uniformly loosen and remove the cylinder head bolts, in several passes, in the sequence shown.



KDRF199A

⚠ CAUTION

Head warpage or cracking could result from removing bolts in an incorrect order.

- 2) Lift the cylinder head from the dowels on the cylinder block and place the cylinder head on wooden blocks on a bench.

⚠ CAUTION

Be careful not to damage the contact surfaces of the cylinder head and cylinder block.

EM-66


Engine Mechanical System

Disassembly

 NOTICE

Identify MLA, valves and valve springs as they are removed so that each item can be reinstalled in its original position.


1. Remove the MLAs(A).



KDRF200A


2. Remove the valves.

- 1) Using the SST(09222-3K000, 09222-3C300), compress the valve spring and remove retainer lock.



KDRF201A

- 2) Remove the spring retainer.
- 3) Remove the valve spring.
- 4) Remove the valve.
- 5) Using the SST(09222-29000), remove the valve stem seal.




KDRF234A

 NOTICE

Do not reuse old valve stem seals.

3. Remove the OCV(A).



KDRF202A

Cylinder Head Assembly

EM-67

Inspection

Cylinder Head

1. Inspect for flatness.

Using a precision straight edge and feeler gauge, measure the surface contacting cylinder block and the manifolds for warpage.


Flatness of cylinder head gasket surface

Standard : Less than 0.05mm(0.002in.)

[Less than 0.02mm(0.0008in.)/150x150]

Flatness of manifold gasket surface

Standard : Less than 0.03mm(0.001in)/110x110



EDQF160A

2. Inspect for cracks.

Check the combustion chamber, intake ports, exhaust ports and cylinder block surface for cracks. If cracked, replace the cylinder head.


Valve And Valve Spring

1. Inspect valve stems and valve guides.

- 1) Using a caliper gauge, measure the inside diameter of the valve guide.

Valve guide I.D.

Intake / Exhaust : 5.500 ~ 5.512mm (0.216 ~ 0.217in.)




ECBF034A

- 2) Using a micrometer, measure the diameter of the valve stem.

Valve stem O.D.

Intake : 5.465 ~ 5.480mm (0.2151 ~ 0.2157in.)

Exhaust : 5.458 ~ 5.470mm (0.2149 ~ 0.2153in.)



KCRF227A

EM-68

Engine Mechanical System

- 3) Subtract the valve stem diameter measurement from the valve guide inside diameter measurement.

Valve stem-to-guide clearance

[Standard]

Intake : 0.020 ~ 0.047mm (0.0008 ~ 0.0018in.)

Exhaust : 0.030 ~ 0.054mm (0.0012 ~ 0.0021in.)

[Limit]

Intake : 0.07mm (0.0027in.)

Exhaust : 0.09mm (0.0035in.)

2. Inspect valves.


- 1) Check the valve is ground to the correct valve face angle.
- 2) Check that the surface of the valve for wear.
If the valve face is worn, replace the valve.
- 3) Check the valve head margin thickness.
If the margin thickness is less than minimum, replace the valve.

Margin

[Standard]

Intake : 1.56 ~ 1.86mm (0.06142 ~ 0.07323in.)

Exhaust : 1.73 ~ 2.03mm (0.06811 ~ 0.07992in.)



ECKD221A

- 4) Check the valve length.

Length

Intake : 105.27mm (4.1445in)

Exhaust : 105.50mm (4.1535in)

- 5) Check the surface of the valve stem tip for wear.
If the valve stem tip is worn, replace the valve.

3. Inspect valve seats

Check the valve seat for evidence of overheating and improper contact with the valve face.

If the valve seat is worn, replace cylinder head.

Before reconditioning the seat, check the valve guide for wear. If the valve guide is worn, replace cylinder head. Recondition the valve seat with a valve seat grinder or cutter. The valve seat contact width should be within specifications and centered on the valve face.

4. Inspect valve springs.


- 1) Using a steel square, measure the out-of-square of the valve spring.
- 2) Using vernier calipers, measure the free length of the valve spring.

Valve spring

[Standard]

Free height : 43.86mm (1.7267in.)

Out-of-square : 1.5°



KCRF205A

Cylinder Head Assembly

EM-69

MLA

1. Inspect MLAs.

Using a micrometer, measure the MLA outside diameter.

MLA O.D.

Intake/Exhaust :

34.964 ~ 34.980mm(1.3765 ~ 1.3771in.)

2. Using a caliper gauge, measure MLA tappet bore inner diameter of cylinder head.

Tappet bore I.D.

Intake/Exhaust :

35.000 ~ 35.025mm(1.3779 ~ 1.3789in.)

3. Subtract MLA outside diameter measurement from tappet bore inside diameter measurement.

MLA to tappet bore clearance

[Standard]

Intake/Exhaust : 0.020 ~ 0.061mm(0.0008 ~ 0.0024in.)

[Limit]

Intake/Exhaust : 0.07mm(0.0027in.)

Camshaft

1. Inspect cam lobes.


Using a micrometer, measure the cam lobe height.

Cam height

[Standard value]

Intake : 46.8mm (1.8425in.)

Exhaust : 45.8mm (1.8031in.)




KCRF206A

If the cam lobe height is less than standard, replace the camshaft.

2. Inspect the camshaft journal clearance.

- 1) Clean the bearing caps and camshaft journals.
- 2) Place the camshafts on the cylinder head.
- 3) Lay a strip of plastigage across each of the camshaft journals.



KCRF207A

EM-70


Engine Mechanical System

- 4) Install the bearing cap (A) and thrust bearing cap (B) with specified torque.


Tightening torque :

1st step : 5.8N.m (0.6kgf.m, 4.3lb-ft)

2nd step : 9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)



SBHEM8133D



SBHEM8134D

⚠ CAUTION

Do not turn the camshaft.

- 5) Remove the bearing caps.
6) Measure the plastigage at its widest point.

Bearing oil clearance

[Standard value]

Intake


No.1 journal : 0.020 ~ 0.057mm (0.0008 ~ 0.0022in.)

No.2,3,4 journal : 0.030 ~ 0.067mm (0.0012 ~ 0.0026in.)

Exhaust

No.1 journal : 0.027 ~ 0.057mm (0.0010 ~ 0.0022in.)

No.2,3,4 journal : 0.030 ~ 0.067mm (0.0012 ~ 0.0026in.)




KCRF208A

If the oil clearance is greater than maximum, replace the camshaft. If necessary, replace cylinder head.

- 7) Completely remove the plastigage.
8) Remove the camshafts.
3. Inspect the camshaft end play.
1) Install the camshafts.
2) Using a dial indicator, measure the end play while moving the camshaft back and forth.

Camshaft end play

[Standard value] : 0.02 ~ 0.18mm(0.0008 ~ 0.0071in.)



KDRF196B

If the end play is greater than maximum, replace the camshaft. If necessary, replace cylinder head.

- 3) Remove the camshafts.


Cylinder Head Assembly

EM-71

CVVT Assembly

1. Inspect the CVVT assembly.

- 1) Check that the CVVT assembly will not turn.
- 2) Apply vinyl tape to the retard hole except the one indicated by the arrow in the illustration.



ECRF015A


- 3) Wrap tape around the tip of the air gun and apply air of approx. 150kpa(1.5kgf/cm², 21psi) to the port of the camshaft.
(Perform this in order to release the lock pin for the maximum delay angle locking.)

NOTICE

When the oil splashes, wipe it off with a shop rag.

- 4) Under the condition of (3), turn the CVVT assembly to the advance angle side (the arrow marked direction in the illustration) with your hand.

Depending on the air pressure, the CVVT assembly will turn to the advance side without applying force by hand.



SGHEM7010N

- 5) Except the position where the lock pin meets at the maximum delay angle, let the CVVT assembly turn back and forth and check the movable range and that there is no interference.

Standard: Movable smoothly in the range about 30°

- 6) Turn the CVVT assembly with your hand and lock it at the maximum delay angle position (clockwise).

EM-72

Engine Mechanical System

Reassembly

 NOTICE

Thoroughly clean all parts to be assembled.

Before installing the parts, apply fresh engine oil to all sliding and rotating surfaces.

Replace oil seals with new ones.


1. Install the valves.

- 1) Using the SST(09222-3C100), push in a new oil seal.

 NOTICE

Do not reuse old valve stem seals.

Incorrect installation of the seal could result in oil leakage past the valve guides.




KCRF120B

2) Install the valve, valve spring and spring retainer.

 NOTICE

Place valve springs so that the side coated with enamel faces toward the valve spring retainer and then install the retainer.

- 3) Using the SST(09222 - 3K000, 09222-3C300), compress the spring and install the retainer locks. After installing the valves, ensure that the retainer locks are correctly in place before releasing the valve spring compressor.




KDRF201A

- 4) Lightly tap the end of each valve stem two or three times with the wooden handle of a hammer to ensure proper seating of the valve and retainer lock.

2. Install the MLAs.

Check that the MLA rotates smoothly by hand.



KDRF200A

 NOTICE

MLA can be reinstalled in its original position.


Cylinder Head Assembly

EM-73

3. Install the OCV(A).

Tightening torque

9.80 ~ 11.76Nm(1.0 ~ 1.2kgf.m, 7.23 ~ 8.68lb-ft)



NOTICE

- Install OCV with gray colored connector into LH bank.
- Install OCV with black colored connector into RH bank.

CAUTION

- Do not reuse the OCV when dropped.
- Keep the OCV clean.
- Do not hold the OCV sleeve during servicing.
- When the OCV is installed on the engine, do not move the engine while holding the OCV yoke.

Installation


NOTICE

- Thoroughly clean all parts to be assembled.
- Always use a new head and manifold gasket.
- The cylinder head gasket is a metal gasket. Take care not to bend it.
- Rotate the crankshaft, set the No.1 piston at TDC.

1. Install the cylinder head.

- The sealant locations on cylinder head and cylinder block must be free of engine oil and ETC.
- Apply sealant on cylinder block top face before assembling cylinder head gaskets.

The part must be assembled within 5 minutes after sealant was applied.



EM-74

Engine Mechanical System

NOTICE

Refer to below illustration to apply the sealant.


Bead width :

2.0~3.0 mm (0.078 ~ 0.118 in.)

Sealant locations :

1.0~1.5mm (0.039 ~ 0.059 in.) from block surface


Recommended sealant : Liquid sealant TB1217H



ECBF018A

- c. Apply sealant on cylinder head gaskets after assembling cylinder head gaskets on cylinder block.


The part must be assembled within 5 minutes after sealant was applied.



ECBF019A

NOTICE

Be careful of the installation direction.




KDRF203A

- d. Install the cylinder head.

NOTICE

Remove the extruded sealant after assembling cylinder heads.



KDRF198A

Cylinder Head Assembly

EM-75



2. Install cylinder head bolts.

- 1) Do not apply engine oil on the threads and under the heads of the cylinder head bolts.
- 2) Using SST(09221-4A000), install and tighten the cylinder head bolts and plate washers, in several passes, in the sequence shown.


Tightening torque

Head bolt: 39.2N.m (4.0kgf.m, 28.9lb-ft)+ 120° + 90°

Bolt (A): 18.6 ~ 23.5Nm (1.9 ~ 2.4kgf.m, 13.7 ~ 17.4lb-ft)




KDRF199B



ECBF035A

09221 - 4A000




KDRF223A

3. Install the CVVT assembly.

Tightening torque :

64.7 ~ 76.5N.m (6.6 ~ 7.8kgf.m, 47.7 ~ 56.4lb-ft)



KCRF122A


⚠ CAUTION

- Install camshaft-inlet to dowel pin of CVVT assembly.
At this time, attend not to be installed to oil hole of camshaft-inlet.
- Hold the hexagonal head wrench portion of the camshaft with a vise, and install the bolt and CVVT assembly.
- Do not rotate CVVT assembly when camshaft is installed to dowel pin of CVVT assembly.


EM-76

Engine Mechanical System

4. Install the LH/RH camshaft assembly (A).



SBHEM8072D




SBHEM8073D

CAUTION

- Apply a light coat of engine oil on camshaft journals.
- Assemble the key groove of camshaft rear side to the same level of head top surface.
- Be careful the right, left bank, intake, exhaust side before assembling.

Intake Camshaft



SENEM8006D


As for camshaft identification, refer to the table below.

Displacement	Outer diameter	
	LH	RH
BH 3.3L Intake camshaft	A : 27mm (1.0630in.)	A : 27mm (1.0630in.)
	B : 30mm (1.1811in.)	B : 30mm (1.1811in.)
	C : 27mm (1.0630in.)	C : 30mm (1.1811in.)
	D : 27mm (1.0630in.)	D : 30mm (1.1811in.)
BH 3.8L Intake camshaft	A : 27mm (1.0630in.)	A : 27mm (1.0630in.)
	B : 30mm (1.1811in.)	B : 30mm (1.1811in.)
	C : 30mm (1.1811in.)	C : 27mm (1.0630in.)
	D : 27mm (1.0630in.)	D : 30mm (1.1811in.)

Cylinder Head Assembly

EM-77

Exhaust Camshaft



SBHEM8109D

As for camshaft identification, refer to the table below.


Displacement	Outer diameter	
	LH	RH
BH 3.3L / 3.8L Exhaust camshaft	A : 27mm (1.0630in.)	A : 27mm (1.0630in.)
	B : 30mm (1.1811in.)	B : 30mm (1.1811in.)
	C : 27mm (1.0630in.)	C : 30mm (1.1811in.)

5. Install the LH/RH camshaft bearing cap (A) and thrust bearing cap (B).


Tightening torque

1st step : 5.8N.m (0.6kgf.m, 4.3lb-ft)

2nd step : 9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)



SBHEM8133D




SBHEM8134D

CAUTION

Be sure to install the thrust bearing cap bolts and the bearing cap bolts in the correct place.

NOTICE

Be careful the right, left bank, intake, exhaust side before assembling.



ECBF036A

A : L(LH),R(RH)

B : I(Intake), None(Exhaust)

C : Journal number

D : Front mark

CAUTION

Rotate the crankshaft not to contact the valves to the pistons by making the pistons below 10mm(0.3937in.) from the top of cylinder block.


EM-78

Engine Mechanical System


6. Install the LH/RH exhaust camshaft OCV (A).

Tightening torque :

9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)



SBHEM8068D




SBHEM8069D


7. Install the LH/RH exhaust manifold (A) with a new gasket.

Tightening torque :

39.2 ~ 44.1N.m (4.0 ~ 4.5kgf.m, 28.9 ~ 32.5lb-ft)



SBHEM8048D



SBHEM8049D


Cylinder Head Assembly

EM-79


8. Install the LH/RH exhaust manifold heat protector (A).

Tightening torque :

9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)



SBHEM8046D




SBHEM8047D

9. Install the exhaust manifold stays (A).

Tightening torque :

34.3 ~ 41.2N.m (3.5 ~ 4.2kgf.m, 25.3 ~ 30.4lb-ft)



SBHEM8204D

10. Install the intake the manifold (B) with a new gasket, and connect the water vent hose (A).

⚠ CAUTION

- Be sure to drain the engine coolant before removing the intake manifold.
- If any coolant drained from the cylinder head vent hole has entered the intake port. This can potentially lead to engine trouble.

Tightening torque


Step 1: 3.9 ~ 5.9N.m (0.4 ~ 0.6kgf.m, 2.9 ~ 4.3lb-ft)

Step 2:

Nut-18.62 ~ 23.52N.m (1.9~2.4kgf.m, 13.74~17.36lb-ft)

Bolt -26.5 ~ 31.4 N.m (2.7 ~ 3.2 kgf.m, 19.5 ~ 23.1lb-ft)

Step 3: Repeat 2nd step twice or more.



SBHEM8148D

a - h : 1st step order


1 ~ 8 : 2nd step order

EM-80

Engine Mechanical System

NOTICE

Confirm the manifold gasket identification mark (LH, RH) and be careful of the installation direction.




SBHEM8045D

11. Install the water temperature control assembly (A) with a new gasket.

Tightening torque :


19.6 ~ 23.5Nm (2.0 ~ 2.4kgf.m, 14.5 ~ 17.4lb-ft)



SBHEM8041D


CAUTION

When tightening the bolt (C), use a ground bolt.



SBHEM8042D

12. Connect the heater hoses (A) and brake vacuum hose (B).



SBHEM8006D

Cylinder Head Assembly

EM-81

13. Install the timing chain. (Refer to Timing system in this group)

NOTICE

- Refill engine oil.
- Clean the battery posts and cable terminals with sandpaper. Assemble and then apply grease to prevent corrosion.
- Inspect for fuel leakage.
 - After assembling the fuel line, turn on the ignition switch (do not operate the starter) so that the fuel pump runs for approximately two seconds and fuel line pressurizes.
 - Repeat this operation two or three times, then check for fuel leakage at any point in the fuel lines.
- Refill radiator and reservoir tank with engine coolant.
- Bleed air from the cooling system.
 - Start engine and let it run until it warms up. (Until the radiator fan operates 3 or 4 times.)
 - Turn Off the engine. Check the level in the radiator, add coolant if needed. This will allow trapped air to be removed from the cooling system.
 - Put radiator cap on tightly, then run the engine again and check for leaks.




دیجیتال خودرو سامانه (مسئولیت محدود)
اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

EM-82

Engine Mechanical System

Cylinder Block

Components




SBHEM9110L

- | | | |
|---------------------------------|---------------------------------|--------------------|
| 1. Piston ring | 5. Piston pin | 8. Baffle plate |
| 2. Piston | 6. Connecting rod lower bearing | 9. Upper oil pan |
| 3. Connecting rod | 7. Connecting rod bearing cap | 10. Cylinder block |
| 4. Connecting rod upper bearing | | |

Cylinder Block

EM-83



SBHEM9078L

1. Oil drain cover
2. Oil drain cover gasket
3. Crank shaft upper bearing
4. Thrust bearing

5. Adapter plate
6. Drive plate
7. Crank shaft adapter
8. Rear oil seal

9. Rear oil seal case
10. Crankshaft
11. Crankshaft lower bearing
12. Main bearing cap

EM-84

Engine Mechanical System

Disassembly


⚠ CAUTION

- Use fender covers to avoid damaging painted surfaces.
- To avoid damage, unplug the wiring connectors carefully while holding the connector portion.

📖 NOTICE


- Mark all wiring and hoses to avoid misconnection.
- Inspect the timing belt before removing the cylinder head.
- Turn the crankshaft pulley so that the No.1 piston is at top dead center.
- Engine removal is required for this procedure.

1. Remove the engine assembly from the vehicle. (Refer to Engine and transmission assembly in this group)
2. Install the engine to engine stand for disassembly.
3. Remove the intake manifold and exhaust manifold. (Refer to Intake and exhaust system in this group)
4. Remove the timing chain. (Refer to Timing system in this group)
5. Remove the water temperature control assembly. (Refer to Cooling system in this group)
6. Remove the cylinder head. (Refer to Cylinder head in this group)
7. Remove the oil pump. (Refer to Lubrication system in this group)
8. Remove the oil filter assembly. (Refer to Lubrication system in this group)
9. Remove the drive plate (A) and adapter plate (B).




SBHEM8079D

10. Remove the crankshaft adapter (A).




SBHEM8080D

11. Remove the knock sensor (A).



SBHEM8081D




SBHEM8082D

Cylinder Block


EM-85

12. Remove the upper oil pan (A).




SBHEM8083D

13. Remove the baffle plate (A).




SBHEM8206D

14. Remove the rear oil seal case (A).



KDRF208A

15. Remove the oil drain cover (A).



KDRF209A

16. Check the connecting rod end play.

17. Check the connecting rod cap oil clearance.

18. Remove the piston and connecting rod assemblies.

- 1) Using a ridge reamer, remove all the carbon from the top of the cylinder.
- 2) Push the piston, connecting rod assembly and upper bearing through the top of the cylinder block.

NOTICE

- Keep the bearings, connecting rod and cap together.
- Arrange the piston and connecting rod assemblies in the correct order.


19. Remove the crankshaft main bearing cap and check oil clearance.

20. Check the crankshaft end play.

EM-86

Engine Mechanical System

21. Lift the crankshaft (A) out of engine, being careful not to damage journals.



KDRF210A

NOTICE

Arrange the main bearings and thrust bearings in the correct order.

22. Check fit between piston and piston pin.

Try to move the piston back and forth on the piston pin. If any movement is felt, replace piston and piston pin as a set.

23. Remove the piston rings.

- 1) Using a piston ring expander, remove the 2 compression rings.
- 2) Remove 2 side rails and the spacer by hand.

NOTICE

Arrange the piston rings in the correct order only.

24. Disconnect connecting rod from piston. Using a press, remove the piston pin from the piston.

Press-in load : 800 ~ 1400kg (1764 ~ 3086lb)


Inspection

Connecting Rod And Crankshaft

1. Check the connecting rod end play.

Using a feeler gauge, measure the end play while moving the connecting rod back and forth.

Standard end play : 0.1 ~ 0.25mm (0.004 ~ 0.010in.)



KDRF211A

- If out-of-tolerance, install a new connecting rod.
- If still out-of-tolerance, replace the crankshaft.


Cylinder Block

EM-87

2. Check the connecting rod bearing oil clearance.
 - 1) Check the matchmarks on the connecting rod and cap are aligned to ensure correct reassembly.
 - 2) Remove 2 connecting rod cap bolts.
 - 3) Remove the connecting rod cap and bearing half.
 - 4) Clean the crank pin and bearing.
 - 5) Place plastigage across the crank pin.
 - 6) Reinstall the bearing half and cap, and torque the bolts.

Tightening torque

19.6Nm (2.0kgf.m, 14.46lb-ft) + 90°



KDRF225A


NOTICE

Do not turn the crankshaft.

- 7) Remove 2 bolts, connecting rod cap and bearing half.
- 8) Measure the plastigage at its widest point.

Standard oil clearance

0.038 ~ 0.056mm(0.0015 ~ 0.0022in.)



KDRF212A

- 9) If the plastigage measures too wide or too narrow, remove the upper half of the bearing, install a new, complete bearing with the same color mark (select the color as shown in the next column), and recheck the clearance.

CAUTION

Do not file, shim, or scrape the bearings or the caps to adjust clearance.

- 10) If the plastigage shows the clearance is still incorrect, try the next larger or smaller bearing (the color listed above or below that one), and check clearance again.


NOTICE

If the proper clearance cannot be obtained by using the appropriate larger or smaller bearings, replace the crankshaft and start over.

CAUTION

If the marks are indecipherable because of an accumulation of dirt and dust, do not scrub them with a wire brush or scraper. Clean them only with solvent or detergent.

Connecting Rod Mark Location




EDQF196A

Identification Of Connecting Rod

Class	Mark	Inside Diameter
0	a	58.000 ~ 58.006mm (2.2834 ~ 2.2837in.)
1	b	58.006 ~ 58.012mm (2.2837 ~ 2.2839in.)
2	c	58.012 ~ 58.018mm (2.2839 ~ 2.2842in.)

EM-88


Engine Mechanical System

Crankshaft Pin Mark Location
Identification Of Crankshaft

SBHEM8112D

Discrimination Of Crankshaft

Class	Mark	Outside Diameter Of Pin
I	1 or A	54.966 ~ 54.972mm (2.1640 ~ 2.1642in.)
II	2 or B	54.960 ~ 54.966mm (2.1638 ~ 2.1640in.)
III	3 or C	54.954 ~ 54.960mm (2.1635 ~ 2.1638in.)

Place Of Identification Mark (Connecting
Rod Bearing)

ECRF021A

Identification Of Connecting Rod Bearing

Class	Mark	Thickness Of Bearing
E	BLUE	1.514 ~ 1.517mm (0.0596 ~ 0.0597in.)
D	BLACK	1.511 ~ 1.514mm (0.0595 ~ 0.0596in.)
C	BROWN	1.508 ~ 1.511mm (0.0594 ~ 0.0595in.)
B	GREEN	1.505 ~ 1.508mm (0.0593 ~ 0.0594in.)
A	YELLOW	1.502 ~ 1.505mm (0.0591 ~ 0.0593in.)

11) Selection

		Connecting Rod Identification Mark		
		0(a)	1(b)	2(c)
Crankshaft Identification Mark	1 or A	A (YELLOW)	B (GREEN)	C (BROWN)
	2 or B	B (GREEN)	C (BROWN)	D (BLACK)
	3 or C	C (BROWN)	D (BLACK)	E (BLUE)

Cylinder Block

EM-89

3. Check the crankshaft bearing oil clearance.


- 1) To check main bearing-to-journal oil clearance, remove the main bearing caps and bearing halves.
- 2) Clean each main journal and bearing half with a clean shop towel.
- 3) Place one strip of plastigage across each main journal.
- 4) Reinstall the bearings and caps, then torque the bolts.

Tightening torque

49.0Nm(5.0 kgf.m, 36.2lb-ft) + 90°

19.6Nm(2.0 kgf.m, 14.5lb-ft) + 120°

29.4 ~ 31.4Nm(3.0 ~ 3.2 kgf.m, 21.7 ~ 23.1lb-ft)



SBHEM8113D


NOTICE

Do not turn the crankshaft.

- 5) Remove the cap and bearing again, and measure the widest part of the plastigage.

Standard oil clearance

0.022 ~ 0.040mm (0.0009 ~ 0.0016in.)



KCRF170A

- 6) If the plastigage measures too wide or too narrow, remove the upper half of the bearing, install a new, complete bearing with the same color mark (select the color as shown in the next column), and recheck the clearance.

CAUTION

Do not file, shim, or scrape the bearings or the caps to adjust clearance.

- 7) If the plastigage shows the clearance is still incorrect, try the next larger or smaller bearing (the color listed above or below that one), and check clearance again.

NOTICE

If the proper clearance cannot be obtained by using the appropriate larger or smaller bearings, replace the crankshaft and start over.


CAUTION

If the marks are indecipherable because of an accumulation of dirt and dust, do not scrub them with a wire brush or scraper. Clean them only with solvent or detergent.

Crankshaft bore mark location

Letters have been stamped on the block as a mark for the size of each of the 4 main journal bores.

Use them, and the numbers or bar stamped on the crank (marks for main journal size), to choose the correct bearings.



ECBF038A

EM-90


Engine Mechanical System

Discrimination Of Cylinder Block

Class	Mark	Inside Diameter
a	A	73.500 ~ 73.506mm (2.8937 ~ 2.8939in.)
b	B	73.506 ~ 73.512mm (2.8939 ~ 2.8942in.)
c	C	73.512 ~ 73.518mm (2.8942 ~ 2.8944in.)

Crankshaft Journal Mark Location

Discrimination Of Crankshaft




SBHEM8114D

Discrimination Of Crankshaft

Class	Mark	Outside Diameter Of Journal
I	1 or A	68.954 ~ 68.960mm (2.7147 ~ 2.7150in.)
II	2 or B	68.948 ~ 68.954mm (2.7145 ~ 2.7147in.)
III	3 or C	68.942 ~ 68.948mm (2.7142 ~ 2.7145in.)

Place Of Identification Mark (Crankshaft Bearing)



ECRF022A

Discrimination Of Crankshaft Bearing

Class	Mark	Thickness Of Bearing
E	BLUE	2.277 ~ 2.280mm (0.0896 ~ 0.0897in.)
D	BLACK	2.274 ~ 2.277mm (0.0895 ~ 0.0896in.)
C	BROWN	2.271 ~ 2.274mm (0.0894 ~ 0.0895in.)
B	GREEN	2.268 ~ 2.271mm (0.0893 ~ 0.0894in.)
A	YELLOW	2.265 ~ 2.268mm (0.0892 ~ 0.0893in.)

Selection

		Crankshaft Bore Identification Mark		
		a(A)	b(B)	c(C)
Crankshaft Identification Mark	1 or A	A (YELLOW)	B (GREEN)	C (BROWN)
	2 or B	B (GREEN)	C (BROWN)	D (BLACK)
	3 or C	C (BROWN)	D (BLACK)	E (BLUE)

Cylinder Block


EM-91

4. Check crankshaft end play.

Using a dial indicator, measure the thrust clearance while prying the crankshaft back and forth with a screwdriver.

Standard end play

0.10 ~ 0.28mm (0.0039 ~ 0.0110in.)



ECKD001B

If the end play is greater than maximum, replace the thrust bearings as a set.

Thrust bearing thickness

2.41 ~ 2.45mm (0.0949 ~ 0.0964in.)

5. Inspect main journals and crank pins


Using a micrometer, measure the diameter of each main journal and crank pin.

Main journal diameter :

68.942 ~ 68.960mm (2.7142 ~ 2.7149in.)

Crank pin diameter :

54.954 ~ 54.972mm (2.1635 ~ 2.1642in.)



ECKD001E

EM-92

Engine Mechanical System

Connecting Rods

1. When reinstalling, make sure that cylinder numbers put on the connecting rod and cap at disassembly match. When a new connecting rod is installed, make sure that the notches for holding the bearing in place are on the same side.
2. Replace the connecting rod if it is damaged on the thrust faces at either end. Also if step wear or a severely rough surface of the inside diameter of the small end is apparent, the rod must be replaced as well.
3. Using a connecting rod aligning tool, check the rod for bend and twist. If the measured value is close to the repair limit, correct the rod by a press. Any connecting rod that has been severely bent or distorted should be replaced.

Allowable bend of connecting rod :

0.05mm / 100mm (0.0020 in./3.94 in.) or less

Allowable twist of connecting rod :

0.1mm / 100mm (0.0039 in./3.94 in.) or less


Cylinder Block

1. Remove the gasket material.
Using a gasket scraper, remove all the gasket material from the top surface of the cylinder block.
2. Clean the cylinder block
Using a soft brush and solvent, thoroughly clean the cylinder block.
3. Inspect the top surface of the cylinder block for flatness.
Using a precision straight edge and feeler gauge, measure the surface contacting the cylinder head gasket for warpage.

Flatness of cylinder block gasket surface

Standard : Less than 0.05mm(0.0020 in.),

Less than 0.02mm(0.0008in.) / 150 x 150



EDQF154A

Cylinder Block

EM-93

4. Inspect cylinder bore diameter

Visually check the cylinder for vertical scratches.

If deep scratches are present, replace the cylinder block.


5. Inspect cylinder bore diameter

Using a cylinder bore gauge, measure the cylinder bore diameter at position in the thrust and axial directions.

Standard diameter


[3.8L] 96.00 ~ 96.03mm (3.7795 ~ 3.7807in.)

[3.3L] 92.00 ~ 92.03mm (3.6220 ~ 3.6232in.)



EDQF153A

6. Check the cylinder bore size code on the cylinder block.




ECFB002A

Class	Size code	Cylinder bore inner diameter	
		3.3L	3.8L
A	A	92.00~92.01mm (3.6220~3.6224in.)	96.00~96.01mm (3.7795~3.7799in.)
B	B	92.01~92.02mm (3.6224~3.6228in.)	96.01~96.02mm (3.7799~3.7803in.)
C	C	92.02~92.03mm (3.6228~3.6232in.)	96.02~96.03mm (3.7803~3.7807in.)

EM-94

Engine Mechanical System

7. Check the piston size code(A) and the front mark(B) on the piston top face.



SGHEM7002N

Class	Size code	Piston outer diameter	
		3.3L	3.8L
A	A	91.96~91.97mm (3.6204~3.6208in.)	95.96~95.97mm (3.7779~3.7783in.)
B	B	91.97~91.98mm (3.6208~3.6212in.)	95.97~95.98mm (3.7783~3.7787in.)
C	C	91.98~91.99mm (3.6212~3.6216in.)	95.98~95.99mm (3.7787~3.7791in.)

8. Select the piston related to cylinder bore class.

Clearance : 0.03 ~ 0.05mm(0.0012 ~ 0.0020in.)

Piston And Rings

1. Clean piston

- 1) Using a gasket scraper, remove the carbon from the piston top.
- 2) Using a groove cleaning tool, clean the piston ring grooves.
- 3) Using solvent and a brush, thoroughly clean the piston.

 NOTICE


Do not use a wire brush.

2. The standard measurement of the piston outside diameter is taken 14 mm (0.5512 in.) from the bottom of the piston.

Standard diameter

[3.8L] 95.96 ~ 95.99mm (3.7779 ~ 3.7791in.)

[3.3L] 91.96 ~ 91.99mm (3.6204 ~ 3.6216in.)



ECKD001D

Cylinder Block

EM-95

3. Calculate the difference between the cylinder bore diameter and the piston diameter.

Piston-to-cylinder clearance

0.03 ~ 0.05mm (0.0012 ~ 0.0020in.)

4. Inspect the piston ring side clearance.

Using a feeler gauge, measure the clearance between new piston ring and the wall of the ring groove.

Piston ring side clearance

Standard

No.1 : 0.03 ~ 0.07mm (0.0012 ~ 0.0027in.)

No.2 : 0.03 ~ 0.07mm (0.0012 ~ 0.0027in.)


Oil ring : 0.06 ~ 0.15mm (0.0024 ~ 0.0059in.)

Limit

No.1 : 0.1mm (0.004in.)

No.2 : 0.1mm (0.004in.)

Oil ring : 0.2mm (0.008in.)



ECKD001G

If the clearance is greater than maximum, replace the piston.

5. Inspect piston ring end gap.

To measure the piston ring end gap, insert a piston ring into the cylinder bore. Position the ring at right angles to the cylinder wall by gently pressing it down with a piston. Measure the gap with a feeler gauge. If the gap exceeds the service limit, replace the piston ring. If the gap is too large, recheck the cylinder bore diameter against the wear limits. If the bore is over the service limit, the cylinder block must be replaced.

Piston ring end gap

Standard

No.1 : 0.17 ~ 0.32mm (0.0067 ~ 0.0126in.)

No.2 : 0.32 ~ 0.47mm (0.0126 ~ 0.0185in.)


Oil ring : 0.20 ~ 0.70mm (0.0079 ~ 0.0275in.)

Limit

No.1 : 0.6mm (0.0236in.)

No.2 : 0.7mm (0.0275in.)

Oil ring : 0.8mm (0.0315in.)



ECKD001K

EM-96


Engine Mechanical System

Piston Pins

1. Measure the diameter of the piston pin.

Piston pin diameter

23.001 ~ 23.006mm (0.9056 ~ 0.9057in.)



ECKD001Z

2. Measure the piston pin-to-piston clearance.

Piston pin-to-piston clearance

0.01 ~ 0.02mm (0.0004 ~ 0.0008in.)

3. Check the difference between the piston pin diameter and the connecting rod small end diameter.

Piston pin-to-connecting rod interference

-0.032 ~ -0.016mm (-0.0012 ~ -0.0007in.)


Reassembly

NOTICE

- Thoroughly clean all parts to be assembled.
- Before installing the parts, apply fresh engine oil to all sliding and rotating surfaces.
- Replace all gaskets, O-rings and oil seals with new parts.

1. Assemble the piston and the connecting rod.


- 1) Use a hydraulic press for installation.
- 2) The piston front mark and the connecting rod front mark must face the timing belt side of the engine.



SGHEM7012N

2. Install the piston rings.

- 1) Install the oil ring spacer and 2 side rails by hand.
- 2) Using a piston ring expander, install the 2 compression rings with the code mark facing upward.
- 3) Position the piston rings so that the ring ends are as shown.




SBHEM8153D

Cylinder Block

EM-97

3. Install the connecting rod bearings.

- 1) Align the bearing claw with the groove of the connecting rod or connecting rod cap.
- 2) Install the bearings(A) in the connecting rod and connecting rod cap(B).




SGHEM7013N

4. Install the main bearings.

NOTICE

Upper bearings have an oil groove of oil holes; Lower bearings do not.

- 1) Align the bearing claw with the claw groove of the cylinder block, push in the 4 upper bearings(A).




KDRF216A

- 2) Align the bearing claw with the claw groove of the main bearing cap, and push in the 4 lower bearings.


5. Install the thrust bearings.

Install the 2 thrust bearings(A) under the No.3 journal position of the cylinder block with the oil grooves facing outward.



ECKD324A

6. Place the crankshaft(A) on the cylinder block.



KDRF210A

EM-98

Engine Mechanical System

7. Place the main bearing caps on cylinder block.
8. Install the main bearing cap bolts.
 - 1) Install and uniformly tighten the bearing cap bolts, in several passes, in the sequence shown.

Tightening torque

Main bearing cap bolt


49.0N.m (5.0 kgf.m, 36.2lb-ft) + 90° (1 ~ 8)

19.6N.m (2.0 kgf.m, 14.5lb-ft) + 120° (9 ~ 16)

29.4 ~ 31.4N.m (3.0 ~ 3.2 kgf.m, 21.7 ~ 23.1lb-ft) (17 ~ 24)

NOTICE


- Always use new main bearing cap bolts.
- If any of the bearing cap bolts are broken or deformed, replace it.



SBHEM8113D

Use the SST(09221-4A000), install main bearing cap bolts.

09221 - 4A000



KDRF224A

- 2) Check that the crankshaft turns smoothly.

9. Check crankshaft end play.
10. Install the piston and connecting rod assemblies.

NOTICE


Before installing the pistons, apply a coat of engine oil to the ring grooves and cylinder bores.

- 1) Install the ring compressor, check that the bearing is securely in place, then position the piston in the cylinder, and tap it in using the wooden handle of a hammer.
- 2) Stop after the ring compressor pops free, and check the connecting rod-to-check journal alignment before pushing the piston into place.
- 3) Apply engine oil to the bolt threads. Install the rod caps with bearings, and torque the bolts.

Tightening torque

19.6N.m (2.0kgf.m, 14.5lb-ft) + 90°

Use SST(09221-4A000), install connecting rod bearing cap bolts.




KDRF225A

Cylinder Block

EM-99

NOTICE

- Always use new connecting rod bearing cap bolts.
- Maintain downward force on the ring compressor to prevent the rings from expanding before entering the cylinder bore.




ECKD001F

11. Check the connecting rod end play.

12. Install the oil drain cover(A).

Tightening torque


9.8 ~ 11.8Nm (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)



KDRF209A

NOTICE

- Clean the sealing face before assembling two parts.
- Remove harmful foreign materials on the sealing face before applying sealant
- Before assembling oil drain cover, the liquid sealant TB1217H should be applied to the oil drain cover.
- The part must be assembled within 5 minutes after sealant was applied.
- Apply sealant to the inner threads of the bolt holes.



SBHEM8115D


EM-100

Engine Mechanical System

13. Install the rear oil seal case(A).

Tightening torque


9.8 ~ 11.8Nm (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)



KDRF208A


NOTICE

- Clean the sealing face before assembling two parts.
- Remove harmful foreign materials on the sealing face before applying sealant
- Before assembling rear oil seal case, the liquid sealant TB1217H should be applied to the rear oil seal case.
- The part must be assembled within 5 minutes after sealant was applied.
- Apply sealant to the inner threads of the bolt holes.



KDRF218A

14. Using the SST(09231-3C200, 09231-H1100), install rear oil seal.




KDRF237A

15. Install the baffle plate.

Install and uniformly tighten the baffle plate bolts, in several passes, in the sequence shown.

Tightening torque

9.8 ~ 11.8Nm (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)



SBHEM8116D

Cylinder Block


EM-101

16. Install the upper oil pan.

- Using a gasket scraper, remove all the old packing material from the gasket surfaces.
- Before assembling the oil pan, the liquid sealant TB1217H should be applied on upper oil pan.

The part must be assembled within 5 minutes after the sealant was applied.

Bead width : 2.5mm(0.1in.)



SBHEM8097D

NOTICE


- Clean the sealing face before assembling two parts.
- Remove harmful foreign materials on the sealing face before applying sealant
- When applying sealant gasket, sealant must not protrude into the inside of oil pan.
- To prevent leakage of oil, apply sealant gasket to the inner threads of the bolt holes.

c. Install the upper oil pan.

Uniformly tighten the bolts in several passes.

Tightening torque

9.8 ~ 11.8Nm (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)



SBHEM8098D


EM-102

Engine Mechanical System


17. Install the knock sensor(A).

Tightening torque

15.7 ~ 23.5Nm (1.6 ~ 2.4kgf.m, 11.6 ~ 17.3lb-ft)




SBHEM8081D



SBHEM8082D

18. Install the crankshaft adapter (A).




SBHEM8080D

19. Install the drive plate (A) and adapter plate (B).

Tightening torque :

71.6 ~ 75.5N.m (7.3 ~ 7.7kgf.m, 52.8 ~ 55.7lb-ft)



SBHEM8079D

20. Install the oil filter assembly. (Refer to Lubrication system in this group)

21. Install the oil pump. (Refer to Lubrication system in this group)

22. Install the cylinder head. (Refer to Cylinder head in this group)

23. Install the water temperature control assembly. (Refer to Cooling system in this group)

24. Install the timing chain. (Refer to Timing system in this group)

25. Install the intake manifold and exhaust manifold. (Refer to Intake and exhaust system in this group)

26. Install the engine assembly to the vehicle. (Refer to Engine and transmission assembly in this group)

Cooling System

EM-103

Cooling System

Coolant

Replacement And Air Bleeding

CAUTION

Never remove the radiator cap when the engine is hot. Serious scalding could be caused by hot fluid under high pressure escaping from the radiator.

NOTICE

When pouring engine coolant, be sure to shut the relay box lid and not to let coolant spill on the electrical parts or the paint. If any coolant spills, rinse it off immediately.

1. Make sure the engine and radiator are cool to the touch.
2. Remove the radiator cap.
3. Loosen the drain plug, and drain the coolant.
4. Tighten the radiator drain plug securely.
5. Remove, drain and reinstall the reservoir. Fill the tank halfway to the MAX mark with water, then up to the MAX mark with antifreeze.
6. Fill the radiator with water through the radiator cap and tighten the cap.

NOTICE

To most effectively bleed the air, pour the water slowly and press on the upper / lower radiator hoses.

7. Start the engine and allow to come to normal operating temperature. Wait for the cooling fans to turn on several times. Accelerate the engine to aid in purging trapped air. Shut engine off.
8. Wait until the engine is cool.
9. Repeat steps 1 to 8 until the drained water runs clear.

10. Fill fluid mixture with coolant and water (5 : 5) (Tropical region – 4:6) slowly through the radiator cap. Push the upper/lower hoses of the radiator so as bleed air easily.

NOTICE

- Use only genuine antifreeze/coolant.
- For best corrosion protection, the coolant concentration must be maintained year-round at 35% minimum. Coolant concentrations less than 35% may not provide sufficient protection against corrosion or freezing.
- Coolant concentrations greater than 60% will impair cooling efficiency and are not recommended.

CAUTION

- Do not mix different brands of antifreeze/coolants.
- Do not use additional rust inhibitors or antirust products; they may not be compatible with the coolant.


11. Start the engine and run coolant circulates.
12. When the cooling fan operates and coolant circulates, refill coolant through the radiator cap.
13. Repeat step.11 until the cooling fan 3 ~ 5times and bleed air sufficiently out of the cooling system.
14. Install the radiator cap and fill the reservoir tank to the "MAX" line with coolant.
15. Run the vehicle under idle until the cooling fan operates 2 ~ 3 times.
16. Stop the engine and wait coolant gets cool.
17. Repeat 10 to 15 until the coolant level doesn't fall any more, bleed air out of the cooling system.

NOTICE

As it is to bleed air out to the cooling system and refill coolant when coolant gets cool completely, recheck the coolant level in the reservoir tank for 2 ~ 3 days after replacing coolant.

Coolant capacity :

8.4 ~ 8.6L (8.9 ~ 9.1Us.qts, 7.4 ~ 7.6 Imp.qts)

EM-104**Engine Mechanical System****Radiator****Components**

SBHEM9084L

1. Fan
2. Fan motor assembly
3. Shroud
4. Coolant reservoir tank

5. Radiator lower hose
6. Radiator upper hose
7. Radiator assembly


Cooling System

EM-105

Inspection

Cap Testing

1. Remove the radiator cap, wet its seal with engine coolant, then install it to pressure tester.




ECKD501X

2. Apply a pressure of 93 ~ 123kPa (0.95 ~ 1.25kgf/cm², 14 ~ 19psi).
3. Check for a drop in pressure.
4. If the pressure drops, replace the cap.

Radiator Leakage

1. Wait until engine is cool, then carefully remove the radiator cap and fill the radiator with engine coolant, then install a pressure tester on it.



SBHEM8137D

2. Apply a pressure of 93 ~ 123kPa (0.95 ~ 1.25kgf/cm², 14 ~ 19psi).
3. Inspect for engine coolant leaks and a drop in pressure.
4. If the pressure drops, check hoses, the radiator and the water pump for leakage. If there is no leakage, inspect the heater core, the cylinder block and the cylinder head.
5. Remove the tester and reinstall the radiator cap.

NOTICE


Check for engine oil in coolant and/or coolant in engine oil.

EM-106

Engine Mechanical System


Removal

1. Disconnect the battery negative cable
2. Loosen the drain plug and drain the engine coolant.
3. Remove the air duct (A).




SBHEM8001D

4. Remove the radiator upper hose (A) and lower hose (B).




SBHEM8003D




SBHEM8004D

5. Disconnect the ATF cooler hoses (A).



SBHEM8005D

6. Disconnect the fan motor connector (A).
7. Remove the radiator & condenser mounting bolt (B).



SBHEM8138D

8. Remove the radiator & cooling fan assembly from the vehicle.

Cooling System

EM-107

Installation

1. Installation is reverse order of removal.
2. Connect the fan motor connector.
3. Install the radiator upper hose & lower hose, and connect the ATF cooler hoses.
4. Fill the radiator with coolant and check for leaks.

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




EM-108

Engine Mechanical System

Water pump

Components



SBHEM9123L

1. Water pump pulley
2. Water pump
3. Water pump gasket
4. LH coolant pipe

5. RH coolant pipe
6. Throttle body coolant hose & pipe
7. Water temperature control assembly

Cooling System

EM-109

Removal


Water Pump

1. Loosen the drain plug, and drain the engine coolant.

CAUTION


Never remove the radiator cap when the engine is hot. Serious scalding could be caused by hot fluid under high pressure escaping from the radiator.

2. Remove the drive belt (A).




SBHEM8058D

3. Remove the water pump pulley (A).



SBHEM8059D

4. Remove the water pump (A).



SBHEM8085D

EM-110

Engine Mechanical System

Water Temperature Control Assembly

⚠ CAUTION

- To avoid damage, unplug the wiring connectors carefully while holding the connector portion.


📌 NOTICE

- Mark all wiring and hoses to avoid misconnection.

1. Disconnect the battery negative cable.
2. Loosen the drain plug and drain the engine coolant.
3. Remove the engine cover (A).


📌 NOTICE

Remove the engine cover bolts as following method.



SBHEM8211D


4. Remove the engine side cover.
5. Remove the air duct (A).



SBHEM8001D


6. Remove the intake air hose and air cleaner assembly.

- 1) Disconnect the MAFS connector (A).
- 2) Disconnect the breather hose (B).
- 3) Remove the resonator (C).
- 4) Remove the intake air hose (D) and air cleaner assembly (E).



SBHEM8002D


7. Remove the radiator upper hose (A) and lower hose (B).



SBHEM8003D


Cooling System

EM-111



SBHEM8004D


8. Disconnect the heater hoses (A) and brake vacuum hose (B).



SBHEM8006D


9. Disconnect the engine wiring connectors.

- 1) Disconnect the power steering oil pressure switch connector(A) and RH knock sensor connector(B).




SBHEM8024D

- 2) Disconnect the MAP sensor connector (A), ETC connector (B), RH exhaust OCV connector (C), RH injector connector (D) and RH ignition coil connector (E).



SBHEM8025D

- 3) Disconnect the LH knock sensor connector (A), LH/RH intake OCV connector (B) and LH exhaust OCV connector (C).




SBHEM8026D

EM-112


Engine Mechanical System

- 4) Disconnect the LH injector connector (A) and LH ignition coil connector (B).




SBHEM8027D

- 5) Disconnect the oil pressure switch connector (A), LH exhaust camshaft CMP sensor connector (B) and LH oxygen sensor connector (C).




SBHEM8029D

- 6) Disconnect the LH intake camshaft CMP sensor connector (A), RH intake camshaft CMP sensor connector (B) and condenser connector (C).



SBHEM8030D

- 7) Disconnect the VIS solenoid valve connector (A), PCSV connector (B) and RH oxygen sensor connector (C).




SBHEM8031D

Cooling System


EM-113

- 8) Disconnect the water temperature sensor connector (A) and oil temperature sensor connector (B).



SBHEM8032D


- 9) Disconnect the RH exhaust camshaft CMP sensor connector (A).



SBHEM8033D

10. Remove the jump cable cover.


11. Disconnect the wiring (A) from the jump cable.



SBHEM8011D

12. Remove the fuse & relay box cover.

13. Remove the fuse & relay box mounting bolts (A) and wiring mounting bolts (B).




SBHEM8012D

EM-114


Engine Mechanical System

14. Remove the fuse & relay box (A) after disconnect from the connector (B).



SBHEM8013D


15. Remove the connector (A) and wirings.



SBHEM8014D


16. Straighten up the disconnected wirings.

17. Remove the oil level gauge mounting bolt (A).




SBHEM8139D

18. Remove the LH side coolant pipe and hose (A).




SBHEM8036D

19. Remove the vacuum pipe (A).



SBHEM8140D

20. Remove the throttle body coolant hose & pipe (A).




SBHEM8038D

Cooling System


EM-115

21. Remove the RH side coolant pipe (A).




SBHEM8039D

22. Remove the heater pipe & hose (A).




SBHEM8203D

23. Remove the mounting bolts (B,C) and then remove the water temperature control assembly (A).



SBHEM8041D



SBHEM8042D


EM-116

Engine Mechanical System

Installation

Water Pump

1. Install the water pump (A) with the new gasket (B).



SBHEM8141D

NOTICE

- Clean the contact face before assembly.
- Always use a new bolt (C) and gaskets (B).

Tightening torque

G(4) :

21.56 ~ 23.52N.m (2.2 ~ 2.4kgf.m, 15.91 ~ 17.36lb-ft)

H(1) :

9.80 ~ 11.76N.m (1.0 ~ 1.2kgf.m, 7.23 ~ 8.68lb-ft)

I(1) :

9.80 ~ 11.76N.m (1.0 ~ 1.2kgf.m, 7.23 ~ 8.68lb-ft)

J(1) :

9.80 ~ 11.76N.m (1.0 ~ 1.2kgf.m, 7.23 ~ 8.68lb-ft)


K(4) :

9.80 ~ 11.76N.m (1.0 ~ 1.2kgf.m, 7.23 ~ 8.68lb-ft)

L(1):

21.56 ~ 26.46N.m (2.2 ~ 2.7kgf.m, 15.91 ~ 19.53lb-ft)

- New bolt




SBHEM8142D

2. Install the water pump pulley (A).


Tightening torque :

7.8 ~ 9.8N.m (0.8 ~ 1.0kgf.m, 5.8 ~ 7.2lb-ft)



SBHEM8059D

3. Install the drive belt (A).



SBHEM8058D

4. Fill the radiator with coolant and check for leaks.

Cooling System


EM-117

Water Temperature Control Assembly

1. Install the water temperature control assembly (A) with a new gasket.

Tightening torque :


19.6 ~ 23.5Nm (2.0 ~ 2.4kgf.m, 14.5 ~ 17.4lb-ft)



SBHEM8041D


⚠ CAUTION

When tightening the bolt (C), use a ground bolt.



SBHEM8042D

2. Install the heater pipe & hose (A).




SBHEM8203D

3. Install the RH side coolant pipe (A).

Tightening torque :

19.6 ~ 23.5N.m (2.0 ~ 2.4kgf.m, 14.5 ~ 17.4lb-ft)



SBHEM8039D


EM-118

Engine Mechanical System

4. Install the throttle body coolant hose & pipe (A).


Tightening torque :

9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)



SBHEM8038D

5. Install the vacuum pipe (A).




SBHEM8140D

6. Install the LH side coolant pipe and hose (A).

Tightening torque

Bolt (B): 19.6 ~ 23.5Nm (2.0 ~ 2.4kgf.m, 14.5 ~ 17.4lb-ft)

Bolt (C): 9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)




SBHEM8143D

7. Install the oil level gauge tube (A).

Tightening torque :

18.6 ~ 22.6N.m (1.9 ~ 2.3kgf.m, 13.7 ~ 16.6lb-ft)




SBHEM8139D

Cooling System


EM-119

8. Connect the connector (A) and wirings.




SBHEM8014D

9. Connect the fuse & relay box(A) to the connector(B).



SBHEM8013D


10. Install the fuse & relay box mounting bolts (A) and wiring mounting bolts (B).



SBHEM8012D

11. Install the fuse & relay box cover.

12. Connect the wiring (A) to the jump cable.




SBHEM8011D

13. Install the jump cable cover.

14. Connect the engine wiring connectors.

- 1) Connect the RH exhaust camshaft CMP sensor connector (A).




SBHEM8033D

EM-120


Engine Mechanical System

- 2) Connect the water temperature sensor connector (A) and oil temperature sensor connector (B).




SBHEM8032D

- 3) Connect the VIS solenoid valve connector (A), PCSV connector (B) and RH oxygen sensor connector (C).




SBHEM8031D

- 4) Connect the LH intake camshaft CMP sensor connector (A), RH intake camshaft CMP sensor connector (B) and condenser connector (C).



SBHEM8030D

- 5) Connect the oil pressure switch connector (A), LH exhaust camshaft CMP sensor connector (B) and LH oxygen sensor connector (C).




SBHEM8029D

Cooling System


EM-121

- 6) Connect the LH injector connector (A) and LH ignition coil connector (B).




SBHEM8027D

- 7) Connect the LH knock sensor connector (A), LH/RH intake OCV connector (B) and LH exhaust OCV connector (C).




SBHEM8026D

- 8) Connect the MAP sensor connector (A), ETC connector (B), RH exhaust OCV connector (C), RH injector connector (D) and RH ignition coil connector (E).



SBHEM8025D

- 9) Connect the power steering oil pressure switch connector(A) and RH knock sensor connector(B).




SBHEM8024D

EM-122


Engine Mechanical System

15. Connect the heater hoses (A) and brake vacuum hose (B).




SBHEM8006D

16. Install the radiator upper hose (A) and lower hose (B).



SBHEM8003D



SBHEM8004D

17. Install the intake air hose and air cleaner assembly.

- 1) Install the intake air hose (D) and air cleaner assembly (E).

Tightening torque

Bolt (D) : 1.9 ~ 2.9 N.m (0.2 ~ 0.3 kgf.m, 1.4 ~ 2.2 lb-ft)


Bolt (E) : 7.8 ~ 9.8 N.m (0.8 ~ 1.0 kgf.m, 5.8 ~ 7.2 lb-ft)

- 2) Install the resonator (C).

Tightening torque :


Bolt (C) : 7.8 ~ 9.8 N.m (0.8 ~ 1.0 kgf.m, 5.8 ~ 7.2 lb-ft)

- 3) Connect the breather hose (B).
4) Connect the MAFS connector (A).



SBHEM8002D

18. Install the air duct (A).



SBHEM8001D

Cooling System


EM-123

19. Install the engine side cover.

20. Install the engine cover (A).

NOTICE

Install the engine cover bolts as following method.



SBHEM8211D

21. Connect the battery negative cable.

NOTICE

- Refill engine coolant.
- Refill radiator and reservoir tank with engine coolant.
- Bleed air from the cooling system.
 - Start engine and let it run until it warms up. (Until the radiator fan operates 3 or 4 times.)
 - Turn Off the engine. Check the level in the radiator, add coolant if needed. This will allow trapped air to be removed from the cooling system.
 - Put radiator cap on tightly, then run the engine again and check for leaks.
- Clean the battery posts and cable terminals with sandpaper assemble them, then apply grease to prevent corrosion.

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



EM-124

Engine Mechanical System

Troubleshooting

Symptoms		Possible Causes		Remedy
Coolant leakage	From the bleed hole of the water pump	Visually check	Check leaks after about ten-minute warming up.	If coolant still leaks, replace a water pump.
	From gaskets or bolts		Check the tightening of the water pump mounting bolts.	If leakage stops, reuse the water pump (Do not replace the pump with a new one).
	From outer surface of water pump		Check damage of gaskets or inflow of dust.	Retighten the mounting bolts.
	From outer surface of water pump		Check the material or any cracks of the water pump.	Replace the gasket and clean dust off.
Noise	- From bearings - From mechanical seals - Impeller interference	Inspection with a stethoscope	After starting the engine, check noise with a stethoscope.	If there is no noise, reuse the water pump (do not replace it).
		Inspection after removing a drive belt	After removing a water pump and a drive belt, check noise again.	If there is any noise from the water pump, remove the drive belt and recheck.
		Inspection after removing a water pump	After removing a water pump and a drive belt, check noise again.	If there is noise, reuse the water pump. Check other drive line parts.
				If there is no noise, replace the water pump with a new one.
Overheating	- Damaged impeller - Loosened impeller	Loosened impeller	Corrosion of the impeller wing	- Check engine coolant. - Poor coolant quality / Maintenance check
			Impeller separation from the shaft	Replace the water pump.

Cooling System

EM-125


Thermostat

Removal

NOTICE


Removal of the thermostat would have an adverse effect, causing a lowering of cooling efficiency. Do not remove the thermostat, even if the engine tends to overheat.

1. Drain engine coolant so its level is below thermostat.
2. Remove the water inlet fitting (A) and the thermostat (B).



Installation

1. Place the thermostat in thermostat housing.
 - 1) Install the thermostat with the jiggle valve upward.
 - 2) Install a new thermostat (B).



2. Install the water inlet fitting (A).

Tightening torque :

16.7 ~ 19.6N.m (1.7 ~ 2.0kgf.m, 12.3 ~ 14.5lb-ft)

3. Fill with engine coolant.
4. Start engine and check for leaks.

EM-126

Engine Mechanical System

Troubleshooting

Symptoms		Possible Causes		Remedy
Coolant leakage	From the thermostat gasket	Check the mounting bolts	Check the torque of the mounting bolts	Retighten the bolts and check leakage again.
		Check the gasket for damage	Check gasket or seal for damage	Replace gaskets and reuse the thermostat.
Cooled excessively	- Low heater performance (cool air blown-out) - Thermogauge indicates 'LOW'	Visually check after removing the radiator cap.	Insufficient coolant or leakage.	After refilling coolant, recheck.
		GDS check & Starting engine	- Check DTCs - Check connection of the fan clutch or the fan motor. ※ If the fan clutch is always connected, there will be a noise at idle.	- Check the engine coolant sensor, wiring and connectors. - Replace the components.
		Remove the thermostat and inspect	- Check if there are dusts or chips in the thermostat valve. - Check adherence of the thermostat.	- Clean the thermostat valve and reuse the thermostat. - Replace the thermostat, if it doesn't work properly.
Heated excessively	- Engine overheated - Thermogauge indicates 'HI'	Visually check after removing the radiator cap.	- Insufficient coolant or leakage. ※ Be careful when removing a radiator cap of the overheated vehicle. - Check air in cooling system.	- After refilling coolant, recheck. - Check the cylinder head gaskets for damage and the tightening torque of the mounting bolts.
		GDS check & Starting engine	- Check DTCs - Check the fan motor performance as temperature varies. - Check if the fan clutch slips. - Check the water pump adherence or impeller damaged.	- Check the engine coolant sensor, wiring and connectors. - Check the fan motor, the relay and the connector. - Replace the fan clutch, if it doesn't work properly. - Replace the water pump, if it doesn't work properly.
		Immerse the thermostat in boiling water and inspection.	- After removing the thermostat, check it works properly. ※ Check the thermostat opens at the valve opening temperature.	Replace the thermostat, if it doesn't work properly.


Lubrication System

EM-127

Lubrication System

Oil Pump

Components



SBHEM9087L

- | | | |
|-----------------------|-------------|--------------------------|
| 1. Oil filter cap | 5. O-ring | 9. Oil pump sprocket |
| 2. O-ring | 6. Gasket | 10. Oil pump chain cover |
| 3. Oil filter element | 7. Oil pump | 11. Lower oil pan |
| 4. Oil filter body | 8. Gasket | |

EM-128


Engine Mechanical System

Removal

Oil Pump

1. Drain the engine oil.
2. Remove the lower oil pan (A).


Insert the blade of SST(09215-3C000) between the upper oil pan and lower oil pan. Cut off applied sealer and remove the lower oil pan.



NOTICE


- Insert the SST between the oil pan and the ladder frame by tapping it with a plastic hammer in the direction of arrow.
- After tapping the SST with a plastic hammer along the direction of arrow around more than 2/3 edge of the oil pan, remove it from the ladder frame.
- Do not turn over the SST abruptly without tapping. It be result in damage of the SST.
- Be careful not to damage the contact surfaces of Upper oil pan and lower oil pan.

3. Remove the oil pump chain cover (A).




SBHEM8209D

4. Remove the oil pump chain sprocket (A).



KDRF189A

5. Remove the oil pump (A).




KDRF190A

Lubrication System

EM-129


Oil Filter Assembly

1. Remove the water temperature control assembly. (Refer to Cooling system in this group)
2. Remove the intake manifold. (Refer to Intake and exhaust system in this group)
3. Wait for 5 minutes after loosening the oil filter cap to drain well the oil in the oil filter.



SBHEM8119D

4. Remove the oil filter body.



SBHEM8121D


Installation

Oil Pump

1. Install the oil pump (A).

Tightening torque :

20.6 ~ 22.6N.m (2.1 ~ 2.3kgf.m, 15.2 ~ 16.6lb-ft)



KDRF222A


NOTICE

Always use a new O-ring (B).

2. Install the oil pump sprocket (A) and the oil pump chain on the oil pump.

Tightening torque :

18.6 ~ 21.6N.m (1.9 ~ 2.2kgf.m, 13.7 ~ 15.9lb-ft)



KDRF189A


EM-130

Engine Mechanical System

3. Install the oil pump chain cover (A).

Tightening torque :

9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)




SBHEM8209D

4. Install the lower oil pan (A).

- 1) Using a gasket scraper, remove all the old packing material from the gasket surfaces.
- 2) Before assembling the oil pan, the liquid sealant TB 1217H should be applied on oil pan. The part must be assembled within 5 minutes after the sealant was applied.

Bead width : 2.5mm(0.1in.)



SBLM16020L

⚠ CAUTION


- Clean the sealing face before assembling two parts.
- Remove harmful foreign matters on the sealing face before applying sealant.
- When applying sealant gasket, sealant must not be protruded into the inside of oil pan.
- To prevent leakage of oil, apply sealant gasket to the inner threads of the bolt holes.

3) Install the oil pan (A).

Uniformly tighten the bolts in several passes.

Tightening torque :

9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)



SBLM16102L

5. After assembly, wait at least 30 minutes before filling the engine with oil.

Lubrication System


EM-131

Oil Filter Assembly

1. Install the oil filter body.

Tightening torque :


9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)



SBHEM8119D

⚠ CAUTION

- All rubber gaskets must not be damaged by assembling parts.
- Always use a new O-ring (C) and oil seal (B).



SBHEM8122D

2. Install the intake manifold. (Refer to Intake and exhaust system in this group)
3. Install the water temperature control assembly. (Refer to Cooling system in this group)

EM-132


Engine Mechanical System

Oil Pressure Switch

Inspection


1. Check the continuity between the terminal and the body with an ohmmeter.

If there is no continuity, replace the oil pressure switch.



ECKD001W

2. Check the continuity between the terminal and the body when the fine wire is pushed. If there is continuity even when the fine wire is pushed, replace the switch.



ECKD001Y

دیجیتال خودرو
شرکت دیجیتال خودرو سامانه (مسئولیت محدود)
اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Lubrication System

EM-133

Engine Oil

Inspection

1. Check the engine oil quality. Check the oil deterioration, entry of water, discoloring or thinning. If the quality is visibly poor, replace the oil.

2. Check the engine oil level.

After warming up the engine and then 5 minutes after the engine stop, oil level should be between the "L" and "F" marks in the dipstick.

If low, check for leakage and add oil up to the "F" mark.

NOTICE

Do not fill with engine oil above the "F" mark.

Selection Of Engine Oil

Recommended API classification :Above SJ or SL

Recommended SAE classification : 5W-20

NOTICE

For best performance and maximum protection of all types of operation, select only those lubricants which :

1. Satisfy the requirement of the API or ACEA classification.
2. Have proper SAE grade number for expected ambient temperature range.
3. Lubricants that do not have both an SAE grade number and API service classification on the container should not be used.

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



EM-134


Engine Mechanical System

Replacement

⚠ CAUTION


- Prolonged and repeated contact with mineral oil will result in the removal of natural fats from the skin, leading to dryness, irritation and dermatitis. In addition, used engine oil contains potentially harmful contaminants which may cause skin cancer.
- Exercise caution in order to minimize the length and frequency of contact of your skin to used oil. Wear protective clothing and gloves. Wash your skin thoroughly with soap and water, or use water-less hand cleaner, to remove any used engine oil. Do not use gasoline, thinners, or solvents.
- In order to preserve the environment, used oil and used oil filter must be disposed of only at designated disposal sites.

1. Park the car on level ground.
Start the engine and let it warm up.
2. Turn the engine off and open the hood.
Remove the engine cover.
3. Wait for 5 minutes after loosening the oil filter cap to drain well the oil in the oil filter.



SBHEM8119D

4. Drain engine oil.
 - 1) Remove the oil filler cap.
 - 2) After lifting the car, remove the oil drain plug and drain oil into a container.
5. Replace the oil filter.
 - 1) Disconnect the oil filter cap from the oil filter body.
 - 2) Remove the oil filter element.
 - 3) Check and clean the oil filter installation surface.
 - 4) Check the part number of a new oil filter is same as old one.
 - 5) Install a new oil filter element (A) and two new O-rings (B).



SENM17205L

- 6) Apply clean engine oil to the new O-rings.
Lightly screw the oil filter cap into place, and tighten it until the O-ring contacts the seat.
- 7) Finally tighten it again by specified tightening torque.

Tightening torque :

24.5N.m (2.5kgf.m, 18.1lb-ft)

Lubrication System

EM-135

6. Fill new engine oil.

- 1) Install the oil drain plug with a new gasket.

Tightening torque :

34.3 ~ 44.1N.m (3.5 ~ 4.5kgf.m, 25.3 ~ 32.5lb-ft)

- 2) Fill with new engine oil, after removing the engine oil level gauge.

Engine Oil quantity

Total : 6.0 L (6.34 US qt, 5.27 Imp qt)

Oil pan : 5.5 L (5.81 US qt, 4.83 Imp qt)

Drain and refill including oil filter :

5.2 L (4.49 US qt, 4.57 Imp qt)

⚠ CAUTION

- Fill a half oil of the total amount first and do the rest again after about one minute later.
- Do not fill oil over the 'F' line, checking the level with the oil level gauge.

- 3) Install the oil filler cap and oil level gauge.

7. Start the engine and check to be sure no oil is leaking from the drain plug or oil filter.

8. Recheck the engine oil level.



شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

EM-136

Engine Mechanical System


Intake And Exhaust System

Intake Manifold

Components

<NOTE>

The delivery pipe(2) may be disassembled from the intake system in removal or installation.



Torque : N.m (kgf.m, lb-ft)

SBHEM9088L

1. Surge tank
2. Delivery pipe

3. Intake manifold
4. Intake manifold gasket

Intake And Exhaust System

EM-137

Removal

⚠ CAUTION

- To avoid damage, unplug the wiring connectors carefully while holding the connector portion.


📌 NOTICE

- Mark all wiring and hoses to avoid misconnection.

1. Disconnect the battery negative cable.
2. Loosen the drain plug and drain the engine coolant.
3. Remove the engine cover (A).


📌 NOTICE

Remove the engine cover bolts as following method.



SBHEM8211D


4. Remove the engine side cover.
5. Remove the air duct (A).



SBHEM8001D


6. Remove the intake air hose and air cleaner assembly.

- 1) Disconnect the MAFS connector (A).
- 2) Disconnect the breather hose (B).
- 3) Remove the resonator (C).
- 4) Remove the intake air hose (D) and air cleaner assembly (E).



SBHEM8002D

7. Remove the fuel hose (A).




SBHEM8015D

EM-138

Engine Mechanical System


8. Disconnect the brake vacuum hose.



SBHEM8144D


9. Disconnect the engine wiring connectors.

- 1) Disconnect the power steering oil pressure switch connector(A) and RH knock sensor connector(B).




SBHEM8024D

- 2) Disconnect the MAP sensor connector (A), ETC connector (B), RH exhaust OCV connector (C), RH injector connector (D) and RH ignition coil connector (E).



SBHEM8025D

- 3) Disconnect the LH knock sensor connector (A), LH/RH intake OCV connector (B) and LH exhaust OCV connector (C).




SBHEM8026D

Intake And Exhaust System


EM-139

- 4) Disconnect the LH injector connector (A) and LH ignition coil connector (B).




SBHEM8027D

- 5) Disconnect the oil pressure switch connector (A), LH exhaust camshaft CMP sensor connector (B) and LH oxygen sensor connector (C).




SBHEM8029D

- 6) Disconnect the LH intake camshaft CMP sensor connector (A), RH intake camshaft CMP sensor connector (B) and condenser connector (C).



SBHEM8030D

- 7) Disconnect the VIS solenoid valve connector (A), PCSV connector (B) and RH oxygen sensor connector (C).




SBHEM8031D

EM-140


Engine Mechanical System

- 8) Disconnect the water temperature sensor connector (A) and oil temperature sensor connector (B).




SBHEM8032D

- 9) Disconnect the RH exhaust camshaft CMP sensor connector (A).




SBHEM8033D

10. Remove the fuel pipe (A) and vacuum pipe (B).




SBHEM8037D

11. Remove the throttle body coolant hoses (A) and PCV hose (B).




SBHEM8091D

12. Remove the surge tank stay (A).



SBHEM8145D

13. Remove the surge tank assembly (A).




SBHEM8043D

Intake And Exhaust System

EM-141

14. Disconnect the RH injector connector (A).




SBHEM8146D

15. Disconnect the water vent hose (A) and then remove the intake the manifold (B).

CAUTION

- Be sure to drain the engine coolant before removing the intake manifold.
- If any coolant drained from the cylinder head vent hole has entered the intake port. This can potentially lead to engine trouble.



SBHEM8148D

Installation

1. Install the intake the manifold (B) with a new gasket, and connect the water vent hose (A).

CAUTION

- Be sure to drain the engine coolant before removing the intake manifold.
- If any coolant drained from the cylinder head vent hole has entered the intake port. This can potentially lead to engine trouble.

Tightening torque


Step 1: 3.9 ~ 5.9N.m (0.4 ~ 0.6kgf.m, 2.9 ~ 4.3lb-ft)

Step 2:

Nut- 18.62 ~ 23.52N.m (1.9~2.4kgf.m, 13.74~17.36lb-ft)

Bolt -26.5 ~ 31.4N.m (2.7~3.2kgf.m, 19.5~23.1lb-ft)

Step 3: Repeat 2nd step twice or more.



SBHEM8148D

a - h : 1st step order


1 ~ 8 : 2nd step order

EM-142

Engine Mechanical System


NOTICE

Confirm the manifold gasket identification mark (LH, RH) and be careful of the installation direction.



SBHEM8045D

2. Connect the RH injector connector (A).




SBHEM8146D

3. Install the surge tank assembly (A).

Tightening torque :

9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)




SBHEM8043D

4. Install the surge tank stay (A).

Tightening torque :

27.5 ~ 31.4N.m (2.8 ~ 3.2kgf.m, 20.3 ~ 23.1lb-ft)




SBHEM8145D

Intake And Exhaust System

EM-143

5. Install the throttle body coolant hoses (A) and PCV hose (B).




SBHEM8091D

6. Install the fuel pipe (A) and vacuum pipe (B).

Tightening torque :


9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)



SBHEM8037D


7. Connect the engine wiring connectors.

- 1) Connect the RH exhaust camshaft CMP sensor connector (A).



SBHEM8033D

- 2) Connect the water temperature sensor connector (A) and oil temperature sensor connector (B).




SBHEM8032D

EM-144


Engine Mechanical System

- 3) Connect the VIS solenoid valve connector (A), PCSV connector (B) and RH oxygen sensor connector (C).




SBHEM8031D

- 4) Connect the LH intake camshaft CMP sensor connector (A), RH intake camshaft CMP sensor connector (B) and condenser connector (C).




SBHEM8030D

- 5) Connect the oil pressure switch connector (A), LH exhaust camshaft CMP sensor connector (B) and LH oxygen sensor connector (C).



SBHEM8029D

- 6) Connect the LH injector connector (A) and LH ignition coil connector (B).




SBHEM8027D

Intake And Exhaust System


EM-145

- 7) Connect the LH knock sensor connector (A), LH/RH intake OCV connector (B) and LH exhaust OCV connector (C).




SBHEM8026D

- 8) Connect the MAP sensor connector (A), ETC connector (B), RH exhaust OCV connector (C), RH injector connector (D) and RH ignition coil connector (E).



SBHEM8025D

- 9) Connect the power steering oil pressure switch connector(A) and RH knock sensor connector(B).




SBHEM8024D

8. Connect the brake vacuum hose (A).

9. Install the fuel hose (A).

Tightening torque :

9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)



SBHEM8015D

EM-146

Engine Mechanical System

10. Install the intake air hose and air cleaner assembly.

- 1) Install the intake air hose (D) and air cleaner assembly (E).

Tightening torque

Bolt (D) : 1.9 ~ 2.9N.m (0.2 ~ 0.3kgf.m, 1.4 ~ 2.2lb-ft)


Bolt (E) : 7.8 ~ 9.8N.m (0.8 ~ 1.0kgf.m, 5.8 ~ 7.2lb-ft)

- 2) Install the resonator (C).

Tightening torque


Bolt (C) : 7.8 ~ 9.8N.m (0.8 ~ 1.0kgf.m, 5.8 ~ 7.2lb-ft)

- 3) Connect the breather hose (B).
- 4) Connect the MAFS connector (A).



SBHEM8002D

11. Install the air duct (A).




SBHEM8001D

12. Install the engine side cover.

13. Install the engine cover (A).

NOTICE

Install the engine cover bolts as following method.



SBHEM8211D

14. Connect the battery negative cable.

NOTICE


- Refill engine coolant.
- Refill radiator and reservoir tank with engine coolant.
- Bleed air from the cooling system.
 - Start engine and let it run until it warms up. (Until the radiator fan operates 3 or 4 times.)
 - Turn Off the engine. Check the level in the radiator, add coolant if needed. This will allow trapped air to be removed from the cooling system.
 - Put radiator cap on tightly, then run the engine again and check for leaks.
- Clean the battery posts and cable terminals with sandpaper. Assemble and, then apply grease to prevent corrosion.

Intake And Exhaust System

EM-147

Exhaust Manifold

Components



SBHEM9089L

1. Gasket
2. Exhaust manifold

3. Heat protector

EM-148

Engine Mechanical System

Removal

CAUTION

- To avoid damage, unplug the wiring connectors carefully while holding the connector portion.


NOTICE

- Mark all wiring and hoses to avoid misconnection.

1. Disconnect the battery negative cable.
2. Loosen the drain plug and drain the engine coolant.
3. Remove the engine cover (A).


NOTICE

Remove the engine cover bolts as following method.



SBHEM8211D


4. Remove the engine side cover.
5. Remove the air duct (A).



SBHEM8001D


6. Remove the intake air hose and air cleaner assembly.

- 1) Disconnect the MAFS connector (A).
- 2) Disconnect the breather hose (B).
- 3) Remove the resonator (C).
- 4) Remove the intake air hose (D) and air cleaner assembly (E).



SBHEM8002D


7. Remove the radiator upper hose (A) and lower hose (B).



SBHEM8003D


Intake And Exhaust System

EM-149




SBHEM8004D

8. Disconnect the LH oxygen sensor connector (A).




SBHEM9111L

9. Disconnect the RH oxygen sensor connector (A).




SBHEM8147D

10. Remove the oil level gauge tube (A).




SBHEM8034D

11. Remove the LH side coolant pipe and hose (A).



SBHEM8036D


12. Remove the throttle body coolant hose & pipe (A).



SBHEM8038D


EM-150**Engine Mechanical System**

13. Remove the RH side coolant pipe(A).




SBHEM8039D

14. Remove the exhaust manifold stays (A).




SBHEM8204D

15. Remove the LH/RH exhaust manifold heat protector (A).




SBHEM8046D




SBHEM8047D

16. Remove the LH/RH exhaust manifold (A).



SBHEM8048D



SBHEM8049D

Intake And Exhaust System


EM-151

Installation


1. Install the LH/RH exhaust manifold (A).

Tightening torque :

39.2 ~ 44.1N.m (4.0 ~ 4.5kgf.m, 28.9 ~ 32.5lb-ft)



SBHEM8048D




SBHEM8049D


2. Install the LH/RH exhaust manifold heat protector (A).

Tightening torque :

9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)



SBHEM8046D



SBHEM8047D


EM-152

Engine Mechanical System

3. Install the exhaust manifold stays (A).

Tightening torque :

34.3 ~ 41.2N.m (3.5 ~ 4.2kgf.m, 25.3 ~ 30.4lb-ft)




SBHEM8204D

4. Install the RH side coolant pipe (A).

Tightening torque :

19.6 ~ 23.5Nm (2.0 ~ 2.4kgf.m, 14.5 ~ 17.4lb-ft)




SBHEM8039D

5. Install the throttle body coolant hose & pipe (A).

Tightening torque :

9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)




SBHEM8038D

6. Install the LH side coolant pipe and hose (A).

Tightening torque

Bolt (B): 19.6 ~ 23.5Nm (2.0 ~ 2.4kgf.m, 14.5 ~ 17.4lb-ft)

Bolt (C): 9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)



SBHEM8143D


Intake And Exhaust System

EM-153

7. Install the oil level gauge tube (A).


Tightening torque :

18.6 ~ 22.6N.m (1.9 ~ 2.3kgf.m, 13.7 ~ 16.6lb-ft)




SBHEM8034D

8. Connect the RH oxygen sensor connector (A).




SBHEM8147D

9. Connect the LH oxygen sensor connector (A).




SBHEM9111L

10. Install the radiator upper hose(A) and lower hose(B).



SBHEM8003D



SBHEM8004D

EM-154

Engine Mechanical System

11. Install the intake air hose and air cleaner assembly.

- 1) Install the intake air hose (D) and air cleaner assembly (E).

Tightening torque

Bolt (D) : 1.9 ~ 2.9N.m (0.2 ~ 0.3kgf.m, 1.4 ~ 2.2lb-ft)


Bolt (E) : 7.8 ~ 9.8N.m (0.8 ~ 1.0kgf.m, 5.8 ~ 7.2lb-ft)

- 2) Install the resonator (C).

Tightening torque


Bolt (C) : 7.8 ~ 9.8N.m (0.8 ~ 1.0kgf.m, 5.8 ~ 7.2lb-ft)

- 3) Connect the breather hose (B).
- 4) Connect the MAFS connector (A).



SBHEM8002D

12. Install the air duct (A).




SBHEM8001D

13. Install the engine side cover.

14. Install the engine cover (A).

NOTICE

Install the engine cover bolts as following method.



SBHEM8211D

15. Connect the battery negative cable.

NOTICE


- Refill engine coolant.
- Refill radiator and reservoir tank with engine coolant.
- Bleed air from the cooling system.
 - Start engine and let it run until it warms up. (Until the radiator fan operates 3 or 4 times.)
 - Turn Off the engine. Check the level in the radiator, add coolant if needed. This will allow trapped air to be removed from the cooling system.
 - Put radiator cap on tightly, then run the engine again and check for leaks.
- Clean the battery posts and cable terminals with sandpaper. Assemble and, then apply grease to prevent corrosion.

Intake And Exhaust System

EM-155

Muffler

Components



SBHEM9090L

1. Front muffler
2. Catalytic converter

3. Center muffler
4. Main muffler