

EE-2

Engine Electrical System

General Information

Specification

Starting System

Item			Specifications
Starter	Type		Reduction drive (with planetary gear)
	Rated voltage		12V, 2.0KW
	No. of pinion teeth		9
	No-load characteristics	Voltage	11.5V
		Amperage	120A, MAX
		Speed	4,000rpm, MIN
	Commutator diameter	Standard	35 mm (1.378 in)
		Limit	
	Undercut depth	Standard	0.7 mm (0.028 in)
		Limit	

Charging System

Item		Specifications
Alternator	Rated voltage	12V, 120A
	Speed	5,900 ~ 12,000 rpm
	Voltage regulator	I.C regulator built-in type
	Regulator setting voltage	14.4 ± 0.3V
	Temperature compensation	-10 ± 3mV/°C
Battery	Type	72 - 30 FL
	Cold cranking amperage at -18°C (0°F)	720A
	Reserve capacity	160min
	Specific gravity at 20°C (77°F)	1.280 ± 0.01

NOTICE

- COLD CRANKING AMPERAGE is the amperage a battery can deliver for 30 seconds and maintain a terminal voltage of 7.2V or greater at a specified temperature.
- REVERSE CAPACITY RATING is amount of time a battery can deliver 25A and maintain a minimum terminal voltage of 10.5V at 25.7°C(77°F)

• Battery type notation:

--	--

 -

--	--

--	--

--	--

① ② ③ ④

- ① : 5HR capacity
- ② : Battery length
- ③ : Battery width
- ④ : Terminal location

SGKEE8100N

General Information

EE-3

Preheating System

Item		Specifications
Glow plug	Rated voltage	DC 11V
	Current	16A \pm 1.5A after 4 seconds loading at rated voltage
Glow plug relay	Rated voltage	DC 12V
	Operating voltage range	DC 9V ~ DC 16V
	Operating temperature range	-40°C ~ 120°C
	Rated load current	DC 12V, 70A


Tightening Torque

Items	Nm	kgf.m	lb.ft
Generator terminal (B+)	5 ~ 7	0.5 ~ 0.7	3.6 ~ 5.1
Starter motor terminal (B+)	10 ~ 12	1.0 ~ 1.2	7.3 ~ 8.8
Battery terminal	4 ~ 6	0.4 ~ 0.6	2.9 ~ 4.3
Glow plug	15 ~ 20	1.5 ~ 2.0	11 ~ 15
Glow plug plate attaching nut	0.8 ~ 1.5	0.08 ~ 0.15	0.6 ~ 1.1

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



EE-4

Engine Electrical System

Troubleshooting
Charging System

Symptom	Suspect Area	Remedy
Charging warning indicator does not light with ignition switch "ON" and engine off	Fuse blown	Check fuses
	Light burned out	Replace light
	Wiring connection loose	Tighten loose connections
	Electronic voltage regulator	Replace voltage regulator
Charging warning indicator does not go out with engine running (Battery requires frequent recharging)	Drive belt loose or worn	Adjust tension or replace drive belt
	Battery cables loose, corroded or worn	Repair or replace cables
	Fuse blown	Check fuses
	Fusible link blown	Replace fusible link
	Electronic voltage regulator or generator	Test generator
	Wiring	Repair wiring
Engine hesitates/poor acceleration Overcharge	Drive belt loose or worn	Adjust tension or replace drive belt
	Wiring connection loose or open circuit	Tighten loose connection or repair wiring
	Fusible link blown	Replace fusible link
	Poor grounding	Repair
	Electronic voltage regulator or generator	Test generator, if faulty, repair or replace
	Worn battery	Replace battery
	Electronic voltage regulator	Replace voltage regulator
	Voltage sensing wire	Repair wire


General Information

EE-5

Starting System

Symptom	Suspect Area	Remedy
Engine will not crank	Battery charge low	Charge or replace battery
	Battery cables loose, corroded or worn out	Repair or replace cables
	Transaxle range switch (Vehicle with automatic transaxle only)	Adjust or replace switch
	Fusible link blown	Replace fusible link
	Starter motor faulty	Repair starter motor
	Ignition switch faulty	Inspect
Engine cranks slowly	Battery charge low	Charge or replace battery
	Battery cables loose, corroded or worn out	Repair or replace cables
	Starter motor	Repair starter motor
Starter keeps running	Starter motor	Repair starter motor
	Ignition switch	Inspect
Starter spins but engine will not crank	Short in wiring	Repair wiring
	Pinion gear teeth broken or starter motor	Repair starter motor
	Ring gear teeth broken	Replace flywheel ring gear or torque converter

Reference Service Tools

Tool (Number and name)	Illustration	Use
Micro-570 Battery checker	 LBLG001A	(Using with Thermal Printer_182-003A)

EE-6


Engine Electrical System

The Micro 570 Analyzer

The Micro 570 Analyzer provides the ability to test the charging and starting systems, including the battery, starter and alternator.

⚠ CAUTION


Because of the possibility of personal injury, always use extreme caution and appropriate eye protection when working with batteries.



EBKD001A

Keypad


The Micro 570 button on the key pad provide the following functions :



LBGE012A

Battery Test Procedure

1. Connect the tester to the battery.
 - Red clamp to battery positive (+) terminal.
 - Black clamp to battery negative (-) terminal.




EBKD001C

⚠ CAUTION

Connect clamps securely. If "CHECK CONNECTION" message is displayed on the screen, reconnect clamps securely.

2. The tester will ask if the battery is connected "IN-VEHICLE" or "OUT-OF-VEHICLE". Make your selection by pressing the arrow buttons; then press ENTER.




SXME9129D

General Information

EE-7

3. Select CCA and press the ENTER button.




SXME9130D

NOTICE

CCA : Cold cranking amps, is an SAE specification for cranking battery at -0.4°F (-18°C).

4. Set the CCA value displayed on the screen to the CCA value marked on the battery label by pressing up and down buttons and press ENTER.




EBKD001F

NOTICE

The battery ratings(CCA) displayed on the tester must be identical to the ratings marked on battery label.


5. The tester will conduct battery test.



SXME9131D

6. The tester displays battery test results including voltage and battery ratings.

Refer to the following table and take the appropriate action as recommended by the Micro 570.



SXME9132D

EE-8

Engine Electrical System

Battery Test Results


Result On Printer	Remedy
GOOD BATTERY	No action is required.
GOOD RECHARGE	Battery is in a good state. Recharge the battery and use.
CHARGE & RETEST	Battery is not charged properly. - Charge and test the battery again. (Failure to charge the battery fully may read incorrect measurement value.)
REPLACE BATTERY	Replace battery and recheck the charging system. - Improper connection between battery and vehicle cables may cause "REPLACE BATTERY", retest the battery after removing cables and connecting the tester to the battery terminal directly prior to replacing the battery.
BAD CELL-REPLACE	Charge and retest the battery. - If the Micro 570 recommends "REPLACE BATTERY", replace the battery and recheck the charging system.

⚠ WARNING

Whenever filing a claim for battery, the print out of the battery test results must be attached.


Starter Test Procedure

7. After the battery test, press ENTER immediately for the starter test.



EBKD001H


8. Start the engine.



EBKD001I

9. Cranking voltage and starter test results will be displayed on the screen.

Refer to the following table and take the appropriate action as recommended by the Micro 570.



SXME9133D

General Information

EE-9

Starter Test Results


Result On Printer	Remedy
CRANKING VOLTAGE NORMAL	System shows a normal starter draw.
CRANKING VOLTAGE LOW	Cranking voltage is lower than normal level. - Check starter.
CHARGE BATTERY	The state of battery charge is too low to test. - Charge the battery and retest.
REPLACE BATTERY	Replace battery. - If the vehicle is not started though the battery condition of "GOOD BATTERY" is displayed, check wiring for open circuit, battery cable connection, starter and repair or replace as necessary. - If the engine does crank, check fuel system.

NOTICE

When testing the vehicle with old diesel engines, the test result will not be favorable if the glow plug is not heated. Conduct the test after warming up the engine for 5 minutes.


Charging System Test Procedure

10. Press ENTER to begin charging system test.




EBKD001K

11. The tester displays the actual voltage of alternator. Press ENTER to continue.



EBKD001L


12. Turn off all electrical load and rev engine for 5 seconds with pressing the accelerator pedal. (Follow the instructions on the screen)




EBKD001M

EE-10

Engine Electrical System




SXMEE9134D




SXMEE9135D

13. The message that engine RPM is detected will be displayed on the screen. Press ENTER to continue.




SXMEE9136D

14. If the engine RPM is not detected, press ENTER after revving engine.




SXMEE9137D

15. The tester will conduct charging system test during loads off.



EBKD001O




SXMEE9138D

General Information


EE-11

16. Turn on electrical loads (air conditioner, lamps, audio and etc). Press ENTER to continue.




SXMEE9139D

17. The tester will conduct charging system test during loads on.




SXMEE9140D


18. Rev engine for 5 seconds with pressing the accelerator pedal. (Follow the instructions on the screen)



SXMEE9141D



SXMEE9142D




SXMEE9143D

EE-12


Engine Electrical System

19. The message that engine RPM is detected will be displayed on the screen. Press ENTER to continue.




SXME9144D

20. If the engine RPM is not detected, press ENTER after revving engine.



SXME9145D


21. Turn off electrical loads (air conditioner, lamps, audio and etc). Turn the engine off.




SXME9146D

22. Charging voltage and charging system test results will be displayed on the screen.


Shut off engine and disconnect the tester clamps from the battery. Refer to the following table and take the appropriate action as recommended by the Micro 570.



SXME9147D



EBKD001P



SXME9148D

General Information

EE-13

Charging System Test Results

Result On Printer	Remedy
CHARGING SYSTEM NORMAL / DIODE RIPPLE NORMAL	Charging system is normal.
NO CHARGING VOLTAGE	Alternator does not supply charging current to battery. - Check belts, connection between alternator and battery and replace belts or cable or alternator as necessary.
LOW CHARGING VOLTAGE	Alternator does not supply charging current to battery and electrical load to system fully. - Check belts and alternator and replace as necessary.
HIGH CHARGING VOLTAGE	The voltage from alternator to battery is higher than normal limit during voltage regulating. - Check connection and ground and replace regulator as necessary. - Check electrolyte level in the battery.
EXCESS RIPPLE DETECTED	One or more diodes in the alternator is not functioning properly. - Check alternator mounting and belts and replace as necessary.

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




EE-14

Engine Electrical System

Charging System


Description

The conventional internal voltage detection type alternator controls the charging voltage regardless of the battery condition and according to the external load change so that it sometimes causes battery under or over charging or causes flickering of meters and lamps due to ripples of generated voltage resulting from load fluctuation. The figure below show the internal circuits of the alternator and voltage regulator.



SMGE19001L

1. Drive belt pulley
2. Rotor
3. Starter
4. Brush
5. Vacuum pump



SNFEE6008L

On-vehicle Inspection

⚠ CAUTION

- Check that the battery cables are connected to the correct terminals.
- Disconnect the battery cables when the battery is given a quick charge.
- Do not perform tests with a high voltage insulation resistance tester.
- Never disconnect the battery while the engine is running.

Check Battery Terminals, Fusible Link And Fuses

1. Check that the battery terminals are not loose or corroded.
2. Check the fusible link and fuses for continuity.

Charging System

EE-15


Inspect Drive Belt

1. Visually check the belt for excessive wear, frayed cords etc.

If any defect has been found, replace the drive belt.

NOTICE

Cracks on the rib side of a belt are considered acceptable. If the belt has chunks missing from the ribs, it should be replaced.



LBIF019A

2. Using a belt tension gauge, measure the drive belt tension.

Visually Check Alternator Wiring And Listen For Abnormal Noises

1. Check that the wiring is in good condition.
2. Check that there is no abnormal noise from the alternator while the engine is running.

Check Discharge Warning Light Circuit

1. Warm up the engine and then turn it off.
2. Turn off all accessories.
3. Turn the ignition switch "ON". Check that the discharge warning light is it.
4. Start the engine. Check that the light goes off.

Inspect Charging System

Voltage Drop Test Of Alternator Output Wire

This test determines whether or not the wiring between the alternator "B" terminal and the battery (+) terminal is good by the voltage drop method.


Preparation

1. Turn the ignition switch to "OFF".

NOTICE

To find abnormal conditions of the connection, actions should not be taken on the two terminals and each connection during the test.

2. Connect a digital voltmeter between the alternator "B" terminal and battery (+) lead wire to the battery (+) terminal. Connect the (+) lead wire of the voltmeter to the "B" terminal and the (-) lead wire to the battery (+) terminal.



SNFEE6006L

Conditions For The Test

1. Start the engine.
2. Switch on the headlamps, blower motor and so on. And then, read the voltmeter under this condition.

Result

1. The voltmeter may indicate the standard value.

Standard value : 0.2V max.

2. If the value of the voltmeter is higher than expected (above 0.2V max.), poor wiring is suspected. In this case check the wiring from the alternator "B" terminal to the fusible link to the battery (+) terminal. Check for loose connections, color change due to an overheated harness, etc. Correct them before testing again.
3. Upon completion of the test, set the engine speed at idle. Turn off the head lamps, blower motor and the ignition switch.

EE-16

Engine Electrical System

Output Current Test

This test determines whether or not the alternator gives an output current that is equivalent to the nominal output.

Preparation

1. Prior to the test, check the following items and correct as necessary.

Check the battery installed in the vehicle to ensure that it is in good condition. The battery checking method is described in "BATTERY".

The battery that is used to test the output current should be one that has been partially discharged. With a fully charged battery, the test may not be conducted correctly due to an insufficient load.


Check the tension of the alternator drive belt.

2. Turn off the ignition switch.
3. Disconnect the battery ground cable.
4. Disconnect the alternator output wire from the alternator "B" terminal.
5. Connect a DC ammeter (0 to 150A) in series between the "B" terminal and the disconnected output wire. Be sure to connect the (-) lead wire of the ammeter to the disconnected output wire.

NOTICE

Tighten each connection securely, as a heavy current will flow. Do not rely on clips.

6. Connect a voltmeter (0 to 20V) between the "B" terminal and ground. Connect the (+) lead wire to the alternator "B" terminal and (-) lead wire to a good ground.
7. Attach an engine tachometer and connect the battery ground cable.
8. Leave the engine hood open.



LBIF023A

Test

1. Check to see that the voltmeter reads as the same value as the battery voltage. If the voltmeter reads 0V, and the open circuit in the wire between the alternator "B" terminal and battery (+) terminal, a blown fusible link or poor grounding is suspected.
2. Start the engine and turn on the headlights.
3. Set the headlights to high beam and the heater blower switch to HIGH, quickly increase the engine speed to 2,500 rpm and read the maximum output current value indicated by the ammeter.

NOTICE

After the engine starts up, the charging current quickly drops. Therefore, the above operation must be done quickly to read the maximum current value correctly.

Result

1. The ammeter reading must be higher than the limit value. If it is lower but the alternator output wire is in good condition, remove the alternator from the vehicle and test it.

Limit value (120A alternator) : 60A min.

NOTICE

- The nominal output current value is shown on the nameplate affixed to the alternator body.
- The output current value changes with the electrical load and the temperature of the alternator itself. Therefore, the nominal output current may not be obtained. If such is the case, keep the headlights on the cause discharge of the battery, or use the lights of another vehicle to increase the electrical load. The nominal output current may not be obtained if the temperature of the alternator itself or ambient temperature is too high. In such a case, reduce the temperature before testing again.

2. Upon completion of the output current test, lower the engine speed to idle and turn off the ignition switch.
3. Disconnect the battery ground cable.
4. Remove the ammeter and voltmeter and the engine tachometer.
5. Connect the alternator output wire to the alternator "B" terminal.
6. Connect the battery ground cable.

Charging System


EE-17

Regulated Voltage Test

The purpose of this test is to check that the electronic voltage regulator controls voltage correctly.

Preparation

1. Prior to the test, check the following items and correct if necessary.
Check that the battery installed on the vehicle is fully charged. For battery checking method, see "BATTERY".
Check the alternator drive belt tension.
2. Turn ignition switch to "OFF".
3. Disconnect the battery ground cable.
4. Connect a digital voltmeter between the "B" terminal of the alternator and ground. Connect the (+) lead of the voltmeter to the "B" terminal of the alternator. Connect the (-) lead to good ground or the battery (-) terminal.
5. Disconnect the alternator output wire from the alternator "B" terminal.
6. Connect a DC ammeter (0 to 150A) in series between the "B" terminal and the disconnected output wire. Connect the (-) lead wire of the ammeter to the disconnected output wire.
7. Attach the engine tachometer and connect the battery ground cable.



LBIF024A

Test

1. Turn on the ignition switch and check to see that the voltmeter indicates the following value.

Voltage : Battery voltage

If it reads 0V, there is an open circuit in the wire between the alternator "B" terminal and the battery and the battery (-), or the fusible link is blown.

2. Start the engine. Keep all lights and accessories off.
3. Run the engine at a speed of about 2,500 rpm and read the voltmeter when the alternator output current drops to 10A or less.

Result

1. If the voltmeter reading agrees with the value listed in the Regulating Voltage Table below, the voltage regulator is functioning correctly. If the reading is other than the standard value, the voltage regulator or the alternator is faulty.

Regulating Voltage Table

Voltage regulator ambient temperature °C (°F)	Regulating voltage (V)
-30 (-22)	14.1 ~ 15.2
20 (68)	14.1 ~ 14.7
120 (248)	13.3 ~ 14.7


2. Upon completion of the test, reduce the engine speed to idle, and turn off the ignition switch.
3. Disconnect the battery ground cable.
4. Remove the voltmeter and ammeter and the engine tachometer.
5. Connect the alternator output wire to the alternator "B" terminal.
6. Connect the battery ground cable.

EE-18

Engine Electrical System

Alternator

Components



SMGE19002L

1. Pulley
2. Front frame assembly
3. Rotor
4. Stator
5. Brush & Regulator assembly


6. Rear frame assembly
7. Nuts
8. Through bolts
9. Washer
10. Pump assembly

Charging System

EE-19


Replacement

1. Disconnect the battery negative terminal first, then the positive terminal.
2. Disconnect the alternator connector(A) and "B" terminal cable(B) from the alternator(C).
3. Disconnect the vacuum pump oil drain hose(D), vacuum pump oil feed hose(E) and vacuum hose(F).



SJMEM6001D

4. Remove the mounting bolt and remove the alternator.




SMGEE6005D

5. Installation is the reverse of removal.

Installation

Installation is the reverse of removal.

1. Before install the rotor to the rear bracket, fix the brush(C) by inserting the wire(A) to the rear bracket(B) hole.
2. Remove the wire(A) after assembly the rotor.




KBSD101R

EE-20

Engine Electrical System


Disassembly

1. Remove the pulley(A).




SMGEE6501D

2. After loosening the three bolts(A). Remove the vacuum pump(B).




LBIF049A

3. Remove the B terminal insulator(A) and loosen the five rear cover mounting nuts(B).



LBIF050A

4. After loosening the four through bolts(A), remove the rear cover(B).




SMGEE6504D

Charging System


EE-21

5. After removing the weld between the stator lead and diode lead(A), remove the regulator assembly(B).



LBIF052A

6. Separate the rotor(A), stator(B), and front cover(C).




LBIF053A

Inspection

Inspect Rotor

1. Check that there is continuity between the slip rings(A).




LBIF054A

2. Check that there is no continuity between the slip rings and the rotor(B) or rotor shaft(C).
3. If the rotor fails either continuity check, replace the alternator.

Inspect Stator

1. Check that there is continuity between each pair of leads(A).



LBIF055A


2. Check that there is no continuity between each lead and the coil core.
3. If the coil fails either continuity check, replace the generator.

EE-22

Engine Electrical System

Battery

Components



SMGE19003L

1. Battery assembly
2. Battery insulation pad
3. Battery mounting bracket

4. Battery tray assembly
5. Bolts

Charging System

EE-23

Description

1. The Closed Maintenance Free(CMF) battery is, as the name implies, totally maintenance free and has no removable battery cell cap.
2. The Closed Maintenance Free(CMF) battery is, water never needs to be added to the maintenance free battery.
3. The battery is completely sealed, except for small vent holes in the cover.

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




EE-24

Engine Electrical System

Inspection

Battery Diagnostic Flow



SXMEE9150L

Charging System

EE-25

Vehicle parasitic current inspection

1. Turn the all electric devices OFF, and then turn the ignition switch OFF.
2. Close all doors except the engine hood, and then lock all doors.
 - 1) Disconnect the hood switch connector.
 - 2) Close the trunk lid.
 - 3) Close the doors or remove the door switches.
3. Wait a few minutes until the vehicle's electrical systems go to sleep mode.

NOTICE

For an accurate measurement of a vehicle parasitic current, all electrical systems should go to sleep mode. (It takes at least one hour or at most one day.) However, an approximate vehicle parasitic current can be measured after 10~20 minutes.


4. Connect an ammeter in series between the battery (-) terminal and the ground cable, and then disconnect the clamp from the battery (-) terminal slowly.

CAUTION

Be careful that the lead wires of an ammeter do not come off from the battery (-) terminal and the ground cable to prevent the battery from being reset. In case the battery is reset, connect the battery cable again, and then start the engine or turn the ignition switch ON for more than 10 sec. Repeat the procedure from No. 1.

To prevent the battery from being reset during the inspection,

- a. Connect a jump cable between the battery (-) terminal and the ground cable.
- b. Disconnect the ground cable from the battery (-) terminal.
- c. Connect an ammeter between the battery (-) terminal and the ground cable.
- d. After disconnecting the jump cable, read the current value of the ammeter.



SVQEE0002L

5. Read the current value of the ammeter.

- If the parasitic current is over the limit value, search for abnormal circuit by removing a fuse one by one and checking the parasitic current.
- Check the parasitic current again, and search for suspected unit by removing a unit connected with the abnormal circuit one by one.

Limit value (after 10~20 min.) : Below 50mA

EE-26

Engine Electrical System


Cleaning

1. Make sure the ignition switch and all accessories are in the OFF position.
2. Disconnect the battery cables (negative first).
3. Remove the battery from the vehicle.

⚠CAUTION

Care should be taken in the event the battery case is cracked or leaking, to protect your skin from the electrolyte.

Heavy rubber gloves (not the household type) should be wore when removing the battery.



EBJD008B


4. Inspect the battery tray for damage caused by the loss of electrolyte. If acid damage is present, it will be necessary to clean the area with a solution of clean warm water and baking soda. Scrub the area with a stiff brush and wipe off with a cloth moistened with baking soda and water.
5. Clean the top of the battery with the same solution as described above.
6. Inspect the battery case and cover for cracks. If cracks are present, the battery must be replaced.

7. Clean the battery posts with a suitable battery post tool.
8. Clean the inside surface of the terminal clamps with a suitable battery cleaning tool. Replace damaged or frayed cables and broken terminal clamps.
9. Install the battery in the vehicle.
10. Connect the cable terminals to the battery post, making sure tops of the terminals are flush with the tops of the posts.
11. Tighten the terminal nuts securely.
12. Coat all connections with light mineral grease after tightening.

⚠CAUTION

When batteries are being charged, an explosive gas forms beneath the cover of each cell. Do not smoke near batteries being charged or which have recently been charged. Do not break live circuit at the terminals of batteries being charged.

A spark will occur when the circuit is broken. Keep open flames away from battery.



EBJD008A

Starting System

EE-27

Starting System


Description

The starting system includes the battery, starter motor, solenoid switch, ignition switch, inhibitor switch(A/T), ignition lock switch, connection wires and the battery cable.

When the ignition key is turned to the start position, current flows and energizes the starter motor's solenoid coil.

The solenoid plunger and clutch shift lever are activated, and the clutch pinion engages the ring gear.

The contacts close and the starter motor cranks. In order to prevent damage caused by excessive rotation of the starter armature when the engine starts, the clutch pinion gear overruns.



SMGE19004L

1. Clutch roller
2. Clutch sub assembly
3. Magnetic switch

Inspection

Starter Test

NOTICE

The air temperature must be between 59 and 100° F (15 and 38° C) before testing.

Recommended procedure :

- Use a starter system tester.
- Connect and operate the equipment in accordance with the manufacturer's instructions.
- Test and troubleshoot as described.

Alternate Procedure :

- Use the following equipment :
 - Ammeter, 0~400A
 - Voltmeter, 0~20V (accurate within 0.1 volt)
 - Tachometer, 0~1,200 rpm
- Hook up a voltmeter and ammeter as shown.

NOTICE

After this test, or any subsequent repair, reset the ECM/PCM to clear any codes.

Check the Starter Engagement :

1. Remove the ECM(B+) fuse from the fuse/relay box.
2. Turn the ignition switch to START (III) with the shift lever in N or P position (A/T) or with the clutch pedal depressed (M/T). The starter should crank the engine.
 - If the starter does not crank the engine, go to step 3.
 - If it cranks the engine erratically or too slowly, go to "Check for Wear and Damage" on the next page.
3. Check the battery, battery positive cable, ground, starter cut relay, and the wire connections for looseness and corrosion. Test again.

If the starter still does not crank the engine, go to step 4.
4. Unplug the connector from the starter.
5. Connect a jumper wire from the battery positive (+) terminal to the solenoid terminal.

The starter should crank the engine.

 - If the starter still does not crank the engine, remove it, and diagnose its internal problem.
 - If the starter cranks the engine, go to step 6.


EE-28

Engine Electrical System

6. Check the ignition switch.
7. Check the starter relay.
8. Check the A/T gear position switch (A/T) or the clutch interlock switch (M/T).
9. Check for an open in the wire between the ignition switch and starter.

Starter Solenoid Test


1. Disconnect the wires from the Sterminal and the M terminal.
2. Connect the battery as shown. If the starter pinion pops out, it is working properly. To avoid damaging the starter, do not leave the battery connected for more than 10 seconds.



LBIF065A

3. Disconnect the battery from the M terminal.

If the pinion does not retract, the hold-in coil is working properly. To avoid damaging the starter, do not leave the battery connected for more than 10 seconds.




LBIF066A

Starting System

EE-29

4. Disconnect the battery also from the body. If the pinion retracts immediately, it is working properly. To avoid damaging the starter, do not leave the battery connected for more than 10 seconds.




LBIF067A

Free Running Test

1. Place the starter motor in a vise equipped with soft jaws and connect a fully-charged 12-volt battery to starter motor as follows :
2. Connect a test ammeter (100-ampere scale) and carbon pile rheostat as shown in the illustration.
3. Connect a voltmeter (15-volt scale) across starter motor.
4. Rotate carbon pile to the off position.
5. Connect the battery cable from battery's negative post to the starter motor body.
6. Adjust until battery voltage shown on the voltmeter reads 11 volts.
7. Confirm that the maximum amperage is within the specifications and that the starter motor turns smoothly and freely :

Current : Max. 120 Amps

Speed : Min. 4,000 rpm



LBIF068A

Cleaning


1. Do not immerse parts in cleaning solvent. Immersing the yoke assembly and/or armature will damage the insulation. Wipe these parts with a cloth only.
2. Do not immerse the drive unit in cleaning solvent. The overrun clutch is pre-lubricated at the factory and solvent will wash lubrication from the clutch.
3. The drive unit may be cleaned with a brush moistened with cleaning solvent and wiped dry with a cloth.

EE-30

Engine Electrical System

Starter

Components



SMGE19005L


- | | |
|----------------------------|--------------------|
| 1. Front bracket | 8. Magnetic switch |
| 2. Overrun clutch assembly | 9. Packing |
| 3. Idle gear | 10. Rear cover |
| 4. Driver gear | 11. Brush holder |
| 5. Idle gear bearing | 12. Packing |
| 6. Housing | 13. Yoke assembly |
| 7. Spring | |

Starting System

EE-31

Replacement

1. Disconnect the battery negative cable.
2. Disconnect the starter cable(A) from the B terminal(B) on the solenoid(C), then disconnect the connector(D) from the S terminal(E).



LBIG001B

3. Remove the 2 bolts holding the starter, then remove the starter.

Tightening torque


42.2~53.9 N.m (4.3~5.5 kgf.m, 31.1~39.8 lb-ft)

4. Installation is the reverse of removal.
5. Connect the battery positive cable and negative cable to the battery.

Inspection

Armature Inspection And Test

1. Remove the starter.
2. Disassemble the starter as shown at the beginning of this procedure.
3. Inspect the armature for wear or damage from contact with the permanent magnet. If there is wear or damage, replace the armature.




LBIF093A

4. Measure the commutator (A) runout.
 - If the commutator runout is within the service limit, check the commutator for carbon dust or brass chips between the segments.
 - If the commutator runout is not within the service limit, replace the armature.

Commutator Runout

Standard (New) : 0.02mm (0.001 in.) max.

Service limit : 0.05mm (0.002 in.)




LBIF094A

EE-32


Engine Electrical System

5. Check for continuity between the segments of the commutator. If an open circuit exists between any segments, replace the armature.



LBIF095A


6. Check with an ohmmeter that no continuity exists between the commutator (A) and armature coil core (B), and between the commutator and armature shaft (C). If continuity exists, replace the armature.



LBIF096A

Inspect Starter Brush

Brushes that are worn out, or oil-soaked, should be replaced.




LBIF097A

Starting System

EE-33

Starter Brush Holder Test

Check that there is no continuity between the (+) brush holder (A) and (-) brush holder (B). If there is no continuity, replace the brush holder assembly.



LBIF098A


Inspect Overrunning Clutch

1. Slide the overrunning clutch along the shaft.

Replace it if does not slide smoothly.

2. Rotate the overrunning clutch (A) both ways.

Does it lock in one direction and rotate smoothly in reverse? If it does not lock in either direction or it locks in both directions, replace it.



ABHE013A

3. If the starter driver gear (B) is worn or damaged, replace the overrunning clutch assembly: the gear is not available separately.


Check the condition of the flywheel or torque converter ring gear if the starter drive gear teeth are damaged.

EE-34

Engine Electrical System


Disassembly

1. Remove the nut(A) and disconnect the lead wire(B) from the magnetic switch terminal(C).



LBIF085A

2. Remove the 2 bolts(A) and pull out the yoke assembly(B) with the armature(C) from the front bracket(D).




LBIF086A

3. Using a screwdriver, hold the spring tank back and disconnect the brush(A) from the brush holder(B).

Disconnect the 2 brushes and remove the brush holder.


NOTICE

Check that the positive(+) lead wires are not grounded.



LBIF087A

4. Remove the 3 screws(A) and disconnect the housing rear cover(B) and packing(C).




LBIF088A

Starting System


EE-35

5. Remove the magnetic switch(A) and spring coil(B).




LBIF089A

6. Remove the 2 screws(A) and disconnect the clutch sub assembly(B), idle gear(C), idle gear bearing(D) and drive gear(E) from the housing(F).



LBIF090A

7. Using a magnetic finger(A), remove the steel ball(B) from the clutch shaft hole.




LBIF091A

8. Reassembly is the reverse of disassembly.

NOTICE

When installing the yoke assembly(A), use a new O-ring(B) and align the mark(C) on the housing to the mark(D) range of the brush holder.



LBIF092A


EE-36

Engine Electrical System

Starter Relay

Inspection

1. Remove the fuse box cover.
2. Remove the starter relay(A).





AVIE004A

3. Inspect the relay continuity.

- Using an ohmmeter, check that there is continuity between terminals 85 and 86.
If there is no continuity, replace the relay.
- Check that there is no continuity between terminals 30 and 87.
If there is continuity, replace the relay.

4. Inspect the relay operation.

- Apply battery positive voltage across terminals 85 and 86.
- Using an ohmmeter, check that there is continuity between terminals 30 and 87.
If there is no continuity, replace the relay.



LDAD510B


5. Install the starter relay.
6. Install the fuse box cover.

Preheating System

EE-37

Preheating System

Component Location



SMGE19006L

1. Glow relay
2. Glow plug connector
3. Glow plug

4. Plate
5. Washer nuts

EE-38

Engine Electrical System

Inspect Preheating System

Conditions before inspection :


Battery voltage : 12V

1. Connect voltmeter between glow plug plate and plug body (ground).
2. Check indicated value on voltmeter with ignition switch ON.
3. Check that preheat indication lamp lights for about 6 seconds and indicates battery voltage (about 9V or over) for about 36 seconds immediately after ignition switch is turned on. [At cooling water temperature 20°C (68°F)]

NOTICE

Continuity time varies depending upon cooling water temperature.

4. After checking 3, set ignition switch at START position.
5. The system is normal if battery voltage (about 9V or over) is generated for about 6 seconds during engine cranking and after start operation. [at cooling water temperature 20°C (68°F)]
6. When the voltage or continuity time is not normal, check the terminal voltage in glow control unit, and single parts.



LBIF117A

Inspect Glow Plus

1. Check the continuity between the terminal and body as illustrated. Replace if discontinuity or with large resistance.


Standard value : 0.25Ω



CAUTION

Remove oil from plug before measuring as glow plug resistance is very small.

2. Check for rust on glow plug plate.
3. Check glow plug for damage.




LBIF118A

Preheating System

EE-39


Inspect Glow Plug Relay

1. Remove the glow plug relay.
2. Inspect the relay continuity.
 - Using an ohmmeter, check that there is continuity between terminals 85 and 86.
 - If there is no continuity, replace the relay.
 - Check that there is no continuity between terminals 30 and 87.
 - If there is continuity, replace the relay.



SNFEE6004L

3. Inspect the relay operation.
 - Apply battery positive voltage across terminals 85 and 86.
 - Using an ohmmeter, check that there is continuity between terminals 87 and 30.
 - If there is no continuity, replace the relay.



SNFEE6005L

4. Install the glow plug relay.