

MT-2**Manual Transaxle System****General Information****Tightening Torques**

Item	N.m	Kgf.m	lb-ft
Magnetic plug	58.9~78.5	6.0~8.0	43.4~57.9
Rail support bracket	19.6~26.5	2.0~2.7	14.5~19.5
Oil filler plug	29.4~34.3	3.0~3.5	21.7~25.3
Idler shaft bolt	24.5~29.4	2.5~3.0	18.1~21.7
Back up lamp switch	29.4~34.3	3.0~3.5	21.7~25.3
Complete	9.8~11.8	1.0~1.2	7.2~8.7

Lubricants

Item	Lubricant	Quantity
Transaxle input shaft spline	CASMOLY L9508	0.2 gr.
Transaxle case gasket	LOCTITE 587 or 5060	As required

Service Standard

Item	Specification [mm(inch)]
Differential end play	0.15T-0.20T (0.0059T~0.0079T)
Input shaft end play	0.05T-0 (0.0020T~0)
1st output shaft end play	0.05T-0.10T (0.0020T~0.0039T)
2nd output shaft end play	0.05T-0.10T (0.0020T~0.0039T)
1st gear end play	0.135T-0.435T (0.0053T~0.0171T)
2nd gear end play	0.230T-0.430T (0.0091T~0.0169T)
3rd gear end play	0.135T-0.405T (0.0053T~0.0159T)
4th gear end play	0.230T-0.430T (0.0091T~0.0169T)
5th gear end play	0.125T-0.305T (0.0049T~0.0120T)
6th gear end play	0.155-0.445 (0.0061~0.0175)
Reverse gear end play	0.135T-0.345T (0.0053T~0.0136T)

General Information

MT-3

Spacers

Part name	Thickness [mm(inch)]	Identification number
Spacer (For adjustment of input shaft rear bearing end play)	2.15 (0.0846)	15
	2.20 (0.0866)	20
	2.25 (0.0886)	25
	2.30 (0.0906)	30
	2.35 (0.0925)	35
	2.40 (0.0945)	40
	2.45 (0.0965)	45
	2.50 (0.0984)	50
	2.55 (0.1004)	55
	2.60 (0.1024)	60
	2.65 (0.1043)	65
	2.70 (0.1063)	70
	2.75 (0.1083)	75
	2.80 (0.1102)	80
	2.85 (0.1122)	85
Spacer (For adjustment of 1st output shaft rear bearing end play)	2.30 (0.0906)	30
	2.35 (0.0925)	35
	2.40 (0.0945)	40
	2.45 (0.0965)	45
	2.50 (0.0984)	50
	2.55 (0.1004)	55
	2.60 (0.1024)	60
	2.65 (0.1043)	65
	2.70 (0.1063)	70
2.75 (0.1083)	75	
2.80 (0.1102)	80	

MT-4



Manual Transaxle System

Part name	Thickness [mm(inch)]	Identification number
Spacer (For adjustment of 2nd output shaft rear bearing end play)	2.30 (0.0906)	30
	2.35 (0.0925)	35
	2.40 (0.0945)	40
	2.45 (0.0965)	45
	2.50 (0.0984)	50
	2.55 (0.1004)	55
	2.60 (0.1024)	60
	2.65 (0.1043)	65
	2.70 (0.1063)	70
	2.75 (0.1083)	75
	2.80 (0.1102)	80
Spacer (For adjustment of differential end play)	1.13(0.0445)	13
	1.16(0.0457)	16
	1.19(0.0469)	19
	1.22 (0.0480)	22
	1.25 (0.0492)	25
	1.28 (0.0504)	28
	1.31 (0.0516)	31
	1.34 (0.0528)	34
	1.37 (0.0539)	37
	1.40 (0.0551)	40
	1.43 (0.0563)	43
	1.46 (0.0575)	46
	1.49 (0.0587)	49
	1.52 (0.0598)	52
	1.55 (0.0610)	55
	1.58 (0.0622)	58
	1.61 (0.0634)	61
	1.64 (0.0646)	64
	1.67 (0.0657)	67
1.70 (0.0669)	70	

General Information

MT-5

Special Service Tools

Tools (Number and name)	Illustration	Use
09527-4A000 Removing plate	 <p style="text-align: center;">KMRE001T</p>	Removal of the 1st output shaft front taper roller bearing.
09432-3K000 Oil seal installer	 <p style="text-align: center;">KMRE001U</p>	Installation of an input shaft oil seal in a clutch housing.

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




MT-6

Manual Transaxle System

Manual Transaxle System

Manual Transaxle

Components



S226M0000L


- | | | |
|------------------------------------|-----------------------|--|
| 1. Transaxle case | 7. 5th/6th shift fork | 13. Differential assembly |
| 2. Taper roller bearing outer race | 8. Spring pin | 14. Needle bearing |
| 3. 1st/2nd shift fork | 9. Input shaft | 15. Clutch housing |
| 4. Reverse shift fork | 10. Oil guide | 16. Concentric slave cylinder assembly |
| 5. Shift rail | 11. 1st output shaft | 17. Boot |
| 6. 3rd/4th shift fork | 12. 2nd output shaft | 18. Rail support bracket |

Manual Transaxle System

MT-7


Disassembly

1. After removing the boot, disassemble the concentric slave cylinder assembly.
2. Remove the shift control cable bracket assembly(A).
3. Remove the select lever(C) and shift link assembly(D).




KMRE007J

4. Remove the back up lamp switch(A).




S226M0001L

5. Remove the control shaft complete(A).



KMRE007L

6. Disconnect the transaxle hanger.
7. Remove the oil filler plug and the idler shaft bolt.
8. Disconnect the clutch housing(B) from the transaxle case(A).




KMRE007A

MT-8

Manual Transaxle System

- Remove the spring pins from the shift rail(3rd/4th & Reverse).




KMRE007K

- Remove the shift folks(4EA) and shaft rails(2EA) and rail support bracket.
- Remove the parts in the order as shown below.
2nd output shaft → input shaft → 1st output shaft → differential assembly.
- Remove the reverse idler gear assembly.
- Remove the magnetic plug and the concentric slave cylinder.
- Remove oil guides, bearing outer races, dowel pins and spacers from the clutch housing.
- Remove oil seals and guides from the clutch housing.


Reassembly

- Assemble the reverse idler gear assembly.
- Measure the height with a height gauge(C), after fixing the taper roller bearing outer race(B) to the differential assembly(A).



KMRE006B

- After installing the taper roller bearing outer race(B) to both sides of the input shaft(A), measure the height with a gauge.




LM71002A

Manual Transaxle System


MT-9

4. After installing the taper roller bearing outer race(B) to both sides of the 1st output shaft(A), measure the height with a gauge.




KMRE006D

5. After installing the taper roller bearing outer race(B) to both sides of the 2nd output shaft(A), measure the height with a gauge.




S226M0002L

6. Assemble oil seals and guides to the clutch housing(A).



KMRE006F



KMRE006G

MT-10


Manual Transaxle System

7. Install the concentric slave cylinder assembly(A) and the boot.

Tightening torque :


11.8~14.7N.m (1.2~1.5kgf.m, 8.7~10.8lb-ft)

Give it a series of tightenings.




KMRE006H

8. Fix the oil guides(B), bearing outer races, dowel pins and spacers(C) to the clutch housing(A).



KMRE006I




KMRE006J

9. Insert a rubber bushing in the hole for the concentric slave cylinder.

10. Tighten the magnetic plug(A).

Tightening torque :

58.8~78.5N.m (6.0~8.0kgf.m, 43.4~57.9lb-ft)




KMRE006K

Manual Transaxle System

MT-11

11. Measure the end play with a thickness gauge(B) in the reverse gear(A) of the 1st output shaft.


Standard Value : 0.135~0.345mm



KMRE006L

12. Measure the end play with a thickness gauge(B) in the 1st gear(A) of the 1st output shaft.


Standard Value : 0.135~0.435mm



KMRE006M

13. Measure the end play with a thickness gauge(B) in the 2nd gear(A) of the 1st output shaft.


Standard Value : 0.230~0.430mm



KMRE006N

14. Measure the end play with a thickness gauge(B) in the 5th gear(A) of the 2nd output shaft(A).

Standard Value : 0.125~0.305mm




LM71002B

MT-12

Manual Transaxle System

15. Measure the end play with a thickness gauge(B) in the 6th gear(A) of the 2nd output shaft.


Standard Value : 0.155~0.445mm



S226M0004L

16. Measure the end play with a thickness gauge(B) in the 3rd gear(A) of the 2nd output shaft.


Standard Value : 0.135~0.405mm



LM71002C


17. Measure the end play with a thickness gauge(B) in the 4th gear(A) of the 2nd output shaft.

Standard Value : 0.230~0.430mm



LM71002D

18. Install the reverse idler gear assembly(A) with a spacer in the clutch housing(B).




KMRE006R

Manual Transaxle System


MT-13

19. Install the differential assembly(A) with a spacer in the clutch housing.




KMRE006S

20. Install the 1st output shaft(A) with a spacer in the clutch housing.




KMRE006T

21. Install the input shaft(A) with a spacer in the clutch housing.



LM71002E

22. Install the 2nd output shaft(A) with a spacer in the clutch housing.



LM71002F


MT-14

Manual Transaxle System

23. Install the shift fork(4EA)(A) and shift rails(2EA)(B) and rail support bracket.

Tightening torque :

19.6~26.5N.m (2.0~2.7kgf.m, 14.5~19.5lb-ft) (3EA)




LM71002G


24. Fix them by inserting a pin into the shift rail(A, B).

NOTICE

Strike the spring pins with slit facing front or rear side.



KMRE006X



LM71002H

25. Insert spacers, bushings and bearing outer races in the transaxle case.

NOTICE

Differential end play [mm(inch)]: 0.15T-0.20T (0.0059T~0.0079T) (Preload : 686.5N.m, 70kgf.m, 506.3lb-ft)

Input shaft end play [mm(inch)]: 0.05T-0 (0.0020T~0) (Preload : 686.5N.m, 70kgf.m, 506.3lb-ft)

1st output shaft end play [mm(inch)]: 0.05T-0.10T (0.0020T~0.0039T) (Preload : 686.5N.m, 70kgf.m, 506.3lb-ft)

2nd output shaft end play [mm(inch)]: 0.05T-0.10T (0.0020T~0.0039T) (Preload : 686.5N.m, 70kgf.m, 506.3lb-ft)

Spacer thickness[mm(inch)] = Clutch housing height[mm(inch)] + Transaxle case [mm(inch)] - Measured length [mm(inch)] + end play + tolerance value 0.05mm(0.0020inch)

When measuring the length of the output shaft, the outer races on both sides should be installed to the output shaft.

Measure the length at least 3 other points and take the average value for accuracy.

When measuring end play, take the average.

Tolerance means the applied value of shafts and differential length for the transaxle case weight.

Manual Transaxle System

MT-15

Part name	Thickness [mm(inch)]	Identification number
Spacer (For adjustment of input shaft rear bearing end play)	2.15 (0.0846)	15
	2.20 (0.0866)	20
	2.25 (0.0886)	25
	2.30 (0.0906)	30
	2.35 (0.0925)	35
	2.40 (0.0945)	40
	2.45 (0.0965)	45
	2.50 (0.0984)	50
	2.55 (0.1004)	55
	2.60 (0.1024)	60
	2.65 (0.1043)	65
	2.70 (0.1063)	70
	2.75 (0.1083)	75
	2.80 (0.1102)	80
2.85 (0.1122)	85	
Spacer (For adjustment of 1st output shaft rear bearing end play)	2.30 (0.0906)	30
	2.35 (0.0925)	35
	2.40 (0.0945)	40
	2.45 (0.0965)	45
	2.50 (0.0984)	50
	2.55 (0.1004)	55
	2.60 (0.1024)	60
	2.65 (0.1043)	65
	2.70 (0.1063)	70
	2.75 (0.1083)	75
2.80 (0.1102)	80	

MT-16

Manual Transaxle System


Part name	Thickness [mm(inch)]	Identification number
Spacer (For adjustment of 2nd output shaft rear bearing end play)	2.30 (0.0906)	30
	2.35 (0.0925)	35
	2.40 (0.0945)	40
	2.45 (0.0965)	45
	2.50 (0.0984)	50
	2.55 (0.1004)	55
	2.60 (0.1024)	60
	2.65 (0.1043)	65
	2.70 (0.1063)	70
	2.75 (0.1083)	75
	2.80 (0.1102)	80
Spacer (For adjustment of differential end play)	1.13(0.0445)	13
	1.16(0.0457)	16
	1.19(0.0469)	19
	1.22 (0.0480)	22
	1.25 (0.0492)	25
	1.28 (0.0504)	28
	1.31 (0.0516)	31
	1.34 (0.0528)	34
	1.37 (0.0539)	37
	1.40 (0.0551)	40
	1.43 (0.0563)	43
	1.46 (0.0575)	46
	1.49 (0.0587)	49
	1.52 (0.0598)	52
	1.55 (0.0610)	55
	1.58 (0.0622)	58
	1.61 (0.0634)	61
	1.64 (0.0646)	64
	1.67 (0.0657)	67
1.70 (0.0669)	70	

Manual Transaxle System

MT-17

26. Apply the liquid gasket(B) on the transaxle case(A).


Specification : LOCTITE 587 or 5060



KMRE006Z

27. Align the pin position with the hole on the reverse idler gear damper.

28. Install the transaxle case(A) with the clutch housing(B).



KMRE007A

29. Tighten the oil filler plug(A) and idler shaft bolt(B).


Tightening torque :

29.4~34.3N.m (3.0~3.5kgf.m, 21.7~25.3lb-ft)

(Oil filler plug)

24.5~29.4N.m(2.5~3.0kgf.m, 18.1~21.7 ib-ft)

(Idler shaft bolt)



KMRE007B

MT-18

Manual Transaxle System

30. Fix the transaxle hanger(A), detent pins(4EA)(B) and oil seal(C).


Tightening torque :

Transaxle case bolt(20EA)

24.5~29.4N.m (2.5~3.0kgf.m, 18.1~21.7lb-ft)(D)

NOTICE



Press the detent pins for the step to be the same level as the surface on the transmission case(4 places).



31. Applying a liquid gasket(A) on the contacting surface of the control shaft complete(B), install it.

Tightening torque :

9.8~11.8N.m (1.0~1.2kgf.m, 7.2~8.7lb-ft) (7EA)




Manual Transaxle System

MT-19

32. Tighten the back up lamp switch(A) and neutral switch(B).

Tightening torque :

29.4~34.3N.m (3.0~3.5kgf.m, 21.7~25.3lb-ft)




S226M0001L


33. Install the select lever(A) and the shift link assembly(B) aligning their position with the identification mark(yellow) which is on the control shaft complete(C).

Tightening torque :

42.2~53.9N.m (4.3~5.5kgf.m, 31.1~39.8lb-ft) (3EA)



KMRE007G




KMRE007H

34. Install the shift control cable bracket assembly(A).

Tightening torque :

14.7~19.6N.m (1.5~2.2kgf.m, 10.8~14.5lb-ft)



S226M0003L


MT-20

Manual Transaxle System

Manual Transaxle Gear System

Input Shaft

Components



S226M0010L

- | | |
|------------------------------------|------------------------------------|
| 1. Taper roller bearing outer race | 6. 3rd Input gear |
| 2. Taper roller bearing | 7. 4th Input gear |
| 3. 5th Input gear | 8. Taper roller bearing |
| 4. 6th Input gear | 9. Taper roller bearing outer race |
| 5. Input shaft | 10. Snap ring |

Manual Transaxle Gear System

MT-21

Disassembly


⚠ CAUTION

It is highly recommended not to disassemble input shaft assembly.

If you have a problem with a part in the input shaft assembly, replace it with a new input shaft assembly.


The procedures below are just for reference.

1. Heat the 5th/6th input gear(A) with a heat gun SST(B)(09432-3E000).




S226M0011L

2. Using a press(A), separate the 5th/6th input gear(B) and the front side taper roller bearing(C) at a time.



S226M0012L


3. Remove the spacer.
4. Heating the 3rd/4th gear(A) with a heat gun, separate the gear(A) and the rear side taper roller bearing(B) with a press(C).



KMRE001P

Reassembly

1. Heating the 6th input gear(A) with a heat gun SST(09432-3E000), insert the input shaft into it with a press.




LM71001B


MT-22

Manual Transaxle System

2. Heating the 5th input gear(B) with a heat gun SST(09432-3E000), insert the input shaft(C) into it with a press(D).




3. Using a press(B), do the same procedure as described above with the front side taper roller bearing(A) for its installation.



Manual Transaxle Gear System


MT-23

4. Heating the 3rd gear(B) with a heat gun, insert the input shaft(rear side) into it with a press(A).




LMIG001D

5. Heating the 4th gear(B) with a heat gun, insert the input shaft(rear side) into it with a press(A).




LM71001G

6. Using a press(B), do the same procedure as described above with the rear side taper roller bearing(A) for its installation.



LM71001H



LM71001I


MT-24

Manual Transaxle System

Output Shaft

Components

The 1st Output Shaft




S226M0020L

- | | | |
|------------------------------------|---------------------------------|---------------------------------|
| 1. Oil guide ring | 11. Reverse sleeve | 21. Snap ring |
| 2. Taper roller bearing | 12. Snap ring | 22. Needle roller bearing |
| 3. 1st output shaft | 13. Needle roller bearing | 23. 2nd outer synchronizer ring |
| 4. Needle roller bearing | 14. Snap ring | 24. 2nd synchronizer cone |
| 5. Reverse driven gear | 15. 1st output gear | 25. 2nd inner synchronizer ring |
| 6. Reverse inner synchronizer ring | 16. 1st inner synchronizer ring | 26. 2nd output gear |
| 7. Reverse synchronizer cone | 17. 1st synchronizer cone | 27. Spacer |
| 8. Reverse outer synchronizer ring | 18. 1st outer synchronizer ring | 28. Taper roller bearing |
| 9. Reverse hub | 19. 1st/2nd hub | 29. Snap ring |
| 10. Synchronizer key stopper | 20. 1st/2nd sleeve | 30. Synchronizer key assembly |

Manual Transaxle Gear System

MT-25

The 2nd Output Shaft



S226M0021L

- | | | |
|--------------------------|---------------------------------|---------------------------------|
| 1. Oil guide ring | 10. Retainer ring | 19. 4th outer synchronizer ring |
| 2. Taper roller bearing | 11. Needle roller bearing | 20. 4th synchronizer cone |
| 3. 2nd output shaft | 12. 3th output gear | 21. 4th inner synchronizer ring |
| 4. Needle roller bearing | 13. 3th inner synchronizer ring | 22. Needle roller bearing |
| 5. 5th output gear | 14. 3th synchronizer cone | 23. 4th output gear |
| 6. 5th synchronizer ring | 15. 3th outer synchronizer ring | 24. Spacer |
| 7. 5th hub | 16. 3th/4th hub | 25. Taper roller bearing |
| 8. 5th sleeve | 17. 3th/4th sleeve | 26. Snap ring |
| 9. 6th output gear | 18. Snap ring | 27. Synchronizer key assembly |
| | | 28. 6th synchronizer ring |


MT-26

Manual Transaxle System

Disassembly


The 1st Output Shaft

1. Remove the oil guide ring(B) from the front taper roller bearing(A).




KMRE005A

2. Using a press(A) and the SST(09527-4A000), remove the front side taper roller bearing(B).




KMRE005B

3. Remove the rear side snap ring(A).



KMRE003C

4. Using a press(C), remove the rear side taper roller bearing(A) and the 2nd output gear(B).




KMRE005C

5. Remove the 2nd triple cone assembly.

Manual Transaxle Gear System



MT-27

6. Remove the needle roller bearing(A).





KMRE002W

7. Remove the snap ring(A).



KMRE002V


8. Remove the 1st/2nd sleeve(A).



KMRE002T

9. Disassemble the 1st synchronizer key assembly (3EA).

10. Using a press(A), remove the 1st output gear(B), 1st synchronizer assembly and hub at a time.




KMRE005D

MT-28


Manual Transaxle System

11. Remove the snap ring(A).




KMRE002M

12. Remove the needle roller bearing(A).




KMRE002L

13. Remove the snap ring(A).



KMRE002K

14. Using a press(A), remove the reverse gear(B), synchronizer assembly and hub.




KMRE005E

Manual Transaxle Gear System

MT-29


15. Remove the needle roller bearing(A).



KMRE002C

The 2nd Output Shaft


1. Remove the oil guide ring(A) from the front side taper roller bearing(B).



KMRE004B

2. Using a press, remove the front side taper roller bearing.



3. Remove the rear side snap ring(A).



LM71004B

4. Setting a press up in the 4th output gear, remove the assemblies at a time.

5. Remove the needle roller bearing(A).




LM71004C

MT-30


Manual Transaxle System

6. Remove the 4th double cone ring assembly(A).



LM71004D

7. Remove the snap ring(A).




LM71004E


8. Setting a press up in the 3rd output gear, remove the assemblies at a time.

9. Remove the snap ring.

10. Remove the needle roller bearing(A).



11. Remove the retainer ring(A) and spacers(B).




LM71004F

S226M0022L

Manual Transaxle Gear System


MT-31

12. Remove the 6th output gear(A).




LM71004H

13. Remove the 6th synchronizer ring(A).




LMIG001C

14. Remove the 5th sleeve(A).



KMRE003K

15. After removing the 5th synchronizer keys, pull out the hub assembly(A) with a press.




KMRE005G

MT-32

Manual Transaxle System


16. Remove the needle roller bearing(A).



KMRE003F


Reassembly
The 1st Output Shaft

1. Installing the needle roller bearing(A), apply gear oil around.




KMRE002C

2. Install the reverse driven gear(A).



KMRE002D

3. Install the reverse inner synchronizer ring with the reverse synchronizer cone(A).




KMRE002E

Manual Transaxle Gear System

MT-33

4. Assemble the reverse outer synchronizer ring (A)(triple cone type).




KMRE002F

5. Install the reverse hub(A) with a press(B).

NOTICE


Align the groove(C) of the reverse hub with the protrusion(C) of the output synchronizer ring.



KMRE002G


NOTICE

The hub surface which has the three grooves(A) in triangle should face the 1st gear side.



KMRE002H

6. Insert the three 1st/2nd synchronizer key assemblies(A).




KMRE002I

MT-34

Manual Transaxle System

7. Insert the synchronizer key stopper(A).




LMIG001B

8. Install the reverse sleeve(A) by tapping softly with a rubber hammer.

9. Insert the three key assemblies in the reverse sleeve by pushing the balls.


NOTICE

- Aligning the groove & protrusion(B), install the reverse sleeve(A).




KMRE002J

- The sleeve surface which has the groove(A) should face the 1st gear side.



KMRE002U

10. Selecting the snap ring(A) which makes the gap be 0~0.03mm(0.0012inch), install it.




KMRE002K

Manual Transaxle Gear System


MT-35

11. Installing the needle roller bearing(A), apply gear oil around.




KMRE002L

12. Install the snap ring(A) (thickness: 2.5mm or 0.0984inch).




KMRE002M

13. Install the 1st gear assembly(A).



KMRE002N

14. Install the 1st inner synchronizer ring with the 1st synchronizer cone(A).




KMRE002O

MT-36

Manual Transaxle System

15. Assemble the 1st outer synchronizer ring(A)(triple cone type).




KMRE002P

16. Using a press, install the 1st/2nd hub(A).

NOTICE


Align the groove(C) of the hub with the protrusion(C) of the output synchronizer ring.



KMRE002Q


NOTICE

The hub surface which has the four grooves(B) in parallel should face the 2nd gear side.



KMRE002R

17. Insert the three 1st/2nd synchronizer key assemblies(A).



KMRE002S

Manual Transaxle Gear System



MT-37

18. Install the 1st/2nd sleeve(A) by tapping softly with a rubber hammer.

Insert the three key assemblies in the 1st/2nd sleeve by pushing them.

NOTICE


Align the groove & protrusion(B), install the 1st/2nd sleeve(A).



KMRE002T



NOTICE

The sleeve surface which has the groove(A) should face the 1st gear side.





KMRE002U

19. Selecting the snap ring(A) which makes the gap be 0~0.03mm(0.0012inch), install it.



KMRE002V

20. Installing the needle roller bearing(A), apply gear oil around.




KMRE002W


MT-38

Manual Transaxle System


21. Install the 2nd outer synchronizer ring(A).




22. Install the 2nd synchronizer cone with the 2nd inner synchronizer ring(A)(triple cone type).



23. Assemble the 2nd output gear(A).




24. Assemble the spacer(A).



Manual Transaxle Gear System

MT-39

25. Using a press, assemble the rear side taper roller bearing(A).





KMRE003B

26. Assemble the snap ring(A).


NOTICE

Selecting the snap ring which makes the gap be 0~0.03mm(0.0012inch), install it.




KMRE003C

27. Using a press, assemble the front side taper roller bearing(A).



KMRE003D

28. Using a press, insert the oil guide ring(A) into the front side taper roller bearing(B).




KMRE003E

MT-40

Manual Transaxle System


The 2nd Output Shaft

1. Assemble the needle roller bearing(A).




KMRE003F

2. Assemble the 5th output gear(A).



KMRE003G

3. Assemble the 5th synchronizer ring(A).




KMRE003H

4. Using a press, assemble the 5th hub(A).

NOTICE

The hub surface which has the four grooves(B) in parallel should face the 6th gear side.




EMRE003I

Manual Transaxle Gear System



MT-41

5. Insert the three 5th/6th synchronizer key assemblies(A).




KMRE003J

6. Taking care of the grooves(B), assemble the 5th/6th sleeve(A).




KMRE003K

7. Selecting the snap ring(A) with makes the gap be 0~0.03mm(0.0012inch), install it.



8. Assemble the 6th synchronizer ring(A).




LM71005B

LMIG001C

MT-42


Manual Transaxle System

9. Install the 6th gear(A).




LM71005A

10. Install the spacer and retainer.



S226M0023L



11. Assemble the needle roller bearing(A).



S226M0024L

12. Install the snap ring(thickness: 2.5mm or 0.0984inch).

13. Assemble the 3rd output gear assembly(A).




S226M0025L

Manual Transaxle Gear System

MT-43

14. Assemble the 3rd inner synchronizer ring(A), synchronizer cone(B) and outer synchronizer ring(C). Apply gear oil around.




LM71005E

15. Using a press, install the 3rd/4th hub(A).


NOTICE

- The hub surface which has the four grooves in parallel should face the 4th gear side.
- Assemble the hub, aligning the groove & protrusion(C).



LM71005F

16. Insert the three 3rd/4th synchronizer key assemblies(A).




LM71005G

MT-44

Manual Transaxle System


17. The sleeve surface which has the groove should face the 3rd gear side(A).
Align the grooves(B) in the sleeve with the ones of the hub.

Align the grooves(B) in the sleeve with the ones of the hub.




LM71005H

شرکت دیجیتال خودرو (مسئولیت محدود)




KMRE004C

18. Selecting the snap ring(A) which makes the gap be 0~0.03mm(0.0012inch), install it.



LM71005I

19. Assemble the 4th double cone ring assembly(A).




LM71005J


Manual Transaxle Gear System

MT-45


20. Insert the needle roller bearing(A).



22. Using a press, assemble the spacer(A).




21. Insert the 4th output gear assembly(A).



LM71005K

23. Using a press, install the taper roller bearing(A).



LM71005M


LM71005L

LM71005N


MT-46

Manual Transaxle System


24. Selecting the snap ring(A) which makes the gap be 0~0.03mm(0.0012inch), install it.



26. Using a press, insert the oil guide ring(A) into the front side taper roller bearing(B).



25. Using a press, install the front side taper roller bearing(A).



KMRE004A




Manual Transaxle Gear System

MT-47

Reverse Idler Gear Assembly

Components



S226M0030L

- | | |
|---------------------------|--------------------------------|
| 1. Oil guide | 5. Reverse idler gear assembly |
| 2. Needle roller bearing | 6. Needle roller bearing |
| 3. Reverse idler spacer A | 7. Bearing retainer |
| 4. Reverse idler spacer B | |

Reassembly

1. Insert the reverse idler spacers in the reverse idler gear assembly.
2. Insert the needle roller bearing into the bearing retainer by tapping.
3. Install the rest of the parts manually.


MT-48

Manual Transaxle System

Manual Transaxle Control System

Shift Fork

Components



S226M0040L

- 1. 1st/2nd shift fork
- 2. 3rd/4th shift fork
- 3. 5th/6th shift fork 4. Reverse shift fork

- 5. Shift rail
- 6. Spring pin
- 7. Rail support bracket