

Clutch System

GENERAL

CLUTCH SYSTEM

CLUTCH COVER AND DISC

CLUTCH PEDAL

CLUTCH MASTER CYLINDER

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



GENERAL**SPECIFICATION** EC11DECE

Item	SPECIFICATION
Clutch operation	Hydraulic type
Clutch disc	Single dry with diaphragm
Clutch cover assembly	Self Adjusting Clutch


TIGHTENING TORQUE

Item	Nm	kgf.m	lb-ft
Clutch cover (6EA)	25~36	2.5~3.6	18.2~26.2
Clutch pedal bracket mounting	17~26	1.7~2.6	12.3~18.9
Oil chamber bolt	8~12	0.8~1.2	5.8~8.6
Connecting rod adjusting bolt	9~14	0.9~1.4	6.5~10.1
Clutch master cylinder mounting	17~26	1.7~2.6	12.3~18.8
Clutch switch nut	8~10	0.8~1.0	5.8~7.27
Clutch pedal bolt/nut	25~34	2.5~3.4	18.1~24.7
Ignition lock switch nut	8~10	0.8~1.0	5.8~7.27
C.S.C. assembly mounting nut	12~15	1.2~1.5	8.7~10.8

SERVICE STANDARD

Item	Standard value [mm(in)]
Clutch pedal stroke	150~155 (5.90~6.10)
Clutch pedal free play	6~13 (0.24~0.51)

SPECIAL TOOLS EE92F61C

Tool (Number and Name)	Illustration	Use
09411-43000 Clutch disc guide	 LOKG002A	Installation of the clutch disc

CLUTCH SYSTEM


CH -3

CLUTCH SYSTEM

DESCRIPTION EB27D04B

SELF ADJUSTING CLUTCH(S.A.C.) COVER

- As a clutch disc facing is worn away according to its durability, a cover weight is increasing and a clutch pedal pressure can be more needed.



LOKG001A


CONCENTRIC SLAVE CYLINDER-C.S.C.

It improves working efficiency and lowers the number and the weight of part by unifying clutch release control parts(clutch release bearing ~ clutch release cylinder) in a manual transaxle.

OPERATION ECCA75CF

CONCENTRIC SLAVE CYLINDER-C.S.C

When the clutch pedal is pressed, oil pressure is transmitted along the arrow directions shown below and that moves the clutch slave cylinder and the diaphragm spring of the clutch cover.




KORE001B

CLUTCH COVER AND DISC

COMPONENTS

E501F1C7



1. Engine flywheel
2. Clutch disc

3. Clutch cover

LOKG001B


CLUTCH SYSTEM

CH -5

REPLACEMENT

E879B1FB

1. Remove a transaxle assembly (refer to 'MT'-group).
2. Remove the clutch cover bolts. Not to be bent or twisted, loosen them in diagonal directions.



LOKG001D

3. Remove the clutch cover and disc.
4. Using the SST(09411-43000), install a clutch disc and cover.

CAUTION

- Replace a clutch cover and disc as a set.

* Possible problems when not following the caution

- When replacing only a disc, slip problem can occur because of the initial clamp load loss by the adjusting ring's unusual work.
- When replacing only a disc, it can be difficult to cut power because the thickness of the disc cannot be permitted.


- Apply grease on a disc spline part and transmission input shaft spline part as required.

* Possible problems when not following

- When not applying: Excessively wear of splines and bad clutch operation
- When excessively applying: Scattered grease by centrifugal force contaminates the clutch disc. Loss of friction force can cause a slip

- The 'T/M SIDE' marked surface should face the transaxle.
→ If the surface face the opposite side, there can be an interference between a disc and a flywheel surface.

اولن سامانه هنر جیتال خودرو سامانه (مسئولیت خودرو)



"T/M SIDE"
Mark

LOKG001E


5. Tighten the clutch cover.

TORQUE:

24.5~35.3Nm (2.5~3.6kgf.m, 18.1~26.0lb-ft) (6EA)

CAUTION

When installing the clutch cover, tighten the bolts in diagonal directions not to be bent or twisted.



LOKG001F


CAUTION

- * **Possible problems when not following**
- **When tightening the bolt completely at a time: the clutch cover can be twisted and vibration can occur.**
- **On vehicles with self adjusting clutches, it is necessary to follow this caution.**
- **Not following tightening torque: There can be bad torque transmission in clutch and relaxation possibility of bolts.**

INSPECTION

EA41A5EB


1. Inspect diaphragm spring wear which is in contact with a concentric slave cylinder bearing.



KORE002I

2. Check the clutch cover and disc surface for wear or crack.
3. Check the clutch disc lining for slipping or oil mark.
4. Measure the depth from a clutch lining surface to a rivet. If the measured value is less than the specification below, replace it.

Specification: 0.3mm(0.0118in)



EORE002J


CLUTCH SYSTEM

CH -7

CLUTCH PEDAL

COMPONENTS

EBB8432D




- 1. Pedal pad
- 2. Clutch arm assembly
- 3. Self locking pin
- 4. Stopper
- 5. Bush
- 6. Turn over spring
- 7. Ignition lock switch
- 8. Ignition lock switch
- 9. Clutch member assembly
- 10. Cowl bracket assembly
- 11. Clutch master cylinder assembly

SCMCH6002L


REMOVAL E9CFD3B5**NOTE**

Do not spill brake fluid on the vehicle; it may damage the paint if brake fluid does contact the paint, wash it off immediately with water.


1. Remove the brake fluid from the clutch master cylinder reservoir with a syringe.
2. Clamp the clutch master cylinder hose(A). If there is no enough room for clamping, you can also clamp the hose from the brake master cylinder side.

[LHD]


SCMCH6001D

[RHD]**[LHD]**

SCMCH6002D

[RHD]

SCMCH6010L




SCMCH6008L


CLUTCH SYSTEM

CH -9

- Remove the ignition lock switch.
- Remove the clutch pedal assembly mounting nuts (A-3ea) and bolt (B-2ea).



SCMCH6007D



SCMCH6004D

- Remove the clutch pedal and the master cylinder assembly together.

INSTALLATION EA045E12

NOTE

- The clutch pedal and the clutch master cylinder are supplied as an assembly.
- Inspect the continuity of the ignition lock switch.
- Remove the floor mat before adjusting the clutch pedal.

- Installation is in reverse order of removal.
- Install a new one by tightening the bolts of the clutch pedal bracket.

TORQUE :

19~26 Nm(1.9~2.6 kgf.m, 13.8~18.9 lb-ft)

- Bleed the air in C.S.C.(Concentric Slave Cylinder) system refering to ADJUSTMENT PROCEDURE.
- Adjust the clutch pedal and the ignition lock switch.

INSPECTION E5F8EBFA

IGNITION LOCK SWITCH

- Disconnect 2P-connector from a ignition lock switch.
- Disconnect the ignition lock switch. (if you can install a tester with the switch fixed, this step can be omissible)
- Check for continuity between terminals. (refer to the table below)

Clutch pedal position	Ignition lock switch	Continuity
Released	Released	NO
Pressed	Pressed	YES

If there is difference between what tested and the table above, replace the ignition lock switch with a new one.

If not, install the ignition lock switch and adjust the clutch pedal.

TORQUE :

8~10Nm (0.8~1.0kgf.m, 5.8~7.2lb-ft)

ADJUSTMENT PROCEDURE E412CCDF

CONCENTRIC SLAVE CYLINDER AIR BLEEDING PROCEDURE

1. After disconnecting a cap from the concentric slave cylinder air bleeder, insert a vinyl hose in the plug.
2. Loosening the plug screw, press and release the clutch pedal about 10 times.

NOTE

Hold the air bleeder body not to rotate with a spanner(A). The holding is needed when the plug loosened or tightened.

3. Tighten the plug during the clutch pedal pressed. Afterwards, raise the pedal with a hand.

TORQUE :

25~29Nm (2.5~2.9Kgf.m, 18.2~21.1lb-ft)

4. After pressing the clutch pedal 3 times more, loosen the plug and retighten it with the pedal pressed. Raise it again, then.
5. Repeat the step 4 two or three times. (until there is no bubble in the fluid)

CAUTION

1. *Do not clamp the pipe of a concentric slave cylinder.*
2. *Be careful not to damage O-rings.*

CLUTCH PEDAL AND IGNITION LOCK SWITCH

NOTE

- *Inspect a ignition lock switch.*
- *Remove the driver's seat mat to adjust a clutch pedal.*
- *No gap between a clutch master cylinder piston and push rod can cause clutch slip.*


1. Loosen and draw out the bolt until it is off the pedal surface.
2. Push and pull a clutch master cylinder push rod to satisfy the specification below.

Specification [mm(in)]

Clutch pedal stroke(A) - 150~155(5.90~6.10)

Clutch pedal free play(B) - 6~13(0.24~0.51)

Clutch pedal distance(C) - 234.7(9.24)



SCMCH6005D

3. With no pressure on a clutch pedal, tighten the bolt until it contacts on the pedal.
4. Fix the bolt with a nut.

TORQUE :

14~20Nm (1.4~2.0kgf.m, 10.2~14.5lb-ft)

5. Press the clutch pedal to the seat ground.
6. Adjust the ignition lock switch position with the pedal a little(23~26mm) raised.
7. Install the ignition lock switch firmly.

TORQUE:

8~10Nm (0.8~1.0kgf.m, 5.8~7.2lb-ft)

دیجیتال خودرو


شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



CLUTCH MASTER CYLINDER

COMPONENTS EA99ED83



1. Rod assembly
2. Boot
3. Key
4. Plate
5. Piston assembly
6. Spring

7. Body assembly
8. Clip
9. Rubber
10. Nipple
11. Flexible hose