General Information

Specifications

uel Delivery System					
Items			Specification		
Fuel Tank	Capacity	70 lit. (18.5 U.S.gal., 74.0 U.S.qt., 61.6 Imp.qt.)			
Fuel Filter	Туре		Paper type		
Fuel Pressure Regulator	Regulated Fuel Pressure		343 kPa	a (3.50 kgf/㎝, 49.7	′ psi)
	Туре		Ele	ctrical, in-tank type	;
Fuel Pump	Driven by			Electric motor	
Sensors Nanifold Absolute Pressure S > Type: Piezo-resistive pres	· · · ·		Engine Coolant Ter ▷ Type: Thermisto ▷ Specification		ECTS)
> Specification			Temperature [ீC(°F)] Re	esistance (^{kΩ})
Pressure (kPa)	Output Voltage (V)		-40(-40)		48.14
20.0	0.79		-20(-4)	14	4.13 ~ 16.83
46.7	1.84		0(32)		5.79
101.3	4.0		20(68)		2.31 ~ 2.59
		•	40(104)		1.15
ntake Air Temperature Sens	or (IATS)	جين	60(140) کے در		0.59
> Type: Thermistor type			80(176)		0.32
> Specification	دىجېتال تغمىركارار	مانه	ا ولين سار		
Temperature [°C(°F)]	Resistance (^k ^Ω)		Throttle Position	Sensor (TPS) [in	tegrated into E
-40(-40)	40.93 ~ 48.35		Module]		
-20(-4)	13.89 ~ 16.03		▷ Type: Variable resistor type		
0(32)	5.38 ~ 6.09		Specification		
10(50)	3.48 ~ 3.90		Throttle Angle(°)		e (V) [Vref = 5.0]
20(68)	2.31 ~ 2.57			TPS1	TPS2
40(104)	1.08 ~ 1.21		0	0	5.0
50(122)	0.76 ~ 0.85		10	0.48	4.52
60(140)	0.54 ~ 0.62		20	0.95	4.05
80(176)	0.29 ~ 0.34		30	1.43	3.57
			40	1.90	3.10
			50	2.38	2.62
			60	2.86	2.14
			70	3.33	1.67
			80	3.81	1.19
			L		1

90

4.29

0.71

021 62 99 92 92

Fuel System

FL-4

Throttle Angle(°)		Out	Output Voltage (V) [Vref = 5.0V]			
		TPS1		TPS2		
100		4.76		0.24		
105		5.0		0		
		C.T	W.O.T			
	PS1 Throttle Angle (°) Output Voltage [Vref=5V]		6.3 ~ 14.7	93.45 ~ 101.85		
TPS1			0.3 ~ 0.7	4.45 ~ 4.85		
	Throttle Ar	ngle (°)	90.3 ~ 98.7	3.15 ~ 11.55		
TPS2	Output Voltage [Vref=5V]		4.3 ~4.7	0.15 ~ 0.55		

Item	Resistance ($^{k\Omega}$)
TPS	0.875 ~ 1.625 [20 ℃(68°F)]

Crankshaft Position Sensor (CKPS)

▷ Type: Hall effect type

Camshaft Position Sensor (CMPS)

- ▷ Type: Hall effect type
- یتال تعمیرکاران خود (KS)
- Type: Piezo-electricity type
- ▷ Specification

ltem	Specification
Capacitance (pF)	850 ~ 1,150

Heated Oxygen Sensor (HO2S) [Bank 1/Sensor 1]: Euro 5 only

- ▷ Type: Zirconia (ZrO2) [Linear] type
- \triangleright Specification

Item	Specification
Heater Resistance (Ω)	2.5 ~ 4.0 [20°℃(69.8°F)]

Heated Oxygen Sensor (HO2S) [Bank 1/Sensor 1]: Except Euro 5

- D Type: Zirconia (ZrO2) [Binary] Type
- \triangleright Specification

A/F Ratio (λ)	Output Voltage(V)
RICH	Approx. 0.9
LEAN	Approx. 0.04
Item	Specification
Heater Resistance (Ω)	3.3 ~ 4.1 [21℃(69.8°F)]

Heated Oxygen Sensor (HO2S) [Bank 1/Sensor 2] ▷ Type: Zirconia (ZrO2) [Binary] Type

Specification

A/F Ratio (λ)	Output Voltage(V)	
RICH	Approx. 0.9	
LEAN	Approx. 0.04	
Item	Specification	
Heater Resistance (Ω)	3.3 ~ 4.1 [21°C(69.8°F)]	

Accelerator Position Sensor (APS)

 \triangleright Type: Variable resistor type

Specification

Accelerator	Output Voltage (V)		
Position	APS1	APS2	
C.T	0.7 ~ 0.8	0.29 ~ 0.46	
W.O.T	$3.85 \simeq 4.35$	1.93 ~ 2.18	

021 62 99 92 92

FL-5

General Information

Actuators

Injector

 \triangleright Specification

ltem	Specification
Coil Resistance (Ω)	13.8~15.2 [20 [°] C(68 [°] F)]

ETC Motor [integrated into ETC Module]

 \triangleright Specification

ltem	Specification
Coil Resistance (Ω)	1.2 ~ 1.8 [20°℃(68°F)]

Purge Control Solenoid Valve (PCSV)

 \triangleright Specification

Item	Specification
Coil Resistance (Ω)	19.0~22.0 [20 [°] C(68 [°] F)]

CVVT Oil Control Valve (OCV)

Specification

Item	Specification	0 00
Coil Resistance (Ω)	6.9 ~ 7.9 [20℃(68°F)]	تيجيه

اولین سامانه دیجیتال تعمیرکاران خو Service Standard

Item			Speci	fication
Ignition Timing (°)			BTDC 6° \pm 5°	
		۸Τ	N, P-range	600 ± 100
Idle Speed (rpm)	A/C OFF	AT	D-range	600 ± 100
		MT	Neutral	650 ± 100
		AT N, P-range 6	600 ± 100	
	A/C ON	AI	D-range	600 ± 100
	MT	Neutral	650 ± 100	

Variable Intake Solenoid (VIS) Valve

 \triangleright Specification

Item	Specification
Coil Resistance (Ω)	30.0 ~ 35.0 [20°℃(68°F)]

Ignition Coil

 \triangleright Type: Stick type

▷ Specification

Item	Specification
1st Coil Resistance (Ω)	0.62 ± 10%[20℃(68°F)]
2nd Coil Resistance ($^{k\Omega}$)	7.0 ± 15%[20℃(68°F)]

Fuel System

Tightening Torques

Engine	Control	System

Item	kgf.m	N.m	lb-ft
ECM installation bolt	1.0 ~ 1.2	9.8 ~ 11.8	7.2 ~ 8.7
ECM bracket installation bolt	1.0 ~ 1.2	9.8 ~ 11.8	7.2 ~ 8.7
Manifold absolute pressure sensor installation bolt	1.0 ~ 1.2	9.8 ~ 11.8	7.2 ~ 8.7
Crankshaft position sensor installation bolt	1.0 ~ 1.2	9.8 ~ 11.8	7.2 ~ 8.7
Crankshaft position sensor cover installation bolt (M8)	1.9 ~ 2.4	18.6 ~ 23.5	13.7 ~ 17.4
Crankshaft position sensor cover installation bolt (M6)	1.0 ~ 1.2	9.8 ~ 11.8	7.2 ~ 8.7
Camshaft position sensor (Bank 1 / Intake) installation bolt	1.0 ~ 1.2	9.8 ~ 11.8	7.2 ~ 8.7
Camshaft position sensor (Bank 1 / Exhaust) installation bolt	1.0 ~ 1.2	9.8 ~ 11.8	7.2 ~ 8.7
Knock sensor installation bolt	1.9 ~ 2.4	18.6 ~ 23.5	13.7 ~ 17.4
Heated oxygen sensor (Bank 1 / sensor 1) installation	3.6 ~4.6	35 ~ 45	25.8 ~ 33.2
Heated oxygen sensor (Bank 1 / sensor 2) installation	3.6 ~4.6	35 ~ 45	25.8 ~ 33.2
Electronic throttle body installation bolt	1.0 ~ 1.2	9.8 ~ 11.8	7.2 ~ 8.7
Purge control solenoid valve bracket installation bolt	1.0 ~ 1.2	9.8 ~ 11.8	7.2 ~ 8.7
CV <mark>VT oil c</mark> ontrol valve (Bank 1 / Intake) installation bolt	1.0 ~ 1.2	9.8 ~ 11.8	7.2 ~ 8.7
CVVT oil control valve (Bank 1 / Exhaust) installation bolt	1.0 ~ 1.2	9.8 ~ 11.8	7.2 ~ 8.7
Ignition coil installation bolt	1.0 ~ 1.2	9.8 ~ 11.8	7.2 ~ 8.7

Fuel Delivery System

سامانه دیجیتال تعمیرItémران خودرو در ایران	kgf.m	N.m	lb-ft
Fuel tank band installation nut	4.0 ~ 5.5	39.2 ~ 54.0	28.9 ~ 39.8
Fuel pump plate cover installation bolt	0.2~0.3	2.0 ~ 2.9	1.4 ~ 2.2
Filler-neck assembly bracket installation nut	0.4 ~ 0.6	3.9 ~ 5.9	2.9~4.3
Accelerator pedal module installation bolt	0.9 ~ 1.4	8.8 ~ 13.7	6.5 ~ 10.1
Accelerator pedal module installation nut	1.0 ~ 1.5	9.8 ~ 14.7	7.2 ~ 10.9
Delivery pipe installation bolt	1.9 ~ 2.4	18.6 ~ 23.5	13.7 ~ 17.4
Delivery pipe installation nut (\leftrightarrow Fuel feed tube)	0.8 ~ 1.0	7.8 ~ 9.8	5.8~7.2

General Information

EI 7

021 62 99 92 92

Special Service Tools

	7
--	---

Tool (Number and Name)	Illustration	Application
Fuel Pressure Gauge (09353-24100)	EFDA003A	Measuring the fuel line pressure
Fuel Pressure Gauge Adapter (09353-38000)	A A A A A A A A A A A A A A A A A A A	Connection between the delivery pipe and the fuel feed line
	BF1A025D	
Fuel Pressure Gauge Connector (09353-24000)		Connection between the Fuel Pressure Gauge (09353-24100) and the Fuel Pr- essure Gauge Adapter (09353-38000)
میرکاران خودرو در ایران	اولین سامانه دیجیتال تح EFDA003C	
Heated Oxygen Sensor Socket Wrench (09392-2H100)		Removal and installation of the heated oxygen sensor
	SFDEM8050L	

Fuel System

Basic Troubleshooting

Basic Troubleshooting Guide

2 Analyze Customer's Problem • Ask the customer about the conditions and environment relative to the issue. (Use CUSTOMER PROBLEM ANALYSIS SHEET). 3 Verify Symptom, and then Check DTC and Freeze Frame Data • Connect the GDS to Diagnostic Link Connector (DLC). • Record the DTC and Freeze Frame Data. • Image: Connect the GDS to Diagnostic Link Connector (DLC). • Record the DTC and Freeze Frame Data, refer to Step 5. • Confirm the Inspection Procedure for the System or Part • Using the SYMPTOM TROUBLESHOOTING GUIDE CHART, choose the correct inspection procedure for the system or part to be checked. 5 Erase the DTC and Freeze Frame Data • WARNING NEVER erase DTC and Freeze Frame Data before completing Step 2 : MIL/DTC in CUSTOMER PROBLEM ANALYSIS SHEET. • Go to Step 11, if you recognize the problem. • Try to recreate or simulate the symptoms of the DTC control of the malfunction as described by customer. • If DTC(s) is/are displayed, go to Step 9. • If DTC(s) is/are displayed, go to Step 9. • If DTC(s) is/are displayed, go to Step 9. • If DTC(s) is/are displayed, go to Step 9. • If DTC(s) is/are displayed, go to Step 9. • If DTC(s) is/are displayed, go to Step 9. • If DTC(s) is/are displayed, go to Step 9. • If DTC(c) des(do) not occur, ref	1	Bring Vehicle to Workshop
(Use CUSTOMER PROBLEM ANALYSIS SHEET). 3 Verify Symptom, and then Check DTC and Freeze Frame Data • Connect the GDS to Diagnostic Link Connector (DLC). • Record the DTC and Freeze Frame Data.	2	Analyze Customer's Problem
 Connect the GDS to Diagnostic Link Connector (DLC). Record the DTC and Freeze Frame Data. NOTE To erase DTC and Freeze Frame Data, refer to Step 5. Confirm the Inspection Procedure for the System or Part Using the SYMPTOM TROUBLESHOOTING GUIDE CHART, choose the correct inspection procedure for the system or part to be checked. Erase the DTC and Freeze Frame Data WARNING NEVER erase DTC and Freeze Frame Data before completing Step 2 : MIL/DTC in CUSTOMER PROBLEM ANALYSIS SHEET. Inspect Vehicle Visually. Go to Step 11, if you recognize the problem. Recreate (Simulate) Symptoms of the DTC and Homestand Symptoms of the DTC. Confirm Symptoms of Problem If DTC(s) is/are not displayed, go to Step 9. If DTC(s) is/are not displayed, go to Step 11. Recreate (Simulate) Symptom Try to recreate or simulate the condition of the malfunction as described by the customer. If DTC(s) is/are not displayed, go to Step 9. If DTC(s) is/are not displayed, go to Step 11. Recreate (Simulate) Symptom Try to recreate or simulate the condition of the malfunction as described by the customer. 	•	
 Record the DTC and Freeze Frame Data. NOTE To erase DTC and Freeze Frame Data, refer to Step 5. Confirm the Inspection Procedure for the System or Part Using the SYMPTOM TROUBLESHOOTING GUIDE CHART, choose the correct inspection procedure for the system or part to be checked. Erase the DTC and Freeze Frame Data WARNING NEVER erase DTC and Freeze Frame Data before completing Step 2 : MIL/DTC in CUSTOMER PROBLEM ANALYSIS SHEET. Inspect Vehicle Visually Go to Step 11, if you recognize the problem. Recreate (Simulate) Symptoms of the DTC on differentiation as described by customer. If DTC(s) is/are displayed, go to Step 9. If DTC(s) is/are displayed, go to Step 11. Recreate (Simulate) Symptom Try to recreate or simulate the condition of the malfunction as described by the customer. If DTC(s) is/are displayed, go to Step 11. Recreate (Simulate) Symptom Try to recreate or simulate the condition of the malfunction as described by the customer. If DTC(s) is/are displayed, go to Step 11. Recreate (Simulate) Symptom Try to recreate or simulate the condition of the malfunction as described by the customer. 	3	Verify Symptom, and then Check DTC and Freeze Frame Data
To erase DTC and Freeze Frame Data, refer to Step 5. 4 Confirm the Inspection Procedure for the System or Part • Using the SYMPTOM TROUBLESHOOTING GUIDE CHART, choose the correct inspection procedure for the system or part to be checked. 5 Erase the DTC and Freeze Frame Data & WARNING NEVER erase DTC and Freeze Frame Data before completing Step 2 : MIL/DTC in CUSTOMER PROBLEM ANALYSIS SHEET. 6 Inspect Vehicle Visually • Go to Step 11, if you recognize the problem. 7 Recreate (Simulate) Symptoms of the DTC and Itology to ustomer. • If DTC(s) is/are displayed, simulate the condition according to troubleshooting procedure for the DTC. 8 Confirm Symptoms of Problem • If DTC(s) is/are not displayed, go to Step 9. • If DTC(s) is/are not displayed, go to Step 9. • If DTC(s) is/are displayed, go to Step 9. • If DTC(s) is/are displayed, go to Step 9. • If DTC(s) is/are displayed, go to Step 9. • If DTC(s) is/are displayed, go to Step 9. • If DTC(s) is/are displayed, go to Step 9. • If DTC(s) is/are displayed, go to Step 9. • If DTC(s) is/are displayed, go to Step 9. • If DTC(s) is/are displayed, go to Step 9. • If DTC(s) is/are displayed, go to Step 9. • I	1	
4 Confirm the Inspection Procedure for the System or Part • Using the SYMPTOM TROUBLESHOOTING GUIDE CHART, choose the correct inspection procedure for the system or part to be checked. 5 Erase the DTC and Freeze Frame Data ∞ WARNING NEVER erase DTC and Freeze Frame Data before completing Step 2 : MIL/DTC in CUSTOMER PROBLEM ANALYSIS SHEET. 6 Inspect Vehicle Visually • Go to Step 11, if you recognize the problem. 7 Recreate (Simulate) Symptoms of the DTC		ΝΟΤΕ
 Using the SYMPTOM TROUBLESHOOTING GUIDE CHART, choose the correct inspection procedure for the system or part to be checked. Erase the DTC and Freeze Frame Data WARNING NEVER erase DTC and Freeze Frame Data before completing Step 2 : MIL/DTC in CUSTOMER PROBLEM ANALYSIS SHEET. Inspect Vehicle Visually Go to Step 11, if you recognize the problem. Recreate (Simulate) Symptoms of the DTC Try to recreate or simulate the symptoms and conditions of the malfunction as described by customer. If DTC(s) is/are displayed, simulate the condition according to troubleshooting procedure for the DTC. Confirm Symptoms of Problem If DTC(s) is/are not displayed, go to Step 9. If DTC(s) is/are displayed, go to Step 9. If DTC(s) is/are displayed, go to Step 9. If DTC(s) is/are displayed, go to Step 9. Try to recreate or simulate the condition of the malfunction as described by the customer. Decreate (Simulate) Symptom Try to recreate or simulate the condition of the malfunction as described by the customer. 		To erase DTC and Freeze Frame Data, refer to Step 5.
or part to be checked.	4	Confirm the Inspection Procedure for the System or Part
WARNING NEVER erase DTC and Freeze Frame Data before completing Step 2 : MIL/DTC in CUSTOMER PROBLEM ANALYSIS SHEET. 6 Inspect Vehicle Visually • Go to Step 11, if you recognize the problem. 7 Recreate (Simulate) Symptoms of the DTC • Try to recreate or simulate the symptoms and conditions of the malfunction as described by customer. • If DTC(s) is/are displayed, simulate the condition according to troubleshooting procedure for the DTC. 8 Confirm Symptoms of Problem • If DTC(s) is/are not displayed, go to Step 9. • If DTC(s) is/are displayed, go to Step 9. • If DTC(s) is/are displayed, go to Step 9. • If DTC(s) is/are displayed, go to Step 9. • If DTC(s) is/are displayed, go to Step 9. • If DTC(s) is/are displayed, go to Step 9. • If DTC(s) is/are displayed, go to Step 9. • If DTC(s) is/are displayed, go to Step 9. • If DTC(s) is/are displayed, go to Step 9. • If DTC(s) is/are displayed, go to Step 9. • If DTC(s) is/are displayed, go to Step 9. • If DTC(s) is/are displayed, go to Step 9. • If DTC(s) is/are displayed, go to Step 9. • If DTC(s) is/are of simulate the condition of the malfunction as described by the customer. 10 Check the DTC	•	-
NEVER erase DTC and Freeze Frame Data before completing Step 2 : MIL/DTC in CUSTOMER PROBLEM ANALYSIS SHEET. 6 Inspect Vehicle Visually • Go to Step 11, if you recognize the problem. 7 Recreate (Simulate) Symptoms of the DTC • Try to recreate or simulate the symptoms and conditions of the malfunction as described by customer. • If DTC(s) is/are displayed, simulate the condition according to troubleshooting procedure for the DTC. 8 Confirm Symptoms of Problem • If DTC(s) is/are not displayed, go to Step 9. • If DTC(s) is/are displayed, go to Step 11. 9 Recreate (Simulate) Symptom • Try to recreate or simulate the condition of the malfunction as described by the customer. 10 Check the DTC	5	Erase the DTC and Freeze Frame Data
 Go to Step 11, if you recognize the problem. 7 Recreate (Simulate) Symptoms of the DTC Try to recreate or simulate the symptoms and conditions of the malfunction as described by customer. If DTC(s) is/are displayed, simulate the condition according to troubleshooting procedure for the DTC. 8 Confirm Symptoms of Problem If DTC(s) is/are not displayed, go to Step 9. If DTC(s) is/are displayed, go to Step 11. 9 Recreate (Simulate) Symptom Try to recreate or simulate the condition of the malfunction as described by the customer. 10 Check the DTC 	C	NEVER erase DTC and Freeze Frame Data before completing Step 2 : MIL/DTC in CUSTOMER PROBLEM
 Go to Step 11, if you recognize the problem. 7 Recreate (Simulate) Symptoms of the DTC Try to recreate or simulate the symptoms and conditions of the malfunction as described by customer. If DTC(s) is/are displayed, simulate the condition according to troubleshooting procedure for the DTC. 8 Confirm Symptoms of Problem If DTC(s) is/are not displayed, go to Step 9. If DTC(s) is/are displayed, go to Step 11. 9 Recreate (Simulate) Symptom Try to recreate or simulate the condition of the malfunction as described by the customer. 10 Check the DTC 		
 Try to recreate or simulate the symptoms and conditions of the malfunction as described by customer. If DTC(s) is/are displayed, simulate the condition according to troubleshooting procedure for the DTC. 8 Confirm Symptoms of Problem If DTC(s) is/are not displayed, go to Step 9. If DTC(s) is/are displayed, go to Step 11. 9 Recreate (Simulate) Symptom Try to recreate or simulate the condition of the malfunction as described by the customer. 10 Check the DTC 	(\$9	
 If DTC(s) is/are displayed, simulate the condition according to troubleshooting procedure for the DTC. Confirm Symptoms of Problem If DTC(s) is/are not displayed, go to Step 9. If DTC(s) is/are displayed, go to Step 11. Recreate (Simulate) Symptom Try to recreate or simulate the condition of the malfunction as described by the customer. Check the DTC 	7	Recreate (Simulate) Symptoms of the DTC
 If DTC(s) is/are not displayed, go to Step 9. If DTC(s) is/are displayed, go to Step 11. 9 Recreate (Simulate) Symptom Try to recreate or simulate the condition of the malfunction as described by the customer. 10 Check the DTC 	•	
If DTC(s) is/are displayed, go to Step 11. Recreate (Simulate) Symptom Try to recreate or simulate the condition of the malfunction as described by the customer. Check the DTC	8	Confirm Symptoms of Problem
Try to recreate or simulate the condition of the malfunction as described by the customer. Check the DTC		
10 Check the DTC	9	Recreate (Simulate) Symptom
	•	Try to recreate or simulate the condition of the malfunction as described by the customer.
If DTC(s) does(do) not occur, refer to INTERMITTENT PROBLEM PROCEDURE in BASIC INSPECTION PROCEDURE.	10	Check the DTC
If DTC(s) occur(s), go to Step 11.	1	
11 Perform Troubleshooting Procedure for DTC	11	Perform Troubleshooting Procedure for DTC
12 Adjust or repair the vehicle	12	Adjust or repair the vehicle
13 Confirmation test	13	Confirmation test
14 END	14	END

STDFL0001N

General Information

FL-9

Customer Problem Analysis Sheet

1. VEHICLE INFORMAITON

VIN No.		Transmission	□ M/T □ A/T □ CVT □ etc.
Production date		Driving type	□ 2WD (FF) □ 2WD (FR) □ 4WD
Odometer Reading	km/mile	DPF (Diesel Engine)	

2. SYMPTOMS

□ Unable to start	 Engine does not turn over Incomplete combustion Initial combustion does not occur 	
□ Difficult to start	□ Engine turns over slowly □ Other	
☐ Poor idling	 □ Rough idling □ Incorrect idling □ Unstable idling (High: rpm, Low:rpm) □ Other 	
☐ Engine stall	 Soon after starting After accelerator pedal depressed After accelerator pedal released During A/C ON Shifting from N to D-range Other 	
☐ Others	□ Poor driving (Surge) □ Knocking □ Poor fuel economy □ Back fire □ After fire □ Other	

3. ENVIRONMENT

Problem frequency	□ Constant □ Sometimes () □ Once only □ Other	
Weather	Fine Cloudy Rainy Snowy Other	
Outdoor temperature	Approx °C/°F	
Place	☐ Highway ☐ Suburbs ☐ Inner City ☐ Uphill ☐ Downhill ☐ Rough road ☐ Other	
Engine temperature	Cold Warming up After warming up Any temperature	
Engine operation Image: Starting in the starting		

۰

4. MIL/DTC

MIL (Malfunction Indicator Lamp)		□ Remains ON □ Sometimes lights up □ Does not light	
DTO	Normal check (Pre-check)	□ Normal □ DTC (□ Freeze Frame Data	_)
DTC	Check mode	□ Normal □ DTC (□ Freeze Frame Data	_)

5. ECM/PCM INFORMATION

ECM/PCM Part No.	
ROM ID	

SCMF10001L

Fuel System

021 62 99 92 92

FL-10

Basic Inspection Procedure

Measuring Condition of Electronic Parts' Resistance

The measured resistance at high temperature after vehicle running may be high or low. So all resistance must be measured at ambient temperature $(20^{\circ}C, 68^{\circ}F)$, unless stated otherwise.


WNOTICE

The measured resistance in except for ambient temperature ($20^{\circ}C$, $68^{\circ}F$) is reference value.

Intermittent Problem Inspection Procedure

Sometimes the most difficult case in troubleshooting is when a problem symptom occurs but does not occur again during testing. An example would be if a problem appears only when the vehicle is cold but has not appeared when warm. In this case, the technician should thoroughly make out a "Customer Problem Analysis Sheet" and recreate (simulate) the environment and condition which occurred when the vehicle was having the issue.

- 1. Clear Diagnostic Trouble Code (DTC).
- Inspect connector connection, and check terminal for poor connections, loose wires, bent, broken or corroded pins, and then verify that the connectors are always securely fastened.



BFGE321A

- 3. Slightly shake the connector and wiring harness vertically and horizontally.
- 4. Repair or replace the component that has a problem.
- 5. Verify that the problem has disappeared with the road test.
- Simulating Vibration
- a. Sensors and Actuators

: Slightly vibrate sensors, actuators or relays with finger.

WARNING

Strong vibration may break sensors, actuators or relays

b. Connectors and Harness

: Lightly shake the connector and wiring harness vertically and then horizontally.

- Simulating Heat
- a. Heat components suspected of causing the malfunction with a hair dryer or other heat source.

WARNING

- DO NOT heat components to the point where they may be damaged.
- DO NOT heat the ECM directly.
- Simulating Water Sprinkling
- a. Sprinkle water onto vehicle to simulate a rainy day or a high humidity condition.

WARNING

DO NOT sprinkle water directly into the engine compartment or electronic components.

- Simulating Electrical Load
- a. Turn on all electrical systems to simulate excessive electrical loads (Radios, fans, lights, rear window defogger, etc.).


021 62 99 92 92

FL-11


General Information

Connector Inspection Procedure

- 1. Handling of Connector
 - a. Never pull on the wiring harness when disconnecting connectors.



c. Listen for a click when locking connectors. This sound indicates that they are securely locked.




BFGE015H

d. When a tester is used to check for continuity, or to measure voltage, always insert tester probe from wire harness side.



BFGE015G

b. When removing the connector with a lock, press or pull locking lever.



BFGE015I


sound indicates that they are securely loc

Fuel System

021 62 99 92 92

FL-12

e. Check waterproof connector terminals from the connector side. Waterproof connectors cannot be accessed from harness side.



BFGE015J

WNOTICE

- Use a fine wire to prevent damage to the terminal.
- Do not damage the terminal when inserting the tester lead.
- 2. Checking Point for Connector
 - a. While the connector is connected:
 Hold the connector, check connecting condition and locking efficiency.
 - b. When the connector is disconnected:


Check missed terminal, crimped terminal or broken core wire by slightly pulling the wire harness.

Visually check for rust, contamination, deformation and bend.

c. Check terminal tightening condition:

Insert a spare male terminal into a female terminal, and then check terminal tightening conditions.

d. Pull lightly on individual wires to ensure that each wire is secured in the terminal.



BFGE015K

- 3. Repair Method of Connector Terminal
 - a. Clean the contact points using air gun and/or shop rag.

MOTICE

Never use sand paper when polishing the contact points, otherwise the contact point may be damaged.

b. In case of abnormal contact pressure, replace the female terminal.

Wire Harness Inspection Procedure

- 1. Before removing the wire harness, check the wire harness position and crimping in order to restore it correctly.
- Check whether the wire harness is twisted, pulled or loosened.
- 3. Check whether the temperature of the wire harness is abnormally high.
- 4. Check whether the wire harness is rotating, moving or vibrating against the sharp edge of a part.
- 5. Check the connection between the wire harness and any installed part.
- 6. If the covering of wire harness is damaged; secure, repair or replace the harness.

General Information


Electrical Circuit Inspection Procedure

Check Open Circuit

- 1. Procedures for Open Circuit
 - Continuity Check
 - Voltage Check

If an open circuit occurs (as seen in [FIG. 1]), it can be found by performing Step 2 (Continuity Check Method) or Step 3 (Voltage Check Method) as shown below.

FIG 1



BFGE501A

2. Continuity Check Method **When measuring for resistance, lightly shake the**


wire harness above and below or from side to side.

Specification (Resistance)

1 Ω or less \rightarrow Normal Circuit 1^{MΩ} or Higher \rightarrow Open Circuit

a. Disconnect connectors (A), (C) and measure resistance between connector (A) and (C) as shown in [FIG. 2].


In [FIG.2.] the measured resistance of line 1 and 2 is higher than $1^{M\Omega}$ and below 1 Ω respectively. Specifically the open circuit is line 1 (Line 2 is normal). To find exact break point, check sub line of line 1 as described in next step.



BFGE501B

b. Disconnect connector (B), and measure for resistance between connector (C) and (B1) and between (B2) and (A) as shown in [FIG. 3].

In this case the measured resistance between connector (C) and (B1) is higher than $1^{M\Omega}$ and the open circuit is between terminal 1 of connector (C) and terminal 1 of connector (B1).



BFGE501C

021 62 99 92 92


Fuel System

FL-14

- 3. Voltage Check Method
 - a. With each connector still connected, measure the voltage between the chassis ground and terminal 1 of each connectors (A), (B) and (C) as shown in [FIG. 4].

The measured voltage of each connector is 5V, 5V and 0V respectively. So the open circuit is between connector (C) and (B).

FIG 4




Check Short Circuit

- 1. Test Method for Short to Ground Circuit
 - Continuity Check with Chassis Ground

If short to ground circuit occurs as shown in [FIG. 5], the broken point can be found by performing Step 2 (Continuity Check Method with Chassis Ground) as shown below.





BFGE501E

BFGE501D

2. Continuity Check Method (with Chassis Ground)


Lightly shake the wire harness above and below, or from side to side when measuring the resistance.

Specification (Resistance)

 $\begin{array}{l} 1\Omega \text{ or less} \rightarrow \text{Short to Ground Circuit} \\ 1M\Omega \text{ or Higher} \rightarrow \text{Normal Circuit} \end{array}$

a. Disconnect connectors (A), (C) and measure for resistance between connector (A) and Chassis Ground as shown in [FIG. 6].

The measured resistance of line 1 and 2 in this example is below 1 Ω and higher than 1M Ω respectively. Specifically the short to ground circuit is line 1 (Line 2 is normal). To find exact broken point, check the sub line of line 1 as described in the following step.



BFGE501F


b. Disconnect connector (B), and measure the resistance between connector (A) and chassis ground, and between (B1) and chassis ground as shown in [FIG. 7].

The measured resistance between connector (B1) and chassis ground is 1Ω or less. The short to ground circuit is between terminal 1 of connector (C) and terminal 1 of connector (B1).

021 62 99 92 92

General Information

FL-15



Fuel System

Symptom Troubleshooting Guide Chart

Main symptom	Diagnostic procedure	Also check for
Unable to start (Engine does not turn over)	 Test the battery Test the starter Inhibitor switch (A/T) or clutch start switch (M/T) 	
Unable to start (Incomplete combusti- on)	 Test the battery Check the fuel pressure Check the ignition circuit Troubleshooting the immobilizer system (In case of immobilizer lamp flashing) 	 DTC Low compression Intake air leaks Slipped or broken timing belt Contaminated fuel
Difficult to start	 Test the battery Check the fuel pressure Check the ECT sensor and circuit (Check DTC) Check the ignition circuit 	 DTC Low compression Intake air leaks Contaminated fuel Weak ignition spark
Poor idling (Rough, unstable or in- correct Idle)	 Check the fuel pressure Check the Injector Check the long term fuel trim and short term fuel trim (Refer to CUSTOMER DATASTREAM) Check the idle speed control circuit (Check DTC) Inspect and test the Throttle Body Check the ECT sensor and circuit (Check DTC) 	 DTC Low compression Intake air leaks Contaminated fuel Weak ignition spark
وليت Engine stall ودرو در ايران	 Test the Battery Check the fuel pressure Check the idle speed control circuit (Check DTC) Check the ignition circuit Check the CKPS Circuit (Check DTC) 	 DTC Intake air leaks Contaminated fuel Weak ignition spark
Poor driving (Surge)	driving 1. Check the fuel pressure	
Knocking	 Check the fuel pressure Inspect the engine coolant Inspect the radiator and the electric cooling fan Check the spark plugs 	DTCContaminated fuel
Poor fuel economy	 Check customer's driving habitsIs A/C on full time or the defroster mode on? Are tires at correct pressure? Is excessively heavy load being carried? Is acceleration too much, too often? Check the fuel pressure Check the injector Test the exhaust system for a possible restriction Check the ECT sensor and circuit 	 DTC Low compression Intake air leaks Contaminated fuel Weak ignition spark

021 62 99 92 92

FL-17

General Information

		·
Main symptom	Diagnostic procedure	Also check for
Hard to refuel (Overflow during refu- eling)	 Test the canister close valve Inspect the fuel filler hose/pipe Pinched, kinked or blocked? Filler hose is torn Inspect the fuel tank vapor vent hose between the EVAP. canister and air filter Check the EVAP. canister 	 Malfunctioning gas stati- on filling nozzle (If this p- roblem occurs at a speci- fic gas station during ref- ueling)



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Fuel System

Engine Control System

Description

If the Gasoline Engine Control system components (sensors, ECM, injector, etc.) fail, interruption to the fuel supply or failure to supply the proper amount of fuel for various engine operating conditions will result. The following situations may be encountered.

- 1. Engine is hard to start or does not start at all.
- 2. Unstable idle.
- 3. Poor driveability

If any of the above conditions are noted, first perform a routine diagnosis that includes basic engine checks (ignition system malfunction, incorrect engine adjustment, etc.). Then, inspect the Gasoline Engine Control system components with the GDS.

WNOTICE

- Before removing or installing any part, read the diagnostic trouble codes and then disconnect the battery negative (-) terminal.
- Before disconnecting the cable from battery terminal, turn the ignition switch to OFF. Removal or connection of the battery cable during engine operation or while the ignition switch is ON could cause damage to the ECM.
- The control harnesses between the ECM and heated oxygen sensor are shielded with the shielded ground wires to the body in order to prevent the influence of ignition noises and radio interference. When the shielded wire is faulty, the control harness must be replaced.
- When checking the generator for the charging state, do not disconnect the battery '+' terminal to prevent the ECM from damage due to the voltage.
- When charging the battery with the external charger, disconnect the vehicle side battery terminals to prevent damage to the ECM.

Malfunction Indicator Lamp (MIL) [EOBD]

A malfunction indicator lamp illuminates to notify the driver that there is a problem with the vehicle. However, the MIL will go off automatically after 3 subsequent sequential driving cycles without the same malfunction. Immediately after the ignition switch is turned on (ON position - do not start), the MIL will illuminate continuously to indicate that the MIL operates normally.

Faults with the following items will illuminate the MIL.

- Catalyst
- Fuel system
- Mass Air Flow Sensor (MAFS)
- Intake Air Temperature Sensor (IATS)
- Engine Coolant Temperature Sensor (ECTS)
- ETC Module
- Upstream Oxygen Sensor
- Upstream Oxygen Sensor Heater
- Downstream Oxygen Sensor
- Downstream Oxygen Sensor Heater
- Injector
- Misfire
- Crankshaft Position Sensor (CKPS)
- Camshaft Position Sensor (CMPS)
- Evaporative Emission Control System
- Vehicle Speed Sensor (VSS)
- Power Supply
- ECM/ PCM
- MT/AT Encoding
- Acceleration Sensor
- MIL-on Request Signal
- Power Stage

MOTICE

Refer to "Inspection Chart For Diagnostic Trouble Codes (DTC)" for more information.

Engine Control System

[NON-EOBD]

A malfunction indicator lamp illuminates to notify the driver that there is a problem with the vehicle. However, the MIL will go off automatically after 3 subsequent sequential driving cycles without the same malfunction. Immediately after the ignition switch is turned on (ON position - do not start), the MIL will illuminate continuously to indicate that the MIL operates normally.

Faults with the following items will illuminate the MIL

- Heated oxygen sensor (HO2S)
- Mass Air Flow sensor (MAFS)
- ETC Module
- Engine coolant temperature sensor (ECTS)
- Injectors
- ECM

Refer to "Inspection Chart For Diagnostic Trouble Codes (DTC)" for more information.

[INSPECTION]

- 1. After turning ON the ignition key, ensure that the light illuminates for about 5 seconds and then goes out.
- 2. If the light does not illuminate, check for an open circuit in the harness, a blown fuse or a blown bulb.


Self-Diagnosis

The ECM monitors the input/output signals (some signals at all times and the others under specified conditions). When the ECM detects an irregularity, it records the diagnostic trouble code, and outputs the signal to the Data Link connector. The diagnosis results can be read with the MIL or the GDS. Diagnostic Trouble Codes (DTC) will remain in the ECM as long as battery power is maintained. The diagnostic trouble codes will, however, be erased when the battery terminal or ECM connector is disconnected, or by the GDS.

MOTICE

If a sensor connector is disconnected with the ignition switch turned on, the diagnostic trouble code (DTC) is recorded. In this case, disconnect the battery negative terminal (-) for 15 seconds or more, and the diagnosis memory will be erased.

The relation between DTC and driving pattern in EOBD system



LGIF601Q

021 62 99 92 92

021 62 99 92 92

FL-20

- 1. When the same malfunction is detected and maintained during two sequential driving cycles, the MIL will automatically illuminate.
- 2. The MIL will go off automatically if no fault is detected after 3 sequential driving cycles.
- 3. A Diagnostic Trouble Code(DTC) is recorded in ECM memory when a malfunction is detected after two sequential driving cycles. The MIL will illuminate when the malfunction is detected on the second driving cycle.

If a misfire is detected, a DTC will be recorded, and the MIL will illuminate, immediately after a fault is first detected.

4. A Diagnostic Trouble Code(DTC) will automatically erase from ECM memory if the same malfunction is not detected for 40 driving cycles.

- A "warm-up cycle" means sufficient vehicle operation such that the coolant temperature has risen by at least 40 degrees Fahrenheit from engine starting and reaches a minimum temperature of 160 degress Fahrenheit.
- A "driving cycle" consists of engine startup, vehicle operation beyond the beginning of closed loop operation.

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



WWW.DIGITALKHODRO.COM


021 62 99 92 92

Fuel System

Engine Control System

Components Location





STFFL1001L

021 62 99 92 92

Fuel System

FL-22

- 1. ECM (Engine Control Module)
- 2. Manifold Absolute Pressure Sensor (MAPS)
- 3. Intake Air Temperature Sensor (IATS)
- 4. Engine Coolant Temperature Sensor (ECTS)
- 5. Throttle Position Sensor (TPS) [integrated into ETC Module]
- 6. Crankshaft Position Sensor (CKPS)
- 7. Camshaft Position Sensor (CMPS) [Bank 1 / Intake]
- 8. Camshaft Position Sensor (CMPS) [Bank 1 / Exhaust]
- 9. Knock Sensor (KS)
- 10. Heated Oxygen Sensor (HO2S) [Bank 1 / Sensor 1]
- 11. Heated Oxygen Sensor (HO2S) [Bank 1 / Sensor 2]
- 12. Accelerator Position Sensor (APS)
- 13. A/C Pressure Transducer (APT)


- 14. Power Steering Pressure Sensor (PSPS)
- 15. ETC Motor [integrated into ETC Module]
- 16. Injector
- 17. Purge Control Solenoid Valve (PCSV)
- 18. CVVT Oil Control Valve (OCV) [Bank 1 / Intake]
- 19. CVVT Oil Control Valve (OCV) [Bank 1 / Exhaust]
- 20. Variable Intake Solenoid (VIS) Valve
- 21. Ignition Coil
- 22. Main Relay
- 23. Fuel Pump Relay
- 24. Data Link Connector (DLC) [16 Pin]
- 25. Multi-Purpose Check Connector [20 Pin]



021 62 99 92 92

Engine Control System


FL-23



Fuel System

8. Camshaft Position Sensor (CMPS) [Bank 1 / Exhaust]	9. Knock Sensor (KS)
CMPS [Bank 1/Exhaust]	Knock Sensor (KS)
STDFL0107N	SNFFL9003N
10. Heated Oxygen Sensor (HO2S) [Bank 1/Sensor 1]	11. Heated Oxygen Sensor (HO2S) [Bank 1/Sensor 2]
HO2S [Bank 1/Sensor 1]	HO2S [Bank 1/Sensor 2] a
SYFFL0139L	SYFFL0140L
12. Accelerator Position Sensor (APS)	13. A/C Pressure Transducer (APT)
STFFL1026D	STFF11110D

Engine Control System



FL-25


021 62 99 92 92

WWW.DIGITALKHODRO.COM

021 62 99 92 92

Fuel System

021 62 99 92 92








Engine Control System

Engine Control Module (ECM)

ECM Terminal And Input/Output signal



ECM Terminal Function

Connector [CHG-K]

Pin No.	Description	Connected to
1	Power ground	Chassis Ground
2	Battery power (B+)	Ignition Switch
3	Power ground	Chassis Ground
4	Battery power (B+)	Main Relay
5	Power ground	Chassis Ground
629	Battery power (B+)	Battery
7	Wheel Speed Sensor (WSS) [+] signal input	Wheel Speed Sensor (WSS) [Without ABS/ESP]
8	مانه دیجیتال تعمیرکاران خودرو در ایرار	اولين س
9	-	
10	-	
11	-	
12	Knock Sensor (KS) signal input	Knock Sensor (KS)
13	Sensor ground	Accelerator Position Sensor (APS) 2
14	Sensor ground	Engine Coolant Temperature Sensor (ECTS)
15	Camshaft Position Sensor (CMPS) [Bank 1/Exhaust] signal input	Camshaft Position Sensor (CMPS) [Bank 1/Exhaust]
16	Sensor ground	Heated Oxygen Sensor [Bank 1/Sensor 1] (Except Euro 5)
17	Crankshaft Position Sensor (CKPS) signal input	Crankshaft Position Sensor (CKPS)
18	Rc/Rp (Pump Cell Voltage)	Heated Oxygen Sensor [Bank 1/Sensor 1] (Euro 5 only)
19	VS+ (NERNST Cell Voltage)	Heated Oxygen Sensor [Bank 1/Sensor 1] (Euro 5 only)
20	VS-/IP- (Common Ground for VS, IP)	Heated Oxygen Sensor [Bank 1/Sensor 1] (Euro 5 only)

021 62 99 92 92

FL-27

SYFFL0006L

WWW.DIGITALKHODRO.COM

021 62 99 92 92

021 62 99 92 92

FL-28

Fuel System

Pin No.	Description	Connected to
21	-	
22	-	
23	-	
24	Start overrun (Ground)	Start relay
25	Injector (Cylinder #1) control output	Injector (Cylinder #1)
26	Injector (Cylinder #3) control output	Injector (Cylinder #3)
27	Injector (Cylinder #4) control output	Injector (Cylinder #4)
28	Injector (Cylinder #2) control output	Injector (Cylinder #2)
29	Wheel Speed Sensor (WSS) [-] signal input	Wheel Speed Sensor (WSS) [Without ABS/ESP]
30	Sensor power (+5V)	Manifold Absolute Pressure Sensor (MAPS)
31	Manifold Absolute Pressure Sensor (MAPS) signal input	Manifold Absolute Pressure Sensor (MAPS)
32	Throttle Position Sensor (TPS) 2 signal input	Throttle Position Sensor (TPS) 2
33	Engine Coolant Temperature Sensor (ECTS) signal input	Engine Coolant Temperature Sensor (ECTS)
34	Sensor ground	Knock Sensor (KS)
35	Accelerator Position Sensor (APS) 2 signal input	Accelerator Position Sensor (APS) 2
36	Sensor power (+5V)	Accelerator Position Sensor (APS) 2
37	Sensor ground	Camshaft Position Sensor (CMPS) [Bank 1/Exhaust]
38	Heated Oxygen Sensor [Bank 1/Sensor 1] signal input	Heated Oxygen Sensor [Bank 1/Sensor 1] (Except Euro 5)
39	Sensor ground	Crankshaft Position Sensor (CKPS)
40	Vehicle speed signal input	ESP Control Module, ABS Control Module [Without MDPS]
41	Power Steering Pressure Sensor (PSPS) signal input	Power Steering Pressure Sensor (PSPS)
42	Rc (Compensative Resistance)	Heated Oxygen Sensor [Bank 1/Sensor 1] (Euro 5 only)
43	Sensor power (+5V)	A/C Pressure Transducer (APT)
44	-	
45	-	
46	Alternator (COM)	Alternator
47	-	
48	-	
49	-	
50	Variable Intake Solenoid (VIS) Valve control output	Variable Intake Solenoid (VIS) Valve
51	Battery power (B+)	Main Relay

Engine Control System

FL-29

Pin No.	Description	Connected to
52	-	
53	Intake Air Temperature Sensor (IATS) signal input	Intake Air Temperature Sensor (IATS)
54	A/C Pressure Transducer (APT) signal input	A/C Pressure Transducer (APT)
55	-	
56	-	
57	Sensor ground	A/C Pressure Transducer (APT)
58	-	
59	Sensor ground	Throttle Position Sensor (TPS) 1,2
60	Sensor power (+5V)	Accelerator Position Sensor (APS) 1
61	Sensor ground	Accelerator Position Sensor (APS) 1
62	Camshaft Position Sensor (CMPS) [Bank 1/Intake] signal input	Camshaft Position Sensor (CMPS) [Bank 1/Intake]
63	Sensor power (+5V)	Throttle Position Sensor (TPS) 1,2
64	Main Relay control output	Main Relay
65	Cooling Fan Relay [Low] control output	Cooling Fan Relay [Low]
66	CVVT Oil Control (OCV) Valve [Bank 1/Intake] control output	CVVT Oil Control Valve (OCV) [Bank 1/Intake]
67	Purge Control Solenoid Valve (PCSV) control output	Purge Control Solenoid Valve (PCSV)
68	CVVT Oil Control (OCV) Valve [Bank 1/Exhaust] control output	CVVT Oil Control Valve (OCV) [Bank 1/Exhaust]
69	Immobilizer Lamp control output	Immobilizer Lamp [With Immobilizer]
70	Fuel Pump Relay control output	Fuel Pump Relay
71	ETC Motor [+] control output	ETC Motor
72	ETC Motor [-] control output	ETC Motor
73	-	
74	Sensor ground	Manifold Absolute Pressure Sensor (MAPS)
75	Immobilizer communication line	Immobilizer Control
76	LIN communication signal input	Battery Sensor
77	CAN [High]	Other control module, Data Link Connector (DLC),
78	CAN [Low]	Other control module, Data Link Connector (DLC),
79	-	
80	Throttle Position Sensor (TPS) 1 signal input	Throttle Position Sensor (TPS) 1
81	Sensor ground	Power Steering Pressure Sensor (PSPS) [Without MDPS]
82	Accelerator Position Sensor (APS) 1 signal input	Accelerator Position Sensor (APS) 1
83	Sensor ground	Camshaft Position Sensor (CMPS) [Bank 1/Intake]

021 62 99 92 92

FL-30

Fuel System

Pin No.	Description	Connected to
84	Heated Oxygen Sensor (HO2S) [Bank 1/Sensor 2] signal input	Heated Oxygen Sensor (HO2S) [Bank 1/Sensor 2]
85	Sensor ground	Heated Oxygen Sensor (HO2S) [Bank 1/Sensor 2]
86	Engine speed signal output	Smart Key Control Module
87	-	
88	Cooling Fan Relay [High] control output	Cooling Fan Relay [High]
89	-	
90	-	
91	-	
92	-	
93	Heated Oxygen Sensor (HO2S) [Bank 1/Sensor 1] Heater control output	Heated Oxygen Sensor (HO2S) [Bank 1/Sensor 1] (Euro 5 only/ Except Euro 5)
94	Heated Oxygen Sensor (HO2S) [Bank 1/Sensor 2] Heater control output	Heated Oxygen Sensor (HO2S) [Bank 1/Sensor 2]

Connector [CHG-A]

Pin No.	Description	Connected to
ود)	Ignition Coil (Cylinder #4) control output	Ignition Coil (Cylinder #4) [with Immobilizer/with Smart key]
1	Ignition Coil (Cylinder #1) control output	Ignition Coil (Cylinder #1) [without Immobilizer/without Smart key]
2	Shield	Ignition Coil (Cylinder #1,2,3,4)
3	-	
4	-	
5	-	
6	-	
7	-	
8	-	
9	-	
10	-	
11	-	
12	-	
13	Electrical load [Wiper] signal input	Wiper [Low] Relay
14	Alternator (FR)	Alternator
15	-	

Engine Control System

FL-31

Pin No.	Description	Connected to
16	Ignition Coil (Cylinder #2) control output	Ignition Coil (Cylinder #2) [With Immobilizer/with Smart key]
10	Ignition Coil (Cylinder #3) control output	Ignition Coil (Cylinder #3) [Without Immobilizer/without Smart key]
17	-	
18	-	
19	-	
20	-	
21	-	
22	-	
23	-	
24	-	
25	-	
26	-	
27		
28	Start overrun	I/P Junction Box, Transaxle Range Switch (A/T), Start Ralay (M/T)
29	Brake Switch 1 signal input	Brake Switch
30	-	
31	Ignition Coil (Cylinder #1) control output	Ignition Coil (Cylinder #1) [With Immobilizer/with Smart key]
51	Ignition Coil (Cylinder #4) control output	Ignition Coil (Cylinder #4) [Without Immobilizer/without Smart key]
32	-	
33	-	
34	-	
35	-	
36	-	
37	-	
38	-	
39	-	
40	-	
41	-	
42	-	
43	Clutch Switch signal input	Clutch Switch
44	Brake Switch 2 signal input	Brake Switch

021 62 99 92 92

FL-32

Fuel System

Pin No.	Description	Connected to
45	-	
10	Ignition Coil (Cylinder #3) control output	Ignition Coil (Cylinder #3) [With Immobilizer/with Smart key]
46	Ignition Coil (Cylinder #2) control output	Ignition Coil (Cylinder #2) [Without Immobilizer/without Smart key]
47	-	
48	-	
49	-	
50	-	
51	-	
52	-	
53	-	
54	-	
55	-	
56		
57		
58		
59	بجیتال خودرو ساما <u></u> نه (مسئولیت محد	
60	-	
	مانه دیجیتال تعمیرکاران خودرو در ایران	اولین سا

Engine Control System

ECM Terminal Input/ Output signal

Connector [CHG-K]

Pin No.	Description	Condition	Туре	Level	Test Result
1	Power ground	ldle	DC	Max. 50mV	
0	Battery power (B+)	IG OFF	DC	Max. 0.5V	10.2mV
2		IG ON		Battery Voltage	12.02V
3	Power ground	ldle	DC	Max. 50mV	2.8mV
4		IG OFF	50	Max. 1.0V	3.1mV
4	Battery power (B+)	IG ON	DC	Battery Voltage	12.1V
5	Power ground	ldle	DC	Max. 50mV	1.8mV
		Always	Current	Below 2.0 mA	0.4 mA
6	Battery power (B+)	(Without Ignition key)	DC	Battery Voltage	12.88V
7	Wheel Speed Sensor (WSS)	Vehicle Run	SINE	15Hz: Min. 0.13Vpp	
7	[+] signal input	(30KPH)	WAVE	1000Hz: Min. 0.2Vpp	
8					
9					
10	_				
1129	وسامانه (مسئولیت محد	بيتال خودرو	ردت دیج		
12	Knock Sensor (KS) signal input	Knocking	Variable	-0.3 ~ 0.3V	
12		Normal ^{doi}	Frequency	0 V	
13	Sensor ground	Idle	DC	Max. 50mV	30mV
14	Sensor ground	ldle	DC	Max. 50mV	12.4mV
	Camshaft Position Sensor (CMPS) [Bank 1/Exhaust] signal input	Idle	Pulse	HI: Vcc or Battery Voltage	5.0V
15				LO: Max. 0.5V	0.2V
				FREQ: 5.36Hz	
16	Sensor ground	ldle	DC	Max. 50mV	29.0mV
	Crankshaft Position Sensor (CKPS) signal input	ldle	Pulse	HI: Vcc or Battery Voltage	5.00V
17				LO: Max. 0.5V	40mV
	oightir mput			FREQ: 600Hz	
	Rc/Rp (Pump Cell Voltage)	Idle	Analog	Normal: 450±50 mV	
18				Rich: Max. Normal+150 mV	
				Lean: Min. Normal-150 mV	
				Normal: 450±50 mV	
19	VS+ (NERNST Cell Voltage)	Idle	Analog	Rich: Max. Normal+150 mV	
				Lean: Min. Normal-150 mV	

FL-33

FL-34

Fuel System

021 62 99 92 92

Pin No.	Description	Condition	Туре	Level	Test Result
20	VS-/IP- (Common Ground for VS, I- P)	Idle	Analog	Reference for V_IP, V_N	
21	-				
22	-				
23	-				
24	Start overrun (Ground)				
				HI: Battery Voltage	13.8V
				LO: Max. 1.0V	200mV
25	Injector (Cylinder #1) control output	Idle	Pulse	Vpeak: Max. 80V	54.1V
				Frequency	5.21Hz
				Dwell Time	2.74ms
				HI: Battery Voltage	13.9V
				LO: Max. 1.0V	170mV
26	Injector (Cylinder #3) control output	Idle	Pulse	Vpeak: Max. 80V	53.9V
C				Frequency	5.18Hz
				Dwell Time	2.73ms
(المراجع	and Her		HI: Battery Voltage	14V
(59	وسامانه (مسئولیت محد	فيتال حودرو	رحت دیج	LO: Max. 1.0V	160mV
27	Injector (Cylinder #4) control output	نه د یجیتال	Pulse	Vpeak: Max. 80V	54.3V
				Frequency	5.24Hz
				Dwell Time	2.70ms
		Idle	Pulse	HI: Battery Voltage	14.1V
				LO: Max. 1.0V	160mV
28	Injector (Cylinder #2) control output			Vpeak: Max. 80V	53.9V
				Frequency: 5.21Hz	5.21Hz
				Dwell Time: 2.73ms	2.74ms
	Wheel Speed Sensor (WSS) [-]	Vehicle Run	SINE	15Hz: Min. 0.13Vpp	
29	signal input	(30KPH)	WAVE	1000Hz: Min. 0.2Vpp	
		IG OFF		Max. 0.5V	0mV
30	Sensor power (+5V)	IG ON	DC	4.9 ~ 5.1V	4.98V
31	Manifold Absolute Pressure Sensor (MAPS) signal input	Idle	Analog	0.8 ~ 1.6V	1.37V
	Throttle Position Sensor (TPS) 2	C.T	Ameler	4.2 ~ 5.0V	4.52V
32	signal input	W.O.T	Analog	3.3 ~ 3.8V	3.68V

Engine Control System

FL-35

Pin No.	Description	Condition	Туре	Level	Test Result
33	Engine Coolant Temperature Sensor (ECTS) signal input	ldle	Analog	0.5 ~ 4.5V	1.02V
34	Sensor ground	Idle	DC	Max. 50mV	8mV
35	Accelerator Position Sensor (APS)	C.T	Analog	Max. 1.0V	0.4V
35	2 signal input	W.O.T	Analog	1.5 ~ 3.0V	1.9V
36	Sonoor not (± 5)	IG OFF	DC	Max. 0.5V	5mV
30	Sensor power (+5V)	IG ON	DC	4.9 ~ 5.1V	5.02V
37	Sensor ground	Idle	DC	Max. 50mV	11mV
38	Heated Oxygen Sensor	اطام		Rich: 0.6 ~ 1.0V	926mV
38	[Bank 1/Sensor 1] signal input	ldle	DC	Lean: Max. 0.4V	20mV
39	Sensor ground	Idle	DC	Max. 50mV	11mV
				HI: Min. 4.5V	5.0V
10			Dulas	LO: Max. 0.5V	0V
40	Vehicle speed signal input	Vehicle Run	Pulse	Frequency	46.9Hz at Idle
6				Duty(-)	50.4% at Idle
41	Power Steering Pressure Sensor(PSPS) signal input		2:	6	
42	Rc (Compensative Resistance)	idle ldle	Analog	Rc-Rc/Rp < ±0.1V	
42	Sensor power (+5V)	IG OFF	DC	Max. 0.5V	
43		IG ON CO	لیںDCساما	<mark>4.</mark> 9 ~ 5.1V	
44	-				
45	-				
46	Alternator (COM)				
47	-				
48	-				
49	-				
50	Variable Intake Solenoid (VIS)	Active	50	Max. 1.0V	316mV
50	Valve control output	Inactive	DC	Battery Voltage	14.0V
	Battery power (B+)	IG OFF	50	Max. 1.0V	3.1mV
51		IG ON	DC	Battery Voltage	12.3V
52	-				
53	Intake Air Temperature Sensor (IATS) signal input	ldle	Analog	$0 \sim 5.0 V$	2.55V
54	A/C Pressure Transducer (APT) signal input	Idle	DC	0.4 ~ 4.6V	A/C OFF: 1.29 V A/C ON: 2.01V

FL-36

Fuel System

Pin No.	Description	Condition	Туре	Level	Test Result
55	-				
56	-				
57	Sensor ground	Idle	DC	Max. 50mV	11mV
58	-				
59	Sensor ground	Idle	DC	Max. 50mV	6mV
60	Sensor power (+5V)	IG OFF	DC	Max. 0.5V	10mV
00		IG ON		$4.9 \simeq 5.1 V$	5.02V
61	Sensor ground	Idle	DC	Max. 50mV	30mV
				HI: Vcc or Battery Voltage	5.0V
62	Camshaft Position Sensor (CMPS) [Bank 1/Intake] signal input	Idle	Pulse	LO: Max. 0.5V	0.2V
				Frequency	5.2Hz
63	Senser newer $(\pm E)/)$	IG OFF	DC	Max. 0.5V	0V
03	Sensor power (+5V)	IG ON		4.9 ~ 5.1V	5.03V
64	Main Relay control output	Relay OFF	DC	Battery Voltage	12.3V
64		Relay ON		Max. 1.0V	730mV
65	Cooling Fan Rel <mark>a</mark> y [Low] control output	A/C ON	Pulse	HI: Battery Voltage	10.4V
(30				LO: 0 ~ 0.5V	60mV
				HI: Battery Voltage	15.0V
66	CVVT Oil control (OCV) Valve [Bank 1/Intake] control output	نه د _{امل} یتال	Pulse	LO: Max. 1.0V	120mV
00		luie		Frequency	300Hz
				Duty(+)	84.70%
			Pulse	HI: Battery Voltage	14.3V
67	Purge control Solenoid Valve (PCSV) control output	Inactive		LO: Max. 1.0V	80mV
07		Active		Vpeak: Max. 70V	57.0V
				Frequency	16Hz
				HI: Battery Voltage	13.5V
69	CVVT Oil control (OCV) Valve	اطام	Pulse	LO: Max. 1.0V	100mV
68	[Bank 1/Exhaust] control output	Idle		Vpeak: Max.70V	13.5V
				Frequency	300Hz
60		Lamp OFF		HI: Battery Voltage	13.2V
69	Immobilizer Lamp control output	Lamp ON	DC	LO: Max . 2.0V	40mV
70	Fuel Dump Delay control suffrait	Relay OFF		Battery Voltage	12.8V
70	Fuel Pump Relay control output	Relay ON	DC	Max. 1.0V	40mV

Engine Control System

FL-37

Pin No.	Description	Condition	Туре	Level	Test Result
74	ETC Motor [+] control output			HI: Battery Voltage	13.4V
71		ldle	Pulse	LO: Max . 1.0V	0V
70		اما م	Dulas	HI: Battery Voltage	13.3V
72	ETC Motor [-] control output	ldle	Pulse	LO: Max . 1.0V	0V
73	-				
74	Sensor ground	Idle	DC	Max. 50 mV	7mV
75	Immobilizer communication line	During	Pulse	HI: Min. 8.5V	11.8V
75		communicating	Fuise	LO: Max. 3.5V	1.0V
76	LIN communication signal input				
77	CAN [High]	Recessive	Pulse	$2.0 \sim 3.0 V$	2.58V
77		Dominant	Fuise	2.75~4.5V	3.54V
78		Recessive	Dulaa	$2.0 \sim 3.0 V$	2.64V
/0	CAN [Low]	Dominant	Pulse	0.5~2.25V	1.52V
79		1			
80	Throttle Position Sensor (TPS) 1 signal input	C.T	Analog	0.3 ~ 0.9 V	0.65V
00		W.O.T		1.5 ~ 3.0 V	1.63V
81	Sensor ground	بيتال خودرو	رکت دیح	<u>ش</u>	
82	Accelerator Position Sensor (APS) 1 signal input	C.T	Analog	Max. 1.0V	0.8V
02		W.O.T		Min. 4.0V	4.0V
83	Sensor ground	Idle	DC	Max. 50 mV	12mV
84	Heated Oxygen Sensor (HO2S) [Bank 1/Sensor 2] signal input	Idle	DC	Rich: 0.6 ~ 1.0V	74 mV
				Lean: Max. 0.4V	70mV
85	Sensor ground	Idle	DC	Max. 50 mV	10 mV
				HI: Battery Voltage	14.0V
86		Idle	Pulse	LO: Max. 0.5V	60mV
00	Engine speed signal output	luie		Frequency: 20~26Hz	21Hz
				Duty(+)	50%
87	-				
88	Cooling Fan Relay [High] control	Relay OFF	DC	Battery Voltage	
	output	Relay ON		Max. 1.0V	
89	-				
90	-				
91	-				
92	-				

Fuel System

Pin No.	Description	Condition	Туре	Level	Test Result
		Engine Run		HI: Battery Voltage	14.4V
93	Heated Oxygen Sensor (HO2S)		Dulas	LO: Max. 1.0V	0.36V
93	[Bank 1/Sensor 1] Heater control output		Pulse	Frequency	10.0Hz
				Duty(+)	58.30%
				HI: Battery Voltage	14.0V
	Heated Oxygen Sensor (HO2S)			Dulas	LO: Max. 1.0V
94	[Bank 1/Sensor 2] Heater control output	Engine Run	Pulse	e Frequency	7.68Hz
	,			Duty(+)	53.9%

Connector [CHG-A]

Pin No.	Description	Condition	Туре	Level	Test Result
	Ignition Coil (Cylinder #4) control o- utput [with Immobilizer/with Smart key] Ignition Coil (Cylinder #1) control o- utput [without Immobilizer/without Smart key]	Idle	Pulse	1st Voltage: 300~400V	416V
				ON Voltage: Max. 2.0V	1.4V
				Frequency	5.2Hz
		•••••		Dwell Time	2.78ms
229	و سامانه (مسئولیت Shield	یتا idle ودرو	ركتعديج	Max. 50mV	16.8mV
3	-				
4	تعميركاران خودرو در ايراز	نه ديجيتال	ولين سام		
5	-				
6	-				
7	-				
8	-				
9	-				
10	-				
11	-				
12	-				
13	Electrical load [Wiper] signal input				
14	Alternator (ED)	Idle	Pulse	HI: Battery Voltage	13.4V
14	Alternator (FR)			LO: Max 1.5V	40 mV
15	-				

Engine Control System

FL-39

Pin No.	Description	Condition	Туре	Level	Test Result
	Ignition Coil (Cylinder #2) control o-			1st Voltage: 300~400V	416V
16	utput [with Immobilizer/with Smart key]	ldle	Pulse	ON Voltage: Max. 2.0V	1.3V
10	Ignition Coil (Cylinder #3) control o-	luic	T disc	Frequency	5.2Hz
	utput [without Immobilizer/without Smart key]		Dwell Time	Dwell Time	2.73ms
17	-				
18	-				
19	-				
20	-				
21	-				
22	-				
23	-				
24	-	=			
25					
26					
27					
28	Start overrun	بيتان جودرو	ردت دیج		
29	Brake Switch 1 signal input	Brake ON	DC	Battery Voltage	
	تعميركاران فودرودر أيرار	Brake OFF	میں ساما	Max. 0.5 V	
30	-				
	Ignition Coil (Cylinder #1) control o-			1st Voltage: 300~400V	408V
31	utput [with Immobilizer/with Smart key]	Idle	Pulse	ON Voltage: Max. 2.0V	1.6V
	Ignition Coil (Cylinder #4) control o-			Frequency	5.2Hz
	utput [without Immobilizer/without Smart key]			Dwell Time	2.74ms
32	-				
33	-				
34	-				
35	-				
36	-				
37	-				
38	-				
39	-				
40	-				

WWW.DIGITALKHODRO.COM

FL-40


021 62 99 92 92

Fuel System

Pin No.	Description	Condition	Туре	Level	Test Result
41	-				
42	-				
43	Clutch Switch signal input	Release	DC	Max. 0.5V	
43	Clutch Switch signal input	Push		Battery Voltage	
44	Brake Switch 2 signal input	Push	DC	Max. 0.5V	
	Brake Switch 2 Signal Input	Normal		Battery Voltage	
45	-				
	Ignition Coil (Cylinder #3) control o-			1st Voltage: 300~400V	410V
46	utput [with Immobilizer/with Smart key]	Idle	Pulse	ON Voltage: Max. 2.0V	1.5V
	Ignition Coil (Cylinder #2) control o-	luic	1 0130	Frequency	5.2Hz
	utput [without Immobilizer/without Smart key]			Dwell Time	2.78ms
47	-				
48					
49			U _		
50			••		
51	ر سامانه (مس <u></u> ئولیت محد	بيتال حودرو	ردت دیج	ů O	
52					
53	تعمیرکاران خودرو در ایرار	نه ديجيتال	الين سام	O	
54	-				
55	-				
56	-				
57	-				
58	-				
59	-				
60	-				

Engine Control System

Circuit Diagram



STFFL1002L

021 62 99 92 92

WWW.DIGITALKHODRO.COM

021 62 99 92 92

FL-42

Fuel System

MAPS & IATS	ECM
4	K74 - Sensor ground
	K30 - Sensor power (+5V)
	K31 - Manifold Absolute Pressure Sensor (MAPS) signal input
	K53 - Intake Temperature Sensor (IATS) signal input
ECTS	
3	K14 - Sensor ground
	K33 - Engine Coolant Temperature Sensor signal input
CMPS [B1/IN] Main Relay	
	K62 - Camshaft Position Sensor (CMPS) [Bank 1/Intake] signal input
	K83 - Sensor ground
CMPS [B1/EX]	
Main Relay	
	K15 - Camshaft Position Sensor (CMPS) [Bank 1/Exhaust] signal input
2	K37 - Sensor ground
CKPS	
Main Relay	
	K17 - Crankshaft Position Sensor (CKPS) signal input
2	K39 - Sensor ground
KS 00 0 0	
	K12 - Knock Sensor (KS) signal input
ديجيتال خودرو ساماته (مستهلايت) محدود)	K34 - Sensor ground
Except Euro 5	
HO2S [B1/S1] 3 Main Relay	
	K93 - Heated Oxygen Sensor (HO2S) [Bank 1/Sensor 1] Heater control output
	K38 - Heated Oxygen Sensor (HO2S) [Bank 1/Sensor 1] signal input
2	K16 - Sensor ground
	·'
HO2S [B1/S2] 4 Main Relay	
	K94 - Heated Oxygen Sensor (HO2S) [Bank 1/Sensor 2] Heater control output
	K84 - Heated Oxygen Sensor (HO2S) [Bank 1/Sensor 2] signal input
	K85 - Sensor ground
HO2S [B1/S1]	·
1025 [51/31] 4 Main Relay	
	K93 - HO2S (B1/S1) Heater control output
	K19 - VS+ (NERNST Cell Voltage)
	K20 - VS-/IP- (Common Ground for VS,IP)
	K18 - Rc/Rp (Pump Cell Voltage)
6	K42 - Rc (Compensative Resistance)
	'


STFFL1003L

021 62 99 92 92

021 62 99 92 92

Engine Control System

FL-43



STFFL1004L

Fuel System

ETC MODULE	ECM
	K63 - Sensor power (+5V)
	K80 - Throttle Position Sensor (TPS) 1 signal input
	K59 - Sensor ground
	K32 - Throttle Position Sensor (TPS) 2 signal input
ETC MOTOR 3	K71 - ETC Motor [+] control output
6	K72 - ETC Motor [-] control output
	K25 - Injector (Cylinder #1) control output
INJECTOR #2	
	K28 - Injector (Cylinder #2) control output
INJECTOR #3 2	K26 - Injector (Cylinder #3) control output
MAIN RELAY	
	K27 - Injector (Cylinder #4) control output
PCSV 2	
حبتال خودر و سامانه (مسئو 🔿 🖌 حدود)	K67 - Purge Control Solenoid Valve (PCSV) control output
OCV [B1/IN] → MAIN RELAY	
	K66 - CVVT Oil Control (OCV) [Bank 1/Intake] control output
OCV [B1/EX]	
$\nabla t r \nabla t$	K68 - CVVT Oil Control (OCV) [Bank 1/Exhaust] control output
vis	
$\nabla t \pi$	K50 - Variable Intake Solenoid (VIS) Valve control output

SXMF10134L

FL-44

WWW.DIGITALKHODRO.COM

FL-45

Engine Control System

Removal

WNOTICE

When replacing the ECM, the vehicle equipped with immobilizer must be performed the procedure as below.

[In the case of installing used ECM]

- 1. Perform "ECM neutralization mode" procedure with GDS. (Refer to "Immobilizer" in BE group)
- 2. Insert the key and turn it to the IGN ON and OFF position. Then the ECM key register process is completed automatically.


[In the case of installing new ECM]

Insert the key and turn it to the IGN ON and OFF position.

Then the ECM key register process is completed automatically.

- 1. Turn ignition switch OFF and disconnect the negative (-) battery cable.
- 2. Disconnect the ECM Connector (A).

- 3. Remove the air cleaner assembly (Refer to "Intake And Exhaust System" in EM group).
- 4. Remove the mounting bolts (A)/nut (B), and then remove the ECM (C).



SYFFL0340D



STFF11101D

FL-46

Fuel System

Installation

WNOTICE

When replacing the ECM, the vehicle equipped with immobilizer must be performed the procedure as below.

[In the case of installing used ECM]

- 1. Perform "ECM neutralization mode" procedure with GDS. (Refer to "Immobilizer" in BE group)
- 2. Insert the key and turn it to the IGN ON and OFF position. Then the ECM key register process is completed automatically.

[In the case of installing new ECM]

Insert the key and turn it to the IGN ON and OFF position.

Then the ECM key register process is completed automatically.

یتال خودرو سامانه (مسئولیت محدود)

1. Installation is reverse of removal.

ECM installation bolt: $9.8 \sim 11.8 \text{ N.m} (1.0 \sim 1.2 \text{ kgf.m}, 7.2 \sim 8.7 \text{ lb-ft})$ ECM bracket installation bolt/nut: $9.8 \sim 11.8 \text{ N.m} (1.0 \sim 1.2 \text{ kgf.m}, 7.2 \sim 8.7 \text{ lb-ft})$

ECM Problem Inspection Procedure

 TEST ECM GROUND CIRCUIT: Measure resistance between ECM and chassis ground using the backside of ECM harness connector as ECM side check point. If the problem is found, repair it.

Specification: Below 1Ω

- 2. TEST ECM CONNECTOR: Disconnect the ECM connector and visually check the ground terminals on ECM side and harness side for bent pins or poor contact pressure. If the problem is found, repair it.
- If problem is not found in Step 1 and 2, the ECM could be faulty. If so, make sure there were no DTC's before swapping the ECM with a new one, and then check the vehicle again. If DTC's were found, examine this first before swapping ECM.
- 4. RE-TEST THE ORIGINAL ECM: Install the original ECM (may be broken) into a known-good vehicle and check the vehicle. If the problem occurs again, replace the original ECM with a new one. If problem does not occur, this is intermittent problem (Refer to "Intermittent Problem Inspection Procedure" in Basic Inspection Procedure).

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Engine Control System

ETC (Electronic Throttle Control) System

Description

The Electronic Throttle Control (ETC) System consists of a throttle body with an integrated control motor and throttle position sensor (TPS). Instead of the traditional throttle cable, an Accelerator Position Sensor (APS) is used to receive driver input. The ECM uses the APS signal to calculate the target throttle angle; the position of the throttle is then adjusted via ECM control of the ETC motor. The TPS signal is used to provide feedback regarding throttle position to the ECM. Using ETC, precise control over throttle position is possible; the need for external cruise control modules/cables is eliminated.

mm


Gear (Idler)



Throttle Position Sensor (TPS)

ETC Motor

FL-47



Connector


Throttle Body

SBKFL9130L

FL-48

Fuel System

Schematic Diagram



Fail-Safe Mode

مانه (مسئو اtem محدود)	Failنركت ديجيتال خودرو سا	-Safe
ETC Motor	Throttle val	ve stuck at 5°
<i>بی</i> رکاران خودرو در ایران	TPS 1 fault	Replace it with TPS 2
TPS	TPS 2 fault	Replace it with TPS 1
	TPS 1,2 fault	Throttle valve stuck at 5°
	APS 1 fault	Replace it with APS 2
APS	APS 2 fault	Replace it with APS 1
	APS 1,2 fault	Throttle valve stuck at 5°

WNOTICE

When throttle value is stuck at 5°, engine speed is limited at below 1,500rpm and vehicle speed at maximum $40 \sim 50$ km/h ($25 \sim 31$ mph)


FL-49

Engine Control System

Specification

[Throttle Position Sensor (TPS)]

Thuattle Angle(°)	Output Voltage(V) [Vref = 5.0	
Throttle Angle(°)	TPS1	TPS2
0	0.0	5.0
10	0.48	4.52
20	0.95	4.05
30	1.43	3.57
40	1.90	3.10
50	2.38	2.62
60	2.86	2.14
70	3.33	1.67
80	3.81	1.19
90	4.29	0.71
100	4.76	0.24
105	5.0	0



EGRF235A

ltem	Sensor Resistance(^k Ω)
TPS	0.875 ~ 1.625 [20 ℃(68°F)]

[ETC Motor]

Item	Specification	
Coil Resistance (Ω)	1.2 ~ 1.8 [20 ℃(68°F <mark>)</mark>]	


9	DQ	C.T	W.O.T
TPS1	Throttle Angle (°)	6.3 ~ 14.7	93.45 ~ 101 .85
1951	Output Voltage [Vref=5V]	0.3 ~ 0.7	4.45 ~ 4.85
TDS2	Throttle Angle (°)	90.3 ~ 98.7	3.15 ~ 11.5 5
TPS2	Output Voltage [Vref=5V]	4.3 ~4.7	0.15 ~ 0.55

اولين سار

WWW.DIGITALKHODRO.COM

FL-50

Fuel System



STFFL1005L

FL-51

Engine Control System

Inspection

Throttle Position Sensor (TPS)

- 1. Connect the GDS on the Data Link Connector (DLC).
- 2. Start the engine and measure the output voltage of TPS 1 and 2 at C.T. and W.O.T.

Throttle Angle	Output Voltage (V) [Vref = 5.0V]	
Throttle Angle	TPS 1	TPS 2
C.T	0.3 ~ 0.7	4.3 ~ 4.7
W.O.T	4.45 ~ 4.85	0.15 ~ 0.55

- 3. Turn the ignition switch OFF and disconnect the scantool from the DLC.
- 4. Disconnect the ETC module connector and measure the resistance between the ETC module terminals 1 and 2.

Specification: Refer to "Specification"


ETC Motor

- 1. Turn the ignition switch OFF.
- 2. Disconnect the ETC module connector.
- 3. Measure resistance between the ETC module terminals 3 and 6.
- 4. Check that the resistance is within the specification.

Specification: Refer to "Specification"

Removal

- 1. Turn the ignition switch OFF and disconnect the battery negative (-) cable.
- 2. Remove the resonator and the air intake hose (Refer to "Intake And Exhaust System" in EM group).
- 3. Disconnect the ETC module connector (A).
- 4. Disconnect the coolant hoses (B).
- 5. Remove the installation bolts (C), and then remove the ETC module from the engine.



SXMF19131D

Installation

ACAUTION

- Install the component with the specified torques.
- Note that internal damage may occur when the component is dropped. In this case, use it after inspecting.
- 1. Installation is reverse of removal.

Electronic throttle body Installation bolt: 7.8 \sim 11.8 N.m (1.0 \sim 1.2 kgf.m, 5.8 \sim 8.7 lb-ft)

Fuel System

021 62 99 92 92

FL-52

Manifold Absolute Pressure Sensor (MAPS)


Description

Manifold Absolute Pressure Sensor (MAPS) is a speed-density type sensor and is installed on the surge tank. It senses absolute pressure of the surge tank and transfers the analog signal proportional to the pressure to the ECM. By using this signal, the ECM calculates the intake air quantity and engine speed.

The MAPS consists of a piezo-electric element and a hybrid IC amplifying the element output signal. The element is silicon diaphragm type and adapts pressure sensitive variable resistor effect of semi-conductor. Because 100% vacuum and the manifold pressure apply to both sides of the sensor respectively, this sensor can output analog signal by using the silicon variation proportional to pressure change.

Specification

Pressure (kPa)	Output Voltage (V)
20.0	0.79
46.7	1.84
101.3	4.0




SMGF19111L

021 62 99 92 92

Engine Control System

FL-53

Waveform




FL-54

021 62 99 92 92

Fuel System

Circuit Diagram



Test Condition	Output Voltage (V)
IG ON	3.9 ~ 4.1
Idle	0.8 ~ 1.6


021 62 99 92 92

FL-55

Engine Control System

Removal

- 1. Turn the ignition switch OFF and disconnect the battery negative (-) cable.
- 2. Disconnect the manifold absolute pressure sensor connector (A).
- 3. Remove the installation bolt (B), and then remove the sensor from the surge tank.



SXMF19133D

Installation

- Install the component with the specified torques.
- Note that internal damage may occur when the component is dropped. In this case, use it after inspecting.

- Insert the sensor in the installation hole and be careful not to damage when installation.
- 1. Installation is reverse of removal.

Manifold absolute pressure sensor installation bolt: 9.8 \sim 11.8 N.m (1.0 \sim 1.2 kgf.m, 7.2 \sim 8.7 lb-ft)



WWW.DIGITALKHODRO.COM

FL-56

Fuel System

Intake Air Temperature Sensor (IATS)

Description


Intake Air Temperature Sensor (IATS) is included inside Manifold Absolute Pressure Sensor and detects the intake air temperature.

To calculate precise air quantity, correction of the air temperature is needed because air density varies according to the temperature. So the ECM uses not only MAPS signal but also IATS signal. This sensor has a Negative Temperature Coefficient (NTC) Thermister and it's resistance changes in reverse proportion to the temperature.

Ē

Specification

Temperature [°C(°F)]	Resistance (^k Ω)
-40(-40)	40.93 ~ 48.35
-20(-4)	13.89 ~ 16.03
0(32)	$5.38 \simeq 6.09$
10(50)	3.48 ~ 3.90
20(68)	2.31 ~ 2.57
40(104)	1.08 ~ 1.21
50(122)	0.76 ~ 0.85
60(140)	$0.54 \sim 0.62$
80(176)	0.29 ~ 0.34




STFFL1007L

FL-57

Engine Control System

Circuit Diagram




021 62 99 92 92

FL-58

Fuel System

Removal

- 1. Turn the ignition switch OFF and disconnect the battery negative (-) cable.
- 2. Disconnect the manifold absolute pressure sensor connector (A).
- 3. Remove the installation bolt (B), and then remove the sensor from the surge tank.



SXMF19133D

Installation

- Install the component with the specified torques.
- Note that internal damage may occur when the component is dropped. In this case, use it after inspecting.

- Insert the sensor in the installation hole and be careful not to damage when installation.
- 1. Installation is reverse of removal.

Manifold absolute pressure sensor installation bolt: $9.8 \sim 11.8 \text{ N.m} (1.0 \sim 1.2 \text{ kgf.m}, 7.2 \sim 8.7 \text{ lb-ft})$



WWW.DIGITALKHODRO.COM

Engine Control System

Engine Coolant Temperature Sensor (ECTS)

Description

Engine Coolant Temperature Sensor (ECTS) is located in the engine coolant passage of the cylinder head for detecting the engine coolant temperature. The ECTS uses a thermistor whose resistance changes with the temperature.

The electrical resistance of the ECTS decreases as the temperature increases, and increases as the temperature decreases. The reference +5V is supplied to the ECTS via a resistor in the ECM. That is, the resistor in the ECM and the thermistor in the ECTS are connected in series. When the resistance value of the thermistor in the ECTS changes according to the engine coolant temperature, the output voltage also changes.

During cold engine operation, the ECM increases the fuel injection duration and controls the ignition timing using the information of engine coolant temperature to avoid engine stalling and improve drivability.

Specification

Temperature		Decistores (k0)
Ĵ	°F	Resistance (^k Ω)
-40	-40	48.14
-20	-4	14.13 ~ 16.83
0	32	5.79
20	68	2.31 ~ 2.59
40	104	1.15
60	140	0.59
80	176	0.32



STDFL0127N


FL-59

FL-60

021 62 99 92 92

Fuel System


Circuit Diagram



Engine Control System

Removal

- 1. Turn the ignition switch OFF and disconnect the battery negative (-) cable.
- 2. Disconnect the engine coolant temperature sensor connector (A).




Installation

- Install the component with the specified torques.
- Note that internal damage may occur when the component is dropped. In this case, use it after inspecting.

• Apply the engine coolant to the O-ring.

- Insert the sensor in the installation hole and be careful not to damage when installation.
- 1. Installation is reverse of removal.



SYFFL0002D

SXMF19135D

Note that engine coolant may be flowed out from the water temperature control assembly when removing the sensor.

4. Supplement the engine coolant (Refer to "Cooling System" in EM group).

FL-61

FL-62

021 62 99 92 92


Fuel System

Crankshaft Position Sensor (CKPS)

Description


Crankshaft Position Sensor (CKPS) detects the crankshaft position and is one of the most important sensors of the engine control system. If there is no CKPS signal input, the engine may stop because of CKPS signal missing. This sensor is installed on the cylinder block or the transaxle housing and generates alternating current by magnetic flux field which is made by the sensor and the target wheel when engine runs.

The target wheel consists of 58 slots and 2 missing slots on 360 degrees CA (Crank Angle).



EGRF245A

Wave Form



SBKFL9136L


WWW.DIGITALKHODRO.COM

021 62 99 92 92

FL-63

Engine Control System

Circuit Diagram




Fuel System

FL-64


Removal

- 1. Turn the ignition switch OFF and disconnect the battery negative (-) cable.
- 2. Disconnect the crankshaft position sensor connector (A).




3. Remove the protector (A).

SYFFL0003D



STFFL1005D

4. Remove the installation bolt (A), and then remove the crankshaft position sensor.



STFFL1006D

Installation

- Install the component with the specified torques.
- Note that internal damage may occur when the component is dropped. In this case, use it after inspecting.

CAUTION

Apply the engine oil to the O-ring.

CAUTION

Insert the sensor in the installation hole and be careful not to damage when installation.

1. Installation is reverse of removal.

Crankshaft position sensor installation bolt: 9.8 \sim 11.8 N.m (1.0 \sim 1.2 kgf.m, 7.2 \sim 8.7 lb-ft)

Crankshaft position sensor protector installation bolt (M8): 18.6 \sim 23.5 N.m (1.9 \sim 2.4 kgf.m, 13.7 \sim 17.4 lb-ft)

Crankshaft position sensor protector installation bolt (M6): 9.8 \sim 11.8 N.m (1.0 \sim 1.2 kgf.m, 7.2 \sim 8.7 lb-ft)

Engine Control System

Camshaft Position Sensor (CMPS)

Description


Camshaft Position Sensor (CMPS) is a hall sensor and detects the camshaft position by using a hall element.

It is related with Crankshaft Position Sensor (CKPS) and detects the piston position of each cylinder which the CKPS can't detect.

The CMPS is installed on engine head cover and uses a target wheel installed on the camshaft. The Cam Position sensor is a hall-effect type sensor. As the target wheel passes the Hall sensor, the magnetic field changes in the sensor. The sensor then switches a signal which creates a square wave.



Wave Form



SBKFL9136L

WWW.DIGITALKHODRO.COM

021 62 99 92 92


FL-65

Connector

Sensor

FL-66

Fuel System



Specification: Refer to "Wave Form"

Engine Control System

Removal

• DON'T remove the camshaft position sensor during engine running or right after engine stops, or a scald by the flowed out engine oil may occur.

[Bank 1 / Intake]


- 1. Turn the ignition switch OFF and disconnect the battery negative (-) cable.
- 2. Disconnect the camshaft position sensor connector (A).
- 3. Remove the installation bolt (B), and then remove the sensor.



ستال تعمیرکاران خودرودر ایران SXMF19142D

[Bank 1 / Exhaust]

- 1. Turn the ignition switch OFF and disconnect the battery negative (-) cable.
- 2. Disconnect the camshaft position sensor connector (A).
- 3. Remove the hanger and the protector.
- 4. Remove the installation bolt (B), and then remove the sensor.



STFFL1011L

Installation

- Install the component with the specified torques.
- Note that internal damage may occur when the component is dropped. In this case, use it after inspecting.

CAUTION

Apply the engine oil to the O-ring.

Insert the sensor in the installation hole and be careful not to damage when installation.

CAUTION

- Be careful not to damage the sensor housing and the connector.
- Be careful not to damage the O-ring.
- 1. Installation is reverse of removal.

Camshaft position sensor installation bolt: $9.8 \sim 11.8 \text{ N.m} (1.0 \sim 1.2 \text{ kgf.m}, 7.2 \sim 8.7 \text{ lb-ft})$

FL-67

FL-68


Fuel System

Knock Sensor (KS)


Description

Knocking is a phenomenon characterized by undesirable vibration and noise and can cause engine damage. Knock Sensor (KS) is installed on the cylinder block and senses engine knocking.

When knocking occurs, the vibration from the cylinder block is applied as pressure to the piezoelectric element. When a knock occurs, the sensor produces voltage signal. The ECM retards the ignition timing when knocking occurs. If the knocking disappears after retarding the ignition timing, the ECM will advance the ignition timing. This sequential control can improve engine power, torque and fuel economy.



Circuit Diagram



STFFL1012L


021 62 99 92 92

FL-69

Engine Control System

Removal

- 1. Turn the ignition switch OFF and disconnect the battery negative (-) cable.
- 2. Disconnect the knock sensor connector (A).



SXMF19144D

- 3. Remove the under cover (Refer to "Engine and Transaxle System" in EM group).
- 4. Remove the intake manifold stay (Refer to "Intake And Exhaust System" in EM group).
- 5. Remove the installation bolt (A), and then remove the sensor from the cylinder block.

SXMF19145D

Installation

- Install the component with the specified torques.
- Note that internal damage may occur when the component is dropped. In this case, use it after inspecting.
- 1. Installation is reverse of removal.

Knock sensor installation bolt:

18.6 \sim 23.5 N.m (1.9 \sim 2.4 kgf.m, 13.7 \sim 17.4 lb-ft)



FL-70

Fuel System

Heated Oxygen Sensor (HO2S)

Description

Heated Oxygen Sensor (HO2S) consists of zirconium and alumina and is installed both upstream and downstream of the Closed Coupled Catalytic Converter. It varies in accordance with the air/fuel ratio.

The sensor must be hot in order to operate normally. To keep it hot, the sensor has a heater which is controlled by the ECM via a duty cycle signal. When the exhaust gas temperature is lower than the specified value, the heater warms the sensor tip.



Specification

[Except Euro 5]

HO2S [Bank 1/Sensor 1] (Binary type)

A/F Ratio (λ)	Output Voltage(V)
RICH	Approx. 0.9
LEAN	Approx. 0.04
Item	Specification
Heater Resistance (Ω)	3.3 ~ 4.1Ω[21 °C(69.8°F)]

HO2S [Bank 1/Sensor 2] (Binary type)

A/F Ratio (λ)		Output Voltage(V)	
RICH		Approx. 0.9	
LEAN		Approx. 0.04	
Item		Specification	
	Heater Resistance (Ω)	3.3 ~ 4.1Ω[21 ℃(69.8°F)]	
_			

[Euro 5 only]

HO2S [Bank 1/Sensor 1] (Linear type)

الرکت دی	Specification
Heater Resistance (Ω)	2.5 ~ 4.0 [<mark>20℃(68°F)]</mark>


HO2S [Bank 1/Sensor 2] (Binary type)

A/F Ratio (λ)	Output Voltage(V)	
RICH	Approx. 0.9	
LEAN	Approx. 0.04	
ltem	Specification	
Heater Resistance (Ω)	3.3 ~ 4.1Ω[21 °C(69.8°F)]	

FL-71

Engine Control System

Circuit Diagram



FL-72

[Euro 5 only]

[Circuit Diagram]


HO2S [B1/S1] (CHG08)

Fuel System

[Connection Information]

CHG-K

ECM



Inspection

1. Turn the ignition switch OFF.

CHG08

HO2S [B1/S1]

- 2. Disconnect the HO2S connector.
- Measure resistance between the HO2S terminals 4 and 5 [B1/S1] (Euro 5 only).
 Measure resistance between the HO2S terminals 3 and 4 [B1/S1] (Except Euro 5).

E35

HO2S [B1/S2]

- 4. Measure resistance between the HO2S terminals 3 and 4 [B1/S2].
- 5. Check that the resistance is within the specification.

Specification: Refer to "Specification"

STFFL1014L

021 62 99 92 92

FL-73

Engine Control System

Removal

- 1. Turn the ignition switch OFF and disconnect the battery negative (-) cable.
- 2. Disconnect the connector (A), and then remove the sensor (B).


Note that the SST (Part No.: 09392-2H100) is useful when removing the heated oxygen sensor.

[Bank 1 / Sensor 1]



SYFFL0131D

[Bank 1 / Sensor 2]



SYFFL0141D

Installation

- Install the component with the specified torques.
- Note that internal damage may occur when the component is dropped. In this case, use it after inspecting.

CAUTION

- DON'T use a cleaner, spray, or grease to sensing element and connector of the sensor because oil component in them may malfunction the sensor performance.
- Sensor and its wiring may be damaged in case of contacting with the exhaust system (Exhaust Manifold, Catalytic Converter, and so on).
- 1. Installation is reverse of removal.

Heated oxygen sensor installation: $35 \sim 45$ N.m (3.6 \sim 4.6 kgf.m, 25.8 \sim 33.2 lb-ft)

WWW.DIGITALKHODRO.COM

FL-74

Fuel System


Accelerator Position Sensor (APS)

Description

Accelerator Position Sensor (APS) is installed on the accelerator pedal module and detects the rotation angle of the accelerator pedal. The APS is one of the most important sensors in engine control system, so it consists of the two sensors which adapt individual sensor power and ground line. The second sensor monitors the first sensor and its output voltage is half of the first one. If the ratio of the sensor 1 and 2 is out of the range (approximately 1/2), the diagnostic system judges that it is abnormal.


Specification

Accelerator	Output Voltage (V) [Vref = 5V]	
Position	APS1	APS2
C.T	0.7 ~ 0.8	0.29 ~ 0.46
W.O.T	3.85 ~ 4.35	1.93 ~ 2.18



Engine Control System

Circuit Diagram



Inspection

- 1. Connect the GDS on the Data Link Connector (DLC).
- 2. Turn the ignition switch ON.
- 3. Measure the output voltage of the APS 1 and 2 at C.T and W.O.T.

Specification: Refer to "Specification"

021 62 99 92 92

Fuel System

Injector

Description

Based on information from various sensors, the ECM can calculate the fuel amount to be injected. The fuel injector is a solenoid-operated valve and the fuel injection amount is controlled by length of injection time. The ECM controls each injector by grounding the control circuit. When the ECM energizes the injector by grounding the control circuit, the circuit voltage should be low (theoretically 0V) and the fuel is injected. When the ECM de-energizes the injector by opening control circuit, the fuel injector is closed and circuit voltage should momentarily peak.

Specification

ltem	Specification
Coil Resistance (Ω)	13.8 ~ 15.2 [20°℃(68°F)]






ولین سامانه دیچкբсբіо26 تعمیرکاران خودرو در ایران

Engine Control System

FL-77

Circuit Diagram



Inspection

- 1. Turn the ignition switch OFF.
- 2. Disconnect the injector connector.
- 3. Measure resistance between the injector terminals 1 and 2.
- 4. Check that the resistance is within the specification.

Specification: Refer to "Specification"

Fuel System

021 62 99 92 92


FL-78

Removal

- 1. Turn the ignition switch OFF and disconnect the battery negative (-) cable.
- 2. Release the residual pressure in fuel line (Refer to "Release Residual Pressure in Fuel Line" in this group).


When removing the fuel pump relay, a Diagnostic Trouble Code (DTC) may occur. Delete the code with the GDS after completion of "Release Residual Pressure in Fuel Line" work.

- 3. Disconnect the injector connector (A).
- 4. Remove the wiring harness bracket installation bolt (B).
- 5. Remove the installation nut, and then disconnect the fuel feed tube (C).
- 6. Remove the installation bolt (D), and then remove the delivery pipe & injector assembly from the engine.



SXMF19157D

7. Remove the fixing clip (A), and then separate the injector from the delivery pipe.



SXMF19158D

Installation

- Install the component with the specified torques.
- Note that internal damage may occur when the component is dropped. In this case, use it after inspecting.

Apply the engine oil to the injector O-ring.

Inspect the injector O-ring when installing.

1. Installation is reverse of removal.

Delivery pipe installation bolt: $18.6 \sim 23.5 \text{ N.m} (1.9 \sim 2.4 \text{ kgf.m}, 13.7 \sim 17.4 \text{ lb-ft})$ Delivery pipe installation nut (\leftrightarrow Fuel feed tube): $7.8 \sim 9.8 \text{ N.m} (0.8 \sim 1.0 \text{ kgf.m}, 5.8 \sim 7.2 \text{ lb-ft})$

Engine Control System

Purge Control Solenoid Valve (PCSV)

Description

Circuit Diagram

[Circuit Diagram]

Purge Control Solenoid Valve (PCSV) is installed on the surge tank and controls the passage between the canister and the intake manifold. It is a solenoid valve and is open when the ECM grounds the valve control line. When the passage is open (PCSV ON), fuel vapor stored in the canister is transferred to the intake manifold.

021 62 99 92 92




a ° (a a ° l

Specification

Item	Specification	
Coil Resistance (Ω)	19.0 ~ 22.0 [20℃(68	

	Coil Resistance (Ω)	19.0 ~ 22.0 [20 C(68 F)]
		0
	[Connection Information]	
(CHG-K)	. شبکت در	



Inspection

- 1. Turn the ignition switch OFF.
- 2. Disconnect the PCSV connector.
- 3. Measure resistance between the PCSV terminals 1 and 2.
- 4. Check that the resistance is within the specification.

Specification: Refer to "Specification"

STFFL1017L




Fuel System

021 62 99 92 92

FL-80

Removal

- 1. Turn the ignition switch OFF and disconnect the battery negative (-) cable.
- 2. Disconnect the purge control solenoid valve connector (A).
- 3. Disconnect the vapor hoses (B) from the purge control solenoid valve.



Installation


- Install the component with the specified torques.
- Note that internal damage may occur when the component is dropped. In this case, use it after inspecting.

- Be careful of foreign material not to flow into the valve.
- 1. Installation is reverse of removal.

Purge	control	solenoid	valve	bracket	installation
bolt: 9	.8 ~ 11.8	N.m (1.0 ~	⁻ 1.2 kg	f.m, 7.2 ~	8.7 lb-ft)

STFF11006D

4. Remove the valve in the direction of arrow after pressing the center part of the PCSV support bracket with the (-) driver.



STFF11130D

Engine Control System

CVVT Oil Control Valve (OCV)

Description

Continuous Variable Valve Timing (CVVT) system advances or retards the valve timing of the intake and exhaust valve in accordance with the ECM control signal which is calculated by the engine speed and load.

By controlling CVVT, the valve over-lap or under-lap occurs, which makes better fuel economy and reduces exhaust gases (NOx, HC) and improves engine performance through reduction of pumping loss, internal EGR effect, improvement of combustion stability, improvement of volumetric efficiency, and increase of expansion work.

This system consist of


- the CVVT Oil Control Valve (OCV) which supplies the engine oil to the cam phaser or runs out the engine oil from the cam phaser in accordance with the ECM PWM (Pulse With Modulation) control signal,
- and the Cam Phaser which varies the cam phase by using the hydraulic force of the engine oil.

The engine oil getting out of the CVVT oil control valve varies the cam phase in the direction (Intake Advance/Exhaust Retard) or opposite direction (Intake Retard/Exhaust Advance) of the engine rotation by rotating the rotor connected with the camshaft inside the cam phaser.

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



021 62 99 92 92




SBKFL9183L

Specification

Item	Specification	
Coil Resistance (Ω)	6.9 ~ 7.9 [20℃(68°F)]	

Fuel System



Specification: Refer to "Specification"

021 62 99 92 92

FL-83

Engine Control System

Removal

- 1. Turn the ignition switch OFF and disconnect the battery negative (-) cable.
- 2. Disconnect the CVVT oil control valve connector (A).
- 3. Remove the installation bolt (B), and then remove the valve from the engine.

[Bank 1 / Intake]

1. Installation is reverse of removal. CVVT oil control valve installation bolt: 9.8 ~ 11.8 N.m (1.0 ~ 1.2 kgf.m, 7.2 ~ 8.7 lb-ft) 洲 B -M SXMF19161D [Bank 1 / Exhaust] B в SXMF19162D

Installation

- Install the component with the specified torques.
- Note that internal damage may occur when the component is dropped. In this case, use it after inspecting.


• Apply the engine oil to the valve O-ring.

Fuel System

Variable Intake Solenoid (VIS) Valve

Description

Variable Intake manifold Solenoid (VIS) valve is installed on the intake manifold. The VIS valve controls the vacuum modulator which activates a valve in the intake manifold. The ECM opens or closes this valve according to engine condition (Refer to below table).




KFCF1029

Engine condition	VIS valve	Operation	
Medium speed	Closed	Increasing engine performance in low engine speed by reducing intake interference among cylinders	
I I OW / High speed I Upen		Minimizing intake resistance by shortening intake manifold length and increasing area of air entrance	

	Specification	
يتال خودرو سامانه (محمدود)	ltem برکت دید	Specification
	Coil resistance (Ω)	30.0 ~ 35.0 [20℃(68°F)]
نه دیجیتال تعا میر (ان	ولين ساما:	
Medium speed		
Low / High speed		
SNFFL9036N		

Engine Control System

Circuit Diagram




Inspection

- 1. Turn the ignition switch OFF.
- 2. Disconnect the VIS valve connector.
- 3. Measure resistance between VIS valve terminals 1 and 2.

Specification: Refer to "Specification"

Removal

- 1. Turn the ignition switch OFF and disconnect the battery negative (-) cable.
- 2. Disconnect the variable intake solenoid valve connector (A).
- 3. Disconnect the vacuum hoses (B) from the valve.
- 4. Remove the installation nut (C), and then remove the valve from the surge tank.



SXMF19165D


Installation

- Install the component with the specified torques.
- Note that internal damage may occur when the component is dropped. In this case, use it after inspecting.

- Be careful of foreign material not to flow into the valve.
- 1. Installation is reverse of removal.

Fuel Delivery System

Components Location



- 1. Fuel Tank
- 2. Fuel Pump
- 3. Fuel Filter
- 4. Fuel Pressure Regulator
- 5. Canister
- 6. Fuel Tank Air Filter

- 7. Fuel Tank Band
- 8. Fuel Filler Hose
- 9. Leveling Hose
- 10. Ventilation Hose
- 11. Vapor Tube
- 12. Fuel Pump Plate Cover

Fuel System

021 62 99 92 92

WWW.DIGITALKHODRO.COM

021 62 99 92 92

SYFFL0122L

Fuel Delivery System

Fuel Pressure Test


1. Release the residual pressure in fuel line (Refer to "Release Residual Pressure in Fuel Line" in this group).

When removing the fuel pump relay, a Diagnostic Trouble Code (DTC) may occur. Delete the code with the GDS after completion of "Release Residual Pressure in Fuel Line" work.

- 2. Install the Special Service Tool (SST).
 - 1) Disconnect the fuel feed tube from the delivery pipe.

There may be some residual pressure even after "Release Residual Pressure in Fuel Line" work, so cover the hose connection with a shop towel to prevent residual fuel from spilling out before disconnecting any fuel connection.

2) Install the special service tool for measuring the fuel pressure in between the fuel feed tube and the fuel delivery pipe (Refer to the figure below).



STDFL0144N

3. Inspect fuel leakage on connections among the fuel feed tube, the delivery pipe, and the SST components with IG ON.

- 4. Measure Fuel Pressure.
- Start the engine and measure the fuel pressure at idle.

Fuel Pressure: 343 kPa (3.50 kgf/cm², 49.7 psi)

If the fuel pressure differs from the standard value, repair or replace the related part (Refer to the table below).

Fuel Pressure	Cause	Related Part
	Fuel filter clogged	Fuel Filter
Too Low	Fuel leakage	Fuel Pressure Regulator
Too High	Fuel pressure regulator valve stuck	Fuel Pressure Regulator

2) Stop the engine, and then check for the change in the fuel pressure gauge reading.

Standard Value: The gauge reading should hold for about 5 minutes after the engine stops

If the gauge reading should not be held, repair or replace the related part (Refer to the table below).

Fuel Pressure (After Engine Stops)	Cause	Related Part
Fuel Pressure Drops Slowly	Leakage on injector	Injector
Fuel Pressure Drops Immediately	Check valve of fuel pump stuck open	Fuel Pump

- 3) Turn the ignition switch OFF.
- 5. Release the residual pressure in fuel line (Refer to "Release Residual Pressure in Fuel Line").

When removing the fuel pump relay, a Diagnostic Trouble Code (DTC) may occur. Delete the code with the GDS after completion of "Release Residual Pressure in Fuel Line" work.

- 6. Test End
 - Remove the Special Service Tool (SST) from the fuel feed tube and the delivery pipe.
 - 2) Connect the fuel feed tube and the delivery pipe.

<u>FL-87</u>

021 62 99 92 92


Fuel System

Release Residual Pressure in Fuel Line

FL-88

There may be some residual pressure even after "Release Residual Pressure in Fuel Line" work, so cover the hose connection with a shop towel to prevent residual fuel from spilling out before disconnecting any fuel connection.

- 1. Turn the ignition switch OFF and disconnect the battery (-) cable.
- 2. Remove the fuel pump relay (A).





CAUTION

- 3. Connect the battery (-) cable.
- 4. Start the engine and let idle, and then turn the ignition switch OFF after the engine has stopped on its own.
- 5. Disconnect the battery (-) cable, and then install the fuel pump relay (A).
- 6. Connect the battery (-) cable.
- 7. Delete the Diagnostic Trouble Code (DTC) related the fuel pump relay with the GDS.

021 62 99 92 92

FL-89

Fuel Delivery System

Fuel Tank

Removal

- 1. Release the residual pressure in fuel line (Refer to "Release Residual Pressure in Fuel Line" in this group).
- 2. Open the trunk and remove the floor mat.
- 3. Remove the fuel pump service cover (A).
- A Disconnect the fuel pump connector (A).
 5 Disconnect the fuel feed tube quick connector (B).

SYFFL0100L

- 6. Lift the vehicle and support the fuel tank with a jack.
- Remove the center muffler assembly (Refer to "Intake And Exhaust System" in EM group).
- Disconnect the fuel filler hose (A) and leveling hose (B).



Fuel System

021 62 99 92 92

FL-90

10. Remove the brake line bracket (A).



1. Installation is reverse of removal.

Fuel tank band installation nut:

 $39.2 \simeq 54.0$ N.m (4.0 $\simeq 5.5$ kgf.m, 28.9 $\simeq 39.8$ lb-ft)






SYFFL0130L

SYFFL0120L

MOTICE

Remove the fuel tank band as below.




SYFFL0260D

Fuel Delivery System


Fuel Pump

Removal

- 1. Release the residual pressure in fuel line (Refer to "Release Residual Pressure in Fuel Line" in this group).
- 2. Open the trunk and remove the floor mat.
- 3. Remove the fuel pump service cover (A).



- 4. Disconnect the fuel pump connector (A).
- 5. Disconnect the fuel feed tube quick connector (B).
- 6. Remove the plate cover (C) after removing the installation bolt, and then remove the fuel pump from the fuel tank.



SYFFL0123D


Installation

1. Installation is reverse of removal.

Fuel pump plate cover installation bolt: $2.0 \sim 2.9$ N.m ($0.2 \sim 0.3$ kgf.m, $1.4 \sim 2.2$ lb-ft)

CAUTION

Be careful of fuel pump direction when installing (Refer to the groove in the fuel tank).



SYFFL0101L

FL-91

FL-92

Fuel System

4. Remove the return nozzle (B) after releasing the

fixing hook (A).


Fuel Filter

Replacement

- 1. Remove the fuel pump (Refer to "Fuel Pump" in this group).
- 2. Disconnect the electric pump wiring connector (A) and the fuel sender connector (B).
- Α в В SYFFL0310D 5. Remove the reservoir-cup (B) after releasing the fixing hooks (A). SYFFL0280D 3. Remove the cushion pipe fixing clip (C), and then separate the head assembly (D). в SYFFL0300D Ċ SYFFL0290D

Fuel Delivery System

6. Remove the pre-filter (C) after releasing the fixing hooks (A,B).



SYFFL0320D

AUTION Be careful of O-ring.

7. Separate the electric pump motor (A) from the fuel filter (B).



SYFFL0330D

8. Replace new fuel filter.

021 62 99 92 92

021 62 99 92 92

WWW.DIGITALKHODRO.COM

Fuel System


021 62 99 92 92

FL-94


Filler-Neck Assembly

Removal

- 1. Lift the vehicle.
- 2. Disconnect the fuel filler hose (A) and the leveling hose (B).
- 3. Disconnect the ventilation hose (C) from the fuel tank air filter.



- 5. Remove the rear-LH wheel, tire, and the inner wheel house.
- 6. Remove the filler-neck assembly from the vehicle after removing the bracket installation bolt (A).



SYFFL0270D

Installation

1. Installation is reverse of removal.

Filler-neck assembly bracket installation bolt : $3.9 \sim 5.9$ N.m (0.4 \sim 0.6 kgf.m, 2.9 \sim 4.3 lb-ft)


Fuel Delivery System

WWW.DIGITALKHODRO.COM

Accelerator Pedal

Removal

- 1. Turn the ignition switch OFF and disconnect the negative (-) battery cable.
- Disconnect the accelerator position sensor connector (A).




SLMF10409D stallation bolt (B) and nuts (C)

B

SXMFL9265D

3. Remove the installation bolt (B) and nuts (C), and then remove the accelerator pedal module.



SLMF10240D

Installation

1. Installation is reverse of removal.

Accelerator pedal module installation bolt: $8.8 \sim 13.7 \text{ N.m} (0.9 \sim 1.4 \text{ kgf.m}, 6.5 \sim 10.1 \text{ lb-ft})$ Accelerator pedal module installation nut: $9.8 \sim 14.7 \text{ N.m} (1.0 \sim 1.5 \text{ kgf.m}, 7.2 \sim 10.9 \text{ lb-ft})$

FL-95

Delivery Pipe

Removal

- 1. Turn the ignition switch OFF and disconnect the battery negative (-) cable.
- 2. Release the residual pressure in fuel line (Refer to "Release Residual Pressure in Fuel Line" in this group).

ACAUTION

When removing the fuel pump relay, a Diagnostic Trouble Code (DTC) may occur. Delete the code with the GDS after completion of "Release **Residual Pressure in Fuel Line" work.**

- 3. Disconnect the injector connector (A).
- 4. Remove the wiring harness bracket installation bolt (B).
- 5. Remove the installation nut, and then disconnect the fuel feed tube (C).
- 6. Remove the installation bolt (D), and then remove the delivery pipe & injector assembly from the engine.

Installation

1. Installation is reverse of removal.


Delivery pipe installation bolt: 18.6 ~ 23.5 N.m (1.9 ~ 2.4 kgf.m, 13.7 ~ 17.4 lb-ft) Delivery pipe installation nut (↔ Fuel feed tube): 7.8 ~ 9.8 N.m (0.8 ~ 1.0 kgf.m, 5.8 ~ 7.2 lb-ft)



021 62 99 92 92

SXMF19157D

SXMF10158L





Fuel System