

DS-2

Driveshaft and axle

General Information

SPECIFICATION

PROPELLER SHAFT

Items			Specification
Joint type	Front		UJ + UJ
	Rear		UJ + UJ
Length X O.D. (mm(in))	Front(4WD)	Diesel 2.5 VGT A/T	675 X 63.5 (26.57 X 2.50) (Blue)
		Diesel 2.5 VGT M/T	640.8 X 63.5 (25.23 X 2.50) (Green)
		Diesel 2.5 WGT A/T, M/T	660.4 X 63.5 (26.00 X 2.50) (Yellow)
		Gasoline 3.3/3.8 A/T	625.5 X 63.5 (24.63 X 2.50) (Silver)
	Rear(4WD)	Diesel 2.5 VGT A/T	1123 X 76.2 (44.21 X 3.00) (Blue)
		Diesel 2.5 VGT M/T	1156 X 76.2 (45.51 X 3.00) (Green)
		Diesel 2.5 WGT A/T, M/T	1137 X 76.2 (44.76 X 3.00) (Yellow)
		Gasoline 3.3/3.8 A/T	1172 X 76.2 (46.14 X 3.00) (Silver)
	Rear(2WD)	Diesel 2.5 VGT A/T	1462.8 X 76.2 (57.59 X 3.00) (Green)
		Diesel 2.5 WGT A/T	1476 X 76.2 (58.11 X 3.00) (Blue)
		Diesel 2.5 WGT M/T	1496 X 76.2 (58.90 X 3.00) (Yellow)
		Gasoline 3.3/3.8 A/T	1531.6 X 76.2 (60.30 X 3.00) (Silver)
Run-out (mm(in))			0.3 (0.01)

UJ : Universal Joint

O.D. : Outer Diameter

General Information

DS-3

FRONT AXLE AND DRIVESHAFT

Items			Specification
Front axle hub bearing type			Double taper roller bearing
Driveshaft joint type (4WD)		Outer	BJ
		Inner	TSJ
Differential (4WD)	Reduction gear type		Hypoid gear
	Reduction ratio	Diesel 2.5 WGT M/T	4.181 (White)
		Diesel 2.5 VGT M/T	3.727 (Red)
		Diesel 2.5 WGT A/T Diesel 2.5 VGT A/T	3.333 (Green)
		Gasoline 3.3/3.8 A/T	3.333 (Green)

BJ : Birfield Joint, TSJ : Three Spherical Joint

REAR AXLE AND AXLE SHAFT

Items			Specification
Axle housing type			Banjo type
Axle shaft supporting type			Semi-floating type
Differential	Reduction gear type		Hypoid gear
	Reduction ratio	Diesel 2.5 WGT M/T	4.181 (White)
		Diesel 2.5 VGT M/T	3.727 (Red)
		Diesel 2.5 WGT A/T Diesel 2.5 VGT A/T	3.333 (Green)
		Gasoline 3.3/3.8 A/T	3.333 (Green)






LUBRICANTS

Items		Specification	Quantity
Driveshaft	BJ Boot grease	Repair kit grease	210g
	TSJ Boot grease	Repair kit grease	150g
Differential	Hypoid gear oil	SAE90, API GL-5 (MOBIL : MOBIL LUBE HD, SHELL : SHELL SPIRAX HD)	(Fill the reservoir to the plug hole) Front : 1.3L Rear : 1.6L
	LSD oil	SAE 85W-90, API GL-5 (MOBIL : INFILREX 33, SK : G-LS)	

DS-4







Driveshaft and axle

SPECIAL TOOL

Tool (Number and Name)	Illustration	Use
Bushing remover and installer 09216-21100		Press-fitting of the inner shaft housing dust seal
Bearing outer race installer 09432-33700		Installation of the front hub bearing (Use with 09500-21000)
Bar 09500-21000		Installation of the front hub bearing (Use with 09432-33700)
Draft 09517-21400		Removal of the outer race from the carrier
Universal joint remover 09493-43000		Removal and installation of the journal bearing





General Information

DS-5

Tool (Number and Name)	Illustration	Use
Oil seal installer 09517-21000		Press-fitting of the differential drive pinion oil seal (Use with 09500-21000)
Remove plate 09527-4A000		Removal of the differential drive pinion inner bearing
Bearing puller 09517-43001		<ul style="list-style-type: none"> Removal of the front lower arm ball joint Removal of the differential side bearing
Preload socket 09532-11600		Measurement of the drive pinion starting torque (Use with torque wrench)
Oil seal installer 09532-32000		Installation of the differential drive pinion front bearing outer race
Oil seal installer 09542-4A000		Press-fitting of the oil seal into knuckle (Use with 09500-11000)






DS-6

Driveshaft and axle

Tool (Number and Name)	Illustration	Use
Ball joint remover 0K670 321 019		Disconnection of the tie rod ball joint
Oil seal installer 09532-32100B		Installation of the differential drive pinion rear bearing outer race (Use with 09500-11000)
Working base 09517-43401		Supporting for the differential carrier
End yoke holder 09517-21700		Removal and installation of the differential self-locking nut

General Information

DS-7

Tool (Number and Name)	Illustration	Use
Drive pinion OK993 270 A09		For adjusting height of drive pinion
Gauge block OK993 270 A08		
Drive pinion model OK993 270 A10		
Adjusting nut wrench OK993 270 014		For adjusting screw disassembly
LSD test adapter 09530-FM000		For testing of LSD performance.

DS-8

Driveshaft and axle


TROUBLESHOOTING

Symptom		Probable cause	Remedy
Propeller shaft	Noise at start	Worn journal bearing	Replace
		Worn sleeve yoke spline or flange yoke	Replace
		Loose propeller shaft installation	Retighten
	Noise and vibration at high speed	Unbalanced propeller shaft	Replace
		Improper snap ring selection	Adjust the clearance
		Worn journal bearing	Replace
Drive shaft, Inner shaft	Noise during wheel rotation	Housing tube bent	Replace
		Inner shaft bent	
		Inner shaft bearing worn, pounding	Replace
		Drive shaft assembly worn damaged, bent	Check or replace
	Noise due to excessive play of wheel in turning direction	Inner shaft and side gear serration play	Replace
		Drive shaft and side gear serration play	
Axle shaft, axle housing	Noise while wheels are rotating	Bent axle shaft	Replace
		Worn or scarred axle shaft bearing	Replace
	Grease leakage	Worn or damaged oil seal	Replace
		Malfunction of bearing seal	Replace
Differential	Constant noise	Improper drive gear and drive pinion gear tooth contact	Correct or replace
		Loose, worn or damaged side bearing	
		Loose, worn or damaged drive pinion bearing	
		Worn drive gear, drive pinion	
		Worn side gear thrust washer or pinion shaft	
		Deformed drive gear of differential case	
		Damaged gear	
		Foreign material	Eliminate the foreign (Replace the parts if necessary)
		Insufficient oil	Replenish

General Information

DS-9

Symptom		Probable cause	Remedy
Differential	Gear noise while driving	Poor gear engagement	Correct or replace
		Improper gear adjustment	
		Improper drive pinion preload adjustment	
		Damaged gear	Replace
		Foreign material	Eliminate the foreign material and check (Replace the parts if necessary)
		Insufficient oil	Replenish
	Gear noise while coasting	Improper drive pinion preload adjustment	Correct or replace
		Damaged gear	Replace
	Bearing noise while driving or coasting	Cracked or damaged drive pinion rear bearing	Replace
	Noise while turning	Loose side bearing	Replace
		Damaged side gear, pinion gear or pinion shaft	
	Heat	Improper gear backlash	Adjust
		Excessive preload	
		Insufficient oil	Replenish
	Oil leakage	Differential carrier not tightened	Retighten, apply sealant, or replace the gasket
		Seal malfunction	
		Worn or damaged oil seal	Replace
		Excessive oil	Adjust the oil level

DS-10**Driveshaft and axle****Driveshaft Assembly****Front Driveshaft****COMPONENTS (T.S.J.-B.J.)**



- | | |
|----------------------------|-------------------------------|
| 1. B.J assembly | 7. T.S.J boot band |
| 2. B.J inner race and ball | 8. T.S.J boot |
| 3. Snap ring | 9. Circlip |
| 4. B.J boot | 10. T.S.J inner race and ball |
| 5. B.J boot band | 11. Snap ring |
| 6. Drive shaft | 12. T.S.J assembly |
| | 13. Circlip |

LIAC008A

Driveshaft Assembly


DS-11

REPAIR KIT

Kit name	Illustration	Components
T.S.J boot kit		<ul style="list-style-type: none"> • T.S.J boot band • T.S.J boot • Snap ring • Spider assembly • Snap ring • T.S.J assembly • Clip • Grease
B.J boot kit		<ul style="list-style-type: none"> • B.J assembly • B.J inner race and ball • Snap ring • B.J boot • B.J boot band • Grease

دیجیتال خودرو
شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




DS-12

Driveshaft and axle


INSPECTION

1. Inspect for torn or loose CV joint boots.



LIAC005A


2. Test for loose drive shaft splines. By grasping the drive shaft and tugging up and down and fore and aft.
3. Also inspect for bent or broken drive shaft.



LIAC005B


REMOVAL (HALFSHAFTS)

1. Remove the lock nut from front hub.




LJAC019C

2. Remove the upper control arm link lock bolt, spring washer and nut.



LHAC005E

3. Remove tie rod end cotter pin and using a ball joint puller, remove tie rod end from steering knuckle.



OK670-321-019

APAC015B


Driveshaft Assembly

DS-13

4. Mark drive shaft for identical installation position.
5. Using tool, pry the drive shaft from the differential housing.

NOTICE

- Do not pull on the drive shaft ; doing so will damage the boots. Be sure to use the pry bar.




LIAC006G

6. Remove the drive shaft from the knuckle

NOTICE

- Temporarily install the knuckle to the upper arm.



LIAC006F

INSTALLATION

1. Coincide the joining mark between the drive shaft and the differential and insert the shaft.

CAUTION

- Insert the drive shaft (RH side) carefully into the oil seal to avoid any damage.

2. Install the knuckle assembly and tighten.

- 1) Tie-rod ball joint

Tightening torque :

70-80 N·m (7.0-8.0 kg·m, 51-57 lb·ft)

- 2) Upper arm link lock bolt


Tightening torque :

44-55 N·m (4.4-5.5 kg·m, 32-39 lb·ft)

3. Tighten the lock nut and then caulk the flange of lock nut on the end of drive shaft.

Tightening torque :

245-275 N·m (24.5-27.5 kg·m, 177-198 lb·ft)



LIAC007E

4. Install wheel and tire.

DS-14

Driveshaft and axle

DISASSEMBLY


NOTICE

1. Do not disassemble the B.J assembly.
2. The Drive shaft joint uses special grease. Do not substitute with another type of grease.
3. The Boot band should be replaced with a new one.

1. Remove the T.S.J boot band and pull the boot from T.S.J outer race.


NOTICE

Be careful not to damage it.



LIAC009A

2. Remove the clip using a screwdriver.




LIAC009B

3. Remove the drive shaft from the T.S.J outer race.
4. Remove the snap ring and disassemble the inner race and ball from the shaft.
5. Remove the B.J boot band and pull out the T.S.J boot and the B.J boot.

CAUTION

If the boot is reused, wrap a tape around the drive shaft splines to protect the boot.




LIAC009D

REASSEMBLY

1. Wrap a tape around the drive shaft spline (T.S.J side) to avoid boot damage.
2. Apply specified grease to the drive shaft and install the boots.

Items	Quantity (gr.)
B.J	170
T.S.J	140




LIAC011A

3. Add specified grease as much as was wiped away at the time of inspection.
4. Tighten the boot bands.

CAUTION

Keep the specified distance between the boot bands to control the air when they are tightened.



LIAC011B


Driveshaft Assembly

DS-15

Center Bearing And Inner Shaft


REMOVAL (OUTPUT SHAFT)

1. Remove diff mounting bracket.



LIAC012A

2. Remove output shaft from differential housing.




LIAC012B

INSTALLATION

1. Install output shaft to differential case.

Tightening torque :

80-120 N·m (8-12 kg·m, 58-86 lb·ft)



LIAC012B


⚠ CAUTION

- Be carefully that oil seal does not damage by clip during install.

2. Install diff mounting bracket to the bearing housing.

Tightening torque :

110-150 N·m (11-15 kg·m, 80-108 lb·ft)




LIAC012A

3. Tighten diff mounting bracket bolt.


DISASSEMBLY

1. Remove axle clip using plier.



LIAC013A

2. Remove output shaft housing.




LIAC013B

DS-16

Driveshaft and axle

3. Using a hydraulic press, remove bearing housing from the output shaft.



LIAC013C

4. Remove dust seal and then using a hydraulic press, remove bearing.

INSPECTION

- Output shaft for damage.
- Bearing for roughness or noise.
- Dust seal for damage.
- Bearing housing for cracks.

REASSEMBLY (OUTPUT SHAFT)

1. Install dust seal into bearing housing.

NOTICE


- Apply the grease on the lip of dust seal.



LIAC014A

2. Using a hydraulic press, install bearing onto output shaft.

3. Using a hydraulic press, install shaft with bearing into bearing housing.




LIAC014B

4. Install the output shaft housing to the bearing housing.


Tightening torque :

71-95 N·m (7.1-9.5 kg·m, 51-68 lb·ft)



LIAC013B

5. Using a plier, install new clip onto output shaft.



LIAC013A


Front Axle Assembly

DS-17

Front Axle Assembly

INSPECTION

1. Remove two bolts and remove brake caliper from brake rotor. Temporarily tie caliper to vehicle frame with wire.
2. Mount dial indicator with plunger zeroed against brake rotor at 4.7 inch (12 cm) from rotor center.



LIAC016A

3. Turn rotor and read dial indicator for run out dimension.

Run out not to exceed 0.0012 in (0.03 mm)



شرکت دیجیتال خودرو (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران


DS-18

Driveshaft and axle

Front Hub - Axle


REMOVAL

1. Remove the vehicle speed sensor.
2. Remove two bolts and remove brake caliper from brake rotor. Temporarily tie caliper to vehicle frame with wire.




LJAC019D

3. Remove two screws and remove brake rotor.
4. Using a lock nut wrench (or equivalent), remove lock nut and plain washer (2WD).




LJAC019C

5. Remove the upper arm link lock bolt, spring washer and nut.



LHAC005E


6. Remove tie rod end cotter pin and using a ball joint remover, remove tie rod end from steering knuckle.



OK670-321-019

APAC015B

7. Remove lower arm cotter pin using a ball joint remover, and remove lower arm from steering knuckle.



LIAC017A

8. Remove steering knuckle from vehicle.

Front Axle Assembly


DS-19

INSTALLATION

1. Put steering knuckle on the drive shaft end with upper and lower ball joints in mounting holes.
2. Attach lower arm, tighten lock nut, and install cotter pin.

Tightening torque :

160-180 N·m (16.0-18.0 kg·m, 116-130 lb·ft)




LIAC021B

3. Attach tie rod end to knuckle, tighten nut, and install cotter pin.

Tightening torque :

70-80 N·m (7.0-8.0 kg·m, 51-57 lb·ft)




LIAC021C

4. Insert upper arm link lock bolt with spring washer and tighten nut.


Tightening torque :

44-55 N·m (4.4-5.5 kg·m, 32-39 lb·ft)



LHAC017B

5. Install the chamfer of plain washer toward the bearing (2WD)



BIAD021G


6. Screw lock nut up against wheel hub assembly and using a lock nut wrench, tighten nut to tightening torque to set bearing preload. Use spring scale to measure.

Bearing preload :

10 lb·in (Max 60 kg·cm)

Tightening torque :

245-275 N·m (24.5-27.5 kg·m, 178-198 lb·ft)




LIAC021H

7. Caulk the flange of lock nut on the end of drive shaft.
8. Put brake rotor on wheel bearing hub bolts and install the two retaining screws.

DS-20

Driveshaft and axle

9. Mount dial indicator with plunger zeroed against brake rotor at 4.7 in (12 cm) from rotor center.



LIAC021I


10. Turn rotor and read dial indicator for run out dimension.

Run out not to exceed 0.0012 inch (0.03 mm)

11. Install brake caliper and tighten two bolts.

Tightening torque :

80-104 N·m (8.0-10.4 kg·m, 57-75 lb·ft)




LJAC019D

12. Install wheel and tire.

DISASSEMBLY


1. Using a screwdriver, pry out oil seal from knuckle (4WD).



LIAC018A

2. Press the wheel hub from the knuckle (4WD).

Press the knuckle and then remove wheel hub (2WD).



LIAC018C

INSPECTION

1. Inspect bearing for wear or damage.
2. Inspect steering knuckle for wear or damage.

REASSEMBLY

1. Install the dust cover to the knuckle.

Tightening torque :

16-23 N·m (1.6-2.3 kg·m, 12-16 lb·ft)

2. Install new oil seal and then install the wheel hub to the knuckle by pressing.
3. Apply grease to the wheel bearing and seal lip.

Rear Axle Assembly

DS-21


Rear Axle Assembly

SERVICE INSPECTION PROCEDURE

AXLE SHAFT END PLAY CHECK

1. Measure the axle shaft end play using a dial indicator.

Standard value : 0-0.05mm (0-0.002 in.)



LIAC030A

2. If the axle shaft end play exceeds the standard value, replace the bearing with a new one.

GEAR OIL LEVEL CHECK

1. Remove the filler plug and check the quantity of oil in the differential carrier.
2. It is enough if oil is applied until the filler plug.

Specified gear oil :

Hipoid gear oil


Conventional differential

SAE90, API GL-5

With Limited Slip Differential

SAE85W90, API GL-5

SPECIFIED GEAR OIL QUANTITY : 1.6 Liter



LIAC030B


DS-22

Driveshaft and axle

Rear Axle Shaft Assembly


REMOVAL

1. Remove the disk brake and parking brake assembly (Refer to "BR Group").
2. Remove the parking brake cable and speed sensor cable.
3. Remove the rear axle shaft mounting bolt.




LIAC034B

4. Remove the rear axle shaft.



LIAC033A

5. Using the special tool (09526-11100), remove the oil seal.




09526-11100

LIAC033B

INSTALLATION

1. Installation is the reverse of removal.
2. Apply grease to the oil seal lip.
3. Using the special tools (09500-11000, 09532-11500), install the oil seal.




LIAC034A

4. After installing the axle shaft, tighten the nut.

Tightening torque :

43-60 N·m (4.4-6.2 kg·m, 32-44 lb·ft)



LIAC034B

5. Adjust the parking brake lever stroke.


Propeller Shaft Assembly

DS-23

Propeller Shaft Assembly

Propeller Shaft

COMPONENTS




DS-24

Driveshaft and axle

LIAC040A

INSPECTION


1. Check the sleeve yoke, center yoke and flange yoke for wear, damage or cracks.
2. Check the propeller shaft yokes for wear, damage or cracks.
3. Check the propeller shaft for bends, twisting or damage.
4. Check the universal joints for smooth operation in all directions.



LIAC043A

5. Check the center bearing for smooth movement (2WD).
6. Check the center bearing mounting rubber for damage or deterioration (4WD).
7. Measure the propeller shaft run out with a dial indicator.


Limit	Front	0.3 mm (0.012 in.) or less
	Rear	0.3 mm (0.012 in.) or less



LIAC043B

REMOVAL


1. Raise and support vehicle.
2. Place index marks (reference marks) on the propeller shaft and their matching transfer case and differential input shafts.



LIAC042A

3. Remove four bolts holding universal flange to transfer case (4WD).

Remove bolts holding center bearing bracket (2WD).



LIAC042B

4. Remove four bolts holding universal flange to differential.
5. Remove propeller shaft.

NOTICE

- When removing the propeller shaft, be careful not to damage the dust cover or spline.

Propeller Shaft Assembly

DS-25

INSTALLATION

1. Connect propeller shaft flange to companion flange on front differential (4WD).
 - a. Align index marks on the flange and connect the flanges with four bolts and nuts.
 - b. Tighten the bolts and nuts.


Tightening torque :

26-30 N·m (2.6-3.0 kg·m, 19-21 lb·ft)

- Full time 4WD

50-60 N·m (5.0-6.0 kg·m, 36-43 lb·ft)

- Part time 4WD




LIAC044A

2. Connect front propeller shaft flange to companion flange on transfer (4WD).
 - a. Align index marks on the flange and connect the flanges with four bolts and nuts.
 - b. Tighten the bolts.

Tightening torque :

50-60 N·m (5.0-6.0 kg·m, 36-43 lb·ft)




LIAC044B

3. Connect rear propeller shaft flange to companion flange on transfer. (4WD)
 - a. Align index marks on the flange and connect the flanges with four bolts and nuts.

- b. Tighten the bolts.

Tightening torque :

50-60 N·m (5.0-6.0 kg·m, 36-43 lb·ft)




LIAC044D

4. Connect the propeller shaft spline to transmission (2WD)
 - a. Align index mark on the spline and then install the propeller shaft.
 - b. Tighten the bolts holding the center bearing bracket.

Tightening torque :

37-54 N·m (3.7-5.4 kg·m, 27-39 lb·ft)



LIAC042B

⚠ CAUTION

- Be careful not to damage the dust cover of propeller shaft when installing the propeller shaft (2WD)


5. Connect propeller shaft flange to companion flange on rear differential.
 - a. Align index marks on the flange and connect the flange with four bolts and nuts.
 - b. Tighten the bolts and nuts.

Tightening torque :

50-60 N·m (5.0-6.0 kg·m, 36-43 lb·ft)

DS-26

Driveshaft and axle



LIAC044F

6. After installing the propeller shaft fill the grease into the nipple until it comes out from the sleeve yoke plug hole.

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




Differential Carrier Assembly

DS-27

Differential Carrier Assembly

Front Differential Carrier(4WD)

Components




LIAC070A

DS-28

Driveshaft and axle

Front differential components



TORQUE : N·m (kg·m, lb·ft)

- | | | |
|--------------------------|----------------------|-------------------|
| 1. Bearing cap bolt. | 10. Oil seal | 19. Thrust washer |
| 2. Bearing cap | 11. Oil slinger | 20. Side gear |
| 3. Differential assembly | 12. Outer bearing | 21. Washer |
| 4. Spacer | 13. Distance piece | 22. Pinion shaft |
| 5. Side bearing | 14. Inner bearing | 23. Pinion gear |
| 6. Ring gear | 15. Spacer | 24. Case |
| 7. Companion flange | 16. Drive pinion | 25. Actuator |
| 8. Lock nut | 17. Carrier assembly | 26. Hose |
| 9. Lock washer | 18. Pin | 27. Packing |


LIAD074A

Differential Carrier Assembly

DS-29

Removal

1. Drain oil.




LIAC071A

2. Remove the drive shaft and the output shaft.

CAUTION

When removing the drive shaft, be careful not to damage the differential carrier oil seal by interference of spline part.




LIAC071C

3. Remove the front propeller shaft.

NOTICE

Make match mark on the flange yoke and differential companion flange to avoid any mistake when installing them again.




LIAC044F

4. Remove the power steering tube mounting bracket.


Tightening torque :

18-23 N·m (1.8-2.3 kg·m, 13-16 lb·ft)




LIAC071B

5. Remove the differential mounting bracket.



LIAC071E

6. Remove the front member.



LIAC071F

7. Remove the differential mounting bolt.
8. Remove the differential carrier.


DS-30

Driveshaft and axle

Installation

1. Installation is the reverse of removal.
2. Align the matchmark on the flange yoke and the companion flange.


Tighten the propeller shaft and the front differential carrier.



LIAC044F

INSPECTION BEFORE DISASSEMBLY

Mount the differential carrier on the special tool(09517-43401).



09517-43401

LIAC072A


FINAL DRIVE GEAR BACKLASH

1. Fix the drive gear so it cannot move and measure the final drive gearbacklash with a dial indicator.

NOTICE

Measure at four points or more on the circumference of the drive gear.

Standard value : 0.09-0.11mm (0.0035-0.0043 in.)



LIAC072B

DRIVE GEAR RUNOUT

Check the back-face lash as follows:


1. Place a dial gauge on the back-face of the drive gear and measure the runout.

Limit : 0.05 mm (0.0020 in.)

2. If the runout is beyond the limit, check that there are no foreign substances between the drive gear and differential case and, that the bolts fixing the drive gear are not loose.
3. If nothing is wrong in check (2), adjust the drive gear depth and remeasure.

NOTICE

If these adjustments are impossible, replace the case or install a new drive gear/drive pinion as a set.



LIAC072C

Differential Carrier Assembly

DS-31


DIFFERENTIAL GEAR BACKLASH

1. Fix the side gear with a wedge so it cannot move and measure the differential gear backlash with a dial indicator on the pinion gear.

NOTICE

Take the measurements at two places (4 places for LSD) on the pinion gear.

Standard value : 0-0.1 mm (0-0.0039 in.)



LIAC072D

2. If the backlash exceeds the limit, adjust using side bearing spacers.


NOTICE

If adjustment is impossible, replace the side gear and pinion gears as a set.

FINAL DRIVE GEAR TOOTH CONTACT

Check the final drive gear tooth contact by following the steps below :

1. Apply the same amount of machine blue slightly to both surfaces of the drive gear teeth.




LIAC072E

2. Insert a brass rod between the differential carrier and the differential case, and then rotate the companion flange by hand (once in the normal direction, and then once in the reverse direction) while applying a load to the drive gear so that some torque (approximately 25-30 kg-cm) is applied to the drive pinion.

CAUTION

If the drive gear is rotated too much, the tooth contact pattern will become unclear and difficult to check.

3. Check the tooth contact pattern.




LIAC072F

DS-32

Driveshaft and axle

Standard tooth contact pattern


1. Narrow tooth side
2. >Drive-side tooth surface (the side receiving power during acceleration)
3. Wide tooth side
4. Coast-side tooth surface (the side receiving power during coast-down)



Problem

Solution

Tooth contact pattern resulting from excessive pinion height




The drive pinion is positioned too far from the center of the drive gear.

Increase the thickness of the pinion height adjusting shim, and position the drive pinion closer to the center of the drive gear.

Also, for backlash adjustment, reposition the drive gear further from the drive pinion.

Tooth contact pattern resulting from insufficient pinion height



The drive pinion is positioned too close to the center of the drive gear.

Decrease the thickness of the pinion height adjusting shim, and position the drive pinion further from the center of the drive gear.

Also, for backlash adjustment, reposition the drive gear closer to the drive pinion.

- Tooth contact pattern is a method for judging the result of the adjustment of drive pinion height and final drive gear backlash. The adjustment of drive pinion height and final drive gear backlash should be repeated until the tooth contact patterns are similar to the standard tooth contact pattern.
- When you cannot obtain a correct pattern, the drive gear and drive pinion have exceeded their

limits. Both gears should be replaced as a set.

Differential Carrier Assembly

DS-33


4WD CONTROL SYSTEM (PART TIME 4WD)

FUNCTION CHECK

1. Air pressure gauge is attached in between air hoses that connect differential (actuator) with air pump motor assy. Air pressure gauge adjustment screw shall be fastened until it stops ultimately. And make a blind stopper at air check side by using fuel hose etc.

⚠ CAUTION


- Air pressure gauge shall be installed by using 3-way union etc.
- Take heed not to snap or bend the piping hose.



LIAC072L

2. Turn the ignition switch on and shift the transfer lever 2H→4H.
3. Check that the motor starts to revolve in 1 second and stops when Air pressure gauge value displayed with in the specified value.

Specified pressure :

37-57 kPa (5.4-8.2 lb/in², 0.38-0.58 kgf/cm²)

LIAC072M

4. Check that if transfer lever is shifted to 2H then promptly Air pressure gauge value drops down.
5. Confirm that motor returns when Air pressure adjustment screw has been loosened to lower the gauge pressure value after motor had started to revolve by shifting transfer lever to 4H. And also check that the motor stops after several seconds since it started to run.

ACTUATOR CHECK

1. Detach air hose from air pump motor assy. and then attach Air pressure gauge at air hose.
2. Attach compressor air hose to Air pressure gauge and then set to specified pressure by fastening adjustment screw. Whence check that actuator is operated to affect the axle lock.

Specified pressure :

37 kPa (5.4 lb/in², 0.38 kgf/cm²).

⚠ WARNING

Take heed that there is potential for diaphragm breakage if pressure beyond 200 kPa (28 lb/in², 2.0 kgf/cm²) is applied.


Do not use the air gun.

INSPECTION

1. Check the companion flange for wear or damage.
2. Check the bearings for wear or discoloration.
3. Check the gear carrier for cracks.
4. Check the drive pinion and drive gear for wear or cracks.
5. Check the side gears, pinion gears and pinion shaft for wear or damage.
6. Check the side gear spline for wear or damage.
7. Check the length of the distance piece.

Standard length :

54.80-58.09 mm (2.16-2.21 in.)




B17C074A

DS-34

Driveshaft and axle

8. Check the air pump motor

- 1) Attach air pressure gauge, voltmeter and battery to air pump motor as in figure. Air pressure gauge adjustment screw shall be fastened until it stops ultimately. And make a blind stopper at air check side by using fuel hose etc.



LIAC075P

- 2) Confirm that motor runs when battery has been connected. And check that motor stops when returned to specified pressure.

Specified pressure :

37-57 kPa (5.4-8.2 lb/in², 0.38-0.58 kgf/cm²)**CAUTION****Check also air leak.**

- 3) Read voltmeter indication value so as to check if it is within specified range.


Voltage :

about 0 V (when motor runs)

10-14 V (when motor stopped)

9. Check the actuator.


- 1) Attach air pressure gauge to actuator as in figure.

CAUTION**Loosen adjustment screw before attaching air hose to air pressure gauge.**

LIAC075J

- 2) Check that actuator is operated when air pressure gauge adjustment screw has been tightened to set at specified pressure. Also check air leak from actuator.


Adjusted pressure :

37 kPa (5.4 lb/in², 0.38 kgf/cm²)**CAUTION****Take heed that there is potential for diaphragm breakage if pressure beyond 200 kPa (28 lb/in², 2.0 kgf/cm²) is applied.****Do not use the air gun.**

LIAC075K

DISASSEMBLY

1. REMOVAL OF THE DIFFERENTIAL CASE ASSEMBLY

CAUTION**Remove the differential case assembly slowly and carefully. Be careful so that the side bearing outer race is not dropped.****NOTICE***Keep the right and left side bearings separate so that they are not mixed during reassembly.*

LIAC075A

Differential Carrier Assembly


DS-35

2. REMOVAL OF THE SIDE BEARING INNER RACES

Fit the nut on top of the differential case, and then use the special tool(09517-43001) to remove the side bearing inner race.

NOTICE


Attach the prongs of the special tool to the inner race of the side bearing through the notched section in the differential case.



LIAC075B


3. REMOVAL OF DRIVE GEAR

- Make the matchmarks to the differential case and the drive gear.
- Loosen the drive gear attaching bolts in diagonal sequence to remove the drive gear.




LIAC075C

4. REMOVAL OF LOCK PIN (FOR CONVENTIONAL DIFFERENTIAL)



LIAC075D

5. REMOVAL OF SELF-LOCKING NUT



LIAC075E


6. REMOVAL OF DRIVE PINION

- Make the matchmarks to the drive pinion and companion flange.

CAUTION


Matchmarks should not be made to the contact surfaces of the companion flange and the propeller shaft.

- Drive out the drive pinion together with the drive pinion spacer and drive pinion front shims.



LIAC075F

7. REMOVAL OF DRIVE PINION INNER BEARING INNER RACE




LIAC075G

DS-36


Driveshaft and axle

8. REMOVAL OF OIL SEAL / DRIVE PINION OUTER BEARING INNER RACE / DRIVE PINION OUTER BEARING OUTER RACE



LIAC075H


9. REMOVAL OF DRIVE PINION INNER BEARING OUTER RACE



LIAC075I

REASSEMBLY

1. PRESS-FITTING OIL SEAL




LIAC076A

2. DRIVE PINION OUTER BEARING OUTER RACE INSTALLATION

⚠ CAUTION

When press-fitting the outer race, do not incline it.




LIAC076B

3. DRIVE PINION INNER BEARING OUTER RACE INSTALLATION

⚠ CAUTION

When press-fitting the outer race, do not incline it.



LIAC076C


Differential Carrier Assembly

DS-37

4. ADJUSTMENT OF PINION HEIGHT

Adjustment the drive pinion height by the following procedure.

- 1) For assembly of pinion, use drive pinion model(OK993 270 A01), pinion height adjustment gauge body(OK993 270 A09) and gauge block(ht. 28 mm(1.102 in)).



LIAC076D

- 2) Assemble spacer and inner bearing inner race to pinion model and fix it with O-ring.

NOTICE

Use spacer disassembled.



LIAC076E

- 3) Install pinion model assembly to carrier.
- 4) Assemble outer bearing, companion flange washer, and lock nut.


NOTICE

Use washer and lock nut disassembled.

- 5) Tighten lock nut.


NOTICE

- Tighten to the extent the companion flange can be screwed by hand.



LIAC076F

- 6) Put pinion height adjusting gauge body at right angle and adjust it to 0.




LIAC076G

- 7) Put pinion height adjusting gauge body and gauge block to the upper side of pinion model.
- 8) Dial gauge needle should be placed at the lowest part of side bearing.

DS-38

Driveshaft and axle

- 9) Measure minimum positions of both sides (LH, RH).



LIAC076H


- 10) Add both values and divide it by 2.

- 11) If the value of the above step 10 is not within specification, use new spacer adding the values to current spacer.

Standard clearance :


-0.025~0.025 mm (-0.001~0.001 in)

MA-RK	THICKNESS	MA-RK	THICKNESS
08	3.08(0.1212)	29	3.29(0.1259)
11	3.11(0.1224)	32	3.32(0.1307)
14	3.14(0.1236)	35	3.35(0.1318)
17	3.17(0.1248)	38	3.38(0.1330)
20	3.20(0.1259)	41	3.41(0.1342)
23	3.23(0.1271)	44	3.44(0.1354)
26	3.26(0.1283)	47	3.47(0.1366)



LIAC076I

5. Adjustment of drive pinion preload.



LIAC076J

- 1) Install spacer.
- 2) Push inner bearing in using SST.

NOTICE

- Keep pressuring until the sudden increase of necessary power.
- Place the spacer for adjusting pinion height, ensuring exact direction of installation.


- 3) Install distance piece.
- 4) Push outer bearing in using SST.
- 5) Install drive pinion assembly.
- 6) Install companion flange and tighten lock nut.

Tightening torque :

127-284 N·m (13-29 kg·m, 94-210 lb·ft)

NOTICE

Do not install oil seal.



LIAC076K

- 7) Turn companion flange by hand so that bearing be put at the right place.
- 8) Measure preload of drive pinion. If the result is not within specification, use new distance piece and measure again.

Preload :

127-176 N·m (13-18 kg·m, 94-130 lb·ft)

Differential Carrier Assembly

DS-39

- 9) Remove the lock nut and then install the oil seal.
- 10) >Install the companion flange and tighten lock nut.

Tightening torque :

127-284 N·m (13-29 kg·m, 94-210 lb·ft)


6. ADJUSTMENT OF DIFFERENTIAL GEAR BACKLASH

Adjust the differential gear backlash according to the following procedures :

- 1) Assemble the side gears, side gear spacers, pinion gears, and pinion washers into the differential case.
- 2) Temporarily install the pinion shaft.

NOTICE

Do not install the lock pin yet.



LIAC076L


- 3) Insert a wedge in the side gear and measure the differential gear backlash with a dial indicator on the pinion gear.

NOTICE

Measure both pinion gears separately.

Standard value : 0-0.1 mm (0-0.0039 in.)

Limit : 0.2 mm (0.008 in.)



LIAC076M

- 4) If the differential gear backlash exceeds the limit, adjust the backlash by selecting thicker side gear thrust spacers.


- 5) Measure the differential gear backlash once again, and confirm that it is within the limit.

NOTICE

- After adjustment, check that the backlash is within the limit and the differential gear rotates smoothly.
- When adjustment is impossible, replace the side gear and the pinion gear as a set.

7. INSTALLATION OF THE LOCK PIN


- 1) Align the pinion shaft lock pin hole with the differential case lock pin hole, and drive in the lock pin.
- 2) Fix the lock pin in place by staking two points around the lock pin hole with a punch.



LIAC076N

8. INSTALLATION OF THE DRIVE GEAR

- 1) Clean the drive gear attaching bolts.
- 2) Remove the adhesive on the threaded holes of the drive gear use a tap (M10 x 1.25), and then clean the threaded holes with compressed air.




LIAC076O

DS-40

Driveshaft and axle

- 3) Apply the specified adhesive to the threaded holes of the drive gear.


Specified adhesive : LOCTITE #262 or equivalent



LIAC076P

- 4) Install the drive gear in the differential case with the matchmarks properly aligned. Tighten the bolts to the specified torque in a diagonal sequence.

9. PRESS THE SIDE BEARING INNER RACE




LIAC076Q

10. Attach actuator at differential case RH side as figure

CAUTION

Take heed of actuator direction.



LIAC077B


11. ADJUSTMENT OF FINAL DRIVE GEAR BACKLASH

Adjust the final drive gear backlash according to the following procedures :

- 1) Install side bearing spacers which are thinner than those removed, to the side bearing outer races, and then mount the differential case assembly into the gear carrier.


NOTICE

Select side bearing spacers with the same thickness for both the drive pinion side and the drive gear side.



LIAC076R

- 2) Push the differential case to one side, and measure the clearance between the gear carrier and the side bearing with a feeler gauge.




LIAC076S

Differential Carrier Assembly


DS-41

- 3) Select two pairs of spacers, which correspond to the value calculated according to the expression in the illustration. Install one pair each to the drive pinion side and the drive gear side.




LIAC076T

- 4) Install the side bearing spacers and differential case assembly, as shown in the illustration, to the gear carrier.




LIAC076U

- 5) Tap the side bearing spacers with a brass bar to fit them to the side bearing outer race.



LIAC076V

- 6) Align the matchmarks on the gear carrier and the bearing cap and tighten the bearing cap.




LIAC076W

- 7) With the drive pinion locked in place, measure the final drive gear backlash with a dial indicator on the drive gear.

NOTICE

Measure at four points or more on the circumference of the drive gear.

Standard value : 0.09-0.11 mm (0.0035-0.0043 in.)




LIAC076X

- 8) Change the side bearing spacers as illustrated and then adjust the final drive gear backlash between the drive gear and the drive pinion.

NOTICE

When increasing the number of side bearing spacers, use the same number for each and as few as possible.




LIAC076Y

DS-42

Driveshaft and axle

- 9) Check the drive gear and drive pinion for tooth contact. If poor contact is evident, adjust again.
- 10) Measure the drive gear runout at the shoulder on the reverse side of the drive gear.

Limit : 0.05 mm (0.002 in.)



LIAC076Z

- 11) If the drive gear runout exceeds the limit, reinstall by changing the position of the drive gear and differential case, and remeasure.

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




Differential Carrier Assembly


DS-43

Rear Differential Carrier

COMPONENTS



LIAC077A

DS-44**Driveshaft and axle****REAR DIFFERENTIAL COMPONENTS****TORQUE : N-m (kg-m, lb-ft)**

- | | | |
|----------------------------|-------------------------------|----------------------|
| 1. Lock plate | 9. Pinion gear | 17. Spacer |
| 2. Side bearing nut | 10. Side gear | 18. Inner bearing |
| 3. Bearing cap | 11. Side gear thrust washer | 19. Distance piece |
| 4. Side bearing | 12. Spider | 20. Outer bearing |
| 5. Ring gear | 13. Differential carrier case | 21. Companion flange |
| 6. Washer | 14. Lock nut | 22. Oil seal |
| 7. Differential upper case | 15. Lock washer | 23. Oil slinger |
| 8. Differential lower case | 16. Drive pinion | |

LIAC081A

Differential Carrier Assembly


DS-45

REMOVAL

1. Drain the differential gear oil.
2. Remove the rear disk brake.
3. Remove the parking brake and cable.
4. Remove the stabilizer bar.
5. Pull out the rear axle shaft.

⚠ CAUTION

Be careful not to damage the oil seal when pulling axle shaft.




LIAC033A

6. After marking the match mark on the flange yoke of the rear propeller shaft and the companion flange of the differential case, remove the rear propeller shaft assembly.

⚠ CAUTION

Suspend the propeller shaft from the body with wire, etc.




LIAC071D

7. Remove the attaching nuts and strike the lower part of differential carrier assembly with a piece of times several times to loosen, then remove the differential carrier assembly.

⚠ NOTICE

Use care not to strike the companion flange.



LIAC078B

INSTALLATION

1. DIFFERENTIAL CARRIER ASSEMBLY

Apply specified sealant to axle housing flange surface, and install the differential carrier assembly.

Specified sealant : Three bond 1215 or equivalent

Tightening torque :

23-27 Nm (2.3-2.7 kg-m, 16-19 lb-ft)

2. PROPELLER SHART

Align the match marks on the flange yoke and companion flange, and install the propeller shaft.

Tightening torque :

50-60 Nm (500-600 kg-cm, 37-44 lb-ft)

3. AXLE SHAFT ASSEMBLY

- 1) Apply specified sealant to the axle housing and bearing case end faces.

Specified sealant : Three bond 1104

DS-46


Driveshaft and axle

DISASSEMBLY

1. SIDE BEARING NUT

NOTICE

Keep the right and left side bearing nuts separate so that they are not mixed during reassembly.




LIAC082A

2. REMOVAL OF THE DIFFERENTIAL CASE ASSEMBLY

CAUTION

- Remove the differential case assembly slowly and carefully.
- Be careful so that the side bearing outer race is not dropped.
- Keep the right and left side bearing outer races separate so that they are not mixed during reassembly.




LIAC075A

3. REMOVAL OF THE SIDE BEARING INNER RACES

Fit the nut on top of the differential case, and then uses the special tool to remove the side bearing inner race.

NOTICE


Attach the prongs of the special tool (09517-43001) to the inner race of the side bearing through the notched section in the differential case.



LIAC075B


4. REMOVAL OF DRIVE GEAR

- Make the match marks to the differential case and the drive gear.
- Loosen the drive gear attaching bolts in diagonal sequence to remove the drive gear.



LIAC075C

5. REMOVAL THE LOCK NUT



LIAC075E

Differential Carrier Assembly

DS-47


6. REMOVAL OF DRIVE PINION

- Make the match marks on the drive pinion and companion flange.

⚠ CAUTION


Match marks should not be made on the contact surfaces of the companion flange and the propeller shaft.

- Drive out the drive pinion together with the drive pinion spacer and drive pinion front shims.




LIAC075F

7. REMOVAL OF DRIVE PINION REAR BEARING INNER RACE




LIAC075G

8. REMOVAL OF OIL SEAR / DRIVE PINION FRONT BEARING INNER RACE / DRIVE PINION FRONT BEARING OUTER RACE




LIAC075H

9. REMOVAL OF DRIVE PINION REAR BEARING OUTER RACE



LIAC075I

INSPECTION BEFORE DISASSEMBLY



LIAC079A

1. FINAL DRIVE GEAR BACKLASH

Check the final drive gear backlash by the following procedure.


- Place the drive pinion and move the drive gear to check backlash is within the standard range.

⚠ NOTICE

Measure at 4 points on the gear periphery.

Standard value

0.13-0.18 mm (0.0051-0.0071 in.)



LIAC079B

DS-48

Driveshaft and axle

- 2) Adjust with the side bearing nuts if backlash values are not within standard range.

NOTICE


After adjusting, check the state of the final drive gear's tooth contact.

2. DRIVE GEAR RUNOUT

Check the back-face lash as follows:

- 1) Place a dial gauge on the back-face of the drive gear and measure the runout.

Limit : 0.05mm (0.0020in.)



LIAC079C

- 2) If the run out is beyond the limit, check that there are no foreign substances between the drive gear and differential case and, that the bolts fixing the drive gear are not loose.


3. DIFFERENTIAL GEAR BACKLASH

- 1) Fix the side gear with a wedge so it cannot move and measure the differential gear backlash with a dial indicator on the pinion gear.

NOTICE

Take the measurements at two places on the pinion gear.

Standard value : 0-0.1 mm (0-0.0039 in.)



LIAC072D

- 2) If the backlash exceeds the limit, adjust using side bearing spacers.


NOTICE

If adjustment is impossible, replace the side gear and pinion gears as a set.

4. FINAL DRIVE GEAR TOOTH CONTACT

Check the final drive gear tooth contact by following the steps below :

- 1) Apply the same amount of machine blue slightly to both surfaces of the drive gear teeth.



LIAC072E

- 2) Insert a brass rod between the differential carrier and the differential case, and then rotate the companion flange by hand (once in the normal direction, and then once in the reverse direction) while applying a load to the drive gear so that some torque (approximately 25-30kg.cm) is applied to the drive pinion.


CAUTION

If the drive gear is rotated too much, the tooth contact pattern will become unclear and difficult to check.

Differential Carrier Assembly

DS-49

3) Check the tooth contact pattern.



دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




DS-50

Driveshaft and axle

LIAC072F



1. Narrow tooth side
2. Drive-side tooth surface (the side receiving power during acceleration)
3. Wide tooth side
4. Coast-side tooth surface (the side receiving power during coast-down)



Problem

Solution



Tooth contact pattern resulting from excessive pinion height



The drive pinion is positioned too far from the center of the drive gear.

Also, for backlash adjustment, reposition the drive gear further from the drive pinion.

Tooth contact pattern resulting from insufficient pinion height



The drive pinion is positioned too close to the center of the drive gear.

Decrease the thickness of the pinion height adjusting shim, and position the drive pinion further from the center of the drive gear.
Also, for backlash adjustment, reposition the drive gear closer to the drive pinion.

NOTICE

- Tooth contact pattern is a method for judging the result of the adjustment of drive pinion height and final drive gear backlash. The adjustment of drive pinion height and final drive gear backlash should be repeated until the tooth contact patterns are similar to the standard tooth contact pattern.
- When you cannot obtain a correct pattern, the drive

gear and drive pinion have exceeded their limits. Both gears should be replaced as a set.

Differential Carrier Assembly


DS-51

INSPECTION

1. Check the companion flange for wear or damage.
2. Check the bearings for wear or discoloration.
3. Check the gear carrier for cracks.
4. Check the drive pinion and drive gear for wear or cracks.
5. Check the side gears, pinion gears and pinion shaft for wear or damage.
6. Check the side gear spline for wear or damage.
7. Check the length of the distance piece.

Standard length :

54.80-58.09 mm (2.16-2.21 in.)




BI7C074A

REASSEMBLY

1. Install the drive pinion rear bearing outer race and drive pinion front bearing outer race using the special tools (09500-11000, 09500-21000, 09532-31200B and 09532-32000).

CAUTION

Be careful not to press in the outer race when it is inclined.




LIAC084A

2. ADJUSTMENT OF PINION HEIGHT

Adjustment the drive pinion height by the following procedure.

- 1) For assembly of pinion, use drive pinion model (0K993 270 A01), pinion height adjustment gauge body (0K993 270 A09) and gauge block (ht. 28 mm (1.102 in)).




LIAC076D

- 2) Assemble spacer and inner bearing inner race to pinion model and fix it with O-ring.

NOTICE

- Use spacer disassembled.



LIAC076E

- 3) Install pinion model assembly to carrier.
- 4) Assemble outer bearing, companion flange washer, and lock nut.

NOTICE

- Use washer and lock nut disassembled.


- 5) Tighten lock nut.

NOTICE

- Tighten to the extent the companion flange can be screwed by hand.


DS-52

Driveshaft and axle




LIAC076F

- 6) Put pinion height adjusting gauge body at right angle and adjust it to 0.



LIAC076G

- 7) Put pinion height adjusting gauge body and gauge block to the upper side of pinion model.
8) Dial gauge needle should be placed at the lowest part of side bearing.
9) Measure minimum positions of both sides (LH, RH).



LIAC076H


- 10) Add both values and divide it by 2.

- 11) If the value of the above step 10 is not within specification, use new spacer adding the values to current spacer.

Standard clearance :


-0.025~0.025 mm (-0.001~0.001 in)

MARK	THICKNES-S	MARK	THICKNES-S
08	3.08(0.1212)	29	3.29(0.1259)
11	3.11(0.1224)	32	3.32(0.1307)
14	3.14(0.1236)	35	3.35(0.1318)
17	3.17(0.1248)	38	3.38(0.1330)
20	3.20(0.1259)	41	3.41(0.1342)
23	3.23(0.1271)	44	3.44(0.1354)
26	3.26(0.1283)	47	3.47(0.1366)



LIAC076I

3. Adjustment of drive pinion preload.



LIAC076J

- 1) Install spacer.
2) Push inner bearing in using SST.

NOTICE

- Keep pressuring until the sudden increase of necessary power.
- Place the spacer for adjusting pinion height, ensuring exact direction of installation.

- 3) Install distance piece.
4) Push outer bearing in using SST.
5) Install drive pinion assembly.

Differential Carrier Assembly

DS-53


- 6) Install companion flange and tighten lock nut.

Tightening torque :

127-284 N·m (13-29 kg·m, 94-210 lb·ft)

NOTICE

- Do not install oil seal.



LIAC076K

- 7) Turn companion flange by hand so that bearing be put at the right place.
- 8) Measure preload of drive pinion. If the result is not within specification, use new distance piece and measure again.

Preload :

127-176 N·m (13-18 kg·cm, 94-130 lb·ft)

- 9) Remove the lock nut and then install the oil seal.
- 10) Install the companion flange and tighten lock nut.

Tightening torque :


127-284 N·m (13-29 kg·m, 94-210 lb·ft)

ADJUSTMENT OF DIFFERENTIAL GEAR BACKLASH

- Assemble the side gears, side gear spacers, pinion gears, and pinion washers into the differential case.
- Temporarily, install the pinion shaft.

NOTICE

Do not install the lock pin yet.



LIAC076L

3. Insert a wedge in the side gear and measure the differential gear backlash with a dial indicator on the


pinion gear.

NOTICE

Measure both pinion gears separately.

Standard value : 0-0.1 mm (0-0.0039 in.)

Limit : 0.2 mm (0.008 in.)



LIAC076M


4. If the differential gear backlash exceeds the limit, adjust the backlash by installing thicker side gear thrust spacers.
5. Measure the differential gear backlash once again, and confirm that it is within the limit.

NOTICE

- After adjustment, check that the backlash is within the limit and the differential gear rotates smoothly.
- When adjustment is impossible, replace the side gear and the pinion gear as a set.

6. Installation of the drive gear

- Clean the drive gear attaching bolts.
- Remove the adhesive on the threaded holes of the drive gear with a tap (M12 x 1.5), and then clean the threaded holes with compressed air.



LIAC076O

- Apply the specified adhesive to the threaded holes of the drive gear.


Specified adhesive :

LOCTITE #262 or equivalent

DS-54


Driveshaft and axle

- d. Install the drive gear in the differential case with the matchmarks properly aligned. Tighten the bolts to the specified torque (11-15 kg-m) in a diagonal sequence.




LIAC076P

7. Press-fit the side bearing inner race



LIAC076Q

8. Align the match mark on the gear carrier and the bearing cap, and then tighten the bearing cap.




LIAC084B

9. ADJUSTMENT OF FINAL DRIVE GEAR BACKLASH

Adjust final drive gear backlash as follows :

- 1) Using the special tool (09521-43001), temporarily tighten the side bearing nut until it is in the state just before preloading of the side bearing.



LIAC082A


- 2) Measure the final drive gear backlash.

Standard value :

0.13-0.18mm (0.0051-0.0071 in.)

NOTICE

Measure at least 4 points on the drive gear periphery.



LIAC079C


- 3) Using the special tool (09521-43000), adjust the backlash to standard value by moving the side bearing nut as shown.

NOTICE

First turn the side bearing nut for loosening, and then turn (by the same amount) the side bearing nut for tightening.


Differential Carrier Assembly

DS-55




LIAC084C

- 4) Using the special tool (09521-43001) to apply the preload, turn down both right and left side bearing nut on half the distance between centers of two neighboring holes.



LIAC084D

- 5) Choose and install the lock plates two kinds.




LIAC084E


- 6) Check the final drive gear tooth contact. If poor contact is evident, make adjustment.
7) Measure the drive gear run out.

Limit : 0.05mm (0.0020in.)

- 8) When drive gear run out exceeds the limit, remove the differential case and then the drive gears, moving them to different positions and reinstalling them.



LIAC079C

DS-56**Driveshaft and axle****Limited Slip Differential (LSD)****DESCRIPTION****COMPONENTS**

- | | |
|-------------------|------------------------------------------|
| 1. Case | 8. Eared disc S/A (carbon on both sides) |
| 2. Washer-lock | 9. Thrust washer-pinion |
| 3. Screw-lock | 10. Pinion gear |
| 4. Guide-ear | 11. Cross shaft-pinion |
| 5. Plate-preload | 12. Disc-splined friction |
| 6. Spring-preload | 13. Shim-side gear |
| 7. Gear-side | 14. Eared disc S/A (carbon on one side) |

LIAC060A

Differential Carrier Assembly

DS-57

DISASSEMBLY


1. Remove the threaded lock screw and the cross shaft.
2. Without preload on the side gears they can be turned by hand. Rotate the side gears until the pinions are in the window area. Remove the pinions and pinion thrust washers.
3. Remove the gear sub-assemblies (side gear, disc pack, ear guides and disc pack shims). Do not mix parts. Identify the parts so they can be reassembled to the original location.

INSPECTION

1. Check the side gears, pinions, pinion thrust washers, and cross shaft for wear or damage. If there is excessive wear, cracks, nicks, grooves or galling replace the parts.
2. Inspect the carbon surfaces. After cleaning with a solvent, the carbon surface should appear like a coarse weave fabric with flat spots on the peaks of the weave. If the surface is smooth, either from wear or from the weave filled with debris replaces the entire disc pack.
3. Measure the thickness of the carbon friction discs. If any of the double sided discs are less than 2.56 mm (0.101in.) or the single sided disc is less than 2.15mm (0.085 in.), replace the entire disc pack.
4. Inspect the splined friction discs. If they have grooves or a mirror like finishing, replacing the entire disc pack. Small scratches on a buff like finish are okay.


REASSEMBLY AND SHIM SELECTION

1. Apply axle lubricant to all sliding surfaces. Be especially careful to coat the mating surfaces of the friction discs.
2. Starting with a double sided eared disc next to the side gear, stack four eared discs and three splined discs on to the spline of side gear. A splined disc goes in between each eared disc with the last eared disc being single sided and the carbon surface facing the side gear. Use a heavy bearing grease in the ear guides to hold them in place during assembly.



LIAC064A

3. Select a shim 0.76mm (0.030in.) thick and place on the hub side of the disc pack subassembly.
4. Lubricate and assemble the other side gears as above.
5. Install the flange end side gear subassembly and shim in the flange end of the differential case.
6. Position pinion gears and thrust washers on the side gears and install the cross shaft through the case and pinions.
7. Install a dial indicator on the case so that the indicator tip rests against a pinion tooth face.
8. Compress the clutch pack with a large screwdriver or pry bar as shown. Rotate the pinion gear back and forth to obtain backlash. Tooth backlash should be 0 to 0.10mm (0 to 0.004in.). If required, change the 0.76mm (0.30in.) Shim to obtain the proper backlash.



LIAC064B

9. Remove the side gear subassembly and repeat the tooth backlash procedure for the other gear pack on the opposite side of the case.
10. Remove the cross shaft, pinions and thrust washers and reinstall the first side gear subassembly and shim in the flange end of the case.
11. Install a pinion and thrust washer through each window so that the gear teeth mesh and so that the pinions are in line with each other. Rotate one side gear so the pinions and thrust washers rotate at a position where they line up with the cross shaft holes in the case.
12. Install the pinion shaft, lock screw and lock washer. Tighten the lock screw to 30-40Nm (3.1~4.1 kg·m, 22-29lb·ft) torque.