HA-2 Heating, Ventilation, Air Conditioning

General Information

Specification

Item		Specification		
		2.0L	2.4L	2.7L
Compressor	Туре		VS	
	Oil type & Capacity		PAG 150 \pm 10cc	
	Pulley type		6PK-TYPE	
	Displacement	180cc/rev		
Condenser	Heat rejection	14800 - 5% kcal/hr		
APT	The method to measure the Voltage = 0.00878835 * Pressure + 0.37081		+ 0.37081095	
(A/C pressure transducer)	pressure			
Expansion valve	Туре	Block		
Refrigerant	Туре	Type R-134a		
	Capacity [oz.(g)]		17.6 ± 0.88 (500 ± 25	5)

Blower Unit

	em	Specification
Fresh and recirculation	Operating method	Actuator
(2020 0 11 108	Туре	Sirocco
سیئولیت محدود) Blower	Speed step	Auto + 8 speed (Automatic) 1~8 speed (Manual)
ن خودرو در ایران	Speed control	Power mosfet (Automatic)
Air filter	Туре	Particle filter

Heater And Evaporator Unit

Item		Specification	
	Туре	Pin & Tube type	
	Heating capacity	4300 \pm 5% kcal/hr	
Heater	Mode operating method	Actuator	
	Temperature operating met- hod	Actuator	
	Temperature control type	Evaporator temperature sensor	
Evaporator	A/C ON/OFF [[℃] (°F)]	ON : 5.0 ± 0.5 (41 ± 32.9) OFF: 3.0 ± 0.5 (37.4 ± 32.9)	

021 62 99 92 92

HA-

General Information

Troubleshooting

Problem Symptoms Table

Before replacing or repairing air conditioning components, first determine if the malfunction is due to the refrigerant charge, air flow or compressor.

Use the table below to help you find the cause of the problem. The numbers indicate the priority of the likely cause of the problem. Check each part in order. If necessary, replace these parts.

Standard :

Suspect Area Symptom See page 1.Blower fuse 2.Blower motor 3. Power mosfet No blower operation 4.Blower speed control switch 5. Wire harness 1.Engine coolant capacity No air temperature control 2.Heater control assembly 1.Refrigerant capacity 2.A/C Fuse 3. Magnetic clutch 4.Compressor No compressor operation 5.A/C pressure transducer 6.A/C switch 7.Evaporator temperature sensor 8.Wire harness 1.Refrigerant capacity 2.Refrigerant pressure 3.Drive belt 4. Magnetic clutch 5.Compressor No cool comes out 6.A/C pressure transducer 7. Evaporator temperature sensor 8.A/C switch 9.Heater control assembly 10. Wire harness

After correcting the malfunction, check the complete system to ensure that performance is satisfactory.

Heating, Ventilation, Air Conditioning **HA-4**

Symptom	Suspect Area	See page
	1.Refrigerant capacity	
	2.Drive belt	
	3.Magnetic clutch	
	4.Compressor	
Incufficient cooling	5.Condenser	
Insufficient cooling	6.Expansion valve	
	7.Evaporator	
	8.Refrigerant lines	
	9.A/C pressure transducer	
	10. Heater control assembly	
No operation idlours when A/C quitab ON	1.Engine ECM	
No engine idleup when A/C switch ON	2.Wire harness	
No air inlet control	1. Heater control assembly	
	1.Heater control assembly	
No mode control	2.Mode actuator	0
	1.Cooling fan fuse	
	2.Fan motor	
No cooling fan operation	3.Engine ECM	
	4.Wire harness	
Special Service Tools	اولين سامانه ديجيتال تعد	

Tool (Number and name)	Illustration	Use
09977-29000 Disc & hub assembly bolt r- emover		Removal and installation of disc & hub assembly

Air conditioning System


Air conditioning System

Instructions

When Handling Refrigerant

- 1. R-134a liquid refrigerant is highly volatile. A drop on the skin of your hand could result in localized frostbite. When handling the refrigerant, be sure to wear gloves.
- It is standard practice to wear goggles or glasses to protect your eyes, and gloves to protect your hands. If the refrigerant splashes into your eyes, wash them with clean water immediately.
- The R-134a container is highly pressurized. Never leave it in a hot place, and check that the storage temperature is below 52°C (126°F).
- 4. An electronic leak detector should be used to check the system for refrigerant leakage. Bear in mind that the R-134a, upon coming into contact with flame, produces phosgene, a highly toxic gas.
- 5. Use only recommended the lubricant for R-134a systems. If lubricants other than the recommended one used, system failure may occur.
- PAG lubricant absorbs moisture from the atmosphere at a rapid rate, therefore the following precautions must be observed :
 - When removing refrigerant components from a vehicle, cap immediately the components to prevent from the entry of moisture.
 - When installing refrigerant components to a vehicle, do not remove the cap until just before connecting the components.
 - Complete the connection of all refrigerant tubes and hoses without delay to prevent the A/C system from taking on moisture.
 - Use the recommended lubricant from a sealed container only.


7. If an accidental discharge in the system occurs, ventilate the work area before resuming service.



LQAC003A

When Replacing Parts On A/c System

- 1. Never open or loosen a connection before discharging the system.
- 2. Seal the open fittings of components with a cap or plug immediately to prevent intrusion of moisture or dust.
- 3. Do not remove the sealing caps from a replacement component until it is ready to be installed.
- Before connecting an open fitting, always install a new sealing ring. Coat the fitting and seal with refrigerant oil before making the connection.




LQAC003B

7 If an accidental

Heating, Ventilation, Air Conditioning

When Installing Connecting Parts Flange With Guide Pin

Check the new O-ring for damage (use only the specified) and lubricate it using compressor oil. Tighten the nut to specified torque.



		LQAC003C	
	Tightening torque [N.m (kg.m, lb.ft)]		
Size	General bolt, nut		
	4T	7T 🕠	
M6 9	5 - 6 (0.5 - 0.6, 3.6 - 4.3)	9 - 11 (0.9 - 1.1, 6.5 - 7.9)	
M8	12 - 14 (1.2 - 1.4, 8.7 - 10)	20 - 26 (2.0 - 2.6, 14 - 18)	
M10	25 - 28	45 - 55	
WITO	(2.5 - 2.8, 18 - 20)	(4.5 - 5.5, 32 - 39)	
Size	Flange bolt, nut		
SIZE	4T	7T	
M6	5 - 7	8 - 12	
	(0.5 - 0.7, 3.6 - 5.0)	(0.8 - 1.2, 5.8 - 8.6)	
MO	10 - 15	19 - 28	
M8	(1.0 - 1.5, 7 - 10)	(1.9 - 2.8, 14 - 20)	
M10	21 - 31	39 - 60	
M10	(2.1 - 3.1, 15 - 22)	(3.9 - 6.0, 28 - 43)	

WNOTICE

T means tensile intensity, which is stamped on the head of bolt only numeral.

Handling Tubing And Fittings


The internal parts of the refrigeration system will remain in a state of chemical stability as long as pure moisture-free refrigerant and refrigerant oil are used. Abnormal amounts of dirt, moisture or air can upset the chemical stability and cause problems or serious damage.

The Following Precautions Must Be Observed

- 1. When it is necessary to open the refrigeration system, have everything you will need to service the system ready so the system will not be left open any longer than necessary.
- 2. Cap or plug all lines and fittings as soon as they are opened to prevent the entrance of dirt and moisture.
- 3. All lines and components in parts stock should be capped or sealed until they are ready to be used.
- 4. Never attempt to rebind formed lines to fit. Use the correct line for the installation you are servicing.
- 5. All tools, including the refrigerant dispensing manifold, the gauge set manifold and test hoses, should be kept clean and dry.

Air conditioning System


Refrigeration Cycle



EQRF004A

HA-8 Heating, Ventilation, Air Conditioning

Component Location Engine Room




SMGHA9200L

WWW.DIGITALKHODRO.COM

Air conditioning System

Interior



SMGHA9201L

HA-9

021 62 99 92 92

HA-10 Heating, Ventilation, Air Conditioning

Refrigerant System Service Basics Refrigerant Recovery

Use only service equipment that is U.L-listed and is certified to meet the requirements of SAE J2210 to remove HFC-134a(R-134a) from the air conditioning system.


- Air conditioning refrigerant or lubricant vapor can irritate your eyes, nose, or throat.
- Be careful when connecting service equipment.
- Do not breathe refrigerant or vapor.

If accidental system discharge occurs, ventilate work area before resuming service.


Additional health and safety information may be obtained from the refrigerant and lubricant manufacturers.

1. Connect an R-134a refrigerant

Recovery/Recycling/Charging System (A) to the high-pressure service port (B) and the low-pressure service port (C) as shown, following the equipment manufacturer's instructions.



LQLG011A



EQKE004A

 Measure the amount of refrigerant oil removed from the A/C system after the recovery process is completed. Be sure to install the same amount of new refrigerant oil back into the A/C system before charging.

System Evacuation

Use only service equipment that is U.L-listed and is certified to meet the requirements of SAE J2210 to remove HFC-134a(R-134a) from the air conditioning system.

CAUTION

- Air conditioning refrigerant or lubricant vapor can irritate your eyes, nose, or throat.
 - Be careful when connecting service equipment.
- Do not breathe refrigerant or vapor.

If accidental system discharge occurs, ventilate work area before resuming service.

Additional health and safety information may be obtained from the refrigerant and lubricant manufacturers.

1. When an A/C System has been opened to the atmosphere, such as during installation or repair, it must be evacuated using an R-134a refrigerant

Recovery/Recycling/Charging System. (If the system has been open for several days, the receiver/dryer should be replaced, and the system should be evacuated for several hours.)

2. Connect an R-134a refrigerant


Recovery/Recycling/Charging System (A) to the high-pressure service port (B) and the low-pressure service port (C) as shown, following the equipment manufacturer's instructions.

WWW.DIGITALKHODRO.COM

021 62 99 92 92

Air conditioning System

HA-11



EQKE004A

- 3. If the low-pressure does not reach more than 93.3 kPa (700 mmHg, 27.6 in.Hg) in 10 minutes, there is probably a leak in the system. Partially charge the system, and check for leaks (see Leak Test.).
- 4. Remove the low pressure valve from the low-pressure service port.

System Charging

Use only service equipment that is U.L-listed and is certified to meet the requirements of SAE J2210 to remove HFC-134a(R-134a) from the air conditioning system.

- Air conditioning refrigerant or lubricant vapor can irritate your eyes, nose, or throat.
- Be careful when connecting service equipment.
- Do not breathe refrigerant or vapor.

If accidental system discharge occurs, ventilate work area before resuming service.

Additional health and safety information may be obtained from the refrigerant and lubricant manufacturers.

1. Connect an R-134a refrigerant

Recovery/ Recycling/ Charging System (A) to the high-pressure service port (B) as shown, following the equipment manufacturer's instructions.

EQKE004A

2. Add the same amount of new refrigerant oil to system that was removed during recovery. Use only specified refrigerant oil. Charge the system with 18.0 \pm 0.88 oz. (500 \pm 25g) of R-134a refrigerant. Do not overcharge the system the compressor will be damaged.

HA-12 Heating, Ventilation, Air Conditioning


Refrigerant Leak Test

Always conduct a leak test with an electronic leak detector whenever leakage or refrigerant is suspected and when conducting service operations which are accompanied by disassembly or loosening or connection fittings.

In order to use the leak detector properly, read the manual supplied by the manufacturer.

If a gas leak is detected, proceed as follows:

- 1. Check the torque on the connection fittings and, if too loose, tighten to the proper torque. Check for gas leakage with a leak detector (A).
- If leakage continues even after the fitting has been tightened, discharge the refrigerant from the system, disconnect the fittings, and check their seating faces for damage. Always replace, even if the damage is slight.
- 3. Check the compressor oil and add oil if required.
- 4. Charge the system and recheck for gas leaks. If no leaks are found, evacuate and charge the system again.






EQKE007A

WWW.DIGITALKHODRO.COM

021 62 99 92 92

Compressor

Component Location



SMGHA9202L

HA-13

WWW.DIGITALKHODRO.COM


WWW.DIGITALKHODRO.COM

021 62 99 92 92

HA-14

Heating, Ventilation, Air Conditioning

Components



- 1. Bolt
- 2. Disc & hub assembly
- 3. Shim (Gap washer)
- 4. Retainer ring (Pulley)
- 5. Pulley
- 6. Retainer ring (Field coil)

- 7. Field coil
- 8. Screw
- 9. Connector bracket
- 10. Compressor assembly
- 11. Manifold
- 12. Bolt wrench
- 13. Gasket

SMGHA9203L

021 62 99 92 92


HA-15

Air conditioning System

Removal


- 1. If the compressor is marginally operable, run the engine at idle speed, and let the air conditioning work for a few minutes, then shut the engine off.
- 2. Disconnect the negative cable from the battery.
- 3. Recover the refrigerant with a recovery/charging station.
- 4. Loosen the drive belt.
- Remove the bolts, then disconnect the suction line

 (A) and discharge line (B) from the compressor. Plug
 (C) or cap the lines immediately after disconnecting them to avoid moisture and dust contamination.



KQRE105C

 Disconnect the compressor clutch connector (A), and then remove 4 mounting bolts and the compressor.




KQRE105D

Installation

1. Make sure of the length of compressor mounting bolts, and then tighten it $A \rightarrow B \rightarrow C \rightarrow D$ order.

Tightening Torque: 2.04 ~ 3.36 kgf.m



AQJF105E

- 2. Install in the reverse order of removal, and note these items.
 - If you're installing a new compressor, drain all the refrigerant oil from the removed compressor, and measure its volume, Subtract the volume of drained oil from 150cc(5.07 oz.) the result is the amount of oil you should drain from the new compressor (through the suction fitting).
 - Replace the O-rings with new ones at each fitting, and apply a thin coat of refrigerant oil before installing them. Be sure to use the right O-rings for R-134a to avoid leakage.
 - To avoid contamination, do not return the oil to the container once dispensed, and never mix it with other refrigerant oils.
 - Immediately after using the oil, replace the cap on the container and seal it to avoid moisture absorption.
 - Do not spill the refrigerant oil on the vehicle; it may damage the paint; if the refrigerant oil contacts the paint, wash it off immediately.
 - Adjust the drive belt.
 - Charge the system and test its performance.

WWW.DIGITALKHODRO.COM


021 62 99 92 92


HA-16

Heating, Ventilation, Air Conditioning

Disassembly

1. Remove the center bolt (A) while holding the disc & hub assembly with a commercially available disc & hub assembly bolt remover; Special tool number 09977-29000.






AQJF106D

AQJF106E


 Remove the disc & hub assembly (A) and shim (gap washer) (B), taking care not to lose the shims. If the clutch needs adjustment, increase or decrease the number and thickness of shims as necessary, then reinstall the disc & hub assembly, and recheck its clearance. 3. If you remove the field coil, remove retainer ring (A) with retainer ring pliers.

- Be careful not to damage the pulley (B) and compressor during removal/installation.
- Once retainer ring (A) is removed, replace it with a new one.



AQJF106F

 Remove the screw (A) from the field coil ground terminal. Remove the retainer ring (B) and then remove the field coil (C) from the shaft with a puller. Be careful not to damage the coil and compressor.



AQJF106G

- 5. Reassemble the compressor clutch in the reverse order of disassembly, and note these items :
 - Clean the pulley and compressor sliding surfaces with non-petroleum solvent.
 - Install new retainer rings, and make sure they are fully seated in the groove.
 - Make sure that the pulley turns smoothly after its reassembled.

WWW.DIGITALKHODRO.COM


021 62 99 92 92

HA-17

Air conditioning System

Inspection

- Check the plated parts of the disc & hub assembly (A) for color changes, peeling or other damage. If there is damage, replace the clutch set.
- 2. Check the pulley (B) bearing play and drag by rotating the pulley by hand. Replace the clutch set with a new one if it is noisy or has excessive play/drag.




AQJF106A

3. Measure the clearance between the pulley (B) and the disc & hub assembly (A) all the way around. If the clearance is not within specified limits, remove the disc & hub assembly and add or remove shim (gap washer) as needed to increase or decrease clearance.

Clearance : 0.45 ± 0.1 mm (0.018 ± 0.004 in.)

MOTICE


The shims (gap washers) are available in seven thicknesses: 0.7mm, 0.8mm, 0.9mm, 1.0mm, 1.1mm, 1.2mm and 1.3mm.



AQJF106B

- 4. Check operation of the magnetic clutch.
 - Connect the compressor side terminals to the battery (+) terminal and the ground battery (-) terminal to the compressor body.

Check the magnetic clutch operating noise to determine the condition.



AQJF106C



Heating, Ventilation, Air Conditioning

Compressor oil

Inspection

Oil Specification

- 1. The HFC-134a system requires synthetic (PAG) compressor oil whereas the R-12 system requires mineral compressor oil. The two oils must never be mixed.
- Compressor (PAG) oil varies according to compressor model. Be sure to use oil specified for the model of compressor.

Handling Of Oil

- 1. The oil should be free from moisture, dust, metal powder, etc.
- 2. Do not mix with other oil.
- The water content in the oil increases when exposed to the air. After use, seal oil from air immediately. (HFC-134a Compressor Oil absorbs moisture very easily.)
- 4. The compressor oil must be stored in steel containers, not in plastic containers.

Compressor Oil Check

The oil **used** to lubricate the compressor is circulating with the refrigerant.

Whenever replacing any component of the system or a large amount of gas leakage occurs, add oil to maintain the original amount of oil.

Oil total volume in system:

 $150\pm10cc$ (5.07 ±0.34 fl.oz) - α engine, U engine

Oil Return Operation

There is close affinity between the oil and the refrigerant.

During normal operation, part of the oil recirculates with the refrigerant in the system.

When checking the amount of oil in the system, or replacing any component of the system, the compressor must be run in advance for oil return operation. The procedure is as follows :

- 1. Open all the doors and the engine hood.
- 2. Start the engine and air conditioning switch to "ON" and set the blower motor control knob at its highest position.
- 3. Run the compressor for more than 20 minutes between 800 and 1,000 rpm in order to operate the system.
- 4. Stop the engine.

Replacement Of Component Parts

When replacing the system component parts, supply the following amount of oil to the component parts to be installed.

Component parts to be i - nstalled	Amount of Oil
Evaporator	50 cc (1.70 fl.oz)
Condenser	30 cc (1.02 fl.oz)
Receiver/dryer	30 cc (1.02 fl.oz)
Refrigerant line(One piece)	10 cc (0.34 fl.oz)

For compressor replacement, subtract the volume of oil drained from the removed compressor from the specified volume, and drain the calculated volume of oil from the new compressor :


The specified volume - volume of removed compressor = volume to drain from the new compressor.

NOTICE

Even if no oil is drained from the removed compressor, don't drain more than 50cc from new compressor.

Condenser

Component Location



SMGHA9204L

Heating, Ventilation, Air Conditioning

Inspection

- 1. Check the condenser fins for clogging and damage. If clogged, clean them with water, and blow them with compressed air. If bent, gently bend them using a screwdriver or pliers.
- 2. Check the condenser connections for leakage, and repair or replace it, if required.

Replacement

Condenser Assembly

- 1. Recover the refrigerant with a recovery/ recycling/ charging station.
- 2. Disconnect the negative (-) battery terminal.
- 3. Remove the radiator. (Refer to EM Radiator).


-

 Remove 2 bolts, and then remove the condenser (A) by lifting it up. Be careful not to damage the radiator and condenser fins when removing the condenser.

Desiccant

1. Remove the condenser, and then remove the bottom cap (B) with L wrench (A) from the condenser.

TORQUE: 20~25N.m (2.0~2.5kgf·m, 14.5~18.2lb-ft)



KQRE108D

2. Remove the desiccant (A) from condenser using a long nose plier. Check for crumbled desiccant and clogged bottom cap filter.

AQLF108B

- 5. Install in the reverse order of removal, and note these items :
 - If you're installing a new condenser, add refrigerant oil ND-OIL8.
 - Replace the O-rings with new ones at each fitting, and apply a thin coat of refrigerant oil before installing them. Be sure to use the right O-rings for R-134a to avoid leakage.
 - Be careful not to damage the radiator and condenser fins when installing the condenser.
 - Be sure to install the lower mount cushions of condenser securely into the holes.
 - Charge the system, and test its performance.

KQRE108E

- 3. Apply air conditioning compressor oil along the O-rings and threads of the new bottom cap.
- 4. Insert the new desiccant into the receiver drier tank. The desiccant must be sealed in vacuum before it is exposed to air for use.

5. Install the new bottom cap to the condenser.

WNOTICE

- Always replace the desiccant and bottom cap at the same time.
- Replace the O-rings with new ones at each fitting, and apply a thin coat of refrigerant oil before installing them. Be sure to use the right O-rings for R-134a to avoid leakage.
- Be careful not to damage the radiator and condenser fins when installing the condenser.
- Be sure to install the lower mount cushions of condenser securely into the holes.
- Charge the system, and test its performance.

واستساولته ديرجي تاليتهم بكايات خمديرمدير ليران




HA-21

HA-22 Heating, Ventilation, Air Conditioning

Refrigerant line

Component Location



SMGHA9205L

Replacement

- 1. Discharge refrigerant from refrigeration system.
- 2. Replace faulty tube or hose.

Cap the open fittings immediately to keep moisture or dirt out of the system.

3. Tighten joint of bolt or nut to specified torque.

Connections should not be torque tighter than the specified torque.

Part tightened	Kg.m(N.m , lbf.ft)
Condenser - Discharge ho- se	0.5~0.6
Condenser - Liquid tube	
Compressor - Discharge h- ose	0.5~0.6
Compressor - Suction hose	
Expansion valve - Evapor- ator	1.2~1.5

Evacuate air in refrigeration system and charge system with refrigerant.

Specified amount : 500 ± 25g

5. Inspect for leakage of refrigerant.

Using a gas leak detector, check for leakage of the second refrigerant.

6. Inspect A/C operation.



HA-23


HA-24 Heating, Ventilation, Air Conditioning

A/C pressure transducer

Description

A/C pressure transducer convert the pressure value of high pressure line into voltage value after measure it. By converted voltage value, engine ECM controls cooling fan by operating it high speed or low speed. Engine ECM stop the operation of compressor when the temperature of refrigerant line is so high or so low irregularly to optimize air conditioning system.

Component Location



SMGHA9206L


021 62 99 92 92

HA-25

Air conditioning System

Inspection

1. Measure the pressure of high pressure line by measuring voltage output between NO.1 and NO.2 terminals.



EQRF116B

2. Inspect the voltage value whether it is sufficient to be regular value or not.

Voltage= 0.00878835 * Pressure(Psig) + 0.5


3. If the measured voltage value is not specification, replace the A/C pressure transducer.

یتال خودرو سامانه (مسئولیت محدود

ی<mark>ین سامانه دیجیتال تعمیرکاران خودرو در آیرا</mark>ن

Replacement

- 1. Disconnect the negative (-) battery terminal.
- 2. Recover the refrigerant with a recovery/charging station.
- Disconnect A/C pressure transducer connector (3P) (A).



AQLF116C

Take care that liquid & suction pipe are not bent.

4. Installation is the reverse order of removal.

TORQUE : 10~12N.m (1.0~1.2kgf.m, 7.4~8.8lb.ft)

HA-26 Heating, Ventilation, Air Conditioning


Evaporator temperature sensor

Description

The evaporator temperature sensor will detect the evaporator core temperature and interrupt compressor relay power in order to prevent evaporator freezing by excessive cooling.

It is a negative type thermistor whose resistance is inversely proportional to temperature.

Component Location



SMGHA9207L

WWW.DIGITALKHODRO.COM

021 62 99 92 92

HA-27

Air conditioning System

Inspection


- 1. Ignition "OFF"
- Disconnect evaporator temperature sensor.
 Using the multi-tester, Measure resistance between terminal "1" and "2" of evaporator temperature sensor.

TEMP [°C]	RESISTANCE [KΩ]
-10	43.35
0	26.62
10	18.07
20	12.11
30	8.30
40	5.81

2

Replacement

- 1. Remove the crash pad center lower cover. (Refer to BD Crash pad)
- 2. Remove the evapotator sensor connector(A).
- 3. Remove the evaporator temperature sensor(B), by pulling it after rorating 90° in a counterclockwise direction.



KQRE161B

4. Installation is the reverse order of removal.

اولین سامان<mark>ه دیجیتال تعمیرکاران خودرو در ایرا</mark>ن

AQGE116C

HA-28 Heating, Ventilation, Air Conditioning

In-car sensor

Description

- 1. In-car air temperature sensor is located at the center facia panel.
- 2. It perceives the inside temperature, changes the resistance value, and enters the corresponding voltage into the automatic temperature control module.



Component Location

HA-29

021 62 99 92 92

LQLG201A

021 62 99 92 92





AQLF201C

HA-30

Heating, Ventilation, Air Conditioning

Inspection

- 1. Ignition "ON".
- Blow air with changing temperature to the in car sensor air inlet. Measure sensor resistance between 2 and 4 terminals.

Specification

Temperature [°C(°F)]	Resistance between ter - minals 2and 4 (kΩ)
0 (32)	97.71 ± 2.61%
15 (59)	$47.13 \pm 1.45\%$
25 (77)	30.00 ± 1.20%
35 (95)	$19.59 \pm 1.44\%$
50 (122)	10.81 ± 2.26%

In car sensor is negative type thermistor that resistance will rise with lower temperature, and reduce with higher temperature.

Replacement

- 1. Disconnect the negative (-) battery terminal.
- 2. Remove the center facia panel. (Refer to BD group Crash pad).
- Disconnect the connector of in-car sensor (A).Loosen the mounting 2 screws and then remove the in-car sensor (B).

Installation is the reverse order of removal.

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Photo sensor

Description

- 1. The photo sensor (A) is located at the center of defrost nozzle.
- The photo sensor contains a photovoltaic (sensitive to sunlight) diode. The solar radiation received by its light receiving portion, generates an electromotive force in proportion to the amount of radiation received which is transferred to the automatic temperature control module so that the solar radiation compensation will be performed.

Component Location



SMGHA9208L

021 62 99 92 92

HA-31

WWW.DIGITALKHODRO.COM

021 62 99 92 92

HA-32

Heating, Ventilation, Air Conditioning

Inspection

- 1. Ignition "ON".
- 2. Using the scan tool.
- 3. Emit intensive light toward photo sensor using a lamp, and check the output voltage change.
- 4. The voltage will rise with higher intensive light and reduce with lower intensive light.

Replacement

- 1. Disconnect the negative (-) battery terminal.
- 2. With the (-) driver, remove the photo sensor (B) from the center of defrost nozzle (A).

AQGE202D

3. Install in the reverse order of removal.



اولین سامان<mark>ه دیجیتال تعمیرکاران خودرو در ایرا</mark>ن

Water temperature sensor

Description

- 1. Water temperature sensor is located at the heater unit.
- It detects coolant temperature. Its signal is used for cold engine lockout control. When the driver operates the heater before the engine is warmed up, the signal from sensor causes the heater control unit to reduce blower motor speed until coolant temperature reaches the threshold value.

Component Location



SMGHA9209L

021 62 99 92 92

HA-33

WWW.DIGITALKHODRO.COM

WWW.DIGITALKHODRO.COM

021 62 99 92 92

HA-34

Heating, Ventilation, Air Conditioning

Inspection

- 1. Ignition "ON".
- 2. Using the multi-tester, Measure resistance between terminal "1" and "2" of water temperature sensor.

Replacement

- 1. Disconnect the negative (-) battery terminal.
- 2. Remove the grove box. (Refer to BD Crash pad)
- 3. Pull the water temperature sensor out at the heater unit with the clamp (C).

EQ	RF2	203	D

Specification

Coolant temperature [°C(°F)]	Resistance (kΩ)	Voltage (V)	
-10(14)	55.85 ± 3%	4.24 ± 3%	
0(32)	32.91 ± 3%	3.83 ± 3%	1
10(50)	19.99 ± 3%	3.33 ± 3%	
20(68)	12.51 ± 3%	$2.78\pm3\%$	
30(86)	8.047 ± 3%	2.23 ± 3%	
40(104) 3 0 13	5.311 ± 3%	1.73 ± 3%	
50(122)	3.588 ± 3%	1.32 ± 3%	
60(140)	$2.476\pm3\%$	0.99 ± 3%	
70(158)	1.742 ± 3%	0.74 ± 3%	
80(176)	1.246 ± 3%	0.55 ± 3%	

- 3. If the measured resistance is not specification, substitute with a known-good water temperature sensor and check for proper operation.
- 4. If the problem is corrected, replace the water temperature sensor.

MOTICE

Negative type thermistor that resistance will rise with lower temperature, and reduce with higher temperature. AQLF203E

4. Installation is the reverse order of removal.

WNOTICE

Take care that wire of water temperature sensor is not to be damaged.

اولين ساما

Ambient sensor

Component Location

Description

- The ambient temperature sensor is located at the front side of the condenser and detects ambient air temperature. It is a negative type thermistor; resistance will increase with lower temperature, and decrease with higher temperatures.
- The sensor output will be used for discharge temperature control, temperature regulation door control, blower motor level control, mix mode control and in-car humidity control.

MOTICE

If the ambient temperature is below $2.0^{\circ}C$ ($35.6^{\circ}F$), the A/C compressor will be stopped.

The compressor will be operated by manual operating.



SMGHA9210L

HA-35

021 62 99 92 92

Heating, Ventilation, Air Conditioning

Inspection

- 1. Ignition "OFF".
- 2. Disconnect ambient temperature sensor.
- 3. Check the resistance of ambient temperature sensor between terminals 1 and 2 whether it is changed by changing of the ambient temperature.

Specification

Ambient temperature [°C(° F)]	Resistance between termi- nals 1 and 2 (kΩ)
-10 (14)	158.2 ± 3%
0 (32)	95.10 ± 3%
10 (50)	$58.76\pm3\%$
20 (68)	$\textbf{37.30} \pm \textbf{3\%}$

Replacement

- 1. Disconnect the negative (-) battery terminal.
- 2. Remove the front bumper. (Refer to BD group Front bumper)
- 3. Remove the ambient temperature sensor (A).

AQLF203E

4. Installation is the reverse order of removal.

سرکت دیج<mark>یتال خودرو سامانه (مسئولیت محدود</mark>)

ا اولین سامان<mark>ه دیجیتال تعمیرکاران خودرو در ایران</mark>

- 4. If the measured resistance is not specification, substitute with a known-good ambient temperature sensor and check for proper operation.
- 5. If the problem is corrected, replace the ambient temperature sensor.

Air Quality Sensor(AQS)

Description

- 1. A.Q.S is located at center support in front of the engine radiator, and detects hazardous elements in ambient air providing output signal to control.
- 2. It will detect sulfurous acid gas, carbon dioxide, carbon monoxide, hydrocarbon and allergen.

Component Location



HA-37

021 62 99 92 92

HA-38

Heating, Ventilation, Air Conditioning

Inspection

- 1. Ignition "ON"
- 2. Using the scan tool.
- Check the output voltage of AQS between terminals 2 and 3.

Specification :

Condition	Output signal	Fresh/recirculati- on
Normal condition	$4 \sim 5V$	Fresh
Hazardous gas d- etection	0~1V	Recirculation

Replacement

- 1. Disconnect the negative (-) battery terminal.
- 2. Remove the front bumper (Refer to BD group).
- 3. Remove the AQS (B) after loosening the mounting screws.

LQLG204C

4. Installation is the reverse order of removal.

شرکت دیج<mark>ی</mark>تال خودرو سامانه (مسئولیت محدود)

اولین سامان<mark>ه دیجیتال تعمیرکاران خودرو در ایرا</mark>ن BOKE207B

4. AQS diagnosis and fail safe

Detect the open of signal for 7 seconds without choosing the AQS switch when IG on.

If 2.5V or more is detected for 3.5 seconds or more among 7 seconds, be judged the open of AQS signal. Operate as below fail safe function, while choosing AQS.

Fail safe: Release the AQS (AQS cannot be selected), Fresh/recirculation maintains previous situation of AQS selection.

MOTICE

When IG is turned ON, AQS heats for 34 ± 5 seconds, it will output below 1.0 voltage during this time.

Air conditioning System

WWW.DIGITALKHODRO.COM

Humidity Sensor

Description

- 1. Humidity sensor is located at the lower crush pad and detected in-car humidity for in-car humidity control.
- 2. If ambient air temperature or in-car humidity is outside certain range, it will turn on A/C to control in-car humidity preventing in car fogging.

Air conditioner operation depends on ambient temperature and humidity.



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران





021 62 99 92 92

HA-39

HA-40 Heating, Ventilation, Air Conditioning

Component Location



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

LQLG210A

WWW.DIGITALKHODRO.COM

021 62 99 92 92

021 62 99 92 92

HA-41

AQLF201C

Air conditioning System

Inspection

- 1. Ignition "ON".
- 2. Using the scan tool.
- 3. Check the frequency of humidity sensor between terminals 2 and 3.

Humidity (%)	Frequency between termin- als 2and 3 (Hz)
30	6976 ± 5%
50	$6728 \pm 5\%$
60	$6600\pm5\%$
70	$6468 \pm 5\%$
80	6330 ± 5%
90	$6186 \pm 5\%$

- 4. If the measured resistance is not specification, substitute with a known-good humidity sensor and check for proper operation.
- 5. If the problem is corrected, replace the Humidity sensor.

Replacement

- 1. Disconnect the negative (-) battery terminal.
- 2. Remove the center facia lower panel. (Refer to BD group Crash pad)
- 3. Disconnect the humidity sensor connector.
- 4. Loosen 2 screws and then remove the humidity sensor (C).

5. Installation is the reverse order of removal.

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

HA-42 Heating, Ventilation, Air Conditioning

Heater

Heater Unit

COMPONENT LOCATION



SMGHA9212L

Heater

COMPONENTS



- 1. Heater & Evaporator case
- 2. Heater core
- 3. Heater core cover
- 4. PTC heater
- 5. Water temperature sensor
- 6. Water temperature stopper
- 7. Temp control actuator
- 8. Mode control actuator

9. Mode cam

- 10. Defrost door
- 11. Vent door
- 12. Floor door
- 13. Temp control door
- 14. Heater & Evaporator lower case
- 15. Evaporator case seal
- 16. Evaporator core
- 17. Evaporator temp sensor

021 62 99 92 92

SMGHA9213L

021 62 99 92 92

HA-44	Heating,V	ent	tilation, Air Conditioning
 Replacement 1. Disconnect the negative (-) batter 2. Recover the refrigerant with a charging station. 3. When the engine is cool, drain from the radiator. 4. Remove the expansion valve cov 	recovery/ recycling/ the engine coolant	6.	Disconnect the inlet (A) and outlet (B) heater hoses from the heater unit.
 Remove the bolts (A) and the from the evaporator core. Plug or cap the lines immediately them to avoid moisture and dust 	y after disconnecting contamination.	8.	LQLG300E CAUTION Engine coolant will run out when the hoses are disconnected; drain it into a clean drip pan. Be sure not to let coolant spill on electrical parts or painted surfaces. If any coolant spills, rinse it off immediately. Remove the crash pad (Refer to BD group - Crash pad). Remove the cowl cross bar assembly. (Refer to BD group - Crash pad) Remove the heater & blower unit after loosening 3 mounting bolts
	AQLF300D		mounting bolts.

WWW.DIGITALKHODRO.COM

021 62 99 92 92

Heater

10. Remove the blower unit (B) from heater unit after loosening 3 screws.

- AQLF300G
- 11. After disconnect the heater core cover(A), remove the heater core(B).

LF300G

- 13.Be careful that the inlet and outlet pipe are not bent during heater core removal, and pull out the heater core.
- 14. Install the heater core in the reverse order of removal.
- 15. Installation is the reverse order of removal, and note these items :
 - If you're installing a new evaporator, add refrigerant oil (ND-OIL8).
 - Replace the O-rings with new ones at each fitting, and apply a thin coat of refrigerant oil before installing them. Be sure to use the right O-rings for R-134a to avoid leakage.
 - Immediately after using the oil, replace the cap on the container, and seal it to avoid moisture absorption.
 - Do not spill the refrigerant oil on the vehicle ; it may damage the paint ; if the refrigerant oil contacts the paint, wash it off immediately.
 - Apply sealant to the grommets.
 - Make sure that there is no air leakage.
 - Charge the system and test its performance.
 - Do not interchange the inlet and outlet heater hoses and install the hose clamps securely.
 - Refill the cooling system with engine coolant.

اولین سامان<mark>ه دیجیتال تعمیرکاران خودرو در ایرا</mark>ن

AQLF300H

12. After disconnect the evaporator cover(A), remove the evaporator(B).

AQLF300I

HA-46 Heating, Ventilation, Air Conditioning

Temperature Control Actuator

Description

- 1. Heater unit includes mode control actuator and temperature control actuator.
- 2. Temperature control actuator is located at the heater unit. It regulates the temperature by the procedure as follows. Signal from control unit adjusts position of temperature door by operating temperature switch and then temperature will be regulated by the hot/cold air ratio decided by position of temperature door.

Component Location



SMGHA9214L

Heater

021 62 99 92 92

HA-47

Inspection

Max. hea-

ting

controls.

control actuator.

- 1. Ignition "OFF".
- 2. Disconnect the connector of temperature control actuator.
- 3. Verify that the temperature control actuator operates to the hot position when connecting 12V to the terminal 3 and grounding terminal 4.

Verify that the temperature control actuator operates to the cool position when connecting in the reverse.

Replacement

- 1. Disconnect the negative (-) battery terminal.
- 2. Remove the driver's crash pad lower panel (Refer to BD group Crash pad).
- 3. Disconnect the temperature control actuator connector (A) after removing the air duct.
- 4. Loosen the mounting screw and then remove the temperature control actuator (B).

LQLG315B 4. Check the voltage between terminals 6 and 7. Specification Door pos-ition Voltage (6-7) Error detecting Max. coo-ling $0.3 \pm 0.15V$ Low voltage : 0.1V or less

High voltage :

4.9V or more

 $4.7\pm0.15V$

actuator and check for proper operation.

It will feedback current position of actuator to

5. If the measured voltage is not specification, substitute with a known-good temperature control

6. If the problem is corrected, replace the temperature

HA-48 Heating, Ventilation, Air Conditioning

Mode Control Actuator

Description

The mode control actuator is located at the heater unit.

It adjusts position of mode door by operating mode control actuator based on signal of A/C control unit. Pressing mode select switch makes the mode control actuator shift in order of vent \rightarrow B/L \rightarrow floor \rightarrow mix.

Component Location



SMGHA9215L

Heater

HA-49

Inspection

- 1. Ignition "OFF".
- 2. Disconnect the connector of mode control actuator.
- 3. Verify that the mode control actuator operates to the defrost mode when connecting 12V to the terminal 3 and grounding terminal 4.
- 4. Verify that the mode control actuator operates to the vent mode when connecting in the reverse.

Replacement

- 1. Disconnect the negative (-) battery terminal.
- 2. Remove the driver's crash pad lower panel. (Refer to BD group Crash pad).
- Disconnect the mode control actuator connector (A) after removing the air duct.
- 4. Loosen the mounting screws and then remove the mode control actuator (B).

	LQLG316B	AQLF316C
5. Check the voltage between te	rminals 6 and 7.	5. Installation is the reverse order of removal.
Door pos- ition Voltage (6-7)	Error detecting	شرکت دیج
Vent 0.3 ± 0.15V	Low voltage : 0.1V or less	اولین سامان
Defrost 4.7 ± 0.15V	High voltage : 4.9V or more	
 If the measured voltage substitute with a known-good and check for proper operation If the problem is corrected, re actuator. 	I mode control actuator n.	

HA-50 Heating, Ventilation, Air Conditioning

Positive Temperature coefficient)heater

Description

PTC (Positive Temperature Coefficient) heater (A) is an electric heater using a PTC element as an auxiliary heating device that supplements deficiency of interior heat source in highly effective diesel engine (U engine).

Operation Principle

ECM outputs a PTC on signal. Operate PTC from 1st setting to 3rd setting with an interval of 15 seconds. Heat up the air, which passes through a heater core.

LQJF301C LQJF301B **Operation Condition** An electric heater heats up the interior by directly heating Judge the condition by ambient temperature is below the air that passes through the heater. 5°C, coolant temperature is below 70°C, and battery PTC = positive Temperature Coefficient voltage is above 11V and engine RPM is above 700RPM. The name itself implies that the element has a proportional resistance change sensitive to temperature. PTC heater is installed at the exit or the backside of heater core. AQJF301A

WWW.DIGITALKHODRO.COM

021 62 99 92 92

HA-51

Heater

Inspection

Inspect the PTC operation by confirmation logic as below.

- 1. Entering method
 - 1) Set the floor mode, maximum heating
 - 2) Turn off the blower switch
 - 3) Press the intake button more than 5 times.
 - 4) Indicator of entire button is flashed with an interval of 0.5 seconds continuously (Manual). Graphics of the entire LCD display switch on and off with an interval of 0.5 seconds continuously (Automatic)
 5) Confirm the BTC enception by execution the second secon
 - 5) Confirm the PTC operation by operating the blower switch

Manual : 1~4 step, Automatic: 1~8step.

- 6) Each PTC relay is operated with an interval of 3 seconds.
- Execute the PTC operation by confirmation logic for 30 seconds.

2. Cancellation method

- 1) Select the A/C button or intake button.
- 2) IG "OFF".
- 3) Cancel the logic after 30 seconds automatically.
- If the PTC operation is not operated, substitute with a known-good PTC and check for proper operation.
 If the problem is corrected, replace the PTC.

Replacement

- 1. Remove the crash pad glove box. (Refer to BD Crash pad)
- 2. After loosen the PTC heater mounting serew, remove the PTC heater(A).

AQKF301D

3. Remove the PTC heatoer(A).

AQKF301E

4. Installation is the reverse order of removal.

HA-52 Heating, Ventilation, Air Conditioning

Blower

Blower Unit

Component Location



SMGHA9216L

Blower

Components



- 2. Fresh duct case
- 3. Intake door assembly
- 4. Intake actuator

- 6. Air filter housing
- 7. Blower upper case
- 8. Blower lower case

- 10. Blower motor
- 11. Power mosfet

HA-53

021 62 99 92 92

HA-54 Heating, Ventilation, Air Conditioning

Replacement

- 1. Disconnect the negative (-) battery terminal.
- Remove the crash pad.(Refer to BD group Crash pad)
- Disconnect the connectors from the fresh and recirculation actuator, the blower motor and power mosfet.
- Remove the cowl cross bar assembly.(Refer to BD group Crash pad)
- 5. Remove the blower unit (B) from the heater unit after loosening a mounting bolt and 3 screws.

حیصال خورو شرکت دیجیتال ج_{AQLF300} سامانه (مسئولیت محدود)

MOTICE

Make sure that there is no air leaking out of the block of block of the block of th

6. Installation is the reverse order of removal.



Blower

Blower Motor

Component Location



SMGHA9218L

021 62 99 92 92

HA-56

Heating, Ventilation, Air Conditioning

Inspection

1. Connect the battery voltage and check the blower motor rotation.

Replacement

- 1. Disconnect the negative (-) battery terminal.
- 2. Disconnect the connector (A) of the blower motor.

AQIE352C

- 2. If the blower motor voltage is not operated well, substitute with a known-good blower motor and check for proper operation.
- 3. If the problem is corrected, replace the blower motor.

3. Remove the blower motor (A) after loosening the mounting screws.

ترکت دیجیتال خودرو سامانه (مسئولیت محدود

اولین سامان<mark>ه دیجیتال تعمیرکاران خودرو در</mark> ایران

AQJF352B

AQJF352D

4. Installation is the reverse order of removal.

WWW.DIGITALKHODRO.COM

Blower

Power Mosfet

Component Location



SMGHA9219L

021 62 99 92 92

HA-58

Heating, Ventilation, Air Conditioning

Inspection

- 1. Ignition "ON".
- 2. Manually operate the control switch and measure the voltage of blower motor between pin 1 and 2.
- 3. Select the control switch to raise voltage until high speed.

Replacement

- 1. Disconnect the negative (-) battery terminal.
- 2. Disconnect the power mosfet connector (A) at the connecting part between heater and blower unit.
- 3. Remove the power mosfet (B) after loosening the mounting screws.

LQLG335C

4. Installation is the reverse order of removal.

یتال خودرو سامانه (مسئولیت Specification				
For	Motor Voltage			
درو در ایران	ديجيتال Manual كاران خو	d	ł,	
First speed	$3.8\pm0.5V$			
Second speed	$5.0\pm0.5 V$			
Third speed	$6.2\pm0.5V$			
Fourth speed	$7.4\pm0.5V$			
Fifth speed	$8.6\pm0.5V$			
Sixth speed	$9.8\pm0.5V$			
Seventh speed	11.0 ± 0.5V			
eighth speed	Battery(+)			

BQKF355B

AUTO COOLING : Auto speed (4.5V~B+) AUTO HEATING : Auto speed (4.5V~10.5V)

- 4. If the measured voltage is not specification, substitute with a known-good power mosfet and check for proper operation.
- 5. If the problem is corrected, replace the power mosfet.

Blower

HA-59

Climate control air filtar

Description

This has particle filter which eliminates foreign materials and odor. The particle filter includes odor filter as well as conventional dust filter to ensure comfortable interior environment.

Replacement

1. Remove the glove box(A) from the lift(B).

AQLF359C

MOTICE

In case of driving in an air-polluted area or rugged terrain, check and replace the air filter as frequently as possible.

Replacement period : 15,000 km (9320 mile)

AQLF359A

 Open the glove box (B). Lower the glove box down completely by removing the glove box stopper (A) to the glove box.

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

AQJF352B

- 3. Remove the filter cover (A) with pushing the knob.
- 4. Replace the air filter (B), install it after making sure of the direction of air filter.

HA-60 Heating, Ventilation, Air Conditioning

Intake Actuator

Description

- 1. The intake actuator is located at the blower unit.
- 2. It regulates the intake door by signal from control unit.
- 3. Pressing the intake selection switch will shift between recirculation and fresh air modes.

Component Location



SMGHA9220L

Blower

HA-61

AQLF510A

Inspection

- 1. Ignition "OFF".
- 2. Disconnect the intake actuator connector.
- 3. Verify that the intake actuator operates to the recirculation position when connecting 12V to the terminal 3 and grounding terminal 4.
- 4. Verify that the intake actuator operates to the fresh position when connecting in the reverse.

Replacement

- 1. Disconnect the negative (-) battery terminal.
- 2. Remove the glove box (Refer to BD group Crash pad).
- 3. Disconnect the intake actuator connector.
- 4. Loosen the mounting screw and then remove the intake actuator (A) from the blower unit.

5. If the intake actuator is not operated well, substitute with a known-good intake actuator and check for proper operation.
5. Installation is the reverse order of removal.

6. If the problem is corrected, replace the intake actuator.

021 62 99 92 92

HA-62 Heating, Ventilation, Air Conditioning

Controller

Heater & A/C Control Unit(Manual)

Component



AQLF450A

WWW.DIGITALKHODRO.COM

021 62 99 92 92

Controller


Connector Pin Function

HA-63

PIN NO.		Function	PIN NO.		Function름
	1	PTC RLY 2		10	HTD
	2	PTC RLY 3		11	Sensor Ref (5V)
	3	Blower ON Signal		12	-
Connector A	4	PTC ON Signal		13	IGN2
Connector A	5	-		14	Rheostat (ILL-)
	6	-		15	FET (G)
	7	-		16	FET (D)
8	8	-		17	Temp Act'r F/B
	1	Tail lamp (ILL+)	Connector B	18	Modep Act'r F/B
	2	Battery		19	Intake Act'r F/B
3 4 Connector B 6 7	3	A/C output		20	EVA sensor (+)
	4	Mode Act'r (Vent)		21	Blower motor (+)
	5	Mode Act'r (Def)		22	A/C select signal
	6	Temp Act'r (Cool)		23	Rear defog S/W
		Temp Act'r (War- m)		24	Sensor Gnd
(303201"	8	Intake Act'r (Fre)	ئىكت دىچى ت	25	-
(39220	9	Intake Act'r (Rec)		26	Gnd

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

021 62 99 92 92



WWW.DIGITALKHODRO.COM

Controller

Heater & A/C Control Unit(Full Automatic)

Component



021 62 99 92 92



AQLF500A

WWW.DIGITALKHODRO.COM

HA-66

Heating, Ventilation, Air Conditioning

Connector Pin Function


Connector	PIN NO.	Function	Connector	PIN NO.	Function
	1	Tail lamp		1	Sensor REF (+5V)
	2	Battery		2	AQS signal
	3	A/C output		3	AMB sensor (+)
	4	A/C select signal	-	4	Humidity sensor (+)
	5	-	-	5	In car sensor (+)
	6	K-Line	-	6	EVA sensor (+)
	7	-	-	7	Water temp sensor(+)
	8	-	-	8	Speed signal
	9	HTD		9	FET (G)
	10	Rear defog S/W		10	FET (D)
	11	-		11	Blower motor (+)
	12	IGN2		12	Sensor GND
	13	IGN2	Connector (B)	13	-
	14	Rheostat	اولین سامانه	14	-
	15			15	Photo sensor (-)
Connector (A)	16	Temp ACT'R (Co- ol)		16	-
	17	Temp ACT'R (W- arm)		17	In car sensor (-)
	18 18 18 10 10 10 10 10 10 10 10 10 10 10 10 10	Temp ACT'R F/B		18	
	19	Mode ACT'R (Ve- nt)		19	Blower ON signal
	20	Mode ACT'R (D- EF)		20	PTC ON signal
	21	Mode ACT'R F/B		21	PTC RLY 2
	22	Intake ACT'R (F- RE)		22	PTC RLY 3
	23	Intake ACT'R (R- EC)			
	24	Intake ACT'R F/B			
	25	GND			
	26	GND			

Controller

Self-diagnosis

1. Self-diagnosis process

The F.A.T.C. module self test feature will detect electrical malfunction and provide error codes for system components with suspected failures.



WNOTICE DTC data can be retrieved from the control panel directly.

021 62 99 92 92

HA-68

Heating, Ventilation, Air Conditioning

2. How to read self-diagnostic code

After the display panel flickers three times every 0.5 second, the corresponding fault code flickers on the setup temperature display panel every 0.5 second and will show two figures. Codes are displayed in numerical format.

Fault code

Fault code		
Display	DTC	Fail description
0	-	NORMAL
11	B1234	INCAR SENSOR OPEN
12	B1233	INCAR SENSOR SHORT
13	B1238	AMBIET SENSOR OPEN)
14	B1237	AMBIET SENSOR SHORT
15	B1202	WATER TEMP SENSOR OPEN
16	B1203	WATER TEMP SENSOR SHORT
17	B1242	EVAP SENSOR OPEN
18	B1241	EVAP SENSOR SHORT
19	B1245	TEMP POTENTIMETER OPEN
19	B1246	TEMP POTENTIMETER SHORT
20 20	B2406	TEMP POTENTIMETER FAULT
21	B1249	MODE POTENTIMETER OPEN
	B1250	MODE POTENTIMETER SHORT
22	B2409	MODE POTENTIMETER FAULT
23	B1200	HUMIDITY SENSOR OPEN
24	B1201	HUMIDITY SENSOR SHORT
25	B1208	INTAKE POTENTIOMETER OPEN
25	B1209	INTAKE POTENTIOMETER SHORT
26	B2408	INTAKE POTENTIOMETER FAULT
27	B1257	AQS SENSOR OPEN
28	B1258	AQS SENSOR SHORT
31	B1259	AQS SENSOR FAULT

WWW.DIGITALKHODRO.COM

Controller

- 3. Fault code display
 - 1) Continuance operation : DTC code is one.

2) Continuance operation : DTC code is more two.

BQKF500D 3) STEP operation A. Nomal or one fault code is same as a continuance operation . B. DTC code os more two.

BQKF500E



BQKF500C

021 62 99 92 92



021 62 99 92 92

HA-70

Heating, Ventilation, Air Conditioning

- 4. If fault codes are displayed during the check, Inspect malfunction causes by referring to fault codes.
- Fail safeIn-car temperature sensor: Control with the value of 25°C(77°F)
 - Ambient temperature sensor: Control with the value of 20°C(67°F)
 - Evaporator temperature sensor: Control with the value of -2°C(28.4°F)
 - 3) Humidity sensor: Control with the value of 10%
 - Temperature sensor : Control with the value of -2°C (28.4°F)
 - 5) Temperature control actuator (Air mix potentiometer):

If temperature setting 17°C-24.5°C, fix at maximum cooling position.

If temperature setting 25°C-32°C, fix at maximum heating position

6) Mode control actuator (Direction potentiometer):

Fix vent position, while selecting vent mode.

Fix defrost position, while selecting all except vent mode.

7) Intake control actuator :


Fix fresh position, while selecting fresh mode.

Fix recirculation position, while selecting recirculation mode.

 AQS sensor : AQS operation OFF.
 Intake position : The position before selecting AQS switch.



021 62 99 92 92



WWW.DIGITALKHODRO.COM