



12- Electrical system

Roof	12-1843
Technical specifications ...	12-1843
Operating Principle	12-1844
Diagnosis Information and Procedures	12-1845
Removal and Installation .	12-1851

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



12

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Roof



Roof

Technical specifications

General specifications

Name	Specification	
Normal operating voltage	12V	13V
Operating voltage range	9~16V	9~15V
Operating environment temperature	-30 °C ~ 85 °C	-30 °C ~ 90 °C

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



12

12-1843



Operating Principle

System overview

If your vehicle is equipped with a sunroof, you can open, close, or tilt the sunroof with the sunroof control switch on the roof. The sunroof can only be operated when the ignition switch is in "ON" position.

⚠ Warning:

Do not operate the sunroof during driving process, otherwise the vehicle may be loss of control due to driver attention transfer, resulting in traffic accidents, with property damage or person injury or even death.

The sunroof system consists of the following components:

- Skylight switch
- Skylight motor
- Sunroof frame assembly

Power window function logic description

Remote control window closing function

When BCM/PEPS controller receives the remote control locking high-frequency signal for more than 2s sent from the remote control key, if all remote control window closing conditions are met, BCM/PEPS controller will perform the window and sunroof closing function. (all configurations are provided with the sunroof closing function, without need of diagnosis opening function.)

Remote control window closing function conditions (and):

1. The ignition switch is in OFF position;
2. The remote control key ID is legal;
3. The key insertion signal is withdraw;
4. Receive the remote control locking signal for more than 2s.

Remote window closing operation stop conditions (or):

1. During closing process, receive a remote control locking signal;
2. During closing process, receive a remote control unlocking (door) signal;
3. During closing process, receive a remote control trunk unlocking signal;
4. During closing process, the left front door lock status signal is switched from vain to the low level (unlocking);
5. During closing process, the ignition switch is in non-OFF position.

The remote control window close stop function executes the action:

Do not perform the corresponding unlocking and locking function, perform the window closing stop function; the sunroof will be closed continuously.

During the remote control window closing process, PEPS will outputs the high level signal (continuous 2s) to the sunroof controller.



Roof



Diagnosis Information and Procedures

Diagnosis Instructions

Before the sunroof system troubleshooting, must familiarize and understand its working principle, and then perform its diagnosis, which helps to determine the correct troubleshooting steps in case of a fault, and more importantly, to determine whether the situation described by the user is normal. In any sunroof system fault diagnosis, must first inspect it, and guide the maintenance staff to take the next logical steps for fault diagnosis. Comprehend and correctly use the diagnostic flow chart to shorten the diagnosis time and avoid the misjudgement.

General equipment

Digital multimeter
Diagnostic equipment of vehicle

Visual inspection

1. Confirm the problem raised by the customer.
2. Check for the evident mechanical or electrical damage trace.

Visual inspection table

Electrical
• Fuse
• Harness or plug
• Dashboard fuse box
• Skylight switch
• Skylight motor
• PEPS ECU/BCM
3. Check the system lines easy to see or can be seen.
4. If the observed or raised problem is the evident and the cause has been found, ensure to fix this fault before proceeding with the next step.
5. If for the problem, there are no obvious findings, then confirm the fault and refer to the symptom table.



Fault symptoms table

Symptom	Possible cause	Recommended measure
The sunroof can not be opened	<ul style="list-style-type: none"> • Skylight mechanical seizing • Fuse • Harness or plug • Dashboard fuse box • Skylight switch • Skylight motor • PEPS ECU/BCM 	Refer to: Diagnosis procedure about that the sunroof can not be opened
The opened sunroof can not be closed	<ul style="list-style-type: none"> • Skylight mechanical seizing • Skylight switch • Skylight motor 	Refer to: Diagnosis procedure about that the opened sunroof can not be closed
The sunroof is leaked	<ul style="list-style-type: none"> • Seal strips • The drain tube is disconnected • The sunroof is stuck and can not be closed completely 	<ul style="list-style-type: none"> • Repair or replace the seal strips • Reinstall the sunroof drain tube • Inspect and repair the sunroof
The sunroof sends an abnormal sound	<ul style="list-style-type: none"> • There is a foreign matter in the sunroof chute • Skylight motor 	<ul style="list-style-type: none"> • Clean up the foreign matter and lubricate the chute • Replace the sunroof motor Refer to: Replacement of skylight motor

Roof



Diagnosis procedure about the skylight can not be opened



Test condition	Details/results/measures
1. General inspection.	<p>A. Inspect whether the sunroof is installed properly and whether there is mechanical jam.</p> <p>B. Inspect the sunroof motor and sunroof switch wiring harness connector for loosening, aging, falling off and other abnormalities.</p> <p>Is it OK after checking?</p> <p>→Yes To step 2.</p> <p>→No Repair the fault position.</p>
2. Check the fuse.	<p>A. Inspect the sunroof motor fuses FS10 and FS29.</p> <p>Fuse rated capacity: FS10 (10A), FS29 (15 A)</p> <p>Is it OK after checking?</p> <p>→Yes To step 3.</p> <p>→No Replace the fuse.</p>
3. Inspect the sunroof motor power supply.	<p>A. Operate the ignition switch to turn the power to OFF state.</p> <p>B. Disconnect the battery negative connector.</p> <p>C. Disconnect the skylight motor harness plug R03.</p> <p>D. Connect the battery negative terminal.</p> <p>E. Operate the ignition switch to turn the power to ON state.</p> <p>F. Measure the voltage between Terminal 3 of the sunroof motor wiring harness connector R03 and the reliable grounding point with a multimeter.</p> <p>Standard value: 11 ~ 14 V</p> <p>G. Measure the voltage between skylight motor harness plug R03 terminal 6 and fixed ground point with the multimeter.</p> <p>Standard value: 11 ~ 14 V</p> <p>Is the voltage is OK?</p> <p>→Yes To step 4.</p> <p>→No Inspect and repair the sunroof motor power line fault; if necessary, replace the dashboard wiring box.</p>



Test condition	Details/results/measures
4. Inspect the sunroof motor grounding point.	<p>A. Operate the ignition switch to turn the power to OFF state.</p> <p>B. Disconnect the battery negative connector.</p> <p>C. Disconnect the skylight motor harness plug R03.</p> <p>D. Measure the resistance between Terminal 1 of the sunroof motor wiring harness connector R03 and the reliable grounding point with a multimeter.</p> <p>Standard value: Less than 5Ω</p> <p>E. Measure the voltage between skylight motor harness plug R03 terminal 2 and fixed ground point with the multimeter.</p> <p>Standard value: Less than 5Ω</p> <p>Is the resistance normal?</p> <p>→Yes To step 5.</p> <p>→No Inspect and repair the sunroof motor grounding point fault; if necessary, replace the wiring harness.</p>
5. Inspect the sunroof control signal line.	<p>A. Operate the ignition switch to turn the power to OFF state.</p> <p>B. Disconnect the battery negative connector.</p> <p>C. Disconnect the skylight motor harness plug R03.</p> <p>D. Disconnect the PEPS ECU harness plug I24.</p> <p>E. Measure the resistance between Terminal 9 of the sunroof motor wiring harness connector R03 and Terminal 6 of PEPS ECU wiring harness connector I24 with a multimeter.</p> <p>Standard value: Less than 5Ω</p> <p>Is the resistance normal?</p> <p>→Yes To step 6.</p> <p>→No Inspect and repair the sunroof control signal line fault; if necessary, replace the wiring harness.</p>

Roof



Test condition	Details/results/measures
<p>6. Inspect the sunroof switch control grounding point.</p> 	<p>A. Operate the ignition switch to turn the power to OFF state. B. Disconnect the battery negative connector. C. Disconnect the front dome lamp harness plug R06. D. Measure the resistance between Terminal 4 of the front dome lamp wiring harness connector R06 and the reliable grounding point with a multimeter. Standard value: Less than 5Ω Is the resistance normal? →Yes To step 7. →No Inspect and repair the sunroof switch control grounding point fault; if necessary, replace the wiring harness.</p>
<p>7. Inspect the sunroof opening signal line.</p> 	<p>A. Operate the ignition switch to turn the power to OFF state. B. Disconnect the battery negative connector. C. Disconnect the front dome lamp harness plug R06. D. Disconnect the sunroof motor wiring harness connector R03. E. Measure the resistance between Terminal 3 of the front dome lamp wiring harness connector R06 and Terminal 5 of the sunroof motor wiring harness connector R03 with a multimeter. Standard value: Less than 5Ω Is the resistance normal? →Yes To step 8. →No Inspect and repair the sunroof opening signal line fault; if necessary, replace the wiring harness.</p>
<p>8. Check the skylight switch.</p>	<p>A. Replace the sunroof switch. Refer to: Replacement of Sunroof Switch Is the troubleshooting successful? →Yes Replace the sunroof switch. →No To step 9.</p>



Test condition	Details/results/measures
9. Inspect the sunroof motor.	<p>A. Replace the sunroof motor. Refer to: Replace the sunroof motor. Is the troubleshooting successful? →Yes Replace the sunroof motor. →No To step 10.</p>
10. Inspect PEPS control unit.	<p>A. Replace the PEPS control unit. Refer to: Replacement of PEPS control unit Confirm that troubleshooting is completed.</p>

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Roof




Removal and Installation

Replacement of the sunroof glass assembly

Removal

1. Remove the sunroof glass assembly.

(a). Open the sunvisor.



(b). Remove the sunroof glass assembly fixing bolts.

△ **Tips:**

The fixing bolts on both sides can be removed with the same method.

(c). Remove the sunroof glass assembly.

Installation


1. Install the sunroof glass assembly.

(a). The installation sequence is the reverse of the disassembly order.

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

12




12-1851

Replacement of the sunroof motor

Removal

1. Remove the sunroof motor.

(a). Remove the top cover trim; refer to: **Replacement of Top Cover Trim.**



- (b). Disconnect the sunroof motor wiring harness connector.
- (c). Remove the sunroof motor fixing bolts.
- (d). Remove the sunroof motor.

Installation

1. Install the sunroof motor.

(a). The installation sequence is the reverse of the disassembly order.



شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران