

EMA-2

Engine Mechanical System

General Information

Specifications

Description	Specifications	Limit
General		
Type	In-line, Double Overhead Camshaft	
Number of cylinder	4	
Bore	86mm (3.385in)	
Stroke	86mm (3.385in)	
Total displacement	1998cc (121.92in)	
Compression ratio	10.5	
Firing order	1-3-4-2	
Valve timing		
Intake valve		
Opens (ATDC / BTDC)	ATDC 7° ~ BTDC 38°	
Closes (ABDC)	ABDC 63° ~ 18°	
Exhaust		
Opens (BBDC)	BBDC 38°	
Closes (ATDC)	ATDC 6°	
Valve		
Valve length		
Intake	113.18mm (4.4559in.)	112.93mm (4.4460in)
Exhaust	105.84mm (4.1669in.)	105.74mm (4.1629in)
Stem O.D.		
Intake	5.465 ~ 5.480mm (0.2151 ~ 0.2157in.)	
Exhaust	5.458 ~ 5.470mm (0.2149 ~ 0.2153in.)	
Face angle	45.25° ~ 45.75°	
Margin		
Intake	1.02mm (0.0401in.)	
Exhaust	1.09mm (0.0429in.)	
Valve stem to valve guide clearance		
Intake	0.020 ~ 0.047mm (0.00078 ~ 0.00185in.)	0.07mm (0.00275in.)
Exhaust	0.030 ~ 0.054mm (0.00118 ~ 0.00212in.)	0.09mm (0.00354in.)
Valve guide		
Length		
Intake	43.8 ~ 44.2mm (1.7244 ~ 1.7401in.)	
Exhaust	43.8 ~ 44.2mm (1.7244 ~ 1.7401in.)	

General Information

EMA-3

Description	Specifications	Limit
Valve seat		
Width of seat contact		
Intake	1.16 ~ 1.46mm (0.0457 ~ 0.0575in.)	
Exhaust	1.35 ~ 1.65mm (0.0531 ~ 0.0649in.)	
Seat angle	44.75° ~ 45.10°	
Valve spring		
Free length	47.44mm (1.8677in.)	
Load	19.0 ± 0.6kg/35.0mm (41.88 ± 1.32lb/1.3779in)	
	39.8 ± 1.2kg/26.0mm (87.74 ± 2.64lb/1.0236in.)	
Squareness	1.5° MAX.	
Valve clearance		
Cold (20°C[68°F])		
Intake	0.17 ~ 0.23mm (0.0067 ~ 0.0090in.)	0.10 ~ 0.30mm (0.0039 ~ 0.0118in.)
Exhaust	0.27 ~ 0.33mm (0.0106 ~ 0.0129in.)	0.20 ~ 0.40mm (0.0078 ~ 0.0157in.)
Cylinder head		
Flatness of gasket surface	Max. 0.05mm (0.0019in.)	
Flatness of manifold mounting surface	Max. 0.10mm (0.0039in.)	
Cylinder block		
Cylinder bore	86.00 ~ 86.03mm (3.3858 ~ 3.3870in.)	
Out-of-round and taper of cylinder bore	Less than 0.05mm (0.0019in.)	
Clearance with piston (To set limits to new parts)	0.015 ~ 0.035mm (0.0005 ~ 0.0013in.)	
Piston		
O.D (To set limits to new parts)	85.975 ~ 86.0050mm (3.3848 ~ 3.3860in.)	
Ring groove width		
No.1	1.235 ~ 1.250mm (0.0486 ~ 0.0492in.)	1.26mm (0.0496in.)
No.2	1.230 ~ 1.250mm (0.0484 ~ 0.0492in.)	1.26mm (0.0496in.)
Oil ring	2.01 ~ 2.03mm (0.0791 ~ 0.0799in.)	2.05mm (0.0807in.)
Piston ring		
Side clearance		
No.1	0.05 ~ 0.08mm (0.0019 ~ 0.0031in.)	0.1mm (0.004in.)
No.2	0.04 ~ 0.08mm (0.0015 ~ 0.0031in.)	0.1mm (0.004in.)
Oil ring	0.06 ~ 0.15mm (0.0023 ~ 0.0059in.)	0.2mm (0.008in.)
End gap		

EMA-4

Engine Mechanical System

Description			Specifications	Limit
No.1			0.15 ~ 0.30mm (0.0059 ~ 0.0118in.)	0.6mm (0.0236in.)
No.2			0.37 ~ 0.52mm (0.0145 ~ 0.0204in.)	0.7mm (0.0275in.)
Oil ring side rail			0.20 ~ 0.70mm (0.0078 ~ 0.0275in.)	0.8mm (0.0315in.)
Connecting rod				
Bend			0.05mm (0.0020in.) or less	
Twist			0.1mm (0.004in.) or less	
Connecting rod big end to crankshaft side clearance			0.100 ~ 0.250mm (0.0039 ~ 0.010in.)	0.35mm (0.0138in.)
Connecting rod bearing				
Oil clearance (To seat limits to new parts)			0.027 ~ 0.045mm (0.0010 ~ 0.0017in.)	0.05mm (0.0019in.)
Camshaft				
Cam height	Intake		43.8mm (1.7244in.)	
	Exhaust		45.00mm (1.7716in.)	
Journal O.D	Intake	No.1	φ 30mm (1.1811in.)	
		No.2, 3, 4, 5	φ 24mm (0.9449in.)	
	Exhaust	No.1	φ 40mm (1.5748in.)	
		No.2, 3, 4, 5	φ 24mm (0.9449in.)	
Bearing oil clearance	Intake	No.1	0.022 ~ 0.057mm (0.0008 ~ 0.0022in.)	0.09mm (0.0035in.)
		No.2, 3, 4, 5	0.045 ~ 0.082mm (0.0017 ~ 0.0032in.)	0.12mm (0.0047in.)
	Exhaust	No.1, 2, 3, 4, 5	0.045 ~ 0.082mm (0.0017 ~ 0.0032in.)	0.12mm (0.0047in.)
End play			0.04 ~ 0.16mm (0.0015 ~ 0.0062in.)	0.20mm (0.0078in.)
Crankshaft				
Pin O.D.			47.954 ~ 47.972mm (1.8879 ~ 1.8886in.)	
Journal O.D.			51.942 ~ 51.960mm (2.0449 ~ 2.0456in.)	
End play			0.07 ~ 0.25mm (0.0027 ~ 0.0098in.)	
Crankshaft bearing				
Oil clearance			0.020 ~ 0.038mm (0.0007 ~ 0.0014in.)	
Radiator				
Type			Pressurized corrugated fin type	
Cooling method			Water-cooled, pressurized. Forced circulation with water pump	
Radiator cap				
Main valve opening pressure			83 ~ 110kpa (12 ~ 16psi, 0.83 ~ 1.1kg/cm ²)	
Vacuum valve opening pressure			-7kpa (-100psi, -0.07kg/cm ²) or less	
Thermostat				
Type			Wax pellet type with jiggle valve	

General Information

EMA-5

Description		Specifications	Limit
Valve opening temperature		82°C (177°F)	
Full-opening temperature		95°C (201°F)	
Coolant pump		Centrifugal type impeller	
Engine oil			
Oil quantity	Total	4.7L (4.97US qt, 4.13Imp qt)	When replacing a short engine or a block assembly
	Oil pan	3.8L (4.01US qt, 3.34Imp qt)	
	Drain and refill	4.1L (4.33US qt, 3.60Imp qt)	Including oil filter
Oil grade	Recommendation (except Middle East)	5W-20/GF4&SM	If not available, refer to the recommended API or ILSAC classification and SAE viscosity number.
	Classification	API SL, SM or above ILSAC GF3, GF4 or above	Satisfy the requirement of the API or ILSAC classification.
	SAE viscosity grade	Recommended SAE viscosity number	Refer to the "Lubrication System"
Oil pressure (at 1000rpm)		108kPa (1.1kg/cm ² , 15.6psi) or above	Oil temperature in oil pan : 110±2°C (230±36°F)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

EMA-6

Engine Mechanical System

Tightening Torques

Item	N.m	kgf.m	lb-ft
Ladder frame bolt (M8 x 55)	23.5 ~ 27.4	2.4 ~ 2.8	17.4 ~ 20.2
Ladder frame bolt (M8 x 103)	23.5 ~ 27.4	2.4 ~ 2.8	17.4 ~ 20.2
Oil pump bolt	8.8 + 16.7 + 25.5	0.9 + 1.7 + 2.6	6.5 + 12.3 + 18.8
Timing chain cover bolt (M8)	18.6 ~ 22.5	1.9 ~ 2.3	13.7 ~ 16.6
Timing chain cover bolt (M6)	7.8 ~ 9.8	0.8 ~ 1.0	5.8 ~ 7.2
Oil pan bolt (M6 x 10)	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Oil pan bolt (M8 x 103)	26.5 ~ 30.4	2.7 ~ 3.1	19.5 ~ 22.4
Engine support bracket bolt (M8 x 30)	19.6 ~ 24.5	2.0 ~ 2.5	14.5 ~ 18.1
Engine support bracket bolt (M10 x 40)	39.2 ~ 44.1	4.0 ~ 4.5	28.9 ~ 32.5
Engine support bracket bolt (M10 x 45)	39.2 ~ 44.1	4.0 ~ 4.5	28.9 ~ 32.5
Camshaft bearing cap bolt (M6)	10.8 ~ 12.7	1.1 ~ 1.3	7.9 ~ 9.4
Camshaft bearing cap bolt (M8)	27.4 ~ 31.4	2.8 ~ 3.2	20.3 ~ 23.1
Cylinder head bolt	(32.4~36.3) + (90~95°) + (90~95°)	(3.3~3.7) + (90~95°) + (90~95°)	(23.9~26.8) + (90~95°) + (90~95°)
Engine hanger bolt	27.5 ~ 31.4	2.8 ~ 3.2	20.3 ~ 23.1
Cylinder head cover bolt	7.8 ~ 9.8	0.8 ~ 1.0	5.8 ~ 7.2
Crankshaft pulley bolt	166.6 ~ 176.4	17.0 ~ 18.0	122.9 ~ 130.1
Connecting rod bearing cap bolt	(17.7~21.6) + (88~92°)	(1.8~2.2) + (88~92°)	(13.0~15.9) + (88~92°)
Main bearing cap bolt	(27.5~31.4) + (120~125°)	(2.8~3.2) + (120~125°)	(20.3~23.1) + (120~125°)
Flywheel bolt	117.6 ~ 127.4	12.0 ~ 13.0	86.8 ~ 93.9
Drive plate bolt	117.6 ~ 127.4	12.0 ~ 13.0	86.8 ~ 93.9
Timing chain tensioner bolt	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Timing chain tensioner arm bolt	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Timing chain guide bolt	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
OCV bolt	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
CVVT bolt	53.9 ~ 63.7	5.5 ~ 6.5	39.7 ~ 47.0
Exhaust camshaft sprocket bolt	53.9 ~ 63.7	5.5 ~ 6.5	39.7 ~ 47.0
Oil pump chain tensioner arm bolt	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Oil pump chain guide bolt	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Oil pump chain tensioner bolt	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Water pump bolt	18.6 ~ 23.5	1.9 ~ 2.4	13.7 ~ 17.4
A/C compressor bracket bolt	19.6 ~ 23.5	2.0 ~ 2.4	14.5 ~ 17.4
P/S pump bracket bolt	44.1 ~ 53.9	4.5 ~ 5.5	32.5 ~ 39.8

General Information

EMA-7

Item	N.m	kgf.m	lb-ft
Tensioner assy intergrated bracket bolt	39.2 ~ 44.1	4.0 ~ 4.5	28.9 ~ 32.5
Water temperature control assembly nut	18.6 ~ 23.5	1.9 ~ 2.4	13.7 ~ 17.4
Water temperature control assembly bolt	14.7 ~ 19.6	1.5 ~ 2.0	10.8 ~ 14.5
Water inlet pipe nut	18.6 ~ 23.5	1.9 ~ 2.4	13.7 ~ 17.4
Oil level gauge assembly bolt	7.8 ~ 11.8	0.8 ~ 1.2	5.8 ~ 8.7
Ignition coil bolt	3.9 ~ 5.9	0.4 ~ 0.6	2.9 ~ 4.3
Intake manifold bolt	18.6 ~ 23.5	1.9 ~ 2.4	13.7 ~ 17.4
Intake manifold nut	18.6 ~ 23.5	1.9 ~ 2.4	13.7 ~ 17.4
Intake manifold stay bolt	18.6 ~ 23.5	1.9 ~ 2.4	13.7 ~ 17.4
Exhaust manifold heat protector bolt	7.8 ~ 11.8	0.8 ~ 1.2	5.8 ~ 8.7
Exhaust manifold nut	49.0 ~ 53.9	5.0 ~ 5.5	36.2 ~ 39.7
Exhaust manifold stay bolt (M8)	18.6 ~ 27.5	1.9 ~ 2.8	13.7 ~ 20.3
Exhaust manifold stay bolt (M10)	51.9 ~ 57.8	5.3 ~ 5.9	38.3 ~ 42.6
Muffler bolt	39.2 ~ 58.8	4.0 ~ 6.0	28.9 ~ 43.4
Engine cover mounting bracket bolt	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Crankshaft position sensor bolt	3.9 ~ 5.9	0.4 ~ 0.6	2.9 ~ 4.3
Oxygen sensor	34.3 ~ 44.1	3.5 ~ 4.5	25.3 ~ 32.5
Knock sensor	16.7 ~ 25.5	1.7 ~ 2.6	12.3 ~ 18.8
Camshaft position sensor	3.9 ~ 5.9	0.4 ~ 0.6	2.9 ~ 4.3
Oil pressure switch	7.8 ~ 11.8	0.8 ~ 1.2	5.8 ~ 8.7
Oil filter	11.8 ~ 15.7	1.2 ~ 1.6	8.7 ~ 11.6

EMA-8

Engine Mechanical System

Compression Pressure Inspection


NOTICE

If there is lack of power, excessive oil consumption or poor fuel economy, measure the compression pressure.

1. Warm up and stop engine.

Allow the engine to warm up to normal operating temperature.

2. Disconnect the injector connectors (A) and ignition coil connectors (B).



STD19345L


3. Remove ignition coils.

4. Remove spark plugs.

Using a 16mm plug wrench, remove the 4 spark plugs.

5. Check cylinder compression pressure.

- a. Insert a compression gauge into the spark plug hole.



STD19350L

- b. Fully open the throttle.

- c. While cranking the engine, measure the compression pressure.

NOTICE

Always use a fully charged battery to obtain engine speed of 200 rpm or more.

- d. Repeat steps (a) through (c) for each cylinder.

NOTICE

This measurement must be done in as short a time as possible.

Compression pressure :

1,283kPa (13.0kgf/cm², 185psi)

Minimum pressure :

1,135kPa (11.5kgf/cm², 164psi)

Difference between each cylinder :

100kPa (1.0kgf/cm², 15psi) or less

- e. If the cylinder compression in 1 or more cylinders is low, pour a small amount of engine oil into the cylinder through the spark plug hole and repeat steps (a) through (c) for cylinders with low compression.

- If adding oil helps the compression, it is likely that the piston rings and/or cylinder bore are worn or damaged.
- If pressure stays low, a valve may be sticking or seating is improper, or there may be leakage past the gasket.

6. Reinstall spark plugs.

7. Install ignition coils.

8. Connect the injector connectors and ignition coil connectors.

General Information


EMA-9

Valve Clearance Inspection And Adjustment

NOTICE

Inspect and adjust the valve clearance when the engine is cold (Engine coolant temperature : 20°C (68°F)) and cylinder head is installed on the cylinder block.


1. Remove the cylinder head cover (A). (Refer to Timing system in this group)



STDM19318L

2. Set No.1 cylinder to TDC/compression.


- a. Turn the crankshaft pulley and align its groove with the timing mark "T" of the lower timing chain cover.



SNFEM8077D

- b. Check that the mark(A) of the camshaft timing sprockets are in straight line on the cylinder head surface as shown in the illustration.


If not, turn the crankshaft one revolution (360°)



ACRF007A

3. Inspect the valve clearance.

- a. Check only the valve indicated as shown. [No. 1 cylinder : TDC/Compression] measure the valve clearance.



No1. Cylinder TDC/compression

ECRF001A

EMA-10

Engine Mechanical System

- Using a thickness gauge, measure the clearance between the tappet and the base circle of camshaft.
- Record the out-of-specification valve clearance measurements. They will be used later to determine the required replacement adjusting tappet.

Valve clearance

Specification


Engine coolant temperature : 20°C [68°F]

Limit

Intake : 0.10 ~ 0.30mm (0.0039 ~ 0.0118in.)

Exhaust : 0.20 ~ 0.40mm (0.0079 ~ 0.0157in.)


- Turn the crankshaft pulley one revolution (360°) and align the groove with timing mark "T" of the lower timing chain cover.
- Check only valves indicated as shown. [NO. 4 cylinder : TDC/compression]. Measure the valve clearance.



No4. Cylinder TDC/compression

ECRF002A

- Adjust the intake and exhaust valve clearance.
 - Set the No.1 cylinder to the TDC/compression.
 - Marks on the timing chain and camshaft timing sprockets.
 - Remove the service hole bolt(A) of the timing chain cover.




SNFEM8078D

CAUTION

The bolt must not be reused once it has been assembled.

- Insert the SST(A) (09240-2G000) in the service hole of the timing chain cover and release the ratchet.




SMGEM8006D

General Information

EMA-11

- e. Remove the front camshaft bearing cap(A).



STD19325L

- f. Remove the exhaust camshaft bearing cap and exhaust camshaft.
g. Remove the intake camshaft bearing cap and intake camshaft.

CAUTION


When disconnect the timing chain from the camshaft timing sprocket, hold the timing chain.

- h. Tie down timing chain so that it doesn't move.

CAUTION

Be careful not to drop anything inside timing chain cover.

- i. Measure the thickness of the removed tappet using a micrometer.



EDKE889D

- j. Calculate the thickness of a new tappet so that the valve clearance comes within the specified value.

Valve clearance (Engine coolant temperature : 20°C)

T : Thickness of removed tappet

A : Measured valve clearance

N : Thickness of new tappet

Intake : $N = T + [A - 0.20\text{mm}(0.0079\text{in.})]$

Exhaust : $N = T + [A - 0.30\text{mm}(0.0118\text{in.})]$

- k. Select a new tappet with a thickness as close as possible to the calculated value.

NOTICE


Shims are available in 47size increments of 0.015mm (0.0006in.) from 3.00mm (0.118in.) to 3.690mm (0.1452in.)

- l. Place a new tappet on the cylinder head.
m. Hold the timing chain, and install the intake camshaft and timing sprocket assembly.
n. Align the matchmarks on the timing chain and camshaft timing sprocket.
o. Install the intake and exhaust camshaft.
p. Install the front bearing cap.
q. Install the service hole bolt.

Tightening torque :

11.8 ~ 14.7N.m (1.2 ~ 1.5kgf.m, 8.7 ~ 10.8lb-ft)

- r. Turn the crankshaft two turns in the operating direction(clockwise) and realign crankshaft sprocket and camshaft sprocket timing marks(A).



ACRF007A

- s. Recheck the valve clearance.

Valve clearance (Engine coolant temperature : 20°C)

[Specification]

Intake : 0.17 ~ 0.23mm (0.0067 ~ 0.0090in.)

Exhaust : 0.27 ~ 0.33mm (0.0106 ~ 0.0129in.)

EMA-12

Engine Mechanical System

Troubleshooting

Symptom	Suspect area	Remedy
Engine misfire with abnormal internal lower engine noises.	Worn crankshaft bearings Loose or improperly engine flywheel	Replace the crankshaft and bearings as required. Repair or replace the flywheel as required.
	Worn piston rings (Oil consumption may or may not cause the engine to misfire.)	Inspect the cylinder for a loss of compression. Repair or replace as required.
	Worn crankshaft thrust bearings	Replace the crankshaft and bearings as required
Engine misfire with abnormal valve train noise.	Stuck valves. (Carbon buildup on the valve stem)	Repair or replace as required
	Excessive worn or mis-aligned timing chain	Replace the timing chain and sprocket as required.
	Worn camshaft lobes.	Replace the camshaft and valve lifters.
Engine misfire with coolant consumption	<ul style="list-style-type: none"> Faulty cylinder head gasket or other damage to the cylinder head and engine block cooling system. Coolant consumption may or may not cause the engine to overheat. 	<ul style="list-style-type: none"> Inspect the cylinder head and engine block for damage to the coolant passages and/or a faulty head gasket. Repair or replace as required.
Engine misfire with excessive oil consumption	Worn valves, guides and/or valve stem oil seals.	Repair or replace as required.
	Worn piston rings. (Oil consumption may or may not cause the engine to misfire)	<ul style="list-style-type: none"> Inspect the cylinder for a loss of compression. Repair or replace as required.
Engine noise on start-up, but only lasting a few seconds.	Incorrect oil viscosity	<ul style="list-style-type: none"> Drain the oil. Install the correct viscosity oil.
	Worn crankshaft thrust bearing.	<ul style="list-style-type: none"> Inspect the thrust bearing and crankshaft. Repair or replace as required.

General Information

EMA-13

Symptom	Suspect area	Remedy
Upper engine noise, regardless of engine speed.	Low oil pressure	Repair or replace as required.
	Broken valve spring.	Replace the valve spring.
	Worn or dirty valve lifters.	Replace the valve lifters.
	Stretched or broken timing chain and/or damaged sprocket teeth.	Replace the timing chain and sprockets.
	Worn timing chain tensioner, if applicable.	Replace the timing chain tensioner as required.
	Worn camshaft lobes.	<ul style="list-style-type: none"> Inspect the camshaft lobes. Replace the timing camshaft and valve lifters as required.
	Worn valve guides or valve stems.	Inspect the valves and valve guides, then repair or replace as required.
	Stuck valves. (Carbon on the valve stem or valve seat may cause the valve to stay open.	Inspect the valves and valve guides, then repair or replace as required.
	Worn drive belt, idler, tensioner and bearing.	Replace as required
Lower engine noise, regardless of engine speed	Low oil pressure	Repair or required.
	Loose or damaged flywheel.	Repair or replace the flywheel.
	Damaged oil pan, contacting the oil pump screen.	<ul style="list-style-type: none"> Inspect the oil pan. Inspect the oil pump screen. Repair or replace as required.
	Oil pump screen loose, damaged or restricted.	<ul style="list-style-type: none"> Inspect the oil pump screen. Repair or replace as required.
	Excessive piston-to-cylinder bore clearance.	<ul style="list-style-type: none"> Inspect the piston, piston pin and cylinder bore. Repair or replace as required.
	Excessive piston pin-to-piston clearance	<ul style="list-style-type: none"> Inspect the piston, piston pin and the connecting rod. Repair or replace as required.
	Excessive connecting rod bearing clearance	Inspect the following components and repair or replace as required. <ul style="list-style-type: none"> The connecting rod bearings. The connecting rods. The crankshaft pin journals.
	Excessive crankshaft bearing clearance	Inspect the following components, and repair or replace as required. <ul style="list-style-type: none"> The crankshaft bearings. The crankshaft main journals. The cylinder block
	Incorrect piston, piston pin and connecting rod installation	<ul style="list-style-type: none"> Verify the piston pins and connecting rods are installed correctly. Repair as required.

EMA-14







Engine Mechanical System

Symption	Suspect area	Remedy
Engine noise under load	Low oil pressure	Repair or replace as required.
	Excessive connecting rod bearing clearance	Inspect the following components and repair or replace as required : <ul style="list-style-type: none"> The connecting rod bearings. The connecting rods. The crankshaft
	Excessive crankshaft bearing clearance	Inspect the following components, and repair or replace as required. <ul style="list-style-type: none"> The crankshaft bearings. The crankshaft main journals. The cylinder block.
Engine will not crank-crankshaft will not rotate	Hydraulically locked cylinder <ul style="list-style-type: none"> Coolant/antifreeze in cylinder. Oil in cylinder. Fuel in cylinder 	<ol style="list-style-type: none"> 1. Remove spark plugs and check for fluid. 2. Inspect for broken head gasket. 3. Inspect for cracked engine block or cylinder head. 4. Inspect for a sticking fuel injector and/or leaking fuel regulator.
	Broken timing chain and/or timing chain and/or timing chain gears.	<ol style="list-style-type: none"> 1. Inspect timing chain and gears. 2. Repair as required.
	Material in cylinder <ul style="list-style-type: none"> Broken valve Piston material Foreign material 	<ol style="list-style-type: none"> 1. Inspect cylinder for damaged components and/or foreign materials. 2. Repair or replace as required.
	Seized crankshaft or connecting rod bearings.	<ol style="list-style-type: none"> 1. Inspect crankshaft and connecting rod bearings. 2. Repair as required.
	Bent or broken connecting rod.	<ol style="list-style-type: none"> 1. Inspect connecing rods. 2. Repair as required.
	Broken crankshaft	<ol style="list-style-type: none"> 1. Inspect crankshaft. 2. Repair as required.

General Information


EMA-15

Special Service Tools

Tool (Number and name)	Illustration	Use
Crankshaft front oil seal installer (09214-3K000) (09231-H1100)	 ACRF002A	Installation of the front oil seal A : 09214-3K000 B : 09231-H1100
Flywheel stopper (09231-3K000)	 KCRF030D	Holds flywheel so that engine doesn't turn/move.
Torque angle adapter (09221-4A000)	 LCAC030A	Installation of bolts & nuts needing an angular method of adjustment.
Valve stem oil seal installer (09222-4A000)	 LCAC030D	Installation of the valve stem oil seal
Valve spring compressor & holder (09222-3K000) (09222-3K100)	 KCRF030B	Removal and installation of the intake or exhaust valve 09222-3K100 (holder)
Crankshaft rear oil seal installer (09214-3K100) (09231-H1100)	 ACRF003A	Installation of the crankshaft rear oil seal A : 09214-3K100 B : 09231-H1100

EMA-16

Engine Mechanical System

Tool (Number and name)	Illustration	Use
Timing chain tensioner ratchet holder (09240-2G000)	 SMGEM8007D	Timing chain tension release In vehicle inspection and adjustment of valve clearance.

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




Engine And Transaxle Assembly

EMA-17

Engine And Transaxle Assembly

Engine Mounting

Components



STDM19335L

1. Engine mounting bracket
2. Transaxle mounting bracket

3. Front roll stopper
4. Rear roll stopper

EMA-18

Engine Mechanical System

Engine And Transaxle Assembly

Removal

⚠ CAUTION

- Use fender covers to avoid damaging painted surfaces.
- To avoid damage, unplug the wiring connectors carefully while holding the connector portion.


📌 NOTICE

Mark all wiring and hoses to avoid misconnection.

1. Disconnect the battery terminals (A) and remove the battery.
2. Remove the engine cover (B).
3. Disconnect the ECM connector (C).
4. Disconnect the breather hose, and then remove the air duct (D) and the air cleaner assembly (E).

Tightening torque :

7.8 ~ 9.8N.m (0.8 ~ 1.0kgf.m, 5.8 ~ 7.2lb-ft)




STD19301L

5. Recover refrigerant and remove the high & low pressure pipe. (Refer to HA Group).

6. Remove the under covers (A).

Tightening torque :

9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)




STD19304L

7. Loosen the drain plug (A), and then drain the engine coolant.

⚠ CAUTION

Never remove the radiator cap when the engine is hot. Serious scalding could be caused by hot fluid under high pressure escaping from the radiator.




SHDM26020D

Engine And Transaxle Assembly

EMA-19


8. Remove the radiator upper hose (A) and lower hose (B).
9. Remove the heater hoses (C).
10. Disconnect the brake booster vacuum hose (D).



STDM19302L


11. Disconnect the wiring connectors and harness clamps from the engine.

- 1) Disconnect the ETC connector (A) and knock sensor connector (B).
- 2) Disconnect the PCSV connector (C).
- 3) Disconnect the ECT connector (D).
- 4) Disconnect the condenser connector (E).
- 5) Disconnect the CKP sensor connector (F).
- 6) Disconnect the oxygen sensor connector (G).




STDM19308L

- 7) Disconnect the power steering fluid pressure switch connector (A).
- 8) Disconnect the MAP sensor connector (B).
- 9) Disconnect the OPS connector (C).
- 10) Disconnect the alternator connector (D) and 'B' terminal cable from the alternator.
- 11) Disconnect the A/C switch connector from the compressor.



STDM19309L

- 12) Disconnect the intake OCV connector (A).




SNFEM8032D

EMA-20


Engine Mechanical System

- 13) Disconnect the CMP sensor connector (A) and the fuel hose (B).




SNFEM8009D

- 14) Disconnect the injector connectors (A) and the ignition coil connectors (B).



STDM19345L

- 15) Disconnect the starter connector (A), and cable (B) from the starter.




SNFEM8034D

12. Disconnect the transaxle control cable and wiring connectors. (Refer to MT or AT group)

13. Remove the lower arm (B) & fork (A) mounting bolt (C). (Refer to SS group)

Tightening torque :

137.3 ~ 156.9N.m (14.0 ~ 16.0kgf.m, 101.3 ~ 115.7lb-ft)




KHBF110C

14. Remove the lower arm ball joint mounting bolts (A). (Refer to SS group)

Tightening torque :

98.1 ~ 117.7N.m (10.0 ~ 12.0kgf.m, 72.3 ~ 86.8lb-ft)



KHBF120A


Engine And Transaxle Assembly

EMA-21

15. Remove the stabilizer bar link mounting nut (A).
(Refer to SS group)

Tightening torque :

98.1 ~ 117.7N.m (10.0 ~ 12.0kgf.m, 72.3 ~ 86.8lb-ft)




STGEM7030D

16. Remove the split pin and castle nut and then disconnect the tie rod end (A) with the knuckle.
(Refer to ST group)

Tightening torque :


23.5 ~ 33.3N.m (2.4 ~ 3.4kgf.m, 17.4 ~ 24.6lb-ft)



STGEM7031D

17. Disconnect the driveshaft from the axle hub.

18. Remove power steering return hose (A) and drain power steering fluid.




KMRE009J

19. Remove steering u-joint mounting bolt (A). (Refer to ST group)

Tightening torque :

29.4 ~ 34.3N.m (3.0 ~ 3.5kgf.m, 21.7 ~ 25.3lb-ft)



STDM19351L


EMA-22

Engine Mechanical System

20. Remove the front muffler (A).

Tightening torque :

39.2 ~ 58.8N.m (4.0 ~ 6.0kgf.m, 28.9 ~ 43.4 b-ft)




STDM19305L

21. Support the sub frame (A) with a floor jack, and then remove the stay (B) and sub frame mounting bolts.

Tightening torque :


137.3 ~ 156.9N.m (14.0 ~ 16.0kgf.m, 101.3 ~ 115.7lb-ft)



KMRE009R

Tightening torque :

44.1 ~ 58.8N.m (4.5 ~ 6.0kgf.m, 32.5 ~ 43.4lb-ft)




SNFEM8036D

22. Disconnect the ground line and then remove the engine mounting bracket (A).

Tightening torque :

63.7 ~ 83.4N.m (6.5 ~ 8.5kgf.m, 47.0 ~ 61.5lb-ft)



STDM19303L


Engine And Transaxle Assembly

EMA-23

23. Disconnect the ground line and then remove the transaxle mounting bracket (A).

Tightening torque :

88.3 ~ 107.9N.m (9.0 ~ 11.0kgf.m, 65.1 ~ 79.6lb-ft)



STDM19310L

24. Lift up the vehicle and remove the engine and transaxle assembly from the bottom of vehicle.

⚠ CAUTION

When removing the engine and transaxle assembly, be careful not to damage any surrounding parts or body components.

Installation

Installation is in the reverse order of removal.

Perform the following :

- Adjust a shift cable.
- Adjust a throttle cable.
- Refill engine with engine oil.
- Refill a transaxle with fluid.
- Refill power steering fluid.
- Refill a radiator and a reservoir tank with engine coolant.
- Place a heater control knob on "HOT" position.
- Bleed air from the cooling system.
 - Start engine and let it run until it warms up. (until the radiator fan operates 3 or 4 times.)
 - Turn Off the engine. Check the level in the radiator, add coolant if needed. This will allow trapped air to be removed from the cooling system.
 - Put radiator cap on tightly, then run the engine again and check for leaks.
- Clean battery posts and cable terminals and assemble.
- Inspect for fuel leakage.
 - After assemble the fuel line, turn on the ignition switch (do not operate the starter) so that the fuel pump runs for approximately two seconds and fuel line pressurizes.
 - Repeat this operation two or three times, then check for fuel leakage at any point in the fuel line.


EMA-24

Engine Mechanical System

Timing System

Timing Chain

Components



STD19346L

1. Intake camshaft
2. Intake CVVT assembly
3. Exhaust camshaft
4. Exhaust camshaft sprocket

5. Timing chain
6. Timing chain tensioner arm
7. Timing chain tensioner guide
8. Timing chain tensioner


9. Oil pump chain guide
10. Oil pump chain
11. Oil pump chain tensioner arm
12. Timing chain cover

Timing System

EMA-25


Removal

1. Disconnect the battery negative cable (A).
2. Remove the engine cover (B).



STDM19316L

3. Remove RH front wheel.
4. Remove RH side cover.
5. Set No.1 cylinder to TDC/compression.




SNFEM8077D

6. Drain the engine oil, and then set a jack to the oil pan.

NOTICE


Place wooden block between the jack and engine oil pan.

7. Disconnect the ground line and then remove the engine mounting bracket (A).



STDM19303L

8. Remove the drive belt (A).




STDM19354L

EMA-26

Engine Mechanical System

9. Remove the idler (A) and drive belt tensioner (B).




STDM19352L

CAUTION

Tensioner pulley bolt is left - handed screw.

10. Remove the water pump pulley (A), crankshaft pulley (B) and engine support bracket (C).




STDM19353L

NOTICE


Use the SST (flywheel stopper, 09231-3K000) to remove the crankshaft pulley bolt, after remove the starter.

11. Disconnect the ignition coil connectors (A) and remove the ignition coils.



STDM19348L

12. Remove the cylinder head cover (A).




STDM19318L

Timing System

EMA-27

13. Remove the compressor lower bolts.



KCRF112A


14. Remove the compressor bracket.

15. Remove the oil pan.

CAUTION

Be careful not to damage the contact surfaces of cylinder block and oil pan.

16. Remove the timing chain cover (A) by gently prying the portions between the cylinder head and cylinder block.



SNFEM8040D


CAUTION

Be careful not to damage the contact surfaces of cylinder block, cylinder head and timing chain cover.


17. The key of crankshaft should be aligned with the mating face of main bearing cap. As a result of this, the piston of No.1 cylinder is placed at the top dead center on compression stroke.

NOTICE

Before removing the timing chain, mark the timing chain with an identification based on the location of the sprocket because the identification mark on the chain for TDC (Top Dead Center) can be erased.



ECRF030A




ECRF031A

EMA-28


Engine Mechanical System

18. Install a set pin after compressing the timing chain tensioner.



KCRF105A


19. Remove the timing chain tensioner (A) and timing chain tensioner arm (B).



STDM19319L

20. Remove the timing chain.

21. Remove the timing chain guide (A).




STDM19320L

Timing System

EMA-29

22. Remove the timing chain oil jet (A).

23. Remove the crankshaft chain sprocket (B).



KCRF101A

24. Remove the oil pump chain.

(Refer to Lubrication system in this group)

Inspection

Sprockets, Chain Tensioner, Chain Guide, Chain Tensioner Arm

1. Check the camshaft sprocket and crankshaft sprocket for abnormal wear, cracks, or damage. Replace as necessary.
2. Inspect the tensioner arm and chain guide for abnormal wear, cracks, or damage. Replace as necessary.
3. Check that the tensioner piston moves smoothly when the ratchet pawl is released with thin rod.

Drive belt, Idler, Pulley

1. Check the idler for excessive oil leakage, abnormal rotation or vibration. Replace if necessary.
2. Check belt for maintenance and abnormal wear of V-ribbed part. Replace if necessary.
3. Check the pulleys for vibration in rotation, oil or dust deposit of V-ribbed part. Replace if necessary.

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



EMA-30


Engine Mechanical System

Installation

1. Install the oil pump chain.
(Refer to Lubrication system in this group)
2. Install the crankshaft sprocket (B).
3. Install the timing chain oil jet (A).

Tightening torque :

7.8 ~ 9.8N.m (0.8 ~ 1.0kgf.m, 5.8 ~ 7.2lb-ft)




KCRF101A

4. Set crankshaft that the key of crankshaft should be aligned with the mating surface of main bearing cap. Put the intake, exhaust camshaft assembly that the TDC mark of intake CVVT sprocket and exhaust camshaft sprocket should be aligned with the top surface of cylinder head. As a result of this, place the piston on No.1 cylinder at the top dead center on compression stroke.

5. Install the timing chain guide (A).

Tightening torque :

9.8 ~ 11.6N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)




STDM19320L

6. Install the timing chain.

To install the timing chain with no slack between each shaft (cam, crank), follow the below procedure.

Crankshaft sprocket (A) → Timing chain guide (B) → Intake CVVT sprocket (C) → Exhaust camshaft sprocket (D).




STDM19321L

Timing System


EMA-31

NOTICE

The timing mark of each sprocket should be matched with timing mark (color link) of timing chain at installing timing chain.



ECRF030A



ECRF031A

7. Install timing chain tensioner arm (B).


Tightening torque :

9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)

8. Install timing chain auto tensioner (A) and remove set pin.


Tightening torque :

9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)



STDM19319L

9. After rotating crankshaft 2 revolutions in regular direction (clockwise viewed from front), confirm the timing mark.



ACRF007A

EMA-32


Engine Mechanical System

10. Install timing chain cover.

- 1) Using a gasket scraper, remove all the old packing material from the gasket surfaces.
- 2) The sealant locations on chain cover and on counter parts (cylinder head, cylinder block, and ladder frame) must be free of engine oil and ETC.
- 3) Before assembling the timing chain cover, the liquid sealant Loctite 5900H or THREEBOND 1217H should be applied on the gap between cylinder head and cylinder block.

The part must be assembled within 5 minutes after sealant was applied.

Bead width : 2.5mm (0.1in.)




KCRF177A

- 4) After applying liquid sealant Loctite 5900H on timing chain cover.

The part must be assembled within 5 minutes after sealant was applied.

Sealant should be applied without discontinuity.

Bead width : 2.5mm (0.1in.)



STDM19355L

- 5) The dowel pins on the cylinder block and holes on the timing chain cover should be used as a reference in order to assemble the timing chain cover to be in exact position.

Tightening torque :

M6: 7.84 ~ 9.8N.m (0.8 ~ 1.0kgf.m, 5.8 ~ 7.2lb-ft)

M8: 18.6 ~ 22.5N.m (1.9 ~ 2.3kgf.m, 13.7 ~ 16.6lb-ft)

CAUTION

The firing and/or blow out test should not be performed within 30 minutes after the timing chain cover was assembled.

Timing System


EMA-33

11. Install oil pan.

- 1) Using a gasket scraper, remove all the old packing material from the gasket surfaces.
- 2) Before assembling the oil pan, the liquid sealant Loctite 5900 should be applied on oil pan.

The part must be assembled within 5 minutes after the sealant was applied.

Sealant : Loctite 5900H or equivalent



KCRF179A

⚠ CAUTION

- When applying sealant gasket, sealant must not be protruded into the inside of oil pan.
- To prevent leakage of oil, apply sealant gasket on the inner threads of the bolt holes.

3) Install oil pan.

Uniformly tighten the bolts in several passes.

Tightening torque

M8 bolts : 26.5 ~ 30.4N.m (2.7 ~ 3.1kgf.m, 19.5 ~ 22.4lb-ft)

M6 bolts : 9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)

⚠ CAUTION

After assembly, wait at least 30 minutes before filling the engine with oil.

12. Install the air compressor bracket.


Tightening torque :

19.6 ~ 23.5N.m (2.0 ~ 2.4kgf.m, 13.7 ~ 14.5lb-ft)

13. Install the compressor lower bolts.

Tightening torque :

19.6 ~ 24.5N.m (2.0 ~ 2.5kgf.m, 13.7 ~ 18.1lb-ft)




KCRF112A

14. Install cylinder head cover.

- 1) The hardening sealant located on the upper area between timing chain cover and cylinder head should be removed before assembling cylinder head cover.
- 2) After applying sealant, it should be assembled within 5 minutes.

Bead width : 2.5mm (0.1in.)



ECRF011A


EMA-34

Engine Mechanical System

- 3) Install the cylinder head cover bolts as following method.

Tightening torque

1st step: 3.9 ~ 5.9N.m (0.4 ~ 0.6kgf.m, 2.9 ~ 4.3lb-ft)
2nd step: 7.8 ~ 9.8N.m (0.8 ~ 1.0kgf.m, 5.8 ~ 7.2lb-ft)




KCRF180A

CAUTION

- Do not reuse cylinder head cover gasket.
- The firing and/or blow out test should not be performed within 30 minutes after the cylinder head cover was assembled.

15. Install the ignition coils and connect the ignition coil connectors (A).



STD19348L

16. Install the engine support bracket (C).

Tightening torque :

M10 : 39.2 ~ 44.1N.m (4.0 ~ 4.5kgf.m, 28.9 ~ 32.5lb-ft)
M8 : 19.6 ~ 24.5N.m (2.0 ~ 2.5kgf.m, 14.5 ~ 18.1lb-ft)

17. Install the crankshaft pulley (B).

Tightening torque :

166.6 ~ 176.4N.m (17.0 ~ 18.0kgf.m, 122.9 ~ 130.1lb-ft)


NOTICE

Use the SST (flywheel stopper, 09231-3K000) to install the crankshaft pulley bolt, after remove the starter.

18. Install the water pump pulley (A).

Tightening torque :

7.8 ~ 9.8N.m (0.8 ~ 1.0kgf.m, 5.8 ~ 7.2lb-ft)



STD19353L

19. Install the drive belt tensioner (B) and tensioner pulley.

Tightening torque :

53.9 ~ 63.7N.m (5.5 ~ 6.5kgf.m, 39.7 ~ 47.0lb-ft)

NOTICE

Tensioner pulley bolt is left-handed screw.


Timing System

EMA-35

20. Install idler pulley (A).

Tightening torque :

53.9 ~ 63.7N.m (5.5 ~ 6.5kgf.m, 39.7 ~ 47.0lb-ft)




STDM19352L

21. Install the drive belt (A).

Crankshaft pulley → A/C pulley → Alternator pulley → Idler pulley → P/S pump pulley → Idler pulley → Water pump pulley → Tensioner pulley.

Rotate auto tensioner arm in the counter - clockwise moving auto tensioner pulley bolt with wrench. After putting belt on auto tensioner pulley, release the auto tensioner pulley slowly.




STDM19354L

22. Install the engine mounting bracket (A) and then connect the ground cable.

Tightening torque :

63.7 ~ 83.4N.m (6.5 ~ 8.5kgf.m, 47.0 ~ 61.5lb-ft)



STDM19303L

23. Remove the RH side cover.

Tightening torque :

8.8 ~ 10.8N.m (0.9 ~ 1.1kgf.m, 6.5 ~ 7.9lb-ft)


24. Install the RH front wheel.

Tightening torque :

88.3 ~ 107.9N.m (9.0 ~ 11.0kgf.m, 65.1 ~ 79.6lb-ft)

25. Install the engine cover (B).

26. Connect the battery negative cable (A).



STDM19316L


EMA-36

Engine Mechanical System

Cylinder Head Assembly

Cylinder Head

Components



STDM19322L

- | | | |
|-------------------------------|-------------------------|---------------------|
| 1. Camshaft bearing cap | 6. Intake CVVT assembly | 11. Valve stem seal |
| 2. Camshaft front bearing cap | 7. MLA | 12. Valve |
| 3. Exhaust camshaft | 8. Retainer lock | 13. Cylinder head |
| 4. Intake camshaft | 9. Retainer | 14. Intake OCV |
| 5. Exhaust camshaft sprocket | 10. Valve spring | |

Cylinder Head Assembly

EMA-37

Removal

Engine removal is not required for this procedure.

⚠ CAUTION

- Use fender covers to avoid damaging painted surfaces.
- To avoid damaging the cylinder head, wait until the engine coolant temperature drops below normal temperature before removing it.
- When handling a metal gasket, take care not to fold the gasket or damage the contact surface of the gasket.
- To avoid damage, unplug the wiring connectors carefully while holding the connector portion.


📌 NOTICE

Mark all wiring and hoses to avoid misconnection.

1. Disconnect the battery terminals (A).
2. Remove the engine cover (B).
3. Disconnect the ECM connector (C).
4. Disconnect the breather hose and then, remove the air duct (D) and air cleaner assembly (E).

Tightening torque :

7.8 ~ 9.8N.m (0.8 ~ 1.0kgf.m, 5.8 ~ 7.2lb-ft)




STDM19301L

5. Remove the under covers (A).


Tightening torque :

9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)



STDM19304L

6. Loosen the drain plug (A), and then drain the engine coolant.




SHDM26020D

EMA-38

Engine Mechanical System


7. Remove the radiator upper hose (A) and lower hose (B).
8. Remove the heater hoses (C).
9. Disconnect the brake booster vacuum hose (D).



STDM19302L


10. Disconnect the wiring connectors and harness clamps from the engine.

- 1) Disconnect the ETC connector (A) and knock sensor connector (B).
- 2) Disconnect the PCSV connector (C).
- 3) Disconnect the ECT connector (D).
- 4) Disconnect the condenser connector (E).
- 5) Disconnect the CKP sensor connector (F).
- 6) Disconnect the oxygen sensor connector (G).




STDM19308L

- 7) Disconnect the power steering fluid pressure switch connector (A).
- 8) Disconnect the MAP sensor connector (B).
- 9) Disconnect the OPS connector (C).
- 10) Disconnect the alternator connector (D) and 'B' terminal cable from the alternator.
- 11) Disconnect the A/C switch connector from the compressor.



STDM19309L

- 12) Disconnect the intake OCV connector (A).




SNFEM8032D

Cylinder Head Assembly


EMA-39

- 13) Disconnect the CMP sensor connector (A) and fuel hose (B).




SNFEM8009D

- 14) Disconnect the injector connectors (A) and ignition coil connectors (B).




STDM19345L

11. Remove timing chain. (Refer to Timing system in this group)
 12. Remove the intake and exhaust manifold. (Refer to Intake and exhaust system in this group)
 13. Remove the water temperature control assembly (A).



STDM19315L

14. Remove the intake CVVT assembly (A) and exhaust camshaft sprocket (B).




STDM19323L

EMA-40

Engine Mechanical System

NOTICE


When removing the sprocket bolt or CVVT assembly bolt, fix the camshaft by wrench at position A.



STDM19324L


15. Remove the camshaft.

- 1) Remove the front camshaft bearing cap (A).




STDM19325L

- 2) Remove the camshaft bearing cap (A), in the sequence shown.




STDM19326L

- 3) Remove the camshafts (A).



STDM19327L

16. Use a torx wrench, remove the intake OCV (A).




STDM19328L

Cylinder Head Assembly

EMA-41

17. Remove the cylinder head bolts, then remove the cylinder head.

- 1) Using triple square wrench, uniformly loosen and remove the 10 cylinder head bolts, in several passes, in the sequence shown. Remove the 10 cylinder head bolts and plate washers.



KCRF162A

CAUTION

Head warpage or cracking could result from removing bolts in an incorrect order.

- 2) Lift the cylinder head from the dowels on the cylinder block and place the cylinder head on wooden blocks on a bench.

CAUTION

Be careful not to damage the contact surfaces of the cylinder head and cylinder block.


18. Remove the cylinder head gasket.

Disassembly

NOTICE

Identify MLA (Mechanical Lash Adjuster), valves, valve springs as they are removed so that each item can be reinstalled in its original position.


1. Remove the MLAs (A).



STDM19329L

2. Remove the valves.

- 1) Using SST (09222-3K000, 09222-3K100), compress the valve spring and remove retainer lock.



09222 - 3K100

STDM19330L

- 2) Remove the spring retainer.
- 3) Remove the valve spring.
- 4) Remove the valve.
- 5) Using needle-nose pliers, remove the valve stem seal.

EMA-42

Engine Mechanical System

Inspection

Cylinder Head

1. Inspect for flatness.



Using a precision straight edge and feeler gauge, measure the surface the contacting the cylinder block and the manifolds for warpage.

Flatness of cylinder head gasket surface

Standard : Less than 0.05mm(0.002in.)
(0.02mm(0.0008in.)/100x100)

Flatness of manifold mounting surface

Standard : Less than 0.1mm(0.0039in.)



ECKD001H

2. Inspect for cracks.

Check the combustion chamber, intake ports, exhaust ports and cylinder block surface for cracks. If cracked, replace the cylinder head.


Valve And Valve Spring

1. Inspect valve stems and valve guides.

- 1) Using a caliper gauge, measure the inside diameter of the valve guide.

Valve guid I.D.

Intake / Exhaust : 5.500 ~ 5.512mm (0.216 ~ 0.217in.)




STQM39122D

- 2) Using a micrometer, measure the diameter of the valve stem.

Valve stem O.D.

Intake : 5.465 ~ 5.480mm (0.2151 ~ 0.2157in.)

Exhaust : 5.458 ~ 5.470mm (0.2149 ~ 0.2153in.)



ECKD220A

Cylinder Head Assembly

EMA-43

- 3) Subtract the valve stem diameter measurement from the valve guide inside diameter measurement.

Valve stem-to-guide clearance

[Standard]

Intake : 0.020 ~ 0.047mm (0.0008 ~ 0.0018in.)

Exhaust : 0.030 ~ 0.054mm (0.0012 ~ 0.0021in.)

[Limit]

Intake : 0.07mm (0.0027in.)

Exhaust : 0.09mm (0.0035in.)

If the clearance is greater than maximum, replace the valve and valve guide.

2. Inspect the valves.

- 1) Check the valve is ground to the correct valve face angle.

- 2) Check that the surface of the valve for wear.

If the valve face is worn, replace the valve.

- 3) Check the valve head margin thickness.


If the margin thickness is less than minimum, replace the valve.

Margin

[Standard]

Intake : 1.02mm(0.0401in.)

Exhaust : 1.09mm(0.0429in.)



ECKD221A

- 4) Check the valve length.

Valve length.

[Standard]

Intake : 113.18mm(4.4559in.)

Exhaust : 105.89mm(4.1689in.)

[Limit]

Intake : 112.93mm(4.4461in.)

Exhaust : 105.74mm(4.1630in.)

- 5) Check the surface of the valve stem tip for wear.

If the valve stem tip is worn, replace the valve.

3. Inspect the valve seats

Check the valve seat for evidence of overheating and improper contact with the valve face.

Replace the seat if necessary.

Before reconditioning the seat, check the valve guide for wear. If the valve guide is worn, replace it, then recondition the seat. Recondition the valve seat with a valve seat grinder or cutter. The valve seat contact width should be within specifications and centered on the valve face.

4. Inspect the valve springs.

- 1) Using a steel square, measure the out-of-square of the valve spring.


- 2) Using a vernier calipers, measure the free length of the valve spring.

Valve spring

[Standard]

Free height : 47.44mm (1.8677in.)

Out-of-square : 1.5°



ECKD222A

If the free length is not as specified, replace the valve spring.

EMA-44

Engine Mechanical System

MLA

1. Inspect the MLA.

Using a micrometer, measure the MLA outside diameter.

MLA O.D.

Intake/Exhaust :

31.964 ~ 31.980mm(1.2584 ~ 1.2590in.)

2. Using a caliper gauge, measure MLA tappet bore inner diameter of cylinder head.

Tappet bore I.D.

Intake/Exhaust :

32.000 ~ 32.025mm(1.2598 ~ 1.2608in.)

3. Subtract MLA outside diameter measurement from tappet bore inside diameter measurement.

MLA to tappet bore clearance

[Standard]

Intake/Exhaust : 0.020 ~ 0.061mm(0.0008 ~ 0.0024in.)

[Limit]

Intake/Exhaust : 0.07mm(0.0027in.)

Camshaft

1. Inspect the cam lobes.


Using a micrometer, measure the cam lobe height.

Cam height

[Standard value]

Intake : 43.70 ~ 43.90mm (1.7204 ~ 1.7283in.)

Exhaust : 44.90 ~ 45.10mm (1.7677 ~ 1.7756in.)




ECKD223A

If the cam lobe height is less than standard, replace the camshaft.

2. Inspect the camshaft journal clearance.

- 1) Clean the bearing caps and camshaft journals.
- 2) Place the camshafts on the cylinder head.
- 3) Lay a strip of plastigage across each of the camshaft journal.



ECKD224A

Cylinder Head Assembly

EMA-45

- 4) Install the bearing caps.

CAUTION

Do not turn the camshaft.

- 5) Remove the bearing caps.
- 6) Measure the plastigage at its widest point.

Bearing oil clearance

[Standard value]

Intake :

No.1 journal : 0.022 ~ 0.057mm (0.00087 ~ 0.00224in)

No.2,3,4,5 : 0.045 ~ 0.082mm (0.00177 ~ 0.00323in)

Exhaust:

No.1,2,3,4,5 : 0.045 ~ 0.082mm (0.00177 ~ 0.00323in)

[Limit]


Intake:

No.1 journal : 0.09mm (0.0035in)

No.2,3,4,5 : 0.12mm (0.0047in)

Exhaust :

No.1,2,3,4,5 : 0.12mm (0.0047in)



ECKD225A

If the oil clearance is greater than maximum, replace the camshaft. If necessary, replace cylinder head.

- 7) Completely remove the plastigage.
- 8) Remove the camshafts.


3. Inspect the camshaft end play.

- 1) Install the camshafts.
- 2) Using a dial indicator, measure the end play while moving the camshaft back and forth.

Camshaft end play

[Standard value] : 0.04 ~ 0.16mm (0.0016 ~ 0.0062in.)

[Limit] : 0.18mm (0.0071in.)



STDM19331L

If the end play is greater than maximum, replace the camshaft. If necessary, replace cylinder head.

- 3) Remove the camshafts.


EMA-46

Engine Mechanical System

CVVT Assembly

1. Inspect the CVVT assembly.

- 1) Check that the CVVT assembly will not turn.
- 2) Apply vinyl tape to the retard hole(A) except the one indicated by the arrow in the illustration.



ECRF015A

- 3) Wind tape around the tip of the air gun and apply air of approx. 150kpa (1.5kgf/cm², 21psi) to the port of the camshaft.


(Perform this order to release the lock pin for the maximum delay angle locking.)

NOTICE

When the oil splashes, wipe it off with a shop rag and the likes.

- 4) Under the condition of (3), turn the CVVT assembly to the advance angle side (the arrow marked direction in the illustration) with your hand.

Depending on the air pressure, the CVVT assembly will turn to the advance side without applying force by hand. Also, under the condition that the pressure can be hardly applied because of the air leakage from the port, there may be the case that the lock pin could be hardly released.



ECRF016A

- 5) Except the position where the lock pin meets at the maximum delay angle, let the CVVT assembly turn back and forth and check the movable range and that there is no disturbance.

Standard :

Movable smoothly in the range about 22.5°

- 6) Turn the CVVT assembly with your hand and lock it at the maximum delay angle position (counter clockwise).

Cylinder Head Assembly

EMA-47

Reassembly

NOTICE

Thoroughly clean all parts to be assembled.

Before installing the parts, apply fresh engine oil to all sliding and rotating surfaces.

Replace oil seals with new ones.


1. Install valves.

- 1) Using SST(09222-4A000), push in a new oil seal.

NOTICE

Do not reuse old valve stem seals.

Incorrect installation of the seal could result in oil leakage past the valve guides.




STDM19332L

- 2) Install the valve, valve spring and spring retainer.

NOTICE

Place valve springs so that the side coated with enamel faces toward the valve spring retainer and then installs the retainer.

- 3) Using the SST(09222-3K000, 09222-3K100), compress the spring and install the retainer locks. After installing the valves, ensure that the retainer locks are correctly in place before releasing the valve spring compressor.




STDM19330L

- 4) Lightly tap the end of each valve stem two or three times with the wooden handle of a hammer to ensure proper seating of the valve and retainer lock.

2. Install the MLAs.

Check that the MLA rotates smoothly by hand.



STDM19329L

NOTICE

MLA can be reinstalled in its original position.


EMA-48

Engine Mechanical System

Installation

NOTICE

- Thoroughly clean all parts to be assembled.
 - Always use a new head and manifold gasket.
 - The cylinder head gasket is a metal gasket. Take care not to bend it.
 - Rotate the crankshaft, set the No.1 piston at TDC.
1. Install the OCV filter.




CAUTION

Keep the OCV filter clean.

2. Install the cylinder head gasket (A) on the cylinder block.

NOTICE

- Be careful of the installation direction.
- Apply liquid gasket (Loctite 5900H) on the edge of cylinder head gasket upside and downside. (At the position 'B')
- After applying sealant, assemble the cylinder head in five minutes.



STDM19334L

3. Place the cylinder head carefully in order not to damage the gasket with the bottom part of the end.

Cylinder Head Assembly

EMA-49

4. Install cylinder head bolts.


- Apply a light coat of engine oil on the threads and under the heads of the cylinder head bolts.
- Using the SST(09221-4A000), tighten the cylinder head bolts and plate washers, in several passes, in the sequence shown.

Tightening torque :

32.4~36.3Nm (3.3~3.7kgf.m, 23.9~26.8lb-ft) + 90~95°
+ 90~95°

⚠ CAUTION

Always use new cylinder head bolt.




KCRF162B

5. Install the intake OCV (A).

Tightening torque :

9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)



STD19328L


⚠ CAUTION

- Do not reuse the OCV when dropped.
- Keep the OCV filter clean.
- Do not hold the OCV sleeve during servicing.
- When the OCV is installed on the engine, do not move the engine with holding the OCV yoke.

6. Install the camshafts.

⚠ NOTICE

Apply a light coat of engine oil on camshaft journals.



STD19327L

EMA-50

Engine Mechanical System

7. Install camshaft bearing caps in their proper locations.


Tightening order.

Group A → Group B → Group C.

Tightening torque :


M6 : 10.8 ~ 12.7N.m(1.1 ~ 1.3kgf.m, 7.9 ~ 9.3lb-ft)

M8 : 27.4 ~ 31.4N.m(2.8 ~ 3.2kgf.m, 20.2 ~ 23.1lb-ft)



ECRF017A


8. Install the intake CVVT assembly (A) and exhaust camshaft sprocket (B).



STDM19323L

NOTICE

When installing the sprocket bolt or CVVT assembly bolt, fix the camshaft by wrench at position A.




STDM19324L

9. Install the water temperature control assembly (A).

Tightening torque :

Bolt : 14.7 ~ 19.6N.m(1.5 ~ 2.0kgf.m, 10.8 ~ 14.5lb-ft)

Nut : 18.6 ~ 23.5N.m(1.9 ~ 2.4kgf.m, 13.7 ~ 17.4lb-ft)



STDM19315L

NOTICE


- Assemble water temp control assembly and water inlet pipe to water pump assembly before nuts for assembling of water inlet pipe to be tightened.
- Insert after wetting O-ring or inner surface of thermostat housing.
- Always use a new O-ring.

Cylinder Head Assembly

EMA-51

10. Install the timing chain. (Refer to Timing system in this group)
11. Install the intake and exhaust manifold. (Refer to Intake and exhaust system in this group)
12. Check and adjust the valve clearance. (Refer to General information in this group)
13. Install cylinder head cover.
 - 1) The hardening sealant located on the upper area between timing chain cover and cylinder head should be removed before assembling cylinder head cover.
 - 2) After applying sealant, it should be assembled within 5 minutes.

Bead width : 2.5mm (0.1in.)




ECRF011A

- 3) Install the cylinder head cover bolts as following method.

Tightening torque :

1st step : 3.9 ~ 5.9N.m(0.4 ~ 0.6kgf.m, 2.9 ~ 4.3lb-ft)

2nd step : 7.8 ~ 9.8N.m(0.8 ~ 1.0kgf.m, 5.8 ~ 7.2lb-ft)



KCRF180A

CAUTION

- Do not reuse cylinder head cover gasket.
- The firing and/or blow out test should not be performed within 30 minutes after the cylinder head cover was assembled.

14. Install the other parts in the reverse order of removal.

NOTICE

- Refill engine oil.
- Clean the battery posts and cable terminals with sandpaper assemble them, and then apply grease to prevent corrosion.
- Inspect for fuel leakage.
 - After assembling the fuel line, turn on the ignition switch (do not operate the starter) so that the fuel pump runs for approximately two seconds and fuel line pressurizes.
 - Repeat this operation two or three times, and then check for fuel leakage at any point in the fuel lines.
- Refill radiator and reservoir tank with engine coolant.
- Bleed air from the cooling system.
 - Start engine and let it run until it warms up. (Until the radiator fan operates 3 or 4 times.)
 - Turn off the engine. Check the level in the radiator, add coolant if needed. This will allow trapped air to be removed from the cooling system.
 - Put radiator cap on tightly, then run the engine again and check for leaks.


EMA-52

Engine Mechanical System

Cylinder Block

Cylinder Block

Components




SNFEM8063L

- | | |
|---------------------------------|---------------------------------|
| 1. Piston ring | 5. Piston pin |
| 2. Piston | 6. Connecting rod lower bearing |
| 3. Connecting rod | 7. Connecting rod bearing cap |
| 4. Connecting rod upper bearing | 8. Ladder frame |

Cylinder Block

EMA-53



Torque : N.m (kgf.m, lb-ft)

SNFEM8064L

1. Crankshaft upper bearing
2. Thrust bearing
3. Crankshaft

4. Crankshaft lower bearing
5. Main bearing cap

EMA-54

Engine Mechanical System


Disassembly

⚠ CAUTION

- Use fender covers to avoid damaging painted surfaces.
- To avoid damage, unplug the wiring connectors carefully while holding the connector portion.


📌 NOTICE

- Mark all wiring and hoses to avoid misconnection.
 - Turn the crankshaft pulley so that the No.1 piston is at top dead center.
 - Engine removal is required for this procedure.
1. Remove the engine assembly from the vehicle. (Refer to Engine and transaxle assembly in this group)
 2. Install the engine to engine stand for disassembly.
 3. Remove the intake manifold and exhaust manifold. (Refer to Intake and exhaust system in this group)
 4. Remove the timing chain. (Refer to Timing system in this group)
 5. Remove the cylinder head assembly. (Refer to Cylinder head in this group)
 6. Remove the drive plate (AT only) or fly wheel (MT only).
 7. Remove the oil pump. (Refer to Lubrication system in this group)
 8. Remove the A/C compressor. (Refer to HA group)
 9. Remove the alternator (A).




KCRF159A

10. Remove the power steering pump and the bracket. (Refer to ST group)



KCRF160A

11. Remove the water pump (A) and the water pump gasket.




KCRF157A

Cylinder Block


EMA-55

- 12.Remove the tensioner assembly integrated bracket (A).




KCRF161A

- 13.Remove the oil level gauge (A).




STDM19336L

- 14.Remove the knock sensor (A).




KCRF143A

- 15.Remove the oil pressure sensor (A).




STDM19337L

- 16.Remove the CKP sensor (A).



KCRF164A

- 17.Remove the ladder frame (A).



KCRF167A

EMA-56

Engine Mechanical System

18. Check the connecting rod end play.
19. Remove the connecting rod caps and check oil clearance.
20. Remove piston and connecting rod assemblies.
 - 1) Using a ridge reamer, remove all the carbon from the top of the cylinder.
 - 2) Push the piston, connecting rod assembly and upper bearing through the top of the cylinder block.


NOTICE

- Keep the bearings, connecting rod and cap together.
- Arrange the piston and connecting rod assemblies in the correct order.

21. Remove crankshaft bearing cap and check oil clearance.
22. Check the crankshaft end play.
23. Lift the crankshaft (A) out of the engine, being careful not to damage journals.

NOTICE

Arrange the main bearings and thrust bearings in the correct order.



KCRF172A

24. Check fit between piston and piston pin.

Try to move the piston back and forth on the piston pin. If any movement is felt, replace the piston and pin as a set.
25. Remove piston rings.
 - 1) Using a piston ring expander, remove the 2 compression rings.
 - 2) Remove 2 side rails and the spacer by hand.

NOTICE

Arrange the piston rings in the correct order only.

26. Disconnect connecting rod from piston.

Cylinder Block

EMA-57

Inspection


Connecting Rod And Crankshaft

1. Check the connecting rod end play.

Using a feeler gauge, measure the end play while moving the connecting rod back and forth.

Standard end play : 0.1 ~ 0.25mm (0.004 ~ 0.010in.)

Maximum end play : 0.35mm (0.0138in.)



KCRF169B

- If out-of-tolerance, install a new connecting rod.
 - If still out-of-tolerance, replace the crankshaft.
2. Check the connecting rod bearing oil clearance.
 - 1) Check the matchmarks on the connecting rod and cap are aligned to ensure correct reassembly.
 - 2) Remove 2 connecting rod cap bolts.
 - 3) Remove the connecting rod cap and bearing half.
 - 4) Clean the crank pin and bearing.
 - 5) Place plastigage across the crank pin.
 - 6) Reinstall the bearing half and cap, and torque the bolts.

Tightening torque

17.7~21.6Nm (1.8~2.2kgf.m, 13.0~15.9lb-ft) + 88~92°

NOTICE


Do not turn the crankshaft.

- 7) Remove 2 bolts, connecting rod cap and bearing half.

- 8) Measure the plastigage at its widest point.

Standard oil clearance

0.027 ~ 0.045mm (0.0010 ~ 0.0017in.)



KCRF169A

- 9) If the plastigage measures too wide or too narrow, remove the upper half of the bearing, install a new, complete bearing with the same color mark (select the color as shown in the next column), and recheck the clearance.

CAUTION

Do not file, shim, or scrape the bearings or the caps to adjust clearance.

- 10) If the plastigage shows the clearance is still incorrect, try the next larger or smaller bearing (the color listed above or below that one), and check clearance again.

NOTICE

If the proper clearance cannot be obtained by using the appropriate larger or smaller bearings, replace the crankshaft and start over.


CAUTION

If the marks are indecipherable because of an accumulation of dirt and dust, do not scrub them with a wire brush or scraper. Clean them only with solvent or detergent.

EMA-58

Engine Mechanical System


Connecting Rod Mark Location



SNFEM8089L

Discrimination Of Connecting Rod

Class	Mark	Inside Diameter
a	A	51.000 ~ 51.006mm (2.0079 ~ 2.0081in.)
b	B	51.006 ~ 51.012mm (2.0081 ~ 2.0083in.)
c	C	51.012 ~ 51.018mm (2.0083 ~ 2.0085in.)

Crankshaft Pin Mark Location
Discrimination Of Crankshaft

SNFEM8090L


NOTICE

Conform to read stamping order as shown arrow direction from #1.

Discrimination Of Crankshaft

Class	Mark	Outside Diameter Of Pin
I	1	47.966 ~ 47.972mm (1.8884 ~ 1.8886in.)
II	2	47.960 ~ 47.966mm (1.8881 ~ 1.8884in.)
III	3	47.954 ~ 47.960mm (1.8879 ~ 1.8881in.)

Place Of Identification Mark (Connecting Rod Bearing) Discrimination Of Connecting Rod Bearing



ECRF021A

Discrimination Of Connecting Rod Bearing

Class	Mark	Thickness Of Bearing
AA	Blue	1.517 ~ 1.520mm (0.0597 ~ 0.0598in.)
A	Black	1.514 ~ 1.517mm (0.0596 ~ 0.0597in.)
B	None	1.511 ~ 1.514mm (0.0595 ~ 0.0596in.)
C	Green	1.508 ~ 1.511mm (0.0594 ~ 0.0595in.)
D	Yellow	1.505 ~ 1.508mm (0.0593 ~ 0.0594in.)

Cylinder Block

EMA-59

11) Selection

Crankshaft Identification Mark	Connecting Rod Identification Mark	Assembling Classification Of Bearing
I (1)	a (A)	D (Yellow)
	b (B)	C (Green)
	c (C)	B (None)
II (2)	a (A)	C (Green)
	b (B)	B (None)
	c (C)	A (Black)
III (3)	a (A)	B (None)
	b (B)	A (Black)
	c (C)	AA (Blue)

3. Check the crankshaft bearing oil clearance.

- 1) To check main bearing-to-journal oil clearance, remove the main caps and bearing halves.
- 2) Clean each main journal and bearing half with a clean shop towel.
- 3) Place one strip of plastigage across each main journal.
- 4) Reinstall the bearings and caps, then torque the bolts.

Tightening torque

27.5~31.4Nm (2.8~3.2kgf.m, 20.3~23.1lb-ft) + 120~125°


NOTICE

Do not turn the crankshaft.

- 5) Remove the cap and bearing again, and measure the widest part of the plastigage.

Standard oil clearance

0.020 ~ 0.038mm (0.0008 ~ 0.0015in.)



KCRF170A

- 6) If the plastigage measures too wide or too narrow, remove the upper half of the bearing, install a new, complete bearing with the same color mark (select the color as shown in the next column), and recheck the clearance.

CAUTION

Do not file, shim, or scrape the bearings or the caps to adjust clearance.

- 7) If the plastigage shows the clearance is still incorrect, try the next larger or smaller bearing (the color listed above or below that one), and check clearance again.

NOTICE

If the proper clearance cannot be obtained by using the appropriate larger or smaller bearings, replace the crankshaft and start over.

CAUTION

If the marks are indecipherable because of an accumulation of dirt and dust, do not scrub them with a wire brush or scraper. Clean them only with solvent or detergent.

EMA-60

Engine Mechanical System

Connecting Rods

1. When reinstalling, make sure that cylinder numbers put on the connecting rod and cap at disassembly match. When a new connecting rod is installed, make sure that the notches for holding the bearing in place are on the same side.
2. Replace the connecting rod if it is damaged on the thrust faces at either end. Also if step wear or a severely rough surface of the inside diameter of the small end is apparent, the rod must be replaced as well.
3. Using a connecting rod aligning tool, check the rod for bend and twist. If the measured value is close to the repair limit, correct the rod by a press. Any connecting rod that has been severely bent or distorted should be replaced.

Allowable bend of connecting rod :

0.05mm / 100mm (0.0020 in./3.94 in.) or less


Allowable twist of connecting rod :

0.1mm / 100mm (0.0039 in./3.94 in.) or less

Crankshaft bore mark location

Letters have been stamped on the block as a mark for the size of each of the 5 main journal bores.

Use them, and the numbers or bar stamped on the crank (marks for main journal size), to choose the correct bearings.




SNFEM8091L

Discrimination Of Cylinder Block

Class	Mark	Inside Diameter
a	A	56.000 ~ 56.006mm (2.2047 ~ 2.2049in.)
b	B	56.006 ~ 56.012mm (2.2049 ~ 2.2052in.)
c	C	56.012 ~ 56.018mm (2.2052 ~ 2.2054in.)

Crankshaft Journal Mark Location Discrimination Of Crankshaft



SNFEM8092L

NOTICE

Conform to read stamping order as shown arrow direction from #1.


Discrimination Of Crankshaft

Class	Mark	Outside Diameter Of Journal
I	1	51.954 ~ 51.960mm (2.0454 ~ 2.0456in.)
II	2	51.948 ~ 51.954mm (2.0452 ~ 2.0454in.)
III	3	51.942 ~ 51.948mm (2.0449 ~ 2.0452in.)

Cylinder Block

EMA-61

Place Of Identification Mark (Crankshaft Bearing) Discrimination Of Crankshaft Bearing



ECRF022A

Discrimination Of Crankshaft Bearing

Class	Mark	Thickness Of Bearing
AA	Blue	2.026 ~ 2.029mm (0.0797 ~ 0.0798in.)
A	Black	2.023 ~ 2.026mm (0.0796 ~ 0.0797in.)
B	None	2.020 ~ 2.023mm (0.0795 ~ 0.0796in.)
C	Green	2.017 ~ 2.020mm (0.0794 ~ 0.795in.)
D	Yellow	2.014 ~ 2.017mm (0.0793 ~ 0.0794in.)

Selection

Crankshaft Identification Mark	Crankshaft Bore Identification Mark	Assembling Classification Of Bearing
I (1)	a (A)	D (Yellow)
	b (B)	C (Green)
	c (C)	B (None)
II (2)	a (A)	C (Green)
	b (B)	B (None)
	c (C)	A (Black)
III (3)	a (A)	B (None)
	b (B)	A (Black)
	c (C)	AA (Blue)


4. Check crankshaft end play.

Using a dial indicator, measure the thrust clearance while prying the crankshaft back and forth with a screwdriver.

Standard end play

0.07 ~ 0.25mm (0.0027 ~ 0.0098in.)

Limit : 0.30mm (0.0118in.)



KCRF211A

If the end play is greater than maximum, replace the thrust bearings as a set.

Thrust bearing thickness

1.925 ~ 1.965mm(0.0758 ~ 0.07736in.)

EMA-62

Engine Mechanical System

5. Inspect main journals and crank pins


Using a micrometer, measure the diameter of each main journal and crank pin.

Main journal diameter :

51.942 ~ 51.960mm (2.0449 ~ 2.0456in.)

Crank pin diameter :

47.954 ~ 47.972mm (1.8879 ~ 1.8886in.)



KCRF212A

Cylinder Block

1. Remove gasket material.

Using a gasket scraper, remove all the gasket material from the top surface of the cylinder block.

2. Clean cylinder block


Using a soft brush and solvent, thoroughly clean the cylinder block.

3. Inspect top surface of cylinder block for flatness.

Using a precision straight edge and feeler gauge, measure the surface contacting the cylinder head gasket for warpage.

Flatness of cylinder block gasket surface

Standard : Less than 0.05mm(0.0020 in.)



KCRF213A

4. Inspect cylinder bore diameter

Visually check the cylinder for vertical scratches.

If deep scratches are present, replace the cylinder block.

Cylinder Block


EMA-63

5. Inspect cylinder bore diameter

Using a cylinder bore gauge, measure the cylinder bore diameter at position in the thrust and axial directions.

Standard diameter

86.00 ~ 86.03mm (3.3858 ~ 3.3870in.)




KCRF214A

NOTICE

Measure position (from the bottom of the cylinder block)

: 110.7mm(4.3582in.)/160mm(6.2992in.)/210mm(8.2677in.)

6. Check the cylinder bore size code on the cylinder block.



SNFEM8093L


Cylinder Bore Inner Diameter

Size Code	Cylinder Bore Inner Diameter
A	86.00 ~ 86.01mm (3.3858 ~ 3.3862in.)
B	86.01 ~ 86.02mm (3.3862 ~ 3.3866in.)
C	86.02 ~ 86.03mm (3.3866 ~ 3.3870in.)

EMA-64

Engine Mechanical System

7. Check the piston size code on the piston top face.



ECKE320B

NOTICE

Stamp the grade mark of basic diameter with rubber stamp.

Piston Outer Diameter

Size Code	Piston Outer Diameter
A	85.975 ~ 85.985mm (3.3848 ~ 3.3852in.)
B	85.985 ~ 85.995mm (3.3852 ~ 3.3856in.)
C	85.995 ~ 86.005mm (3.3856 ~ 3.3860in.)

8. Select the piston related to cylinder bore class.

Clearance : 0.015 ~ 0.035mm (0.00059 ~ 0.00137in.)

Piston And Rings

1. Clean piston

- 1) Using a gasket scraper, remove the carbon from the piston top.
- 2) Using a groove cleaning tool or broken ring, clean the piston ring grooves.
- 3) Using solvent and a brush, thoroughly clean the piston.


NOTICE

Do not use a wire brush.

2. The standard measurement of the piston outside diameter is taken 34.5mm (1.35in.) from the top land of the piston.

Standard diameter

85.975 ~ 86.005mm (3.3848 ~ 3.3860in.)



KCRF215A

3. Calculate the difference between the cylinder bore diameter and the piston diameter.

Piston-to-cylinder clearance

0.015 ~ 0.035mm (0.00059 ~ 0.00137in.)

Cylinder Block

EMA-65

4. Inspect the piston ring side clearance.

Using a feeler gauge, measure the clearance between new piston ring and the wall of the ring groove.

Piston ring side clearance

Standard

No.1 : 0.05 ~ 0.08mm (0.0019 ~ 0.0031in.)

No.2 : 0.04 ~ 0.08mm (0.0015 ~ 0.0031in.)

Oil ring : 0.06 ~ 0.15mm (0.0023 ~ 0.0059in.)

Limit

No.1 : 0.1mm (0.004in.)

No.2 : 0.1mm (0.004in.)

Oil ring : 0.2mm (0.008in.)



KCRF216A

If the clearance is greater than maximum, replace the piston.

5. Inspect piston ring end gap.

To measure the piston ring end gap, insert a piston ring into the cylinder bore. Position the ring at right angles to the cylinder wall by gently pressing it down with a piston. Measure the gap with a feeler gauge. If the gap exceeds the service limit, replace the piston ring. If the gap is too large, recheck the cylinder bore diameter against the wear limits. If the bore is over the service limit, the cylinder block must be rebored.

Piston ring end gap

Standard

No.1 : 0.15 ~ 0.30mm (0.0059 ~ 0.0118in.)

No.2 : 0.37 ~ 0.52mm (0.0145 ~ 0.0204in.)



Oil ring : 0.20 ~ 0.70mm (0.0079 ~ 0.0275in.)

Limit

No.1 : 0.6mm (0.0236in.)

No.2 : 0.7mm (0.0275in.)

Oil ring : 0.8mm (0.0315in.)



KCRF217A

EMA-66


Engine Mechanical System

Piston Pins

1. Measure the diameter of the piston pin.

Piston pin diameter

21.001 ~ 21.006mm (0.8268 ~ 0.8270in.)



KCRF218A

2. Measure the piston pin-to-piston clearance.

Piston pin-to-piston clearance

0.013 ~ 0.023mm (0.0005 ~ 0.0009in.)

3. Check the difference between the piston pin diameter and the connecting rod small end diameter.


Piston pin-to-connecting rod interference

0.016 ~ 0.032mm (0.00063 ~ 0.00126in.)

Oil Pressure Switch

1. Check the continuity between the terminal and the body with an ohmmeter.

If there is no continuity, replace the oil pressure switch.




KCRF219A

2. Check the continuity between the terminal and the body when the fine wire is pushed. If there is continuity even when the fine wire is pushed, replace the switch.

3. If there is no continuity when a 50kpa (7psi) is applied through the oil hole, the switch is operating properly.

Check for air leakage. If air leaks, the diaphragm is broken. Replace it.



KCRF220A

Cylinder Block

EMA-67


Reassembly

NOTICE

- Thoroughly clean all parts to assembled.
- Before installing the parts, apply fresh engine oil to all sliding and rotating surfaces.
- Replace all gaskets, O-rings and oil seals with new parts.

1. Assemble piston and connecting rod.


- 1) Use a hydraulic press for installation.
- 2) The piston front mark and the connecting rod front mark must face the timing belt side of the engine.



KCRF168A

2. Install piston rings.


- 1) Install the oil ring spacer and 2 side rails by hand.
- 2) Using a piston ring expander, install the 2 compression rings with the code mark facing upward.
- 3) Position the piston rings so that the ring ends are as shown.



KCRF221A

3. Install connecting rod bearings.

- 1) Align the bearing claw with the groove of the connecting rod or connecting rod cap.
- 2) Install the bearings(A) in the connecting rod and connecting rod cap(B).



KCRF118B

EMA-68


Engine Mechanical System

4. Install main bearings.

NOTICE

Upper bearings have an oil groove of oil holes; Lower bearings do not.

- 1) Align the bearing claw with the claw groove of the cylinder block, push in the 5 upper bearings(A).




KCRF173A

- 2) Align the bearing claw with the claw groove of the main bearing cap, and push in the 5 lower bearings.


5. Install thrust bearings.

Install the 2 thrust bearings(A) under the No.3 journal position of the cylinder block with the oil grooves facing outward.



KCRF222A

6. Place crankshaft(A) on the cylinder block.



KCRF172A

7. Place main bearing caps on cylinder block.

8. Install main bearing cap bolts.

Tightening torque

27.5~31.4Nm (2.8~3.2kgf.m, 20.3~23.1lb-ft) + 120~125°

CAUTION

Always use new main bearing cap bolts.


NOTICE

- The main bearing cap bolts are tightened in 2 progressive steps.
- If any of the bearing cap bolts is broken or deformed, replace it.

- 1) Apply a light coat of engine oil on the threads and under the bearing cap bolts.
- 2) Install and uniformly tighten the 10 bearing cap bolts(A), in several passes, in the sequence shown.

Tightening torque :

29.4N.m (3.0kgf.m, 21.7lb-ft)



Cylinder Block

EMA-69

KCRF171A

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



EMA-70

Engine Mechanical System

- 3) Retighten the bearing cap bolts by 120° in the numerical order shown.
- 4) Check that the crankshaft turns smoothly.
9. Check crankshaft end play.
10. Install piston and connecting rod assemblies.

NOTICE

Before installing the pistons, apply a coat of engine oil to the ring grooves and cylinder bores.

- 1) Remove the connecting rod caps, and slip short sections of rubber hose over the threaded ends of the connecting rod bolts.
- 2) Install the ring compressor, check that the bearing is securely in place, then position the piston in the cylinder, and tap it in using the wooden handle of a hammer.
- 3) Stop after the ring compressor pops free, and check the connecting rod-to-check journal alignment before pushing the piston into place.
- 4) Apply engine oil to the bolt threads. Install the rod caps with bearings, and torque the bolts.

Tightening torque


17.7~21.6Nm (1.8~2.2kgf.m, 13.0~15.9lb-ft) + 88~92°

CAUTION

Always use new connecting rod cap bolts.

NOTICE

Maintain downward force on the ring compressor to prevent the rings from expanding before entering the cylinder bore.




KCRF223A

11. Apply liquid gasket to the mating surface of cylinder block and ladder frame.

NOTICE

- Be assembling ladder frame, the liquid sealant Loctite 5900H or THREEBOND 1217H should be applied ladder frame.
- The part must be assembled within 5 minutes after sealant was applied.
- Apply sealant to the inner threads of the bolt holes.



ECRF023A

Cylinder Block

EMA-71

12. Install ladder frame(A) with 10 bolts in several passes in sequence shown.

Tightening torque

Step 1 :


7.8 ~ 8.8N.m (0.8 ~ 0.9kgf.m, 5.8 ~ 6.5lb-ft)

Step 2 :


15.7 ~ 18.6N.m (1.6 ~ 1.9kgf.m, 11.6 ~ 13.7lb-ft)

Step 3 :

23.5 ~ 27.5N.m (2.4 ~ 2.8kgf.m, 17.4 ~ 20.3lb-ft)



KCRF167A



SNFEM8094L


13. Install rear oil seal.

- 1) Apply engine oil to a new oil seal lip.
- 2) Using SST(09231-H1100, 09214-3K100) and a hammer, tap in the oil seal until its surface is flush with the rear oil seal retainer edge.

14. Install CKP sensor(A) and sensor cover.

Tightening torque

3.9 ~ 5.9N.m (0.4 ~ 0.6kgf.m, 2.9 ~ 4.3lb-ft)




KCRF164A

15. Install oil pressure sensor.

- 1) Apply adhesive to 2 or 3 threads.
Adhesive : MS 721-39(B) or equivalent.
- 2) Install the oil pressure sensor (A).

Tightening torque

7.8 ~ 11.8N.m (0.8 ~ 1.2kgf.m, 5.8 ~ 8.7lb-ft)



STDM19337L


EMA-72

Engine Mechanical System

16. Install knock sensor(A).

Tightening torque

16.7 ~ 25.5N.m (1.7 ~ 2.6kgf.m, 12.3 ~ 18.8lb-ft)




KCRF143A

17. Install oil level gauge assembly.

- 1) Install a new O-ring on the oil level gauge.
- 2) Apply engine oil on the O-ring.
- 3) Install the oil level gauge assembly(A) with the bolt.

Tightening torque

7.8 ~ 11.8N.m (0.8 ~ 1.2kgf.m, 5.8 ~ 8.7lb-ft)




STD19336L

18. Install tensioner assembly integrated bracket(A).

Tightening torque

39.2 ~ 44.1N.m (4.0 ~ 4.5kgf.m, 28.9 ~ 32.5lb-ft)




KCRF161A

19. Install the water pump (A) with a new water pump gasket.

Tightening torque :

18.6 ~ 23.5N.m (1.9 ~ 2.4kgf.m, 13.7 ~ 17.4lb-ft)




KCRF157A

Cylinder Block

EMA-73

20. Install the power steering pump and the bracket.
(Refer to ST group)




KCRF160A

21. Install the alternator (A).

Tightening torque :

49.0 ~ 63.7N.m (5.0 ~ 6.5kgf.m, 36.2 ~ 47.0lb-ft)



KCRF159A

22. Install the oil pump. (Refer to Lubrication system in this group)
23. Install the cylinder head assembly. (Refer to Cylinder head in this group)
24. Install the timing chain. (Refer to Timing system in this group)
25. Install the oil pan.


- 1) Using a razor blade and gasket scraper, remove all the old gasket material from the gasket surfaces.

NOTICE

Check that the mating surfaces are clean and dry before applying liquid gasket.

- 2) Apply liquid gasket as an even bead, centered between the edges of the mating surface.

Use liquid gasket LOCTITE 5900H or THREEBOND 1217H equivalent (MS721-40).



KCRF179A

NOTICE

- To prevent leakage of oil, apply liquid gasket to the inner threads of the bolt holes.
- Do not install the parts if five minutes or more have elapsed since applying the liquid gasket. Instead, reapply liquid gasket after removing the residue.
- After assembly, wait at least 30 minutes before filling the engine with oil.

EMA-74

Engine Mechanical System

3) Install the oil pan.

Uniformly tighten the bolts in several passes.

Tightening torque :

M8 bolts : 26.5 ~ 30.4N.m (2.7 ~ 3.1kgf.m, 19.5 ~ 22.4lb-ft)

M6 bolts : 9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)

26. Install the A/C compressor. (Refer to HA group)


27. Install the intake manifold and exhaust manifold.

(Refer to Intake and exhaust system in this group)

28. Install the drive plate (AT only) or fly wheel (MT only).

Tightening torque :

117.7 ~ 127.5N.m (12 ~ 13kgf.m, 86.8 ~ 94.0lb-ft)




SNFEM7901L

NOTICE

- Always use new flywheel (drive plate) bolts(C).
- Apply sealant to the screw part (8mm from the end of the bolt) when using new flywheel bolts.

Sealant: Three bond 2403, Loctite 200 or 204



SNFEM7902L

- Install and uniformly tighten the 7 bolts, in several passes.

29. Install the engine assembly on the vehicle.

(Refer to Engine and transaxle assembly in this group)

Cooling System

EMA-75

Cooling System

Coolant

Replacement And Air Bleeding

⚠WARNING

Never remove the radiator cap when the engine is hot. Serious scalding could be caused by hot fluid under high pressure escaping from the radiator.

⚠CAUTION

When pouring engine coolant, be sure to shut the relay box lid and not to let coolant spill on the electrical parts or the paint. If any coolant spills, rinse it off immediately.

1. Make sure the engine and radiator are cool to the touch.
2. Remove radiator cap.
3. Loosen the drain plug, and drain the coolant.
4. Tighten the radiator drain plug securely.
5. After draining engine coolant in the reservoir tank, clean the tank.
6. Fill the radiator with water through the radiator cap and tighten the cap.

📌NOTICE

To most effectively bleed the air, pour the water slowly and press on the upper/lower radiator hoses.

7. Start the engine and allow to come to normal operating temperature. Wait for the cooling fans to turn on several times. Accelerate the engine to aid in purging trapped air. Shut engine off.
8. Wait until the engine is cool.
9. Repeat steps 1 to 8 until the drained water runs clear.

10. Fill fluid mixture with coolant and water (5 : 5) (Tropical region – 4:6) slowly through the radiator cap. Push the upper/lower hoses of the radiator so as bleed air easily.

📌NOTICE

- Use only genuine antifreeze/coolant.
- For best corrosion protection, the coolant concentration must be maintained year-round at 35% minimum.
Coolant concentrations less than 35% may not provide sufficient protection against corrosion or freezing.
- Coolant concentrations greater than 60% will impair cooling efficiency and are not recommended.

⚠CAUTION

- Do not mix different brands of antifreeze/coolants.
- Do not use additional rust inhibitors or antirust products; they may not be compatible with the coolant.

11. Start the engine and run coolant circulates.

When the cooling fan operates and coolant circulates, refill coolant through the radiator cap.

12. Repeat 11 until the cooling fan 3 ~ 5 times and bleed air sufficiently out of the cooling system.
13. Install the radiator cap and fill the reservoir tank to the "MAX" line with coolant.
14. Run the vehicle under idle until the cooling fan operates 2 ~ 3 times.
15. Stop the engine and wait coolant gets cool.
16. Repeat 10 to 15 until the coolant level doesn't fall any more, bleed air out of the cooling system.

📌NOTICE

As it is to bleed air out to the cooling system and refill coolant when coolant gets cool completely, recheck the coolant level in the reservoir tank for 2 ~ 3 days after replacing coolant.


Coolant capacity : 6.3 L (6.6US qt, 5.4Imp qt)

EMA-76

Engine Mechanical System

Water pump

Components



STDM19101L

1. Water pump
2. Gasket

3. Water temperature control assembly

Cooling System


EMA-77

Removal

1. Loosen the drain plug (A), and then drain the engine coolant.


⚠ CAUTION

Never remove the radiator cap when the engine is hot. Serious scalding could be caused by hot fluid under high pressure escaping from the radiator.



SHDM26020D

2. Remove the drive belt (A).




STDM19354L

3. Remove the water inlet pipe nut.
4. Remove the water pump (A) and the water pump gasket.

Tightening torque :

18.6 ~ 23.5N.m (1.9 ~ 2.4kgf.m, 13.7 ~ 17.4lb-ft)



KCRF157A

5. Installation is reverse order of removal with a new water pump gasket.

Inspection

1. Check each part for cracks, damage or wear, and replace the coolant pump assembly if necessary.
2. Check the bearing for damage, abnormal noise and sluggish rotation, and replace the coolant pump assembly if necessary.
3. Check for coolant leakage. If coolant leaks from hole, the seal is defective. Replace the coolant pump assembly.

⚠ NOTICE

A small amount of "weeping" from the bleed hole is normal.

EMA-78

Engine Mechanical System

Troubleshooting

Water Pump

Symptoms		Possible Causes		Remedy
Coolant leakage	<ul style="list-style-type: none"> From the bleed hole of the water pump 	Visually check	<ul style="list-style-type: none"> Check leaks after about ten-minute warming up. 	<ul style="list-style-type: none"> If coolant still leaks, replace a water pump.
	<ul style="list-style-type: none"> From gaskets or bolts 		<ul style="list-style-type: none"> Check the tightening of the water pump mounting bolts. 	<ul style="list-style-type: none"> If leakage stops, reuse the water pump (Do not replace the pump with a new one). Retighten the mounting bolts.
	<ul style="list-style-type: none"> From outer surface of water pump 		<ul style="list-style-type: none"> Check damage of gaskets or inflow of dust. 	<ul style="list-style-type: none"> Replace the gasket and clean dust off.
	<ul style="list-style-type: none"> From outer surface of water pump 		<ul style="list-style-type: none"> Check the material or any cracks of the water pump. 	<ul style="list-style-type: none"> Poor material. If any crack found, replace the water pump.
Noise	<ul style="list-style-type: none"> From bearings From mechanical seals Impeller interference 	Inspection with a stethoscope	<ul style="list-style-type: none"> After starting the engine, check noise with a stethoscope. 	<ul style="list-style-type: none"> If there is no noise, reuse the water pump (do not replace it).
		Inspection after removing a drive belt	<ul style="list-style-type: none"> After removing a water pump and a drive belt, check noise again. 	<ul style="list-style-type: none"> If there is any noise from the water pump, remove the drive belt and recheck.
		Inspection after removing a water pump	<ul style="list-style-type: none"> After removing a water pump and a drive belt, check noise again. 	<ul style="list-style-type: none"> If there is noise, reuse the water pump. Check other drive line parts.
		Inspection after removing a water pump	<ul style="list-style-type: none"> After removing a water pump and a drive belt, check noise again. 	<ul style="list-style-type: none"> If there is no noise, replace the water pump with a new one.
Overheating	<ul style="list-style-type: none"> Damaged impeller Loosened impeller 	Loosened impeller	<ul style="list-style-type: none"> Corrosion of the impeller wing 	<ul style="list-style-type: none"> Check engine coolant. Poor coolant quality / Maintenance check
			<ul style="list-style-type: none"> Impeller separation from the shaft 	<ul style="list-style-type: none"> Replace the water pump.

Cooling System

EMA-79

Thermostat

Removal


NOTICE

Removal of the thermostat would have an adverse effect, causing a lowering of cooling efficiency. Do not remove the thermostat, even if the engine tends to overheat.

1. Disconnect the battery terminals and remove the battery (A).
2. Remove the engine cover (B).
3. Disconnect the ECM connector (C).
4. Disconnect the breather hose and then, remove the air duct (D) and air cleaner assembly (E).


Tightening torque :

7.8 ~ 9.8N.m (0.8 ~ 1.0kgf.m, 5.8 ~ 7.2lb-ft)



STDM19301L

5. Drain engine coolant so its level is below thermostat.
6. Remove the radiator lower hose (A).




STDM19338L

7. Remove the water inlet fitting (A), gasket (B) and thermostat (C).

Tightening torque :

7.8 ~ 11.8N.m (0.8 ~ 1.2kgf.m, 5.8 ~ 8.7lb-ft)



STDM19339L

8. Installation is reverse order of removal.

NOTICE

Install the thermostat with the jiggle valve upward.


9. Fill the engine coolant.
10. Start the engine and check for leaks.
11. Recheck the coolant level.

EMA-80

Engine Mechanical System

Inspection

1. Immerse the thermostat in water and gradually heat the water.



KCRF226A

2. Check the valve opening temperature.

Valve opening temperature: 82°C (177°F)

Full opening temperature: 95°C (205°F)

If the valve opening temperature is not as specified, replace the thermostat.

3. Check the valve lift.

Valve lift : 8mm (0.3in.) or more at 95°C (205°F)

If the valve lift is not as specified, replace the thermostat.



Cooling System

EMA-81

Troubleshooting

Symptoms		Possible Causes		Remedy
Coolant leakage	<ul style="list-style-type: none"> From the thermostat gasket 	Check the mounting bolts	<ul style="list-style-type: none"> Check the torque of the mounting bolts 	<ul style="list-style-type: none"> Retighten the bolts and check leakage again.
		Check the gasket for damage	<ul style="list-style-type: none"> Check gasket or seal for damage 	<ul style="list-style-type: none"> Replace gaskets and reuse the thermostat.
Cooled excessively	<ul style="list-style-type: none"> Low heater performance (cool air blown-out) Thermogauge indicates 'LOW' 	Visually check after removing the radiator cap.	<ul style="list-style-type: none"> Insufficient coolant or leakage. 	<ul style="list-style-type: none"> After refilling coolant, re-check.
		GDS check & Starting engine	<ul style="list-style-type: none"> Check DTCs Check connection of the fan clutch or the fan motor. ※ If the fan clutch is always connected, there will be a noise at idle. 	<ul style="list-style-type: none"> Check the engine coolant sensor, wiring and connectors. Replace the components.
		Remove the thermostat and inspect	<ul style="list-style-type: none"> Check if there are dusts or chips in the thermostat valve. Check adherence of the thermostat. 	<ul style="list-style-type: none"> Clean the thermostat valve and reuse the thermostat. Replace the thermostat, if it doesn't work properly.
Heated excessively	<ul style="list-style-type: none"> Engine overheated Thermogauge indicates 'HI' 	Visually check after removing the radiator cap.	<ul style="list-style-type: none"> Insufficient coolant or leakage. ※ Be careful when removing a radiator cap of the overheated vehicle. Check air in cooling system. 	<ul style="list-style-type: none"> After refilling coolant, re-check. Check the cylinder head gaskets for damage and the tightening torque of the mounting bolts.
		GDS check & Starting engine	<ul style="list-style-type: none"> Check DTCs Check the fan motor performance as temperature varies. Check if the fan clutch slips. Check the water pump adherence or impeller damaged. 	<ul style="list-style-type: none"> Check the engine coolant sensor, wiring and connectors. Check the fan motor, the relay and the connector. Replace the fan clutch, if it doesn't work properly. Replace the water pump, if it doesn't work properly.
		Immerse the thermostat in boiling water and inspection.	<ul style="list-style-type: none"> After removing the thermostat, check it works properly. ※ Check the thermostat opens at the valve opening temperature. 	<ul style="list-style-type: none"> Replace the thermostat, if it doesn't work properly.

EMA-82

Engine Mechanical System


Radiator

Removal

1. Remove the under covers (A).

Tightening torque :

9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)




STDM19304L

2. Loosen the drain plug (A), and then drain the engine coolant.


CAUTION

Never remove the radiator cap when the engine is hot. Serious scalding could be caused by hot fluid under high pressure escaping from the radiator.



SHDM26020D

3. Remove the radiator upper hose (A) and lower hose (B) and reservoir hose.



STDM19340L

4. Remove the radiator.

- 1) Disconnect the fan connector (A) and remove the fan assembly (B).


Tightening torque :

8.8 ~ 10.8N.m (0.9 ~ 1.1kgf.m, 6.5 ~ 7.9lb-ft)

- 2) Remove the radiator upper mounting brackets (C).

Tightening torque :

8.8 ~ 10.8N.m (0.9 ~ 1.1kgf.m, 6.5 ~ 7.9lb-ft)




STDM19311L

Cooling System

EMA-83

[Coupe]



STDM29020D

- 3) After pulling back the condenser fixing bracket and then, remove the radiator assembly.
5. Installation is reverse order of removal.


NOTICE

- Bleed air from the cooling system.
 - Start engine and let it run until it warms up. (Until the radiator fan operates 3 or 4 times.)
 - Turn off engine. Check the coolant level and add coolant if needed. This will allow trapped air to be removed from the cooling system.
 - Put the radiator cap on tightly, then run engine again and check for leaks.

Inspection

Radiator Cap Testing

1. Remove the radiator cap, wet its seal with engine coolant, and then install it on a pressure tester.



ECKD501X

2. Apply a pressure of 93.16 ~ 122.58kpa (0.95 ~ 1.25kg/cm², 13.51 ~ 17.78psi).
3. Check for a drop in pressure.
4. If the pressure drops, replace the cap.

Radiator Leakage Test

1. Wait until engine is cool, then carefully remove the radiator cap and fill the radiator with engine coolant, then install it on the pressure tester.
2. Apply a pressure tester to the radiator and apply a pressure of 93.16 ~ 122.58kpa (0.95 ~ 1.25kg/cm², 13.51 ~ 17.78psi).
3. Inspect for engine coolant leaks and a drop in pressure.
4. Remove the tester and reinstall the radiator cap.

NOTICE

Check for engine oil in the coolant and/or coolant in the engine oil.


EMA-84

Engine Mechanical System

Lubrication System

Oil Pump

Components



STDM19341L

1. Oil pump
2. Oil pump chain
3. Oil pump sprocket


4. Oil pump chain guide
5. Oil pump chain tensioner arm

Lubrication System

EMA-85


Removal

1. Remove the timing chain. (Refer to timing system in this group)
2. Remove the oil pump mechanical tensioner (B).
3. Remove the oil pump chain guide (D).




STDM19342L

4. Remove the oil pump (A) and oil pump chain.



SNFEM8083D

Installation



STDM19342L

1. The key of crankshaft should be aligned with the mating face of main bearing cap. As a result of this, the piston of No.1 cylinder is placed at the top dead center on compression stroke.
2. Assemble the crankshaft sprocket on the crankshaft as the front mark on the crankshaft sprocket to be outward.
3. Tighten the oil pump tensioner bolt(A) after placing the tensioner spring on the dowel pin located in ladder frame, and then insert stopper pin to fix the tensioner(B).

Tightening torque :

9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)

4. Assemble the oil pump chain on the crankshaft sprocket.


EMA-86

Engine Mechanical System

5. Assemble the oil pump assembly (C) on the ladder frame as placing oil pump sprocket in to oil pump.

Tightening torque :

8.8 + 16.7 + 25.5N.m (0.9 + 1.7 + 2.6kgf.m, 6.5 + 12.3 + 18.8lb-ft)



SMGEM8011D

Bolting order

- a. Assemble the bolts in order number as shown with seating torque 25.5 N.m (2.6kgf.m, 18.8 lb-ft)
 - b. Unfasten the bolts as reverse bolting order. (3-2-1)
 - c. Assemble the bolts as specified bolting order in same increments as follows.
6. Install the oil pump chain guide (D) then remove the stopper pin.

Tightening torque :

9.8 ~ 11.8N.m (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)



Lubrication System

EMA-87

Engine Oil

Oil And Filter Replacement


⚠ CAUTION

- Prolonged and repeated contact with mineral oil will result in the removal of natural fats from the skin, leading to dryness, irritation and dermatitis. In addition, used engine oil contains potentially harmful contaminants which may cause skin cancer.
 - Exercise caution in order to minimize the length and frequency of contact of your skin to used oil. Wear protective clothing and gloves. Wash your skin thoroughly with soap and water, or use water-less hand cleaner, to remove any used engine oil. Do not use gasoline, thinners, or solvents.
 - In order to preserve the environment, used oil and used oil filter must be disposed of only at designated disposal sites.
1. Park the car on level ground.
Start the engine and let it warm up.
 2. Drain engine oil.
 - 1) Remove the oil filler cap.
 - 2) After lifting the car, remove the oil drain plug (A) and drain oil into a container.
 3. Replace the oil filter (B).
 - 1) Remove the oil filter.
 - 2) Check and clean the oil filter installation surface.
 - 3) Check the part number of the new oil filter is as same as old one.
 - 4) Apply clean engine oil to the gasket of a new oil filter.
 - 5) Lightly screw the oil filter into place, and tighten it until the gasket contacts the seat.

6) Tighten it with the torque below.

Tightening torque :

11.8 ~ 15.7N.m (1.2 ~ 1.6kgf.m, 8.7 ~ 11.6lb-ft)



STDM19343L

4. Install the oil drain plug with a new gasket.

Tightening torque :

34.3 ~ 44.1N.m (3.5 ~ 4.5kgf.m, 25.3 ~ 32.5lb-ft)

5. Fill with new engine oil, after removing the engine oil level gauge.

Capacity :

Total : 4.7L (4.97US qt, 4.13Imp qt)

Oil pan : 3.8L (4.01US qt, 3.34Imp qt)

Drain and refill including oil filter :

4.1L (4.33US qt, 3.60Imp qt)

6. Install the oil filler cap.

7. Start engine and check for oil leaks and check the oil gauge or light for an indication of oil pressure.

8. Recheck the engine oil level.

Inspection

1. Check the engine oil quality.

Check the oil deterioration, entry of water, discoloring of thinning. If the quality is visibly poor, replace the oil.

2. Check the engine oil level.

After engine warm up stop the engine wait 5 minutes then check the oil level. Oil level should be between the "L" and "F" marks on the dipstick. If low check for leakage and add oil up to the "F" mark.

⚠ NOTICE

Do not fill with engine oil above the "F" mark.

EMA-88

Engine Mechanical System


Selection Of Engine Oil

Recommendation (except Middle East) : 5W-20/GF4&SM
(If not available, refer to the recommended API or ILSAC classification and SAE viscosity number.)

API classification : SL, SM or above

ILSAC classification : GF3, GF4 or above

SAE viscosity grade : Refer to the recommended SAE viscosity number.



SAMM29103L

NOTICE

For best performance and maximum protection of all types of operation, select only those lubricants which :

1. Satisfy the requirement of the API or ILSAC classification.
2. Have proper SAE grade number for expected ambient temperature range.

3. Lubricants that do not have both an SAE grade number and API or ILSAC service classification on the container should not be used.


Intake And Exhaust System

EMA-89

Intake And Exhaust System

Intake Manifold

Components



STDM19344L

1. Intake manifold assembly
2. Electronic throttle body

3. Intake manifold stay

EMA-90


Engine Mechanical System

Removal

1. Disconnect the battery terminals and remove the battery (A).
2. Remove the engine cover (B).
3. Disconnect the ECM connector (C).
4. Disconnect the breather hose and then, remove the air duct (D) and air cleaner assembly (E).

Tightening torque :


7.8 ~ 9.8N.m (0.8 ~ 1.0kgf.m, 5.8 ~ 7.2lb-ft)



STDM19301L


5. Disconnect the wiring connectors and harness clamps from the intake manifold.

- 1) Disconnect the ETC connector (A) and knock sensor connector (B).
- 2) Disconnect the injector connectors (C).
- 3) (3) Remove the wiring harness mounting bolts (D).




STDM19349L

- 4) Disconnect the power steering fluid pressure switch connector (A).
- 5) Disconnect the MAP sensor connector (B).
- 6) Disconnect the OPS connector (C).
- 7) Disconnect the alternator connector (D).
- 8) Disconnect the A/C switch connector from the compressor.



STDM19309L

- 9) Disconnect the intake OCV connector (A).




SNFEM8032D

Intake And Exhaust System

EMA-91

- 10) Disconnect the CMP sensor connector (A) and fuel hose (B).




SNFEM8009D

6. Remove the intake manifold stay (A).

Tightening torque :

18.6 ~ 23.5N.m (1.9 ~ 2.4kgf.m, 13.7 ~ 17.4lb-ft)




STDM19312L

7. Remove the intake manifold assembly.

- 1) Disconnect the PCV hose (A).
- 2) Disconnect the PCSV hose (B) and the brake vacuum hose (C).
- 3) Disconnect the coolant hoses (D) from the throttle body.
- 4) Remove the intake manifold assembly (E).

Tightening torque :

18.6 ~ 23.5N.m (1.9 ~ 2.4kgf.m, 13.7 ~ 17.4lb-ft)



STDM19313L


8. Installation is reverse order of removal.

EMA-92

Engine Mechanical System

Exhaust Manifold

Components



STD19357L

1. Heat protector
2. Exhaust manifold


3. Exhaust manifold gasket
4. Exhaust manifold stay

Intake And Exhaust System

EMA-93

Removal

1. Disconnect the oxygen sensor connector (A).




STDM19347L

2. Remove the front muffler (A).

Tightening torque :

39.2 ~ 58.8N.m (4.0 ~ 6.0kgf.m, 28.9 ~ 43.4lb-ft)




STDM19305L

3. Remove the heat protector (A).

Tightening torque :

7.8 ~ 11.8N.m (0.8 ~ 1.2kgf.m, 5.8 ~ 8.7lb-ft)



SNFEM8015D

4. Remove the exhaust manifold stay (A).

Tightening torque :

M8 bolts :

18.6 ~ 27.5N.m (1.9 ~ 2.8kgf.m, 13.7 ~ 20.3lb-ft)


M10 bolt :

51.9 ~ 57.8N.m (5.3 ~ 5.9kgf.m, 38.3 ~ 42.6lb-ft)

5. Remove the exhaust manifold (B).

Tightening torque :

49.0 ~ 53.9N.m (5.0 ~ 5.5kgf.m, 36.2 ~ 39.7lb-ft)



STDM19314L

6. Installation is reverse order of removal.