


# Wiper and Washer

Circuit Diagram (Page 1 of 3)



09

**Parts Location**

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
Q-001	08-6	Q-016	08-6	Q-018	08-6
B-026	08-16				

**Fuse and Relay**

Fuse/Relay	See Page	Fuse and Relay Box
EF29	06-2	Engine Compartment Fuse and Relay Box
Wiper Low Relay (FRY08)	06-2	Engine Compartment Fuse and Relay Box
Wiper High Relay (FRY09)	06-2	Engine Compartment Fuse and Relay Box

**Location of Junction Connector**


Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
B-019, Q-008	08-16				

**Form of Connector**

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
Q-001	12-16	Q-016	12-16	Q-018	12-16
B-026	12-8	B-019, Q-008	12-8		

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Circuit Diagram (Page 2 of 3)



09

WWE002001

## Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-015	08-12	I-010	08-12	B-026	08-16

## Location of Junction Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-004, B-017	08-12				

## Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-015	12-4	I-010	12-4	B-026	12-8
I-004, B-017	12-4				


# دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Circuit Diagram (Page 3 of 3)



09

WWE003001