


Defrost Control



Harness connector	Name	Pages
C01	Rear Connector of Indoor Fuse Box	17
C05	Rear Connector of Indoor Fuse Box	17
DR01	Front left door connected to body harness connector	114
DR05	Harness connector of left exterior rearview mirror	114
DR11	Front right door connected to body harness connector	114
DR15	Right exterior rearview mirror connector	114
EA03	To instrument harness connector2	75
EN01	Harness connector of engine control module	28
EN04	To instrument harness connector	28
IP05	To harness connector of indoor fuse & relay box	80
IP10	To body harness connector	80
IP27	Harness connector of body control module 3	80
IP29	Harness connector of body control module 1	80
IP40	A/C control module harness connector	80
IP48	To engine harness connector	80
SO03	To instrument harness connector	97/106
SO05	To front right door harness connector	97/106
SO07	To front left door harness connector	97/106
SO11	To harness connector of indoor fuse & relay box	97/106
SO36 (Sedan)	Rear defrost positive harness connector	97
SO38 (Hatch)	To harness connector of tail door	106
SO46 (Hatch)	To body harness connector	107
SO50 (Hatch)	Rear defrost negative harness connector	107
SO62(Hatch)	Rear defrost positive harness connector	107
G10	Body harness grounding	126/127/128
G20 (Hatch)	Backdoor grounding (Hatch)	129