


SQRD4G15B Fuel Supply System

Circuit Diagram (Page 1 of 2)



02 09

EA13T090100

Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-032	08-10	E-028	08-5 (MT) 08-7 (AT)	E-067	08-5 (MT) 08-7 (AT)
E-063	08-5 (MT) 08-7 (AT)	I-005	08-10	I-011	08-10
B-009	08-12	B-008	08-12	E-041	08-5 (MT) 08-7 (AT)

Fuse and Relay

Fuse/Relay	See Page	Fuse and Relay Box
EF26	06-2	Engine Compartment Fuse and Relay Box
EF22	06-2	Engine Compartment Fuse and Relay Box
EF37	06-2	Engine Compartment Fuse and Relay Box
EF31	06-2	Engine Compartment Fuse and Relay Box
EF15	06-2	Engine Compartment Fuse and Relay Box
EF38	06-2	Engine Compartment Fuse and Relay Box
RF01	06-10	IP Fuse and Relay Box
RF10	06-10	IP Fuse and Relay Box
ECM Main Relay	06-2	Engine Compartment Fuse and Relay Box
Fuel Pump Relay	06-2	Engine Compartment Fuse and Relay Box


Location of Junction Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
E-030, I-036	08-5, 08-10 (MT) 08-7, 08-10 (AT)	E-026, B-015	08-5, 08-12 (MT) 08-7, 08-12 (AT)	I-002, B-019	08-10, 08-12

Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-032	12-9	E-028	12-3	E-067	12-6
E-063	12-5	I-005	12-7	I-011	12-7
B-009	12-10	E-041	12-4	B-008	12-10
E-026, B-015	12-3	I-002, B-019	12-7	E-030, I-036	12-3

Circuit Diagram (Page 2 of 2)



دیجیتال خودرو
اولین سامانه دیجیتال تعمیرکاران خودرو در ایران
www.digitalkhodro.com

02 09 52 99 92 92

EA13T090110

Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
E-024	08-3	E-011	08-3	E-010	08-3
E-009	08-3	E-001	08-3		

Location of Junction Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
E-035, E-007	08-5, 08-3 (MT) 08-7, 08-3 (AT)				


Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
E-024	12-3	E-011	12-2	E-010	12-2
E-009	12-2	E-001	12-2	E-035, E-007	12-4

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



021 62 99 92 92

www.digitalkhodro.com 09