


Position lamp (Sedan)



Harness connector	Name	Pages
C01	Rear Connector of Indoor Fuse Box	17
C02	Rear Connector of Indoor Fuse Box	17
C05	Rear Connector of Indoor Fuse Box	17
CA12(Sedan)	Harness connector of front left combination headlamp	23
CA18 (Sedan)	Harness connector of front right combination headlamp	23
IP05	To harness connector of indoor fuse & relay box	80
IP18	Headlamp combination switch harness connector	80
IP29	Harness connector of body control module 1	80
SO11	To harness connector of indoor fuse & relay box	97/106
SO35	To luggage compartment harness connector	97/106
SO37	Harness connector of rear right combination tail lamp	97/106
SO41	Harness connector of rear left combination tail lamp	97/106
SO58 (Sedan)	Harness connector of left license lamp	97
SO59(Sedan)	Harness connector of right license lamp	97
SO51 (Sedan)	To body harness connector	97
G1A	Engine compartment grounding	121
G3	Engine compartment grounding	121
G15	Body harness grounding	126/127/128

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

Connection point	Descriptions	Pages
IP05-33	To backlight adjusting switch	517
IP05-33	To instrument IP03-20	528