


## Reverse radar (Hatch)



| Harness connector | Name                                             | Pages |
|-------------------|--------------------------------------------------|-------|
| IP03              | Combination instrument harness connector         | 80    |
| IP10              | To harness connector of body harness             | 80    |
| IP11              | To harness connector of body harness             | 80    |
| SO02(Hatch)       | To harness connector of instrument harness       | 106   |
| SO03 (Hatch)      | To harness connector of instrument harness       | 106   |
| SO38 (Hatch)      | To harness connector of tail door harness        | 106   |
| SO40 (Hatch)      | Harness connector of PDC                         | 106   |
| SO42(Hatch)       | Harness connector of left parking sensor         | 106   |
| SO43 (Hatch)      | Harness connector of middle left parking sensor  | 106   |
| SO44 (Hatch)      | Harness connector of middle right parking sensor | 106   |
| SO45 (Hatch)      | Harness connector of right parking sensor        | 106   |
| SO46 (Hatch)      | To body harness connector                        | 107   |
| G20 (Hatch)       | Backdoor grounding                               | 129   |

| Connection point | Descriptions           | Pages              |
|------------------|------------------------|--------------------|
| SO40-16          | To reverse lamp switch | 503/507/509<br>511 |
| SO40-16          | To reverse lamp        | 503/507/509<br>511 |
| SO40-16          | To reverse lamp relay  | 505                |

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران