



Center control lock 1



Center control lock 2 (GC6/New King Kong 2016)



Harness connector	Name	Page
CA01	To instrument harness connector	33
DR01	To floor harness connector A	61
DR02	Driver side door connected to instrument harness connector B	61
DR09	Front left door lamp harness connector	61
DR11	Passenger side door connected to instrument harness connector A	61
DR12	Passenger side door connected to instrument harness connector B	61
DR19	Front right door lamp harness connector	61
DR20	Front right lock harness connector	62
DR21	Rear left door connected to floor harness connector A	62
DR25	Rear left lock harness connector	62
DR26	Rear right door connected to floor harness connector A	62
DR30	Rear right lock harness connector	62
DR34	Front left door lock harness connector (New King Kong 2016)	62
DR38	Passenger side door connected to instrument harness connector A (New King Kong 2016)	62
IP03	BCM harness connector A1	46
IP04	BCM harness connector A2	46
IP06	BCM harness connector C	54
IP07	To floor harness connector A	46
IP08	To floor harness connector B	46
IP09	To front left door harness connector A	46
IP13	To engine compartment harness connector	46
IP47	To front right door harness connector A	46
IP48	To front right door harness connector B	46
IP85	To front left door harness connector B (GC6)	46
IP93	To front right door harness connector A (New King Kong 2016)	46
SO01	To rear right door harness connector A	56
SO05	To rear left door harness connector A	43
SO07	To instrument panel harness connector A	56
SO08	To instrument panel harness connector B	56
SO15	Front right door lamp switch harness connector	56
SO16	Front left door lamp switch harness connector	56
SO17	Rear right door lamp switch harness connector	65
SO18	Rear left door lamp switch harness connector	56
G4	Instrument grounding	74
G5	Instrument grounding	74

Connection point	Description	Page
IP03-9	To combination instrument IP01-32	192
	To PEPS control module IP49-4	300
IP03-8	To combination instrument IP01-33	192
	To PEPS control module IP49-5	300
IP03-15	To combination instrument IP01-34	192
	To PEPS control module IP49-6	300
IP03-14	To combination instrument IP01-35	192
	To PEPS control module IP49-7	300
DR10-4	To PEPS control module IP49-3	300