


Supplemental Restraint System

Circuit Diagram (Page 1 of 5)

w/ SIDE AIRBAG



09 - SYSTEM CIRCUITS

Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-002	08-13	I-011	08-13	I-030	08-13
B-026	08-16				

Fuse and Relay

Fuse/Relay	See Page	Fuse and Relay Box
RF08	06-13	Instrument Panel Fuse and Relay Box A

Location of Junction Connector


Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-026, B-047	08-13, 08-19				

Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-002	12-9	I-011	12-9	I-030	12-10
B-026	12-12	I-026, B-047	12-10		


شرکت دیجیتال خودرو (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Circuit Diagram (Page 2 of 5)

w/ SIDE AIRBAG



Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
B-062	08-16	B-020	08-16	B-026	08-19
B-024	08-16	B-030	08-19	B-025	08-16

Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
B-062	12-14	B-020	12-12	B-026	12-12
B-024	12-12	B-030	12-12	B-025	12-12

دیجیتال خودرو


شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Circuit Diagram (Page 3 of 5)

w/ SIDE AIRBAG



Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
B-027	08-16	B-023	08-16	B-063	08-16
B-021	08-16	B-026	08-19		

Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
B-027	12-12	B-023	12-12	B-063	12-14
B-021	12-12	B-026	12-12		

دیجیتال خودرو


شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Circuit Diagram (Page 4 of 5)

w/o SIDE AIRBAG



09 - SYSTEM CIRCUITS

Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-030	08-13	I-011	08-13	I-002	08-13
I-050	08-13				

Fuse and Relay

Fuse/Relay	See Page	Fuse and Relay Box
RF08	06-13	Instrument Panel Fuse and Relay Box A

Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-030	12-10	I-011	12-9	I-002	12-9
I-050	12-10				

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Circuit Diagram (Page 5 of 5)

w/o SIDE AIRBAG
*1: FOR IRAN & RUSSIA
*2: FOR GULF, EGYPT,
CENTRAL & SOUTH AMERICA

