


Supplemental Restraint System

Circuit Diagram (Page 1 of 2)



09

EM1A090300

09 - SYSTEM CIRCUITS

Parts Location

| Connector Code | See Page | Connector Code | See Page | Connector Code | See Page |
|----------------|----------|----------------|----------|----------------|----------|
| I-004 | 08-8 | I-022 | 08-8 | I-030 | 08-8 |
| I-012 | 08-8 | | | | |

Fuse and Relay

| Fuse/Relay | See Page | Fuse and Relay Box |
|------------|----------|-------------------------------------|
| RF04 | 06-13 | Instrument Panel Fuse and Relay Box |

Form of Connector

| Connector Code | See Page | Connector Code | See Page | Connector Code | See Page |
|----------------|----------|----------------|----------|----------------|----------|
| I-004 | 12-4 | I-022 | 12-5 | I-030 | 12-5 |
| I-012 | 12-4 | | | | |

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Circuit Diagram (Page 2 of 2)

