


# Door Lock

Circuit Diagram (Page 1 of 4)



09

**Parts Location**

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
Q-001	08-6	I-001	08-12	I-010	08-12
B-021	08-16				

**Fuse and Relay**

Fuse/Relay	See Page	Fuse and Relay Box
SB04	06-2	Engine Compartment Fuse and Relay Box
RF01	06-8	Instrument Panel Fuse and Relay Box
RF26	06-8	Instrument Panel Fuse and Relay Box

**Location of Junction Connector**


Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
B-018, Q-007	08-16				

**Form of Connector**

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
Q-001	12-16	I-001	12-4	I-010	12-4
B-021	12-8	B-018, Q-007	12-8		

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Circuit Diagram (Page 2 of 4)



09

DLE002001

**Parts Location**

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
B-026	08-16	B-022	08-16	B-036	08-16
F-006	08-25	Q-057	08-6	Q-050	08-6
T-010	08-29	T-016	08-29	T-003	08-29

**Location of Junction Connector**

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
B-024, F-001	08-16	B-025, F-001	08-16	B-019, Q-008	08-16
B-005, T-001	08-16				


**Form of Connector**

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
B-026	12-8	B-022	12-8	B-036	12-8
F-006	12-13	Q-057	12-16	Q-050	12-16
T-010	12-15	T-016	12-15	T-003	12-15
B-024, F-001	12-8	B-025, F-001	12-8	B-019, Q-008	12-8
B-005, T-001	12-8				

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Circuit Diagram (Page 3 of 4)



09

DLE003001

**Parts Location**

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
B-026	08-16	B-015	08-16	B-039	08-16
F-010	08-25	F-009	08-25	H-009	08-26
L-005	08-27	R-005	08-28		

**Location of Junction Connector**

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
B-024, F-001	08-16	B-025, F-001	08-16	B-033, H-001	08-16
B-013, L-001	08-16	B-042, R-001	08-16		


**Form of Connector**

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
B-026	12-8	B-015	12-8	B-039	12-8
F-010	12-13	F-009	12-13	H-009	12-13
L-005	12-14	R-005	12-14	B-042, R-001	12-8
B-024, F-001	12-8	B-025, F-001	12-8	B-033, H-001	12-8
B-013, L-001	12-8				

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Circuit Diagram (Page 4 of 4)



09

DLE004001