



Harness connector	Name	Page
IP04		
IP16		
IP17		
IP37		
EM02		
EM40		
CA02		
CA05		
G6	Instrument panel grounding	72

Connection point	Description	Page
IP16-12	To background light BCM IP49-8	
IP16-22	To rear defrost switch IP06-4	
IP16-7	To rear defrost relay	
IP16-6	To instrument panel IP02-11	