


# Windshield/Window Glass

Circuit Diagram (Page 1 of 4)



## 09 - SYSTEM CIRCUITS

## Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
B-081	08-12	I-001	08-8	I-011	08-8
B-033	08-12	B-030	08-12	B-029	08-12
B-042	08-12	F-004	08-27	H-004	08-28
L-002	08-29	R-002	08-30		

## Fuse and Relay

Fuse/Relay	See Page	Fuse and Relay Box
FB09	06-2	Engine Compartment Fuse and Relay Box
RF05	06-9	Instrument Panel Fuse And Relay Box
RF07	06-9	Instrument Panel Fuse And Relay Box


## Location of Junction Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
B-036, F-001	08-12	B-011, H-001	08-12	B-044, L-001	08-12
B-021, R-006	08-12				

## Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
B-081	12-7	I-001	12-4	I-011	12-4
B-033	12-7	B-030	12-7	B-029	12-7
B-042	12-7	F-004	12-14	H-004	12-14
L-002	12-15	R-002	12-15	B-021, R-006	12-7
B-036, F-001	12-7	B-011, H-001	12-7	B-044, L-001	12-7

Circuit Diagram (Page 2 of 4)



## 09 - SYSTEM CIRCUITS

## Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
B-032	08-12	B-040	08-12	F-007	08-27

## Location of Junction Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
B-035, F-001	08-12	B-036, F-001	08-12		

## Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
B-032	12-7	B-040	12-7	F-007	12-14
B-035, F-001	12-7	B-036, F-001	12-7		


# دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Circuit Diagram (Page 3 of 4)



## 09 - SYSTEM CIRCUITS

## Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
B-032	08-12	I-011	08-8	H-007	08-28
B-015	08-12	L-003	08-29	R-003	08-30
B-040	08-12				

## Location of Junction Connector


Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
B-011, H-001	08-12	B-038, I-015	08-12	B-044, L-001	08-12
B-021, R-001	08-12				

## Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
B-032	12-7	I-011	12-4	H-007	12-14
B-015	12-7	L-003	12-15	R-003	12-15
B-040	12-7	B-011, H-001	12-7	B-038, I-015	12-7
B-044, L-001	12-7	B-021, R-001	12-7		

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Circuit Diagram (Page 4 of 4)

