


Windshield/Window Glass

Circuit Diagram (Page 1 of 4)



09

EM1A090620

Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-004	08-8	B-052	08-11	I-001	08-8
B-020	08-11	B-055	08-11	B-053	08-11
F-006	08-17	H-003	08-18	L-002	08-19
R-002	08-20				

Fuse and Relay

Fuse/Relay	See Page	Fuse and Relay Box
RF05	06-13	Instrument Panel Fuse and Relay Box
RF07	06-13	Instrument Panel Fuse and Relay Box
FB03	06-2	Power Fuse Box


Location of Junction Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
B-050, F-008	08-11, 08-17	B-058, H-002	08-11, 08-18	B-031, L-005	08-11, 08-19
B-056, R-001	08-11, 08-20				

Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-001	12-4	I-004	12-4	B-052	12-8
B-020	12-6	B-053	12-8	B-055	12-8
F-006	12-10	H-003	12-10	L-002	12-11
R-002	12-11	B-050, F-008	12-8, 12-10	B-058, H-002	12-8, 12-10
B-031, L-005	12-7, 12-11	B-056, R-001	12-8, 12-11		

Circuit Diagram (Page 2 of 4)



09

EM1A090630

Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
F-005	08-17	B-051	08-11		

Location of Junction Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
B-050, F-008	08-11, 08-17	B-028, F-008	08-11, 08-17		

Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
F-005	12-10	B-051	12-8	B-050, F-008	12-8, 12-10
B-028, F-008	12-7, 12-10				


دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Circuit Diagram (Page 3 of 4)



09

EM1A090640

Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
H-005	08-18	B-051	08-11	I-001	08-8
L-004	08-19	R-005	08-20		

Location of Junction Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
B-058, H-002	08-11, 08-18	B-031, L-005	08-11, 08-19	B-056, R-001	08-11, 08-20
B-026, I-006	08-11, 08-8				

Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
H-005	12-10	B-051	12-8	I-001	12-4
L-004	12-11	R-005	12-11	B-058, H-002	12-8, 12-10
B-031, L-005	12-7, 12-11	B-056, R-001	12-8, 12-11	B-026, I-006	12-7, 12-4


دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Circuit Diagram (Page 4 of 4)



09

EM1A090650