


Brake Lamp



Harness connector	Name	Pages
C01	Rear Connector of Indoor Fuse Box	17
CA02	To harness connector of instrument harness 2	22
CA13	Harness connector of ABS control module	23
IP05	To harness connector of indoor fuse & relay box	80
IP07	To engine compartment harness connector	80
IP10	To body harness connector	80
IP30	Brake lamp switch harness connector	80
SO33 (Sedan)	High mount brake lamp harness connector	97
SO35 (Sedan)	To luggage compartment harness connector	97
SO37	Harness connector of rear right combination tail lamp	97/106
SO38 (Hatch)	To harness connector of tail door	106
SO41	Harness connector of rear left combination tail lamp	97/106
SO46 (Hatch)	To body harness connector	107
SO51 (Sedan)	To body harness connector	97
SO63 (Hatch)	High mount brake lamp harness connector	107
G14 (Hatch)	Body harness grounding	128
G15 (Hatch)	Body harness grounding	128
G20 (Hatch)	Backdoor grounding	129

شرکت دیجیتال خودرو (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران