




Front Left Power Window (Only Driver Side Door with Anti-Clamp Function) 1






Rear Left Power window (Only Driver Side Door with Anti-clamp Function) 3



Rear Right Power Window (Only Driver Side Door with Anti-clamp Function) 4



Harness connector	Description	Pages
DR02	FL power window motor connector	58
DR10	Harness connector of FL power window switch	58
DR11	FR power window motor harness connector 1	60
DR13	Harness connector of FR power window switch	60
DR19	FR door connecting to instrument panel harness connector	60
DR21	RL door connecting to body harness connector	62
DR23	Harness connector of RL power window motor	62
DR26	Harness connector of RL power window switch	62
DR31	RR door connecting to body harness connector	62
DR33	Harness connector of RR power window motor	62
IP32	To body harness connector 1	40
IP33	To body harness connector 2	40
IP38	To FL door harness connector	40
IP61	Body control module harness connector 1	41
IP62	Body control module harness connector 2	41
IP64	Body control module harness connector 4	41
IP65	Body control module harness connector 5	41
SO01	To RR door harness connector 1	51
SO09	To RR door harness connector 2	51
SO10	To RR door harness connector 3	51
SO16	To RL door harness connector 1	51
G6	Instrument panel grounding	70