


CAN System

Circuit Diagram (Page 1 of 4)



09

Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-010	08-23	I-002	08-23	I-013	08-23
I-037	08-23	I-006	08-23	I-042	08-23

Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-010	12-4	I-002	12-4	I-013	12-4
I-037	12-4	I-006	12-4	I-042	12-4


دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Circuit Diagram (Page 2 of 4)



09

CAE002001

Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
B-034	08-36	Q-054	08-10	Q-004	08-10
Q-014	08-10	Q-013	08-10	Q-025	08-10

Location of Junction Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-051, B-037	08-23, 08-36	I-005, Q-006	08-23, 08-10		

Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
B-034	12-8	Q-054	12-17	Q-004	12-17
Q-014	12-17	Q-013	12-17	Q-025	12-17
I-051, B-037	12-4, 12-8	I-005, Q-006	12-4, 12-17		


دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Circuit Diagram (Page 3 of 4)



09



CAE003001

Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-001	08-23	I-010	08-23	I-016	08-23
I-002	08-23	I-020	08-23	I-040	08-23
I-036	08-23				

Fuse and Relay

Fuse/Relay	See Page	Fuse and Relay Box
RF15	06-8	Instrument Panel Fuse and Relay Box

Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-001	12-4	I-010	12-4	I-016	12-4
I-002	12-4	I-020	12-4	I-040	12-4
I-036	12-4				


دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Circuit Diagram (Page 4 of 4)



09

CAE004001