





Power window 1







Power window 3







Power window 2 (GC6)






Power window 1 (New King Kong 2016)





Power window 3 (New King Kong 2016)



Harness connector	Name	Page
DR08	Power window master control switch harness connector	71
DR01	Driver side door connected to instrument harness connector A	71
IP09	To front left door harness connector A	54
IP03	Central control unit harness connector A1	54
IP04	Central control unit harness connector A2	54
IP06	Central control unit harness connector C	54
DR18	Front right power window switch harness connector	71
DR24	Rear left power window switch harness connector	72
DR29	Rear right power window switch harness connector	72
DR11	Passenger side door connected to instrument harness connector A	71
IP47	To front right door harness connector A	54
DR27	Rear right door connected to floor harness connector B	72
SO02	To rear right door harness connector B	65
DR22	Rear left door connected to floor harness connector B	72
SO06	To rear left door harness connector B	65
IP07	To floor harness connector A	54
SO07	To instrument panel harness connector A	65
SO05	To rear left door harness connector A	65
DR21	Rear left door connected to floor harness connector A	72
SO01	To rear right door harness connector A	65
DR26	Rear right door connected to floor harness connector A	72
IP48	To front right door harness connector B	54
DR12	Passenger side door connected to instrument harness connector B	48
IP10	To front left door harness connector B	54
DR02	Driver side door connected to instrument harness connector B	71
DR28	Rear right power window harness connector	72
DR23	Rear left power window harness connector	72
DR15	Front right power window harness connector	71
DR05	Front left power window harness connector	71
G4	Instrument grounding	84
G5	Instrument grounding	84
G8	Floor grounding	85