



# Instrument Cluster

Circuit Diagram (Page 1 of 2)



02 09

## Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-032	08-10	I-011	08-10	I-031	08-10
E-017	08-3	C-002	08-19	I-005	08-10
I-010	08-10				

## Fuse and Relay

Fuse/Relay	See Page	Fuse and Relay Box
RF01	06-10	IP Fuse and Relay Box
RF10	06-10	IP Fuse and Relay Box

## Location of Junction Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-035, E-029	08-10, 08-5 (MT) 08-10, 08-7 (AT)	E-035, E-007	08-5, 08-3 (MT) 08-7, 08-3 (AT)	I-003, C-001	08-10, 08-19

## Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-032	12-9	I-011	12-7	I-031	12-8
E-017	12-3	C-002	12-16	I-005	12-7
I-010	12-7	I-035, E-029	12-9	E-035, E-007	12-4
I-003, C-001	12-7				

