


ECM ignition System (JL4G18-D+electronic system)



Harness connector	Name	Pages
CA02	To harness connector of instrument harness 2	36
CA27	To engine harness connector	35
EN01	Harness connector of engine control module	28
EN08	Harness connector of knock sensor	29
EN15	Harness connector of camshaft position sensor	29
EN19	Harness connector of ignition coil 1	29
EN20	Harness connector of ignition coil 2	29
EN26	Engine speed sensor harness connector	29
EN28	To harness connector of engine compartment distribution box	29
IP05	To harness connector of indoor fuse & relay box	80
IP07	To engine compartment harness connector	80
C01	Rear Connector of Indoor Fuse Box	17

Connection point	Descriptions	Pages
B	Internal low reference circuit from sensor to ECM	189/227/231
C	5V reference circuit of sensor	189

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

