


PEPS1



wire harness junctor	description	page
M49	RELAY MODULE_A wire harness junctor	25
M54	wire harness junctor	25
M81	button starting module plug in J1 wire harness junctor	25
PMF	IP.BOX F wire harness junctor	25
EPD	IP.BOX D wire harness junctor	16
ME2	main wire harness connecting with engine wire harness 2	25
EM2	engine wire harness connecting with main wire harness 2	17
MF2	main wire harness connecting with frame wire harness 2	26
FM2	frame wire harness connecting with main wire harness 2	46
M52	landing	63

connection point	remark	page
EPD-53	to TCU E31-L1	215
M81-14	to gear shifting handle F46-5	215


دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



PEPS2



wire harness junctor	description	page
F12	PEPS MID LF antenna wire harness junctor	45
F62	transponder antenna wire harness junctor	46
RB07	rear bumper antenna wire harness junctor	39
D02	LH FR door handle switch wire harness junctor	52
M82	button starting module plug in J2 wire harness junctor	25
M83	button starting module plug in J3 wire harness junctor	25
M103	button starting switch wire harness junctor	26
M105	PEPS front LF antenna wire harness junctor	25
MF1	main wire harness connecting with body wire harness junctor 1	26
MF2	main wire harness connecting with body wire harness junctor 1	26
FM1	body wire harness connecting with main wire harness junctor 1	46
FM2	body wire harness connecting with main wire harness junctor 1	46
FR1	body wire harness connecting with radar wire harness junctor 1	45
FD1	body wire harness connecting with LH FR door wire harness junctor 1	46
RF1	radar wire harness connecting with body wire harness junctor 1	39
DF1	LH FR door wire harness connecting with body wire harness junctor 1	52

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

