


Diagnostic interface



Harness connector	Name	Pages
C01	Rear Connector of Indoor Fuse Box	17
IP05	To harness connector of indoor fuse box	80
IP06	To harness connector of engine compartment harness	80
IP12	DLC harness connector	80
IP64	To harness connector of body harness	89
SO77	To harness connector of instrument panel harness	99
CA01	To harness connector of instrument harness 1	22
G7	Instrument grounding	125

Connection point	Descriptions	Pages
IP12-7	To ABS control module CA13-17	402
IP12-7	To ESC control module CA32-10	406
IP12-7	To combination instrument IP03-21	522/524
IP12-7	To A/C control module IP40-24	362
IP12-7	To BMCS SO70-12	414
IP12-7	To BMCS IP74-12	415
IP12-7	To TCU SO68-85	356
IP12-7	To engine immobilizer IP25-7	348
IP12-7	To TPMS control module IP38-5	412
IP12-6	CAN H	550/552/554 556/558/560 561/563/565 567
IP12-14	CAN L	550/552/554 556/558/560 561/563/565 567

CAN Data Communications Network (JL4G18-D+electronic system)

