



TCU

Circuit Diagram (Page 1 of 5)



09

Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
E-012	08-3	E-004	08-3	E-011	08-3
E-006	08-3	E-077	08-3	E-078	08-3
E-079	08-3				

Fuse and Relay


Fuse/Relay	See Page	Fuse and Relay Box
EF08	06-4	Engine Compartment Fuse and Relay Box
EF26	06-4	Engine Compartment Fuse and Relay Box

Form of Connector


Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
E-012	12-2	E-004	12-2	E-011	12-2
E-006	12-2	E-077	12-2	E-078	12-2
E-079	12-2				

دیجیتال خودرو
شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Circuit Diagram (Page 2 of 5)



09

ET11090902

Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-071	08-9	I-077	08-9	E-079	08-3

Location of Junction Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-012, E-059	08-9, 08-3	I-013, E-060	08-9, 08-3		

Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-071	12-7	I-077	12-7	E-079	12-2
I-012, E-059	12-7, 12-2	I-013, E-060	12-7, 12-2		


دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Circuit Diagram (Page 3 of 5)



09

ET11090903

Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
E-005	08-3	E-004	08-3	E-063	08-3
I-010	08-9	I-008	08-9	I-079	08-9
I-071	08-9	E-042	08-3	I-040	08-9
E-075	08-3	E-079	08-3		

Fuse and Relay

Fuse/Relay	See Page	Fuse and Relay Box
EF17	06-4	Engine Compartment Fuse and Relay Box
EF02	06-4	Engine Compartment Fuse and Relay Box
Starter Motor Relay (ERY13)	06-4	Engine Compartment Fuse and Relay Box
RF24	06-15	Instrument Panel Fuse and Relay Box


Location of Junction Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
E-060, I-013	08-3, 08-9	I-028, E-065	08-9, 08-3		

Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
E-005	12-2	E-004	12-2	E-063	12-2
I-010	12-7	I-008	12-7	I-079	12-7
I-071	12-7	E-042	12-2	I-040	12-7
E-075	12-2	E-079	12-2	E-060, I-013	12-2, 12-7
I-028, E-065	12-7, 12-2				

Circuit Diagram (Page 4 of 5)



09

ET11090904

Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
E-079	08-3	E-076	08-3		

Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
E-079	12-2	E-076	12-2		


دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Circuit Diagram (Page 5 of 5)



09

ET11090905