


625DHA DCT (For 1.5TCI Model)

Circuit Diagram (Page 1 of 3)



دیجیتال خودرو
 شرکت دیجیتال خودرو سامانه (مسئولیت محدود)
 اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



09

Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
Q-001	08-6	Q-054	08-6		

Fuse and Relay

Fuse/Relay	See Page	Fuse and Relay Box
EF07	06-2	Engine Compartment Fuse and Relay Box
EF26	06-2	Engine Compartment Fuse and Relay Box
SB03	06-2	Engine Compartment Fuse and Relay Box

Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
Q-001	12-16	Q-054	12-16		


دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Circuit Diagram (Page 2 of 3)



09

SAE002001

Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-001	08-12	I-052	08-12	I-020	08-12
B-026	08-16	Q-054	08-6	Q-003	08-6
Q-043	08-6				

Fuse and Relay

Fuse/Relay	See Page	Fuse and Relay Box
RF07	06-8	Instrument Panel Fuse and Relay Box

Location of Junction Connector


Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
B-017, I-004	08-16	I-005, Q-006	08-12		

Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-001	12-4	I-052	12-4	I-020	12-4
B-026	12-8	Q-054	12-16	Q-003	12-16
Q-043	12-16	B-017, I-004	12-8	I-005, Q-006	12-4

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Circuit Diagram (Page 3 of 3)



09

SAE003001