


passenger compartment / closed compartment lighting



## passenger compartment / closed compartment lighting

item code	description	information
0004	null	/ instrument panel
3011	null	front central interior lamp
3021	null	rear central interior lamp
3036	null	right-hand footwell lamp
3037	null	left-hand footwell lamp
3060	null	driver's courtesy mirror lamp
3061	null	passenger's courtesy mirror lamp
3063	null	roof lighting /
3096	null	connector area lamp
3105	null	boot (or tailgate) light
3115	null	glove box lamp
84C6	null	multifunction control panel
BB00	null	ancillaries battery
BFRM	null	engine fuse and relay box
BSI1	null	built-in systems interface
CA00	null	ignition switch
E300A	null	crimp one information (or equipotential 300A) wire
E305	null	crimp one information (or equipotential 305) wire
E904	null	crimp one information (or equipotential 904) wire
E905	null	crimp one information (or equipotential 905) wire
EC23	null	splice of an "ignition +" protected by fuse no. 23
EM01A	null	crimp earth (earth point number 01A)
EM35A	null	crimp earth (earth point number 35A)
EM35B	null	crimp earth (earth point number 35B)
EM60	null	crimp earth (earth point number 60)
MC13	null	body earth point number 13
MC35A	null	body earth point number 35
MC60A	null	body earth point number 60
MM01	null	engine earth point number 01

اولین سامانه دیجیتال تعمیرکاران خودرو در کشور