


Supplemental Restraint System

Circuit Diagram (Page 1 of 3)



09

Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-001	08-12	I-047	08-12	I-012	08-12
I-042	08-12				

Fuse and Relay

Fuse/Relay	See Page	Fuse and Relay Box
RF05	06-8	Instrument Panel Fuse and Relay Box

Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-001	12-4	I-047	12-4	I-012	12-4
I-042	12-4				




دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Circuit Diagram (Page 2 of 3)



09

Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
B-012	08-16	B-014	08-16	I-042	08-12
I-043	08-12	I-044	08-12	I-045	08-12

Location of Junction Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-004, B-017	08-12				

Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
B-012	12-8	B-014	12-8	I-042	12-4
I-043	12-4	I-044	12-4	I-045	12-4
I-004, B-017	12-4				


دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Circuit Diagram (Page 3 of 3)



دیجیتال خودرو
 شرکت دیجیتال خودرو سامانه (مسئولیت محدود)
 اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

09

RSE003001