


Turn signal lamp and hazard warning lamp (executive edition)



Harness connector	Name	Pages
CA02	To harness connector of instrument harness 2	22
CA12	Harness connector of front left combination headlamp	23
CA18	Harness connector of front right combination headlamp	23
DR01	Front left door connected to body harness connector	114
DR05	Harness connector of left exterior rearview mirror	114
DR11	Front right door connected to body harness connector	114
DR15	Right exterior rearview mirror connector	114
IP07	To engine compartment harness connector	80
IP10	To body harness connector	80
IP18	Headlamp combination switch harness connector	80
IP28	Harness connector of body control module 2	80
IP29	Harness connector of body control module 1	80
IP31	Hazard warning lamp switch harness connector	80
IP49	To body harness connector	80
SO01	To instrument harness connector	97/106
SO03	To instrument harness connector	97/106
SO05	To front right door harness connector	97/106
SO07	To front left door harness connector	97/106
SO78 (Sedan)	To luggage compartment harness connector	99
SO37 (Sedan)	Harness connector of rear right combination tail lamp	97/106
SO41	Harness connector of rear left combination tail lamp	97/106
SO51 (Sedan)	To body harness connector	97
G1A	Engine compartment grounding	121
G3	Engine compartment grounding	121
G7	Instrument panel grounding	125
G10 (Sedan)	Body harness grounding	127
G11 (Sedan)	Body harness grounding	127
G15	Body harness grounding	127