


# Wiper and Washer

Circuit Diagram (Page 1 of 2)



## 09 - SYSTEM CIRCUITS

## Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
E-089	08-7	I-002	08-13	I-006	08-13
B-007	08-16	B-003	08-16	E-062	08-7
E-064	08-7	E-065	08-7	E-034	08-7
T-009	08-24	B-040	08-16		

## Fuse and Relay

Fuse/Relay	See Page	Fuse and Relay Box
FB03	06-2	Power Fuse Box
RF07	06-13	Instrument Panel Fuse and Relay Box A
RF13	06-13	Instrument Panel Fuse and Relay Box A

## Location of Junction Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
B-008, E-059	08-16, 08-7	B-043, T-001	08-16, 08-24		

## Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
E-089	12-5	I-002	12-9	I-006	12-9
B-007	12-11	B-003	12-11	E-062	12-5
E-064	12-5	E-065	12-5	E-034	12-3
T-009	12-19	B-040	12-13	B-008, E-059	12-11
B-043, T-001	12-13				

Circuit Diagram (Page 2 of 2)

