


Instrument Cluster

Circuit Diagram (Page 1 of 2)



09 - SYSTEM CIRCUITS

Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
B-075	08-12	I-001	08-8	B-046	08-12
B-019	08-12	I-017	08-8	I-028	08-8
I-026	08-8				

Fuse and Relay

Fuse/Relay	See Page	Fuse and Relay Box
EF07-1	06-2	Engine Compartment Fuse And Relay Box
EF07	06-2	Engine Compartment Fuse And Relay Box
RF21	06-9	Instrument Panel Fuse And Relay Box
RF03	06-9	Instrument Panel Fuse And Relay Box

Location of Junction Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-015, B-038	08-8	I-016, B-039	08-8	I-039, B-014	08-8

Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
B-075	12-7	I-001	12-4	B-046	12-7
B-019	12-7	I-017	12-4	I-028	12-4
I-026	12-4	I-015, B-038	12-4	I-016, B-039	12-4
I-039, B-014	12-4				

Circuit Diagram (Page 2 of 2)

