


Instrument Panel Fuse and Relay Box



No.	Description	No.	Description
RF01	Dome Light/Daytime Running Light Relay	RF12	Headlight Combination Switch/Brake Light Switch
RF02	Flasher Relay	EF13	Airbag
RF03	Brake Light Switch	RF14	BCM/Instrument Cluster/Immobilizer
RF04	Audio	RF15	-
RF05	Instrument Panel Light	RF16	Audio/Power Mirror/Rear Defroster/Blower
RF06	BCM	RF17	Front Wiper Switch
RF07	Horn Relay	RF18	Front/Rear Wiper
RF08	Rear Defroster Relay	RF19	Cigarette Lighter
RF09	Rear Position Light/License Plate Light	RF20	Starter Motor
RF10	Front Position Light	RF21	A/C Switch
RF11	Alternator/Back-up Light Switch/ABS/ECM	RF22	Diagnostic Interface