


Audio System

Circuit Diagram (Page 1 of 3)



Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-002	08-13	I-011	08-13	I-036	08-13
I-037	08-13				

Fuse and Relay

Fuse/Relay	See Page	Fuse and Relay Box
RF22	06-13	Instrument Panel Fuse and Relay Box A
RF13	06-13	Instrument Panel Fuse and Relay Box A

Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-002	12-9	I-011	12-9	I-036	12-10
I-037	12-10				


دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Circuit Diagram (Page 2 of 3)



09 - SYSTEM CIRCUITS

Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-036	08-13	B-010	08-16	F-008	08-20
B-014	08-16	H-007	08-21		

Location of Junction Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-003, B-009	08-13, 08-16	B-004, F-001	08-16, 08-20	I-026, B-047	08-13, 08-19
B-069, H-001	08-16, 08-21				

Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-036	12-10	B-010	12-11	F-008	12-17
B-014	12-11	H-007	12-17	B-069, H-001	12-15
I-003, B-009	12-9	B-004, F-001	12-11	I-026, B-047	12-10

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Circuit Diagram (Page 3 of 3)

