


Constant Speed Cruise Control

Circuit Diagram (Page 1 of 2)



09

ET11090400

Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
E-061	08-4 (MT)	I-008	08-12	I-009	08-12
	08-7 (CVT)				
I-003	08-12	I-006	08-12	I-044	08-12
I-047	08-12				

Fuse and Relay

Fuse/Relay	See Page	Fuse and Relay Box
RF06	06-12	Instrument Panel Fuse and Relay Box
RF09	06-12	Instrument Panel Fuse and Relay Box


Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-008	12-8	E-061	12-4	I-009	12-8
I-003	12-8	I-006	12-8	I-044	12-10
I-047	12-11				

شرکت دیجیتال خودرو (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Circuit Diagram (Page 2 of 2)



09

دیجیتال خودرو
 شرکت دیجیتال خودرو سامانه (مسئولیت محدود)
 اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

ET11090410