


TCU System

Circuit Diagram (Page 1 of 9)



دیجیتال خودرو
 شرکت دیجیتال خودرو سامانه (مسئولیت محدود)
 اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



09

Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
Q-001	08-10	Q-054	08-10		

Fuse and Relay

Fuse/Relay	See Page	Fuse and Relay Box
EF07	06-2	Engine Compartment Fuse and Relay Box
EF26	06-2	Engine Compartment Fuse and Relay Box
SB03	06-2	Engine Compartment Fuse and Relay Box

Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
Q-001	12-17	Q-054	12-17		


دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Circuit Diagram (Page 2 of 9)



09

SAE002001

Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-001	08-23	B-026	08-36	I-052	08-23
Q-054	08-10	Q-003	08-10	I-020	08-23
Q-043	08-10				

Fuse and Relay

Fuse/Relay	See Page	Fuse and Relay Box
RF07	06-8	Instrument Panel Fuse and Relay Box

Location of Junction Connector


Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
B-017, I-004	08-36, 08-23	I-005, Q-006	08-23, 08-10		

Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-001	12-4	B-026	12-8	I-052	12-4
Q-054	12-17	Q-003	12-17	I-020	12-4
Q-043	12-17	B-017, I-004	12-8, 12-4	I-005, Q-006	12-4, 12-17

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Circuit Diagram (Page 3 of 9)



09

SAE003001