


# Cruise Control System

Circuit Diagram (Page 1 of 3)



09

## Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
Q-001	08-6	Q-025	08-6		

## Fuse and Relay

Fuse/Relay	See Page	Fuse and Relay Box
EF07	06-2	Engine Compartment Fuse and Relay Box
EF26	06-2	Engine Compartment Fuse and Relay Box
EF22	06-2	Engine Compartment Fuse and Relay Box
EF37	06-2	Engine Compartment Fuse and Relay Box
ECM Main Relay (FRY05)	06-2	Engine Compartment Fuse and Relay Box

## Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
Q-001	12-16	Q-025	12-16		


دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Circuit Diagram (Page 2 of 3)



## Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
E-020	08-3	E-010	08-3	E-019	08-3

## Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
E-020	12-2	E-010	12-2	E-019	12-2


# دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Circuit Diagram (Page 3 of 3)



09

CCE003001