


Lighting System

High/Low Beam Light

Circuit Diagram (Page 1 of 2)



09 - SYSTEM CIRCUITS

Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
Q-012	08-3	Q-010	08-3	Q-002	08-3
B-051	08-11	B-019	08-11		

Fuse and Relay


Fuse/Relay	See Page	Fuse and Relay Box
EF14	06-4	Engine Compartment Fuse and Relay Box
EF15	06-4	Engine Compartment Fuse and Relay Box
EF16	06-4	Engine Compartment Fuse and Relay Box
EF17	06-4	Engine Compartment Fuse and Relay Box
Low Beam Relay	06-4	Engine Compartment Fuse and Relay Box
High Beam Relay	06-4	Engine Compartment Fuse and Relay Box

Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
Q-012	12-2	Q-010	12-2	Q-002	12-2
B-051	12-8	B-019	12-6		

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Circuit Diagram (Page 2 of 2)

