


# Fog Light

Circuit Diagram (Page 1 of 2)



## 09 - SYSTEM CIRCUITS

## Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
B-019	08-11	I-031	08-8	I-001	08-8
Q-004	08-3	B-051	08-11	Q-007	08-3
Q-012	08-3				

## Fuse and Relay

Fuse/Relay	See Page	Fuse and Relay Box
EF12	06-4	Engine Compartment Fuse and Relay Box
Front Fog Light Relay	06-4	Engine Compartment Fuse and Relay Box


## Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-001	12-4	I-031	12-5	B-019	12-6
B-051	12-8	Q-004	12-2	Q-007	12-2
Q-012	12-2				

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Circuit Diagram (Page 2 of 2)

