


Instrument panel power source & ground



NL13-08113

Harness connector	Description	Pages
CA03	To instrument harness connector 1	29
IP57	To engine compartment harness connector 1	41
IP01	Harness connector of combination instrument	41
G6	Instrument panel grounding	70
P	Engine grounding	68


دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Combination Instrument Lighting, Indicator




Harness connector	Description	Pages
IP01	Harness connector of combination instrument	41
IP36	To engine compartment harness connector 2	40
CA01	To instrument harness connector 1	29
EM36	To engine compartment harness connector 2	35
CA22	To engine harness connector 2	28

Connection point		Pages
IP01 -14	To left front optical axis regulator motor CA19-3	131
	To FL combination headlamp CA16-6	131
IP01-26	To FL combination headlamp CA12-7	131
	To engine control module EM01-35	100
IP01-25	To high beam lamp relay ER02-2	131
	To lighting combination switch IP42-7	132
IP01-27	To rear fog lamp relay IR01-5	136
IP01-28	To front fog lamp relay ER01-5	136

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران


Sound warning & alarm of instrument panel



Harness connector	Description	Pages
IP01	Harness connector of combination instrument	41
EM02	To harness connector of engine compartment fuse box (2)	35
IP17	To engine harness connector	40
IP23	Radio / CD player harness connector 3	41
SO10	To instrument panel harness connector 3	50
IP33	To body harness connector 2	40
EM10	Oil pressure switch	34
IP28	Harness connector of parking brake switch	40
IP37	To engine compartment harness connector 3	40
CA02	To instrument harness connector 2	29
CA20	Harness connector of brake fluid level sensor	28
IP08	Harness connector of combination adjusting switch	41
IP32	To body harness connector 1	40
SO09	To instrument panel harness connector 2	50
SO27	Harness connector of fuel fluid sensor	50
EM21	Harness connector of speed sensor	34
P	Engine grounding	68
G6	Instrument grounding	70
G4	Engine compartment grounding	67

Connection point	Descriptions	Pages
IP01-16	To immobilizer module IP24-3	117
IP01-30	To alternator EM11-1	94
IP01-7	To parking radar indication lamp IP10-2	194
IP01-29	To headlamp lighting shaft adjusting switch IP14-4	132

Multi-function Instrument



Harness connector	Description	Pages
CA03	To instrument harness connector 3	29
IP01	Harness connector of combination instrument	41
IP03	Harness connector of multi-function instrument	40
IP57	To engine compartment harness connector 3	40
G6	Instrument panel grounding	70

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

