


Parking sensor



Harness connector	Name	Page
IP01	Combination instrument harness connector 1	54
IP02	Multi-functional instrument harness connector	54
IP08	To floor harness connector B	54
IP42	To engine harness connector	54
EN04	To instrument harness connector	39
EN22	Reverse gear switch harness connector	38
EO02	To instrument harness connector	49
EO13	Reverse gear switch harness connector	48
EO44	Reverse lamp switch harness connector (GC6)	48
SO03	Right rear combination lamp harness connector	65
SO04	Rear left combination lamp harness connector	65
SO08	To instrument panel harness connector B	65
SO36	Floor harness connected to rear fog lamp harness connector	65
SO37	Rear fog lamp harness connected to body harness connector	65
SO38	Parking sensor control module harness connector	65
SO39	Parking sensor probe 1 harness connector	65
SO40	Parking sensor probe 2 harness connector	65
SO41	Parking sensor probe 3 harness connector	65
SO42	Parking sensor probe 4 harness connector	65
SO47	Left parking sensor probe harness connector (New King Kong 2016)	65
SO48	Middle parking sensor probe harness connector (New King Kong 2016)	65
SO49	Right parking sensor probe harness connector (New King Kong 2016)	65
G7	Floor grounding	85