


# Lighting System

## Headlight High/Low Beam

### Circuit Diagram (Page 1 of 2)



دیجیتال خودرو  
 شرکت دیجیتال خودرو سامانه (مسئولیت محدود)  
 اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

09

## Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
E-012	08-4 (MT)	E-013	08-4 (MT)	E-062	08-4 (MT)
	08-7 (CVT)		08-7 (CVT)		08-7 (CVT)
E-011	08-4 (MT)	E-007	08-4 (MT)	E-048	08-4 (MT)
	08-7 (CVT)		08-7 (CVT)		08-7 (CVT)
E-047	08-4 (MT)	E-009	08-4 (MT)	E-010	08-4 (MT)
	08-7 (CVT)		08-7 (CVT)		08-7 (CVT)
E-051	08-4 (MT)	I-044	08-12		
	08-7 (CVT)				

## Fuse and Relay

Fuse/Relay	See Page	Fuse and Relay Box
EF01	06-5	Engine Compartment Fuse and Relay Box
EF02	06-5	Engine Compartment Fuse and Relay Box
EF04	06-5	Engine Compartment Fuse and Relay Box
EF06	06-5	Engine Compartment Fuse and Relay Box
Low Beam Relay	06-5	Engine Compartment Fuse and Relay Box
High Beam Relay	06-5	Engine Compartment Fuse and Relay Box

## Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
E-012	12-2	E-013	12-2	E-062	12-4
E-011	12-2	I-044	12-10	E-048	12-4
E-047	12-4	E-009	12-2	E-010	12-2
E-051	12-4	E-007	12-2		

