


INDICATORS & GAUGES

E7F60645

INDICATORS & GAUGES (SUPER VISION TYPE) (1)


SD940-1



INDICATORS & GAUGES

INDICATORS & GAUGES (SUPER VISION TYPE) (2)

SD940-2




ETGSD7940BL

INDICATORS & GAUGES

INDICATORS & GAUGES (SUPER VISION TYPE) (3)


SD940-3



INDICATORS & GAUGES

INDICATORS & GAUGES (SUPER VISION TYPE) (4)

SD940-4



ET/GSD/940DL

INDICATORS & GAUGES

INDICATORS & GAUGES (SUPER VISION TYPE) (5)

| C01/C201 |               | C11/C111/C211 |                    | C101 |                    | E32 |                    |
|----------|---------------|---------------|--------------------|------|--------------------|-----|--------------------|
|          | KUM_WTS_03F_B |               | KUM_NMWP_01F_B     |      | KUM_62Z_03F_B_WTS  |     | AMP_JPT_02F_B_CLIP |
|          | E41           |               | KET_250_01F_B_CLIP |      | KUM_62Z_03F_B_WTS  |     | AMP_EJWP_02F_B     |
|          | E67           |               | BOS_ESP_46F_B_L    |      | KET_250_01F_B_CLIP |     | AMP_EJWP_02F_B     |
|          | M32-A         |               | AMP_MCP_E_04F_B    |      | AMP_0407_16F_W_040 |     | AMP_0407_22F_W_HD  |
|          | M56           |               | AMP_040M2_16F_B    |      | AMP_040M1_16F_B    |     | KET_91A_09F_W      |
|          | AMP_070_14F_W |               | AMP_070_14F_W      |      | AMP_070_14F_W      |     | AMP_070_14F_W      |

INDICATORS & GAUGES

INDICATORS & GAUGES (SUPER VISION TYPE) (6)

SD940-6

MEMO

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

