



BMCS



BMCS (2013)



Harness connector	Name	Pages
C01	Rear Connector of Indoor Fuse Box	17
C02	Rear Connector of Indoor Fuse Box	17
CA04	To harness connector of body harness	22
CA10	To harness connector of fuse box 3	22
CA02	To harness connector of instrument harness 2	22
CA28	To harness connector of instrument harness 4	23
CA29	Cut off harness connector of solenoid valve	23
CA30	Harness connector of air intake solenoid valve	23
IP03	Combination instrument harness connector	80
IP05	To harness connector of indoor fuse box	80
IP07	To harness connector of engine compartment harness	80
IP54	BMCS switch harness connector	89
IP10	To harness connector of body harness	80
IP29	Harness connector of body control module 1	80
IP11	To harness connector of engine compartment harness	80
IP49	To harness connector of body harness (right)	80
IP74	Harness connector of BMCS control module (2013)	89
SO03	To harness connector of instrument harness	97/106
SO70	To harness connector of BMCS controller	98
SO02	To harness connector of instrument harness	97/106
SO12	To harness connector of engine compartment harness	97/106
SO01	To harness connector of instrument harness	97/106
G3	Engine compartment harness grounding	121
G6	Instrument harness grounding	125
G12	Body harness grounding	126/127/128

Connection point	Descriptions	Pages
IP74-19	To Radio/CD player IP33-3	536
IP74-20	To Radio/CD player IP33-8	536
IP54-1	To backlight adjusting switch	518