


Radio/CD Player Power Supply, Signal, Grounding



Harness connector	Name	Pages
C01	Rear Connector of Indoor Fuse Box	17
IP05	To harness connector of indoor fuse & relay box	80
IP33	Harness connector of radio/CD player 1	80
G6	Instrument panel grounding	125
G8	Instrument panel grounding	125

Connection point	Descriptions	Pages
IP33-9	To backlight adjusting switch	517
IP33-11	To combination instrument IP03-23	522/524
IP33-12	To parking switch	526


دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Radio/CD Player Power Supply, Signal, Grounding (Executive Edition, 2013)



Harness connector	Name	Pages
C01	Rear Connector of Indoor Fuse Box	17
IP05	To harness connector of indoor fuse & relay box	80
IP33	Harness connector of Radio/CD player 1	80
G6	Instrument panel grounding	125
G8	Instrument panel grounding	125

Connection point	Descriptions	Pages
IP33-9	To backlight adjusting switch	517
IP33-11	To combination instrument IP03-23	522/524
IP33-12	To reverse lamp switch	509
IP33-3	CAN_H	562
IP33-4	CAN_L	562
IP33-3	To BMCS IP74-19	415
IP33-8	To BMCS IP74-20	415


دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Radio/CD Player Steering Wheel Control (Navigation)



Radio/CD Player Steering Wheel Control (Navigation) (NCAP)



Harness connector	Name	Pages
IP22	Clock spring 1 (horn switch) harness connector	80
IP33	Harness connector of radio/CD player 1	80
IP71	Clock spring 1 (horn switch) harness connector (NCAP)	89
G8	Instrument panel grounding	125


دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




Radio/CD Player Speaker Control




Harness connector	Name	Pages
DR01	Front left door connected to body harness connector	114
DR04	Harness connector of front left tweeter speaker	114
DR09	Harness connector of front left door speaker	114
DR11	Front right door connected to body harness connector	114
DR14	Harness connector of front right tweeter speaker	114
DR19	Harness connector of front right door speaker	114
IP10	Front right seat heating switch harness connector	80
IP11	To harness connector of indoor fuse & relay box	80
IP32	Harness connector of radio/CD player 2	80
IP49	Harness connector of right license lamp	80
SO01	To instrument harness connector	97/106
SO02	To instrument harness connector	97/106
SO03	To instrument harness connector	97/106
SO05	To front right door harness connector	97/106
SO07	To front left door harness connector	97/106
SO31	Harness connector of rear right speaker	97/106
SO32	Harness connector of rear left speaker	97/106

دیجیتال خودرو
شرکت دیجیتال خودرو سامانه (مسئولیت محدود)


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Camera Control (Executive Edition)



Camera Control (2013)



Harness connector	Name	Pages
IP67	Harness connector of Radio/CD player 3	89
IP11	To harness connector of indoor fuse & relay box	80
SO02	To instrument harness connector	97/106
SO78	To luggage compartment harness connector	99
SO79	To body harness connector	99
SO80	Camera harness connector	99

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

